
















Exchangeable Tips for ACT Laptop AC Adapter

Standard Tips AC2055

Type	Picture	Output Voltage	Tips Size	Included in	Suitable for notebook brands	Fit for laptops
H1		19.0V - 2.1A 3.16A	φ5.5*3.0		Samsung	Click here to see full list on page 3~4
H2		19.0V - 2.37A 3.42A	φ4.0*1.35	AC2055	Asus	Click here to see full list on page 5~6
H3		19.0V- 2.1A 2.37A 3.42A	φ5.5*2.5	AC2055	HP Dell IBM Toshiba Lenovo	Click here to see full list on page 7~16
H5D		19.5V - 2.31A 3.34A	φ4.5*3.0	AC2055	Dell	Click here to see full list on page 17
H6		19.5V - 2.31A 3.33A	φ4.5*3.0		HP	Click here to see full list on page 18~21
H7		19.0V - 2.1A 2.37A 3.16A	φ3.0*1.1	AC2055	Acer Asus Samsung LG	Click here to see full list on page 22~24
H9		19.0V - 2.1A 2.37A 3.42A	φ3.5*1.35		Medion	Click here to see full list on page 25
H10		19.0V- 2.15A 3.42A	φ5.5*1.7	AC2055	Acer	Click here to see full list on page 26~31
H11		19.5V- 2.0A 3.0A 3.33	φ6.5*4.4		Sony LG	Click here to see full list on page 32~42

H12		20.0V 2.25A 3.25A	11*4.6	AC2055	Lenovo	Click here to see full list on page 43~44
H13		20.0V 3.25A	φ 7.9*5.5		IBM Lenovo	Click here to see full list on page 45
H13D		19.5V 2.31A 3.33A	φ 7.4*5.0	AC2055	Dell	Click here to see full list on page 46~48
H14		18.5V 3.5A 19.0V 3.33A	φ 7.4*5.0		HP	Click here to see full list on page 49~70
H15		19.5V 3.33A	φ 4.8*1.7	AC2055	HP/Compaq	Click here to see full list on page 71~91
H16		19.0V 2.37A 20.0V 2.25A 3.25A	φ 4.0*1.7		Lenovo Toshiba	Click here to see full list on page 92

Free Tip Service

If your laptop/notebook requires another tip than the tips which are supplied with this product, you can send a request for the right tip to ACT (please check the tiplist in this manual). We cannot guarantee that we have the requested tip at all time. When available, our support desk will send the tip to you for free.

You can send your request for the tip to us by using the supportform on our website: <https://support.act-connectivity.com/hc/requests/new>

H1

19.5V 2.1A 40W 5.5*3.0mm

Samsung Series 9 Notebook:

NP900X1A, NP900X1A-A01US, NP900X1A-A01, NP900X1AA01US;
NP900X1B, NP900X1B-A01US, NP900X1B-A01, NP900X1BA01US;
NP900X1B, NP900X1B-A02US, NP900X1B-A02, NP900X1BA02US;
NP900X3A, NP900X3A-A02US, NP900X3A-A02, NP900X3AA02US
NP900X3A, NP900X3A-A03US, NP900X3A-A03, NP900X3AA03US;
NP900X3A, NP900X3A-A05US, NP900X3A-A05, NP900X3AA05US
NP900X3A, NP900X3A-B01US, NP900X3A-B01, NP900X3AB01US;
NP900X3A, NP900X3A-B02US, NP900X3A-B02, NP900X3AB02US
NP900X1B, NP900X1B-A01SE, NP900X1B-A01, NP900X1BA01SE;
NP900X1B, NP900X1B-A01AU, NP900X1B-A01, NP900X1BA01AU;
NP900X1B, NP900X1B-A01UK, NP900X1B-A01, NP900X1BA01UK;
900X3C 900X4B 900X4C 900X4D NP900X3C NP900X4B NP900X4C NP900X4D

Samsung Series 7 Notebook:

XE700T1A; XE700T1A-A01US; XE700T1A-A02US; XE700T1A-A03US;
XE700T1A-A04US; XE700T1A-A05US; XE700T1A-A06US; XE700T1A-A01; XE700T1A-A02;
XE700T1A-A04;

Samsung Series 5 13.3 Ultrabook:

NP530U3BI, NP530U3B-A02US; 530U3BI, 530U3B-A01US, NP535U3C-A01MY, NP535U3C-A01US,
NP535U3C-A01UK

Samsung Series 5 Chromebook Notebook:

XE500C21, XE500C21-A01US, XE500C21A01US; XE500C21, XE500C21-A03US, XE500C21A03US;
XE500C21, XE500C21-A04US, XE500C21A04US; XE500C21, XE500C21-H01US, XE500C21H01US;
XE500C21, XE500C21-H02US, XE500C21H02US; XE500C21, XE500C21-H04US, XE500C21H04US

Samsung Series 3:

305U1A-A01, 305U1A-A02, 305U1A-A03, 305U1A-A04, 305U1A-A05 NP305U1A, NP305U1A-A01US,
NP305U1A-A02US, NP350U2A, NP350U2A-W01UB, NP300U1A, NP300U1A-A01US NP530U3B :
NP530U3B-A02CA, NP530U3C-A01CA, NP530U3C-A03CA, NP530U4B-A01CA, NP530U4B-S01CA,
NP530U4C-A01CA, NP530U4C-S02CA, NP530U4E-A01CA NP535U3C : NP535U3C-A03CA,
NP535U3C-A04CA, NP535U3C-A01CA, NP535U3C-A02CA NP535U4C : NP535U4C-A01CA,
NP535U4C-A02CA, NP535U4C-S02CA NP540U3C : NP540U3C-A01CA, NP540U3C-A02CA NP900X1B :
NP900X1B-A01CA, NP900X1B-A02CA NP900X3A : NP900X3A-A01CA, NP900X3A-A02CA,
NP900X3A-A03CA, NP900X3A-B01CA

19V 3.6A 5.5*3.0mm for Samsung

Samsung Series 2:NP200B4A, NP200A5B

Samsung Series 3: NP300E4C, NP300E4E, NP300E5A, NP300E5AI, NP300E5C, NP300E5E, NP300V5A, NP305E5A, NP305E5AI, NP305E7A, NP305E7AI, NP305V5A, NP350U2A, NP350U2B, NP350V5C, NP355E5C, NP355V5C, NP365E5C; Np300e4c-a02us, Np300e4c-a03us, Np305e5a-a01us, Np300e5a-a02ub, Np300e5a-a05us, Np300e5c-a01ub, Np300e5c-a02us, Np300e5c-a03us, Np300e5c-a06us, Np300e5c-a07us, Np300e5c-a09us, Np300e5c-a0aus, Np300e5c-a0bus, Np300e5c-a0cus, Np300e5e-a01us, Np300e5e-a02us, Np305e5a-a03us, Np305e5a-a05us, Np305e5a-a07us, Np305e5a-a08us, Np305e7a-a02us, Np305v5a-a0cus, Np350v5c-a01us, Np350v5c-t01us, Np350u2a-w01ub, Np355e5c-a01us, Np365e5c-s01us, Np365e5c-s03us, Np365e5c-s05us

Samsung Series 4:NP400B2B, NP400B4B

Samsung Series 5:NP500P4C, NP510R5E, NP520U4C, NP530U4C, NP530U4B, NP535U4C; Np500p4c-s02us, Np510r5e-a01ub, Np510r5e-a02ub, Np520u4c-a01ub, Np530u4b-a01us, Np530u4c-a01us, Np535u4c-a01us

Samsung Series 6: NP600B4B, NP600B5B

Samsung Series 7 Chronos:NP700Z3A, NP700Z3AH; Np700z3a-s06us, Np700z3a-s07us

Samsung N110 N120 N130 N140 N145 N150 N210 N220 N310 N510 NB30 NC10 NC110 NC20 NC215S NF210 NF310 P530 Q330 Q430 Q530 QX410 QX411 R430 R440 R480 R519 R522 R530 R540 R580 R730 R780 RV510 RV511 RV515 RV520 RV711 RV720 SF310 SF410 SF510 X360 X460; N145-JP02 NC10-11GP NC10-13GB NC110-A01 NF310-A01 NP-N145-JP02US NP-QX410-S02 NP-QX411-W01 NP-QX411-W02UB NP-R480-JAB1US NP-R540-JA06 NP-R580-JBB2 NP-RV510-A05US NP-RV511-A01 NP-RV515- A04US

Compatible P/N:

AD-4019 AD-6019 AD-6019A AD-6019V AD-6519 ADP-60ZH A ADP60ZH A 0335A1960 0335C1960 152884 6500739 BA44-00243A I19A SFB-ACU90WHP_48329 SPA-830E

END H1

H2

Asus 19V 3.42A 4.0mm*1.35mm 65W

Asus

UX30, X302LJ, X302UJ, X302UV, X303L,

Transformer Book Flip series

TP300LJ, TP300LJ-DW024H,

Zenbook series

U38DT, UX301, UX301LA, UX302L, UX303L, UX303LA, UX303LB, UX303LN, UX303U, UX303UA, UX303UB, UX32L, UX32LN, UX360, UX360C, UX360CA, UX360UA, UX360UAK, UX50,

Zenbook Prime series

UX32V, UX32VD, UX42V, UX42VS, UX52VS,

Asus 19V 2.37A 4.0mm*1.35mm 45W

Asus

F540S, F553M, X302LJ, X302UA, X302UJ, X302UV, X441SC, X441UA, X441UV, X456UA, X540LA, X540LJ, X540SC, X540YA, X541SC, X541UA, X553M, X556UA,

TaiChi series

21, 31,

Vivobook series

F201E, Q200, Q200E, S200, S200E, X201, X201E, X202, X202E,

VivoBook Flip series

TP301UA, TP501UA,

Zenbook series

BX21A, BX31A, BX32A, U38DT, U38N, UK31K, UX21, UX21A, UX21E, UX21E-KX007V, UX21E-KX008D, UX301, UX301LA, UX302L, UX302LA, UX302LG, UX302LG-C4019H, UX302LG-C4019P, UX303L, UX303LA, UX303LB, UX303LN, UX303U, UX303UA, UX303UB, UX305C, UX305CA, UX305UA, UX31, UX310UA, UX31A, UX31A-1AR4, UX31A-1AR5, UX31A-1AR7, UX31A-AB71, UX31A-AB72, UX31A-BHI5T11, UX31A-DB51, UX31A-DB52, UX31E, UX31K, UX31LA, UX32A, UX32L, UX32LA, UX32LN, UX330CA, UX330UA, UX360, UX360C, UX360CA, UX360UA, UX360UAK, UX42VS, UX50, UX52VS, UX560UA,

Zenbook Prime series

UX32V, UX32VD, UX42V, UX42VS, UX52VS,

Asus 19V 1.75A 4.0mm*1.35mm 33W

VivoBook series

F200MA F102BA X102BA X200MA X200LA K200MA C200MA C300MA X102BA F102BA
R103BA X200CA X200LA X200MA X201E X202E F200CA R200CA F200MA F200LA F201E

ZenBook series

UX305 UX21A UX31A UX32A BX21A BX31A BX32A F201E Q200E S200E S220 X200T
X201E X202E C200 C300 Q200 S200L S220 X453m F453 X403M

END H2

Toshiba: 19V 3.42A/19V3.95A/19V4.74A 5.5mm*2.5mm

Portégé R700-100, Portégé R700-101, Portégé R700-105, Portégé R700-10E, Portégé R700-10J, Portégé R700-10U, Portégé R700-11G, Portégé R700-12M, Portégé R700-135, Portégé R700-13H, Portégé R700-13J, Portégé R700-14J, Portégé R700-14N, Portégé R700-155, Portégé R700-156, Portégé R700-15C, Portégé R700-15L, Portégé R700-15P, Portégé R700-16R, Portégé R700-172, Portégé R700-174, Portégé R700-177, Portégé R700-179, Portégé R700-17G, Portégé R700-17H, Portégé R700-17N, Portégé R700-17W, Portégé R700-17X, Portégé R700-17Z, Portégé R700-181, Portégé R700-182, Portégé R700-183, Portégé R700-184, Portégé R700-185, Portégé R700-187, Portégé R700-188, Portégé R700-18C, Portégé R700-18D, Portégé R700-18E, Portégé R700-18G, Portégé R700-18P, Portégé R700-18Q, Portégé R700-192, Portégé R700-19F, Portégé R700-19L, Portégé R700-19M, Portégé R700-19T, Portégé R700-1C2, Portégé R700-1C4, Portégé R700-1C8, Portégé R700-1CC, Portégé R700-1CF, Portégé R700-1CQ, Portégé R700-1CV, Portégé R700-1CW, Portégé R700-1CX, Portégé R700-1CZ, Portégé R700-1D0, Portégé R700-1D1, Portégé R700-1D3, Portégé R700-1D5, Portégé R700-1DC, Portégé R700-1DE, Portégé R700-1DF, Portégé R700-1DG, Portégé R700-1DH, Portégé R700-1DJ, Portégé R700-1DK, Portégé R700-1DL, Portégé R700-1DM, Portégé R700-1DN, Portégé R700-1DP, Portégé R700-1DT, Portégé R700-1DZ, Portégé R700-1E0, Portégé R700-1E1, Portégé R700-1E3, Portégé R700-1E8, Portégé R700-1E9, Portégé R700-1EC, Portégé R700-1EG, Portégé R700-1EH, Portégé R700-1EL, Portégé R700-1EM, Portégé R700-1EN, Portégé R700-1EP, Portégé R700-1EQ, Portégé R700-1EZ, Portégé R700-1F0, Portégé R700-1F1, Portégé R700-1F2, Portégé R700-1F3, Portégé R700-1F4, Portégé R700-1F5, Portégé R700-1F6, Portégé R700-1F7, Portégé R700-1FH, Portégé R700-1FJ, Portégé R700-1FK, Portégé R700-1FL, Portégé R700-1FN, Portégé R700-1FP, Portégé R700-1FT, Portégé R700-1FV, Portégé R700-1G0, Portégé R700-1G5, Portégé R700-1G9, Portégé R830, Portégé R830-10P, Portégé R830-10Q, Portégé R830-10R, Portégé R830-10U, Portégé R830-10V, Portégé R830-112, Portégé R830-113, Portégé R830-115, Portégé R830-117, Portégé R830-118, Portégé R830-11K, Portégé R830-11M, Portégé R830-11Q, Portégé R830-130, Portégé R830-135, Portégé R830-137, Portégé R830-138, Portégé R830-139, Portégé R830-13C, Portégé R830-13E, Portégé R830-13P, Portégé R830-147, Portégé R830-14M, Portégé R830-14T, Portégé R830-14V, Portégé R830-18Z, Portégé R830-19G, Portégé R830-19R, Portégé R830-19T, Portégé R830-1C2, Portégé R830-1C4, Portégé R830-1C8, Portégé R830-1DM, Portégé R830-1DQ, Portégé R830-1DR, Portégé R830-1DU, Portégé R830-1DZ, Portégé R830-1E8, Portégé R830-1FR, Portégé R830-1FT, Portégé R830-1FU, Portégé R830-1G2, Portégé R830-1GC, Portégé R830-1GD, Portégé R830-1H5, Portégé R830-1HD, Portégé R830-1HJ, Portégé R830-1HL, Portégé R830-1JD, Portégé R830-1JK, Portégé R830-1JL, Portégé R830-1JM, Portégé R830-1JN, Portégé R830-1JP, Portégé R830-1JQ, Portégé R830-1JV, Portégé R830-1JX, Portégé R830-1JZ, Portégé R830-1K1, Portégé R830-1K2, Portégé R830-1KU, Portégé R830-1LC, Portégé R830-1LK, Portégé R830-1LR, Portégé R830-1LX, Portégé R830-1M3, Portégé R830-1M6, Portégé R830-1MH, Portégé R830-1MM, Portégé R830-1MZ, Portégé R830-1N3, Portégé R830-1NM

QOSMIO F60-10P, QOSMIO F60-12D

Satellite A105-S2716, Satellite A300, Satellite A300D, Satellite A500, Satellite A500D, Satellite A660, Satellite C640-105, Satellite C640-10D, Satellite C640-10M, Satellite C640-10U, Satellite C640-11N, Satellite C640-11P, Satellite C650, Satellite C650D, Satellite C850-101, Satellite C850-108, Satellite C850-10C, Satellite C850-119, Satellite C850-11C, Satellite C850-11Q, Satellite C850-11V, Satellite C850-124, Satellite C850-125, Satellite C850-126, Satellite C850-127, Satellite C850-12K, Satellite C850-12M, Satellite C850-12R, Satellite C850-12V, Satellite C850-131, Satellite C850-132, Satellite C850-134, Satellite C850-138, Satellite C850-13C, Satellite C850-13D, Satellite C850-13E, Satellite C850-13G, Satellite C850-13H, Satellite C850-13J, Satellite C850-13P, Satellite C850-13V, Satellite C850-13X, Satellite C850-13Z, Satellite C850-140, Satellite C850-141, Satellite C850-142, Satellite 850-148, Satellite C850-14X, Satellite C850-156,, Satellite C850-15L,, Satellite C850-161, Satellite C850-168, Satellite C850-16N, Satellite C850-16P, Satellite C850-16Q, Satellite C850-16R, Satellite C850-16W, Satellite C850-175, Satellite C850-176, Satellite C850-177, Satellite C850-A628, Satellite L300, Satellite L300D, Satellite L350D, Satellite L500, Satellite L500-1CT / 12E / 12K / 142, Satellite L500-1UT / 1V1, Satellite L500D, Satellite L500D-13C, Satellite L500D-16L / 16M / 16N, Satellite L505, Satellite L510, Satellite L550, Satellite L550D Satellite L550D-11P, Satellite L555, Satellite L555-112 / 115, Satellite L555-11K / 12E / 133, Satellite L555D, Satellite L630/L635, Satellite L640, Satellite L650, Satellite L650-1FF, Satellite L650-1FH, Satellite L650-1FJ, Satellite L650-1FW, Satellite L650-1GC, Satellite L650-1GD, Satellite L650-1GF, Satellite L650-1GP, Satellite L650-1M8, Satellite L650-1MC, Satellite L650-1MV, Satellite L650-1N6, Satellite L650-1NG, Satellite L650-1NH, Satellite L650-1NL, Satellite L650-1PW, Satellite L650D, Satellite L675D-111, Satellite L750, Satellite L755-10C, Satellite L755-13D, Satellite L755-13E, Satellite L755-13F, Satellite L755-13J, Satellite L755-13K, Satellite L755-13N, Satellite L755-13P, Satellite L755-13X, Satellite L755-13Z, Satellite L755-140, Satellite L755-141, Satellite L755-142, Satellite L755-14P, Satellite L755-15R, Satellite L755-15W, Satellite L755-15X, Satellite L755-162, Satellite L755-17V, Satellite L755-1HW, Satellite L755-1HX, Satellite L755-1J5, Satellite L755-1LD, Satellite L755-1LL, Satellite L755-1LM, Satellite L755-1MU, Satellite L755-1NG, Satellite L755-1NP, Satellite L755D, Satellite L770-12Z, Satellite L770D-10M, Satellite L775-119, Satellite L775-11E, Satellite L775-11F, Satellite L775-11U, Satellite L775-12H, Satellite L775-18E, Satellite L775-18F, Satellite L775D-10L, Satellite L775D-10Q, Satellite L775D-10R, Satellite L775D-10V, Satellite L775D-10W, Satellite L775D-10Z, Satellite L775D-111, Satellite L775D-112 ,Satellite L850-113, Satellite L850-114, Satellite L850-126, Satellite L850-127, Satellite L850-12T, Satellite L850-161, Satellite L850-162, Satellite L850-163, Satellite L850-166, Satellite L850-17V, Satellite L850-17W, Satellite L850-189, Satellite L850-1CX, Satellite L850-1D4, Satellite L850-1D5, Satellite L850-C1B, Satellite L855-12C, Satellite L855-136, Satellite L855D-100, Satellite L855D-104, Satellite M35X, Satellite P500, Satellite Pro A300, Satellite Pro A300D, Satellite Pro C650, Satellite PRO L300D, Satellite PRO L500, Satellite Pro L500, Satellite PRO L500D, Satellite Pro L550, Satellite Pro L630, Satellite Pro L640, Satellite Pro L650, Satellite Pro L670, Satellite Pro P300, Satellite Pro P300D, Satellite R630-13R, Satellite R630-13T, Satellite R630-13U, Satellite R630-13V, Satellite R630-13Z, Satellite R630-140, Satellite R630-141, Satellite R630-143, Satellite R630-144, Satellite

R630-148, Satellite R630-149, Satellite R630-14H, Satellite R630-14N, Satellite R630-14R, Satellite R630-14T, Satellite R630-14X, Satellite R630-14Z, Satellite R630-150, Satellite R630-153, Satellite R630-155, Satellite R630-156, Satellite R830-10D, Satellite R830-10F, Satellite R830-12N, Satellite R830-136, Satellite R830-13D, Satellite R830-13N, Satellite R830-142, Satellite R830-143, Satellite R830-146, Satellite R830-14F, Satellite R830-14N, Satellite R830-1FJ, Satellite R830-1FZ, Satellite R830-1G0, Satellite R830-1G1, Satellite R830-1GZ, Satellite R830-1H3, Satellite R830-1JR, Satellite R830-1JU, Satellite R830-1L4, Satellite R830-1L7, Satellite R830-1MX, Satellite R850-10F, Satellite R850-10H, Satellite R850-12E, Satellite R850-13K, Satellite R850-14T, Satellite R850-15V, Satellite R850-1F6, Satellite R850-1JP, Satellite R850-1L0, Satellite T110, Satellite T110D, Satellite T130, Satellite T130D, Satellite U500

Tecra R840-103, Tecra R840-10C, Tecra R840-10E, Tecra R840-10L, Tecra R840-10Q, Tecra R840-10Z, Tecra R840-11C, Tecra R840-11E, Tecra R840-126, Tecra R840-128, Tecra R840-12F, Tecra R840-12Z, Tecra R840-13U, Tecra R840-14D, Tecra R840-14R, Tecra R840-15L, Tecra R840-16M, Tecra R840-16Q, Tecra R840-17Q, Tecra R840-17R, Tecra R840-17X, Tecra R840-18T, Tecra R840-18W, Tecra R840-18Z, Tecra R840-192, Tecra R840-195, Tecra R840-197, Tecra R840-198, Tecra R840-199, Tecra R840-19N, Tecra R840-19Q, Tecra R840-19R, Tecra R840-1C8, Tecra R840-1CM, Tecra R840-1CZ, Tecra R840-1D5, Tecra R850, Tecra R850-1C0, Tecra R850-1C1, Tecra R850-1CD, Tecra R850-1DP, Tecra R850-1EJ, Tecra R850-1EM, Tecra R850-1EN, Tecra R850-1EP, Tecra R850-1F8, Tecra R850-1F9, Tecra R850-1FC, Tecra R850-1GV, Tecra R850-1HE, Tecra R850-1HG, Tecra R850-1HM, Tecra R850-1HN, Tecra R850-1HP

ASUS: 19V 3.42A/19V4.74A 5.5mm*2.5mm

A Notebook Series A3Ac, A Notebook Series A3Ac, A Notebook Series A3E, A3G Series, A Notebook Series A5E Series, A Notebook Series A6F-APO038P, A Notebook Series A6G, A6Ga Series, A Notebook Series A6J, A Notebook Series A6JA, A Notebook Series A6K, A6L Series, A Notebook Series A6M Series, A Notebook Series A6N, A6Ne Series, A Notebook Series A6R, A Notebook Series A6U, A6V Series, A Notebook Series A6Va, A6Vc Series, A Notebook Series A6VM, A Notebook Series A7 Series, A Notebook Series A7c, A Notebook Series A7cd, A Notebook Series A7d, A Notebook Series A7dc, A Notebook Series A7f, A Notebook Series A7g, A Notebook Series A7j, A Notebook Series A7jc, A Notebook Series A7m, A Notebook Series A7s, A Notebook Series A7tc, A Notebook Series A7u, A Notebook Series A7v, A Notebook Series A7vb, A Notebook Series A7vc, A Notebook Series A8 A8JC/A8JA/A8JS/A8JM/A8F Series, A Notebook Series A8SC, A Notebook Series A9 Series, F Notebook Series F2 Series, F Notebook Series F3 Series, F Notebook Series F3JA, F Notebook Series F3JC, F Notebook Series F3JM, F Notebook Series F3JP, F Notebook Series F3JR, F Notebook Series F3M, F Notebook Series F3P, F Notebook Series F3Q, F Notebook Series F3SC, F Notebook Series F3SR, F Notebook Series F3SV, F Notebook Series F3T, F Notebook Series F3TC, F Notebook Series F50GX, F Notebook Series F50SV-X1, F Notebook Series F70SL, F Notebook Series F7E, F Notebook Series F7Z, F Notebook Series F80SN, F Notebook Series F9 Series, F Notebook Series F9F, F Notebook Series F9S, F Notebook Series F9SG, G Notebook Series G1 Series, G Notebook Series G1S, G Notebook

Series G1SN, G Notebook Series G2 Series, G Notebook Series G2pc, G Notebook Series G2s, K Notebook Series K40, K Notebook Series K40AB, K Notebook Series K40AC, K Notebook Series K40AD, K Notebook Series K40AF, K Notebook Series K40C, K Notebook Series K40ID, K Notebook Series K40IE, K Notebook Series K40IJ, K Notebook Series K40IL, K Notebook Series K40IN, K Notebook Series K40JV, M Notebook Series M2, M2E, M2N Series, M Notebook Series M2000, M2000N Series, M Notebook Series M3, M3N Series, M Notebook Series M51E, M Notebook Series M51SN, M Notebook Series M51TR, M Notebook Series M6, M6N, M6Ne, M6R Series, M Notebook Series M6000, M6000N, M6000R Series, M Notebook Series M6V, N Notebook Series N50VC, N Notebook Series N50VN, N Notebook Series N51TP, N Notebook Series N51VG, U Notebook Series U3S, U Notebook Series U3Sg U Notebook Series U5 Series, U Notebook Series U6SG, U Notebook Series U6V, V Notebook Series V1J, V Notebook Series V1Jp, V Notebook Series V1S, V Notebook Series V1Sn, V Notebook Series V1V, V Notebook Series V6 Series, V Notebook Series VX2-Lamborghini, V Notebook Series VX2SE-Lamborghini, V Notebook Series VX3, V Notebook Series VX3-Lamborghini, W Notebook Series W1JC Carbon, W Notebook Series W2 Series, W Notebook Series W2JC, W Notebook Series W3J, W Notebook Series W5 Series, W Notebook Series W5A, W5Ae Series, W Notebook Series W6, W Notebook Series W7J, W Notebook Series W7S, W Notebook Series W7SG, X Notebook Series X59, X Notebook Series X59SR, Z Notebook Series Z62F / Z62J, X Notebook Series X59, X Notebook Series X59SR

Lenovo: 20V3.25A/20V4.5A/19V4.74A

Lenovo IBM

Essential B470 B570 G470 G570 G575 G770,

IdeaPad 2AG 2BG 2CG 2DG 2QG 2RG 2SG B550 B560 E46 G450 G455 G460 G470 G530 G550e G560 G565 G570 G575 G580 G780 K26 K29 S9 S9e S10 S10-2 S10-3 S10-3c S10-3s S10-3t S10e S12 S300 S400 S405 U160 U300 U300e U310 U400 U410 U460 U460s V470 V470 V570 V570 Y430 Y460 Y466 Z360 Z460 Z470 Z470 Z570,

G430L, G430M, G450, G500, G510, G510-4056, G510-4059, G550, G570 G575, G580, G585, G770, G780; N500, N500-4233, P580, P585; U510, U550; V560, V570; Y300, Y300-7759, Y310, Y310-7756, Y310a, Y310a-7756, Y330, Y400, Y430, Y450, Y460, Y470, Y480, Y510, Y530, Y550, Y550-4186-44U, Y550-4186-45U, Y550-4186-46U, Y550-4186-48U, Y550-4186-4AU, Y550p, Y560, Y560; Y570 08622JU, Y570 08622KU, Z560, Z565, Z570, Z570 10243SU,, Z570 10243WU, Z570 102496U, Z570 10249LU, Z570 10249QU, Z570 10249UU, Z570 1024A3U, Z570 1024AMU, Z570 1024DCU, Z570, Z575, Z575 129922U, Z575 12992DU, Z575 12992JU, Z580, Z585

HP/Compaq: 20V3.25A/20V4.5A/19V4.74A

Compaq Armada 2940 / 3500 / 4100 / 4200;

Compaq Evo N105 / N115 / N160 / N180;

Compaq Presario 1000 / 1010 / 1020 / 1030 / 1040 / 1050 / 1060 / 1065 / 1070 / 1075 / 1080 / 1081 / 1090 / 1090ES;

Compaq Presario 1200 / 1200AM / 1200LA / 1200LB / 1200T / 1200US / 1200XL / 1200XL101 / 1200XL102 / 1200XL103 / 1200XL104 / 1200XL105 / 1200XL106 / 1200XL109 / 1200XL110 / 1200XL111 / 1200XL118 / 1200XL119 / 1200XL125 / 1200XL126 / 1200XL127 / 1200XL3 / 1200XL300 / 1200XL325 / 1200XL401 / 1200XL404 / 1200XL406 / 1200XL408 / 1200XL409 / 1200XL420 / 1200XL423 / 1200XL500 / 1200XL505 / 1200XL510 / 1200XL515 / 1200XL526 / 1201AP / 1201EA / 1201Z / 1202FR / 1202LA / 1203EA / 1205EA / 1207 / 1210 / 1210EA / 1210US / 1211EA / 1211LA / 1212EA / 1213EA / 1213FR / 1214 / 1214FR / 1214NE / 1214SR / 1215 / 1215EA / 1215US / 1216 / 1216EA / 1216UK / 1220 / 1221 / 1230 / 1232 / 1234 / 1235 / 1236 / 1237 / 1240 / 1242 / 1244 / 1245 / 1246 / 1247 / 1250 / 1255 / 1256 / 1260 / 1262 / 1266 / 1267 / 1270 / 1272 / 1273 / 1274 / 1275 / 1277 / 1278 / 1279 / 1280 / 12XL / 12XL101 / 12XL103 / 12XL109 / 12XL113 / 12XL115 / 12XL116 / 12XL122 / 12XL123 / 12XL125 / 12XL129 / 12XL205 / 12XL212 / 12XL300 / 12XL307 / 12XL310 / 12XL325 / 12XL326 / 12XL327 / 12XL4 / 12XL400 / 12XL401 / 12XL403 / 12XL405 / 12XL409 / 12XL410 / 12XL412 / 12XL416 / 12XL420 / 12XL426 / 12XL427 / 12XL430 / 12XL500 / 12XL502 / 12XL505 / 12XL506 / 12XL509 / 12XL510 / 12XL512 / 12XL515 / 12XL517 / 12XL520 / 12XL521 / 12XL531;

Compaq Presario 1400 / 1400T / 1456 / 14XL / 14XL240 / 14XL242 / 14XL245 / 14XL246 / 14XL247 / 14XL250 / 14XL340 / 14XL345 / 14XL352 / 14XL356 / 14XL452 / 14XL454 / 1600 / 1600-XL140 / 1600-XL141 / 1600-XL144 / 1600-XL146 / 1600-XL147;

Compaq Presario 1600-XL150 / 1600-XL151 / 1600-XL153 / 1600-XL155 / 1600XL145 / 1610 / 1611 / 1615 / 1620 / 1621 / 1622 / 1625 / 1626 / 1630 / 1635 / 1640 / 1650 / 1655 / 1660 / 1665 / 1670 / 1672 / 1675 / 1680 / 1681 / 1682 / 1683 / 1685 / 1687 / 1688 / 1690 / 1692 / 1693 / 1694 / 16XL156 / 16XL255 / 16XL256;

Compaq Presario 1700 / 1700AU / 1700EA / 1700KR / 1700T / 1700US / 1700XL573 / 1701EA / 1701FR / 1701LB / 1702AP / 1702EA / 1702FR / 1702KR / 1702LB / 1703KR / 1704KR / 1710 (NOWA WERSJA) / 1710LA / 1710SB (NOWA WERSJA) / 1711AP / 1711LA / 1711TC / 1712AP / 1713AP / 1713EA / 1713TC / 1714EA / 1715AP / 1715CA / 1715TC / 1716EA / 1720CA / 1720US / 1721AP / 1721LA / 1721TC / 1722AP / 1722AU / 1722CA / 1722EA / 1722US / 1724AP / 1724TC / 1725AP / 1725EA / 1725TC / 1726TC / 17XL / 17XL261 / 17XL264 / 17XL265 / 17XL266 / 17XL274 / 17XL275 / 17XL360 / 17XL361 / 17XL362 / 17XL364 / 17XL365 / 17XL366 / 17XL369 / 17XL370 / 17XL371 / 17XL372 / 17XL374 / 17XL375 / 17XL376 / 17XL378 / 17XL379 / 17XL380 / 17XL460 / 17XL461 / 17XL463 / 17XL465 / 17XL466 / 17XL468 / 17XL469 / 17XL470 / 17XL471 / 17XL474 / 17XL475 / 17XL476 / 17XL480 / 17XL482 / 17XL485 / 17XL488 / 17XL492 / 17XL561 / 17XL562 / 17XL563 / 17XL565 / 17XL567 / 17XL568 / 17XL569 / 17XL570 / 17XL571 / 17XL572 / 17XL573 / 17XL574 / 17XL575 / 17XL579 / 17XL580;

Compaq Presario 1800 / 1800-XL182 / 1800-XL183 / 1800-XL185 / 1800-XL186 / 1800EA / 1800FR / 1800LA / 1800T / 1800T-800 / 1800T-850 / 1800XL / 1800XL190 / 1800XL280 / 1800XL380 / 1800XL390 / 1800XL481 / 1802FR / 1805 / 1810 / 1825 / 1827 / 1830 / 18XL /

18XL191 / 18XL192 / 18XL280 / 18XL380 / 18XL381 / 18XL390 / 18XL481 / 18XL482 / 18XL483 / 18XL484 / 18XL485 / 18XL580 / 18XL581 / 18XL583 / 18XL584 / 18XL585 / 18XL586 / 18XL587 / 18XL590;

Compaq Presario 1900-XL160 / 1900-XL162 / 1900-XL164 / 1900-XL165;

Compaq Presario 2700 / 2700AP / 2700EA / 2700GR / 2700SC / 2700T / 2700TC / 2700US / 2701EA / 2701TW / 2701US / 2710CA / 2710EA / 2710TC / 2710US / 2711AP / 2715EA / 2715US / 2716EA / 2720US;

Compaq Presario 700 / 700A / 700AP / 700CA / 700D / 700EA / 700LA / 700UK / 700US / 700Z / 701AP / 701EA / 701FR / 701LA / 701US / 701Z / 702EA / 702NA / 703AP / 705 / 705CA / 705EA / 705US / 706EA / 710 / 710CA / 710EA / 710US / 710Z / 711AP / 711AU / 711CL / 711EA / 711LA / 711TC / 712AP / 712AU / 712EA / 712LA / 714EA / 715 / 715CA / 715EA / 715US / 716EA / 717EA / 718EA / 720AP / 720AU / 720CA / 720EA / 720LA / 720TC / 720US / 721AP / 721AU / 721CL / 721PT / 721UK / 722US / 723RSH / 724AU / 724EA / 725 / 725AP / 725AU / 725CA / 725JP / 725LA / 725US / 726EA / 727EA / 728EA / 730TC / 730US / 731AP / 731EA / 731PT / 732EA / 732US / 733EA / 734EA / 735AP / 735AU / 735LA / 736EA / 737EA / 739EA / 7XXA;

Compaq Presario 800 / 800AP / 800XL / 801KR / 802A / 802KR / 803KR / 80XL300 / 80XL301 / 80XL302 / 80XL304 / 80XL458 / 80XL550;

Compaq Presario 900AP;

CTX EZBook 330F / 390T;

CTX EZBook 400 / 486 / 500;

CTX EZBook 600 / 650CDT / 660CDT;

CTX EZBook 700 / 700E / 700G / 700M / 730CS / 750CDT / 750CS / 750MS / 750MT / 760MS / 760MS-XJ / 760MS-XK / 760MTXK / 764MS-XK / 764MT / 764MT-XK / 770MT-XJ / 772MS-MK / 772MT-MK / 774 MTFK / 774MS-MK / 774MT-MK / 777MS-MK / 777MT-FK / 777MT-MK;

CTX EZBook 800 / 891 / 891E / 893-T-FK / CD;

Fujitsu-Siemens Amilo / Amilo Pro L7310;

Fujitsu-Siemens Lifebook A4170 / A4177 / A4178 / A4187 / A4190;

Fujitsu-Siemens Lifebook C1320 / LH530 / LH531 / P3110 / P770 / P771 / P8020 / P8110 / PH530 / SH531 / T580;

Hitachi VisionBook 133 / 4000 / 4140 / 4140X / 4150 / 4150X / 4350X / 4360X / PLUS / PLUS 4000 / PLUS 4140;

HP Omnibook 2000 / 2100 / 2101 / 2102 / 2103 / 2104 / 2105 / 2106 / 2111 / 2112 / 2113 / 2114 / 2115 / 2116 / 2120 / 2120T / 2121 / 2121T / 2122 / 2122T / 2123 / 2123T / 2124 / 2124T / 2125 / 2125T / 2126 / 2126T / 2127 / 2127T / 2128 / 2129;

HP Omnibook 3000 / 3000CTX / 3100 / 3101 / 3102 / 3250;

HP Omnibook 4000 / 4100 / 4101 / 4102 / 4103 / 4104 / 4105 / 4106 / 4107 / 4108 / 4110 / 4111 / 4150 / 4150B;

HP Omnibook 5000 / 5500 / 5700;

HP Omnibook 6000 / 6000B / 6000C / 6050 / 6100 / 6200;

HP Omnibook 7000 / 7100 / 7103 / 7103T / 7150;

HP Omnibook XE / XE-DA / XE2 / XE2-DA / XE2-DB / XE2-DC / XE2-DD / XE2-DE / XE2-DI / XE3 / XE3-GC / XE3-GD / XE3-GE / XE3-GF / XE3L / XE3L-GF / XE4100 / XE4100 / XE4400 / XE4500 / XE4500;

HP Pavilion 6000;

HP Pavilion N3000 / N3100 / N3110 / N3150 / N3190 / N3200 / N3210 / N3215 / N3250 / N3270 / N3290 / N3295 / N3300 / N3310 / N3330 / N3350 / N3370 / N3390 / N3400 / N3402 / N3410 / N3438 / N3478 / N3490;

HP Pavilion N4562;

HP Pavilion N5000 / N5100 / N5125 / N5130 / N5135 / N5140 / N5150 / N5170 / N5190 / N5195 / N5200 / N5210 / N5210M / N5221 / N5240 / N5241 / N5250 / N5261 / N5270 / N5271 / N5290 / N5295 / N5300 / N5310 / N5311 / N5340 / N5341 / N5350 / N5351 / N5371 / N5381 / N5390 / N5400 / N5402 / N5402L / N5412 / N5415 / N5420 / N5420L / N5421 / N5421L / N5422 / N5425 / N5430 / N5435 / N5440 / N5441 / N5442 / N5444 / N5445 / N5450 / N5451 / N5452 / N5454 / N5455 / N5470 / N5472 / N5474 / N5475 / N5481 / N5482 / N5484 / N5485 / N5490 / N5491 / N5495 / N5500 / N5511L / N5584;

HP Pavilion N6000 / N6100 / N6190 / N6195;

HP Pavilion XH136 / XH156 / XH176 / XH215 / XH216 / XH226 / XH260 / XH335 / XH35 / XH355 / XH365 / XH395 / XH455 / XH485 / XH535 / XH545 / XH555 / XH575 / XH635 / XH675;

HP Pavilion XT118 / XT125 / XT155 / XT178 / XT183 / XT236 / XT276 / XT345 / XT375 / XT395 / XT412 / XT4316WM / XT4345QV / XT512 / XT5300 / XT5335QV / XT5366WM / XT5377QV / XT537QV / XT53QV / XT545 / XT5477WM / XT555 / XT565 / XT575 / XT585 / XT595;

HP Pavilion XU155;

HP Pavilion XZ100 / XZ133 / XZ148 / XZ163 / XZ168 / XZ185 / XZ200 / XZ255 / XZ275 / XZ295 / XZ300 / XZ335 / XZ355;

HP Pavilion ZE4210 / ZE4240;

HP Pavilion ZT1000 / ZT1000-IB / ZT1100 / ZT1114 / ZT1120 / ZT1121S / ZT1122S / ZT1125 / ZT1130 / ZT1131S / ZT1132S / ZT1135 / ZT1141 / ZT1142 / ZT1145 / ZT1150 / ZT1152 / ZT1155 / ZT1162 / ZT1170 / ZT1172 / ZT1175 / ZT1180 / ZT1182 / ZT1185 / ZT1190 / ZT1192 / ZT1195 / ZT1200 / ZT1210 / ZT1230 / ZT1233 / ZT1235 / ZT1243 / ZT1250 / ZT1260 / ZT1270 / ZT1290;

HP Pavilion ZU1155 / ZU1175;

NEC Versa 2400 / 2400CD / 2405 / 2405CD / 2430 / 2430CD / 2435C / 2435CD / 2500 / 2500CD / 2530;

NEC Versa 500 / 5000 / 5060 / 5060X / 5080 / 5080X / 550D;

NEC Versa SXI;

Sager 6200 / 6200D / 7200 / 8549 D20 / 86 / 862 / 87 / 8700 / 98 / NB8600 / NB8700 / NP8100 / NP8300 / NP8320 / NP8500 / NP8550 / NP8600 / NP8620 / NP8623 / NP8700 / P8680 / PENTIUM 86;

Toshiba Satellite 1000 / 1000-Z2 / 1005 / 1005-S157 / 1100-S101 / 1200 / 1200-S121 / 1200-S122 / 1200-S252 / 1600 / 1605CDS / 1620CDS / 1625CDT / 1640CDT / 1670CDS / 1675CDS / 1690CDT / 1695CDT / 1700 / 1715XCDS / 1730 / 1730CDT / 1735XCDS / 1755 / 1755CDT / 1755CE / 1755DVD / 3000-S304 / 3000-S353 / 3000-S514 / 3005-S303 / 3005-S304 / 3005-S403 / 3005-S504;

Twinhead SlimNote 910CV / 9133TV / 9133TZ / 9150TZ / 9166TZ / VX / VXE / VXE3 / VXE500.

Fujitsu/Advent/: 20V3.25A/20V4.5A 5.5mm*2.5mm

FUJITSU AMILO A1645, FUJITSU AMILO L1310G, FUJITSU AMILO L7300, FUJITSU AMILO L7320, FUJITSU AMILO LI1705, ADVENT 2022, ADVENT 2023, ADVENT 2250, ADVENT 2410, ADVENT 3090, ADVENT 3300, ADVENT 4211, ADVENT 4212, ADVENT

4213, ADVENT 4214, ADVENT 4401, ADVENT 4404, ADVENT 4470, ADVENT 4480, ADVENT 4489, ADVENT 4490, ADVENT 5301, ADVENT 5302, ADVENT 5303, ADVENT 5311, ADVENT 5312, ADVENT 5313, ADVENT 5365, ADVENT 5372, ADVENT 5401, ADVENT 5411, ADVENT 9212, ADVENT 9215, ADVENT 9315, ADVENT 9415, ADVENT 9515, ADVENT 9517, ADVENT 9615, ADVENT 9617, ADVENT 3300B, ADVENT 340S2, ADVENT 3480DVD, EI-SYSTEMS 1201, EI-SYSTEMS 1211, EI-SYSTEMS 1212, EI-SYSTEMS 1411, EI-SYSTEMS 1412, EI-SYSTEMS 1511, EI-SYSTEMS 2512, EI-SYSTEMS 2513, EI-SYSTEMS 3000, EI-SYSTEMS 3113, EI-SYSTEMS 308, EI-SYSTEMS 4411, FUJITSU AMILO M1451G, FUJITSU AMILO PI1502, FUJITSU AMILO PI1505, FUJITSU AMILO SI1520, FUJITSU AMILO PRO V3515, ADVENT 5431, ADVENT 5470, ADVENT 5471, ADVENT 5480, ADVENT 5490, ADVENT 5493, ADVENT 5511, ADVENT 5611, ADVENT 5612, ADVENT 5711, ADVENT 5712, ADVENT 6000, ADVENT 6301, ADVENT 6311, ADVENT 6410, ADVENT 6411, ADVENT 6412, ADVENT 6413, ADVENT 6414, ADVENT 6415, ADVENT 6416, ADVENT 6417, ADVENT 6418, ADVENT 6419, ADVENT 6421, ADVENT 6422, ADVENT 4211C, ADVENT 4480DVD, ADVENT 5365DVD, ADVENT 5372DVD, ADVENT 540DVD, ADVENT 5471DVD, ADVENT 5480DVD, ADVENT 6412DVD, ADVENT 6413A, ADVENT 6414B, ADVENT 6415X, ADVENT 6415XP EI-SYSTEMS 3082, EI-SYSTEMS 3084, EI-SYSTEMS 3085, EI-SYSTEMS 3086, EI-SYSTEMS 3087, EI-SYSTEMS 3088, EI-SYSTEMS 3089, EI-SYSTEMS 3090, EI-SYSTEMS 3101, EI-SYSTEMS 3102, EI-SYSTEMS 3103, FUJITSU ESPRIMO V5535, FUJITSU LIFEBOOK A4170, FUJITSU LIFEBOOK A4177, FUJITSU LIFEBOOK A4178, ADVENT 6470, ADVENT 6520, ADVENT 6521, ADVENT 6522, ADVENT 6551, ADVENT 6552, ADVENT 6555, ADVENT 6651, ADVENT 7001, ADVENT 7041, ADVENT 7060, ADVENT 7079, ADVENT 7081, ADVENT 7082, ADVENT 7086, ADVENT 7096, ADVENT 7099, ADVENT 7100, ADVENT 7102, ADVENT 7104, ADVENT 7105, ADVENT 7106, ADVENT 7107, ADVENT 7108, ADVENT 7109, ADVENT 7113, ADVENT 7109A, ADVENT 7109B, ADVENT 7255DVD, ADVENT 7365DVD, ADVENT 8215P, ADVENT 8475DVD, ADVENT 9915W, ADVENT A440, ADVENT DVD7365, ADVENT ERC430, ADVENT ERT2250 ADVENT K100, EI-SYSTEMS 3115, EI-SYSTEMS 3213, EI-SYSTEMS 4113, EI-SYSTEMS 4213, EI-SYSTEMS 4315, EI-SYSTEMS 4401, EI-SYSTEMS 4402, EI-SYSTEMS 4403, EI-SYSTEMS 4405, EI-SYSTEMS 4406, EI-SYSTEMS 4410, FUJITSU LIFEBOOK A4190, FUJITSU AMILO 1451G, FUJITSU AMILO LI 2727, ADVENT 7204, ADVENT 7206, ADVENT 7211, ADVENT 7240, ADVENT 7250, ADVENT 7260, ADVENT 7300, ADVENT 7340, ADVENT 7360, ADVENT 7440, ADVENT 7445, ADVENT 7450, ADVENT 8001, ADVENT 8109, ADVENT 8111, ADVENT 8112, ADVENT 8115, ADVENT 8117, ADVENT 8212, ADVENT 8215, ADVENT 8275, ADVENT 8276, ADVENT 8315, ADVENT 8465, ADVENT 8470, ADVENT 8480, ADVENT 8889, ADVENT 9112, ADVENT K200, ADVENT K4000, ADVENT K6000, ADVENT KC5000, ADVENT KC550, ADVENT QC430, ADVENT QRC430 ADVENT QT5500, ADVENT K1501, ADVENT K1301P, EI-SYSTEMS 4413, EI-SYSTEMS 4414, EI-SYSTEMS 4415, EI-SYSTEMS 4416, EI-SYSTEMS 4417, EI-SYSTEMS 4418 EI-SYSTEMS 4419, EI-SYSTEMS 4430, EI-SYSTEMS 4431, EI-SYSTEMS 4215C, EI-SYSTEMS 4115C, EI-SYSTEMS 3080

MSI X-Slim 20V 4.5A

X Series X400 X430 X320 X340

Classic C Serie,

MSI Wind U Series U120H U90X U160DX U123 U90 U100X U160MX U123H U135 U100
U200 U123T U270 U130 U115 U135DX U120 U160,

Medion Akoya

Mini E Series E1210 E1211 E1221 E1312 97238 97436 7249 97452 97016 97522 97017
97544 97056,

19V2.37A 5.5mm*2.5mm 45W For ASUS TOSHIBA

Asus

F540LA, F540LA-XX070T,

Toshiba

Libretto series

W100, W105,

Portege series

Z30-A-189, Z30-B-119, Z830, Z835,

Satellite series

P800, T210, T210D, T215D, T230, T230D, T235, T235D, U800W,

19V1.75A 5.5mm*2.5mm 33W For ASUS TOSHIBA

Asus

D550MAV, X451M, X451MA, X551M, X551MA, X551MA-DS21Q, X551MA-DS91-CA,
X551MA-RCLN03, X551MA-SX018H, X551MA-SX019D, X551MA-SX020D,
X551MA-SX020H, X551MA-SX030H, X551MA-SX035D, X551MA-SX036D,
X551MA-SX043D, X551MAV

END H3

H5D

DELL 19.5V4.62A 4.5mm*3.0mm / 19.5V3.34A/19V2.31A

XPS 13 (L321X) (L322x),

13 (9343),

XPS 12 (9Q23) / (9Q33),

11 (9P33),

Inspiron series

11 (3147), 11 (3138), 11 (3148), 11 (3157), 11 (3137), 13 (7347), 13 (7348), 14 (5458), 15 (5551),

15 (5555), 15 (5558), 17 (5758), 17 (5759), 17 (5755), Vostro 15 (3558)

XPS series

12, 12 (L221X), 13, 13 ULTRABOOK, 18 (1810), 18 (1820), 18 ALL-IN-ONE

END H5D

H6

HP 19.5V4.62A 4.5mm*3.0mm 90W

HP

Envy Series

15-J000 CTO, 15-J000EB, 15-J000ER, 15-J000SG, 15-J001ER, 15-J001SB, 15-J001SG, 15-J001TX, 15-J002EA, 15-J002ER, 15-J002LA, 15-J003EO, 15-J003LA, 15-J004AX, 15-J004TX, 15-J005EP, 15-J005SS, 15-J005TU, 15-J006AX, 15-J006CL, 15-J007AX, 15-J008AX, 15-J009SS, 15-J010US, 15-J011NR, 15-J012LA, 15-J013CL, 15-J016TX, 15-J019SO, 15-J022TX, 15-J023CL, 15-J024SA, 15-J025TX, 15-J026TX, 15-J027TX, 15-J028TX, 15-J030TX, 15-J030US, 15-J031NR, 15-J032NR, 15-J033TX, 15-J058CA, 15-J060EZ, 15-J063EI, 15-J066EZ, 15-J081EG, 15-J084CA, 15-J084NR, 15-J090EZ, 15Z-J000, 15Z-J000 CTO, 15Z-J100, 17-J000, 17-J001TX, 17-J005EO, 17-J008EO, 17-J010EL, 17-J010US, 17-J011NR, 17-J011SA, 17-J011SP, 17-J013CL, 17-J020US, 17-J021NR, 17-J023CL, 17-J027CL, 17-J029NR, 17-J030US, 17-J034CA, 17-J040NR, 17-J040US, 17-J041NR, 17-J043CL, 17-J044CA, 17-J050US, 17-J051EI, 17-J057OL, 17-J060US, 17-J070CA, 17-J070EZ, 17-J073CA, 17-J082EG, 17-J092NR, 17-J098EF, 17-J099NR, 17-J120US, 17-J130US, 17-J150NR, 17-J160NR, 17-J170CA,

Envy Quad Series

15T-J000, 15T-J100, 17T-J000,

Envy Select Series

15T-J000, 15T-J100, 17T-J000, 17T-J100,

Envy TouchSmart Series

15-J001AX, 15-J001TU, 15-J002AX, 15-J002TU, 15-J003AX, 15-J003CL, 15-J005AX, 15-J006TU, 15-J050US, 15-J052NR, 15-J053CL, 15-J053XX, 15-J063CL, 15-J067CL, 15-J073CA, 17-J000, 17-J010DX, 17-J023CL, 17-J030US, 17-J037CL, 17-J043CL, 17-J078CA, M7-J010DX, M7-J020DX, M7-J078CA,

Pavilion Series

14-E001TX, 14-E002TX, 14-E003TX, 14-E004TX, 14-E005TX, 14-E006TX, 14-E007TX, 14-E008TX, 14-E009TX, 14-E010TX, 14-E011TX, 14-E012TX, 14-E013TX, 14-E014TX, 14-E015TX, 14-E016LA, 14-E016TX, 14-E017TX, 14-E018LA, 14-E018TX, 14-E019TX, 14-E020TX, 14-E036TX, 14-E037TX, 14-E038TX, 14-E039TX, 14-E045TX, 14-E046TX, 14-E047TX, 14-N004AX, 14-N005AX, 14-N006AX, 14-N007AX, 15-E001TX, 15-E002AX, 15-E002TX, 15-E003AX, 15-E003TX, 15-E004AX, 15-E004TX, 15-E005AX, 15-E005TX, 15-E006TX, 15-E007TX, 15-E008AX, 15-E008TX, 15-E009AX, 15-E009TX, 15-E010AX, 15-E010TX, 15-E011AX, 15-E011TX, 15-E012AX, 15-E012TX, 15-E013AX, 15-E013TX, 15-E014AX, 15-E014TX, 15-E015AX, 15-E016AX, 15-E017AX, 15-E018AX, 15-E019AX, 15-E019TU, 15-E020AX, 15-E020TX, 15-E021AX, 15-E022AX, 15-E022TX, 15-E023TX, 15-E024TX, 15-E025AX, 15-E025TX, 15-E027AX, 15-E028AX, 15-E029AX, 15-E030AX,

15-E030TX, 15-E031AX, 15-E031TX, 15-E032AX, 15-E032TX, 15-E033TX, 15-E035TX,
15-E036TX, 15-E037TX, 15-E045TX, 15-E046TX, 15-E048NR, 15-E049TX, 15-E050TX,
15-E051TX, 15-E051XX, 15-E054TX, 15-E055TX, 15-E056TX, 15-E057TX, 15-E058TX,
15-E059TX, 15-E060TX, 15-E101TX, 15-E102TX, 15-E103TX, 15-N001LA, 15-N002LA,
15-N008AX, 15-N013AX, 15-N014AX, 15-N015AX, 15-N016AX, 15T-E000, 15Z-E000,
15Z-N100, 17-E002XX, 17-E052XX, 17-E054CA, 17Z-E000, 17Z-E100, M4-1001TX,
M4-1002TX, M4-1003TX, M4-1004TX, M4-1005TX, M4-1006TX, M4-1007TX, M4-1008TX,
M4-1009TX, M4-1010TX, M4-1011TX, M4-1012TX, M4-1013TX, M4-1014TX, M4-1015TX,

Pavilion TouchSmart Series

14Z-N100, 15-N067CA,

HP 19.5V3.33A 4.5mm*3.0mm 65W

HP

250 G4 Series

M9T03EA, NOZ81EA,

251 G4 series

P5U08EA,

252 G4 series

P5U07EA,

Envy series

13-D010NW, 15-AE100NW, 15-AE120NW, 17-P1000NW,

Pavilion series

14-E006TU, 14-E007TU, 14-E00XXX, 14-N009TU, 14-N00XXX, 14-N025TX, 14-N027TX,
14-N028TX, 14-N029TX, 14-N02XXX, 14-N030TX, 14-N031TX, 14-N03XXX SERIES,
15-AB061NW, 15-AB081NW, 15-AB083NW, 15-AB250NW, 15-E000EIA, 15-E000SI,
15-E000SIA, 15-E000SK, 15-E000SR, 15-E000SX, 15-E001AU, 15-E002AU, 15-E002SE,
15-E002SIA, 15-E002SR, 15-E003AX, 15-E003EP, 15-E003SH, 15-E003SP, 15-E003SR,
15-E004AU, 15-E004AX, 15-E004EJ, 15-E004SL, 15-E004SR, 15-E005AX, 15-E005SR,
15-E005SV, 15-E005SX, 15-E006AU, 15-E006AX, 15-E006EA, 15-E006SG, 15-E006SR,
15-E006TU, 15-E007AX, 15-E007SR, 15-E007TU, 15-E008EA, 15-E008EE, 15-E008SC,
15-E008SE, 15-E008SR, 15-E008SV, 15-E008TU, 15-E009AU, 15-E009AX, 15-E009EE,
15-E009SE, 15-E009TU, 15-E00XXX, 15-E010AX, 15-E010SA, 15-E010SK, 15-E010SZ,
15-E010US, 15-E011EIA, 15-E011SIA, 15-E011SR, 15-E011SX, 15-E012NR, 15-E012SA,
15-E013AX, 15-E013NR, 15-E013SA, 15-E014NR, 15-E014SO, 15-E015EIA, 15-E015NR,
15-E015SIA, 15-E017AU, 15-E017AX, 15-E018AX, 15-E018LA, 15-E018NR, 15-E018SX,
15-E019AX, 15-E019SX, 15-E01XXX, 15-E020NR, 15-E020SX, 15-E020US, 15-E021EL,
15-E021NR, 15-E021SS, 15-E021SX, 15-E022AX, 15-E023TU, 15-E023TX, 15-E024TU,
15-E025SX, 15-E025TU, 15-E026SR, 15-E026SX, 15-E026TX, 15-E027CA, 15-E027CL,

15-E028SX, 15-E028TX, 15-E028US, 15-E029TX, 15-E02XXX SERIES, 15-E030EA, 15-E030SC, 15-E030SO, 15-E030SZ, 15-E031SS, 15-E033CA, 15-E033SS, 15-E033SX, 15-E035SX, 15-E036SC, 15-E036SX, 15-E037CL, 15-E038SX, 15-E039SC, 15-E039TX, 15-E040CA, 15-E040SO, 15-E041CA, 15-E041TX, 15-E042SF, 15-E042TX, 15-E043CL, 15-E044SF, 15-E044TX, 15-E045SX, 15-E045TX, 15-E046TX, 15-E047SX, 15-E049SF, 15-E050SF, 15-E050SG, 15-E050SR, 15-E051EIA, 15-E051SIA, 15-E051SR, 15-E051SX, 15-E051XX, 15-E052SR, 15-E052SV, 15-E053CA, 15-E053SA, 15-E053SR, 15-E054SE, 15-E054ST, 15-E055EIA, 15-E055SE, 15-E055SIA, 15-E055SO, 15-E055ST, 15-E055SX, 15-E056SO, 15-E056SR, 15-E056ST, 15-E057SC, 15-E057SR, 15-E057ST, 15-E058SIA, 15-E058SO, 15-E058SR, 15-E058SX, 15-E059SE, 15-E059SR, 15-E060EE, 15-E060EIA, 15-E060SE, 15-E060SIA, 15-E060SR, 15-E060SX, 15-E061SR, 15-E061SX, 15-E063EO, 15-E063SO, 15-E063SR, 15-E066EIA, 15-E066SI, 15-E066SIA, 15-E068EE, 15-E068SE, 15-E071NR, 15-E071ST, 15-E072SE, 15-E072SO, 15-E073NR, 15-E073SE, 15-E073SO, 15-E074SE, 15-E075NR, 15-E075SE, 15-E076SE, 15-E077NR, 15-E077SG, 15-E078SE, 15-E079EE, 15-E079SE, 15-E080SE, 15-E081EA, 15-E081EE, 15-E081SA, 15-E082EE, 15-E082SE, 15-E083EE, 15-E083SE, 15-E084CA, 15-E085EE, 15-E085SE, 15-E086EE, 15-E086NR, 15-E086SE, 15-E087NR, 15-E088NR, 15-E088SE, 15-E088SK, 15-E089NR, 15-E089SE, 15-E089SK, 15-E090EE, 15-E090SE, 15-E091SE, 15-E092EE, 15-E092SE, 15-N006AX, 15-N009AX, 15-N00XXX, 15-N010TX, 15-N011TU, 15-N011TX, 15-N012TU, 15-N012TX, 15-N013TX, 15-N014TX, 15-N017TX, 15-N018TU, 15-N018TX, 15-N019TU, 15-N019TX, 15-N01XXX, 15-N020TU, 15-N020TX, 15-N021TX, 15-N022TX, 15-N02XXX SERIES, 15-N065SA, 15-N083SA, 15-R100NW, 15Z-E000 CTO,

Pavilion Gaming series

17-AK050NW,

Pavilion x360 series

11-K114NW, 13-A211NW,

Stream series

13-C000NW, 13-C003NW, 13-C010NW,

HP 19.5V2.31A 4.5mm*3.0mm Blue 45W

HP

250, 255,

EliteBook series

820, 840, 850,

EliteBook Folio series

1040,

EliteBook Revolve series

810,

Pavilion series

X360,

Spectre series

13 PRO,

Split series

13-G110DX, 13-G118CA, 13-G160BR, 13-G180LA, 13-G190LA, 13-M001TU, 13-M002TU,
13-M003TU, 13-M004TU, 13-M005TU, 13-M005TU, 13-M006TU, 13-M007TU, 13-M008TU,
13-M009TU, 13-M010DX, 13-M010TU, 13-M011TU, 13-M100BR, 13-M100LA, 13-M102TU,
13-M110BR, 13-M110CA, 13-M110DX, 13-M111SA, 13-M115SG, 13-M160BBR

END H6

H7

Samsung 19V 2.1A 19V2.37A 3.0mm*1.1mm

Samsung Galaxy View 18.4 SM-T670 SM-T677 SM-T670NZKAXAR

Samsung Series 3 NP300U1A NP305U1A NP300u1a-a01us Samsung Series 5 NP530U3C NP540U3C NP530U3B NP530U3BI NP535U3C:
NP530U3B-A01US NP530U3C-A01US NP535U3C-B01US NP540U3C-A01UB
NP540U3C-A02UB NP540U3C-A03UB

Samsung Series 5 Chromebook 500c21 Xe500c21 Xe550c22 Xe550c22-a01us

Samsung Series 7 Slate XE700T1A
XE700T1A-A01US XE700T1A-A02US XE700T1A-A03US XE700T1A-A05US

Samsung Series 9 NP900X3E NP900X3B NP900X3C NP900X4B NP900X4D NP900X4C
NP900X5N NP900X1A NP900X1B NP900X3A NP900X3D:
NP900X1B-A02 NP900X1B-A02US NP900X3A-A03US NP900X3A-A05US
NP900X3A-B01UB NP900X3A-B02US NP900X3A-B06US NP900X3B-A01US
NP900X3C-A01US NP900X3C-A04US NP900X3C-A05US NP900X3D-A01US
NP900X3D-A03US NP900X3D-A04US NP900X3E-A02US NP900X4B-A02US
NP900X4C-A01US NP900X4C-A03US NP900X4C-A06US NP900X4C-A07US
NP900X4C-K01US NP900X4D-A02US NP900X4D-A03US NP900X4D-A05US

Samsung ATIV Book 5 NP540U4E

Samsung ATIV Book 9 13.3" 15" NP900X3L NP900X5L NP900X3L-K03US NP900X3L-K04US
NP900X3L-K06US NP900X5L-K02US

Samsung ATIV Book 9 Lite Plus NP900X3F NP900X3G NP900X3K NP905S3G NP915S3G
NP930X5J NP940X3G NP940X3K NP940X3L NP940X5J:
NP905S3G-K02US NP915S3G-K01US NP915S3G-K02US NP915S3G-K04US
NP915S3G-K05US NP940X3G-K01US NP940X3G-K03US NP940X3G-K04US
NP940X3G-K06US NP940X3G-S03US NP940X5J-K01US NP940X5J-K02US
NP940X3K-K02US NP-940X3L-K01US NP540U4E-K01US

Acer 19V 2.1A 19V2.37A 3.0mm*1.1mm

Acer Chromebook R 11 13 14 15 C730E, C738T, C810, CB3-111, CB3-131, CB3-431,
CB3-531, CB3-532, CB5-132T, CB5-311, CB5-311P: CB3-111-C4HT CB3-111-C670
CB3-111-C6EQ CB3-111-C8UB CB3-131-C3SZ CB3-131-C3VC CB3-431-C0AK
CB3-431-C5EX CB3-431-C5FM CB3-431-C5XK CB3-431-C7M1 CB3-531-C4A5
CB3-532-C47C CB5-132T-C1LK CB5-132T-C32M CB5-132T-C8ZW CB5-311-T1UU

CB5-311-T677 CB5-311-T7NN CB5-311-T9B0 CB5-311-T9Y2 CB5-311P-T9AB
CB5-571-C4G4 C730E-C4BA C730E-C555 C738T-C44Z C810-T78Y C810-T7ZT C810-T9CA

Acer Aspire V 13 V3-331, V3-371, V3-372T: V3-331-P0QW V3-331-P11X V3-331-P4TE
V3-371-51UJ V3-371-56R5 V3-371-57JZ V3-371-596F V3-372T-5051

Acer Aspire Switch 11, 11V, 12, Alpha 12: SW5-171, SW5-171P, SW5-173, SW5-173P,
SW5-271, SA5-271, SA5-271P: SW5-171-325N SW5-171-34ZR SW5-171-39LB
SW5-171-80KM SW5-171-86EE SW5-171P-82B3 SW5-173P-61RD SW5-271-62X3
SW5-271-64V2 SA5-271-57DS SA5-271-594J SA5-271-71NX SA5-271-764D

Acer Aspire One Cloudbook 11, 14: AO1-131, AO1-131M, AO1-431, AO1-431M:
AO1-131-C620 AO1-131-C7DW AO1-131-C9PM AO1-131-C9RK AO1-131M-C1T4
AO1-131M-C667 AO1-431-C3TM AO1-431-C4XG AO1-431-C7F9 AO1-431-C8G8
AO1-431M-C49H

Acer Swift 3 SF314-51: SF314-51-52DH

Acer Spin 5 SP513-51: SP513-51-30EU, SP513-51-55ZR

Asus 19V1.75A 19V2.37A 3.0mm*1.1mm

Asus Zenbook, Zenbook Prime, Flip: U38DT U38N UX21A UX31A UX31LA UX32A UX32VD
UX42VS UX52VS UX301 UX301LA UX302 UX302LA UX303 UX303L UX303LA UX303LB
UX303LN UX303U UX303UA UX303UB UX305C UX305CA UX305F UX305FA UX305L
UX305LA UX305UA UX330UA UX360C UX360CA :
UX301LA-DH71T UX301LA-XH72T UX302LA-BHI5T08 UX303LA-DB51T UX303LA-DS51T
UX303LA-DS52T UX303LA-US51T UX303LB-DS74T UX303LN-DB71T UX303UA-DH51T
UX303UB-DH74T UX305CA-DHM4T UX305CA-EHM1 UX305FA-ASM1 UX305FA-USM1
UX305LA-AB51 UX31A-BHI5T11 UX31A-DH51 UX31A-R5102H UX32A-DB31 UX32A-XB51
UX32VD-DB71 UX32VD-DH71 UX32VD-DS72

Asus Chromebook C200 C200M C200MA C202S C300 C300M C300MA C300SA C301SA:
C200MA-DS01 C300MA-BBCLN10 C300MA-BBCLN12 C300MA-DB01 C300MA-DH01
C300MA-DH02

Asus VivoBook 1015E D553M E403S E403SA F200CA F201E F202E F553M F553MA F556U
F556UA K200MA K553MA Q200 Q200E Q302LA Q302U Q302UA Q303UA S200 S200E
X102B X102BA X200 X200CA X200LA X200M X200MA X201 X201E X202 X202E X540L
X540LA X540S X540SA X553M X553MA X553S X553SA :
1015E-DS01 1015E-DS03 K200MA-DS01T K200MA-DS01T(S) K200MA-DS01T-WH(S)
K553MA-DB01TQ Q200E-BCL0803E Q200E-BHI3T45 Q200E-BSI3T08 Q302UA-BHI5T20
S200E-RHI3T73 X102BA-BH41T X200CA-DB01T X200CA-DB02 X200CA-HCL1104G
X200CA-SCL0301Q X200MA-BCL0705Z X200MA-RCLT07 X200MA-RCLT08

X200MA-SCL0505F X200MA-US01T

Asus Flip Q302L Q503U Q503UA Q504U Q504UA Q302LA-BBI5T14 Q302LA-BBI5T19
Q302LA-BHI3T09 Q302LA-BHI3T11 Q302LA-BSI5T16

Asus Taichi 21 31 Taichi21-DH51 Taichi31-NS51T

Asus EeeBook E402MA E402S E402SA E402MA-EH01

Asus Transformer Book Flip Trio T300L T300LA TP300L TP300LA TP300LD TX201 TX201LA
T300LA-DH51T TP300LD-RHI5T15

END H7

H9

19V2.1A 19V2.37A. 19V3.42A for Medion

Medion Akoya E15301 19V3.42A 35135

Medion Akoya E15411 19V3.42A

Medion Akoya E15303 19.5V 2.31A 45W

Medion Akoya E15407 19V3.42A

Medion Laptop akoya S4403 S4401 S4404 S4402 E14301 E14412 E16401 E15308 S14401 S14402 S14405 S14407

Medion Akoya E14307 E14308 E15308 E15407 S14401 S14402 S14405 S14407

Medion Akoya E14412 E14410 E14409 Medion Akoya E16402 E16401

Gateway Laptop Charger

TYPE60-190-31501 TYPE60-190-3150u GWTN156-1 GWTN156-5BK GWTN156-4 GWTN156-9 GWTN141-2BK GWTN141-10BK GWTN156-7 GWNC31514-BK GWTN156-1BK GWTN156-1BL GWTN156-1GR GWTN156-11CA GWTN156-11BL GWTN156-9BK GWTN156-9BL GWTN156-1RG GWTN156-11 GWTN156-11GN GWTN141-4BL GWTN141-4RG GWTN141-4BK GWTN141-3GR GWTN141-3PR GWTN141-3BL GWTN141-3BK GWTN141-2BL GWTN141-2GR GWTN141-2PR GWTN141-10 GWTN141-10RG

END H9

H10

Acer 19V4.74A 5.5mm*1.7mm 90W

Aspire series

3020, 3100, 3610, 3620A, 3640, 3690, 3750G, 3750ZG, 3820, 4252, 4253G, 4310, 4330, 4520, 4520G, 4551, 4710, 4710G, 4720G, 4730, 4735Z, 4735ZG, 4738, 4740G, 4741G, 4741Z, 4741ZG, 4743G, 4750, 4750G, 4755, 4820TG, 4920, 4920G, 4937, 5102, 5110, 5220, 5230, 5253G, 5310, 5320, 5335, 5510, 5520, 5520G, 5530G, 5535, 5540, 5550, 5560, 5570, 5580, 5590, 5600, 5610, 5611AWLMI, 5611ZWLMI, 5612WLMI, 5613AWLMI, 5620, 5630, 5633WLMI, 5650, 5670, 5680, 5683WLMI, 5684WLMI_TV, 5685WLMI, 5710, 5720ZG, 5730ZG, 5733Z, 5738G, 5742G, 5810TZ, 5820TG, 5910, 5910G, 5920, 5920G, 5930, 5930G, 5943G, 6530G, 6935, 7000, 7003WSMI, 7110, 7220, 7320, 7330, 745Z, 7520, 7520G, 7530, 7530G, 7551G, 7552G, 7560G, 7720, 7720G, 7720Z, 7730, 7730G, 7730Z, 7730ZG, 7741, 7741G, 7741Z, 7741ZG, 7750, 7750G, 7750ZG, 8920G, 8930G, 9100, 9110, 9120, 9300, 9302, 9303WSMI, 9305, 9410, 9413AWSMI, 9413ZWSMI, 9420, 9423WSMI, 9500, 9520, 9525WSMI, E5-473G, E5-573G, E5-771G, E5-771G-51T2, E5-771G-53PN, E5-771G-54UR,

Aspire V15 nitro series

VN7-571,

Extensa series

4620Z, 4630, 4630G, 5120, 5200, 5210, 5220, 5230, 5230E, 5420, 5420G, 5430, 5610, 5610G, 5630, 5630EZ, 5630G, 5630Z, 7120, 7220, 7420, 7620, 7620G,

Ferrari series

1000, 1005WTMI, 5000, 5005WLHI, 5005WLMI,

Travelmate series

260, 280, 420, 4200, 4230, 4233WLMI, 4260, 4280, 4283WLMI, 4283WLMI_UMTS, 430, 4320, 4400, 4730G, 4740G, 4740Z, 5220, 5220G, 5230, 5335, 5530G, 5542G, 5610, 5620, 5623WSMI, 5623WSMI - VISTA, 5624WSMI, 5625WSMI, 5625WSMI - VISTA, 5720, 5735Z, 5740G, 5740Z, 5742G, 5742Z, 5742ZG, 5760G, 6410, 6413LMI, 6460, 6463WLMI, 6464WLMI, 6465WLMI, 6500, 6592, 7220, 7220G, 7320, 7510, 7514WSMI, 7720, 7740, 7750, 8200, 8210, 8210WLHI, 8210WLMI, 8215WLHI, 8215WLMI, 8571,

Emachines

D530, D640G, D730, D730G, D730Z, D730ZG, D732G, D732ZG, E640G, E642G, E644G, E730G, E730ZG, E732G, E732ZG, EME730G, G443G, G630G, G640G, G729G, G729ZG, G730G, G730Z, G730ZG,

745Z, 5749, 5750, 5750G, 5755, 5755G, 5810T, 5810TG, 5820G, 5820T, 5820TG, 5820TZ, 5820TZG, 5830T, 5830TG, 5920G, 5930, 5940G, 5950G, 6530, 6920, 7100, 7230, 7250, 7315, 7330, 7339, 738ZG, 741ZG, 745Z, 7530, 7530G, 7535, 7540, 7551, 7560, 7715Z, 8540, 8735, 9100WLMI, 9101WLMI, 9102WLC, 9102WLCI, 9102WLMI, 9103WLMI, 9104LM, 9104LMI, 9104WLM, 9104WLMI, 9104WSM, 9105WLMI, 9400, E5-422G-45ET, E5-522G, E5-522G-60EP, E5-522G-671W, E5-522G-895M, E5-532G, E5-532G-P9YD, E5-573G, E5-573G-31Q2, E5-573G-59CS, E5-722G, E5-722G-83DD, E5-722G-86B3, E5-722G-86K1, E5-731G, ES1-511, ES1-511-C35L, ES1-711G-P0RD, ES1-731G, ONE 721, S3-951, V3-371, V3-574G, V3-574G-58ZE, V3-574G-755M,

Emachines series

E525-901G16,

Extensa series

2000, 2300, 2350, 2500, 2600, 2900, 2900D, 2900E, 2950, 3000, 3100, 4010, 4100, 4120, 4130, 4210, 4220, 4420, 4430, 4620, 4620Z, 4630Z, 5010, 5200, 5210, 5235, 5610, 5620, 5620G, 5620Z, 5620ZG, 5630, 5630EZ, 5635, 5635Z, 5635ZG, 7230, 7230E, 7630G, 7630ZG,

Ferrari series

1100, 1200, ONE 200,

Travelmate series

200, 200DX, 200T, 201, 201T, 201TXV, 202, 202T, 210, 210T, 210TER, 210TXF, 211, 211T, 212, 212T, 212TE, 212TXV, 213, 213T, 213TX, 213TXV, 220, 222, 222X, 223, 223X, 223XC, 223XV, 225, 225X, 225XC, 225XV, 230, 2300, 2300LC, 2300LCI, 2300LM, 2301, 2301LC, 2301LCI, 2301LMI, 2301NLC, 2301NLCI, 2301NXCI, 2301WLC, 2301WLCI, 2301WLM, 2301WLMI, 2301XC, 2301XCI, 2302, 2302LC, 2302LCI, 2302LM, 2302LMI, 2302NLCI, 2302WLM, 2302WLMI, 2303, 2303LC, 2303LCI, 2303LM, 2303LMI, 2303NLC, 2303NLCI, 2303WLCI, 2303WLM, 2303WLMI, 2303XC, 2304, 2304LC, 2304LCI, 2304LM, 2304LMI, 2304WLCI, 2304WLMI, 2305, 2305LCI, 2306, 2306LCI, 2308, 2308LCI, 2308LMI, 2308WLM, 2308WLMI, 230XC, 230XV, 230XV-PRO, 2310, 2310LCI, 2312, 2312LC, 2312LCI, 2312LM, 2312LMI, 2312NLC, 2312NLM, 2312NWLC, 2312NWLCI, 2312NWLM, 2312NWLMI, 2312WLCI, 2312WLMI, 2313, 2313LC, 2313LCI, 2313LM, 2313LMI, 2313NLC, 2313NLCI, 2313NLM, 2313NLMI, 2313NWLM, 2313NWLMI, 2313WLC, 2313WLCI, 2313WLM, 2313WLMI, 2314, 2314WLMI, 2318, 2318NWLMI, 2318WLM, 2318WLMI, 2319, 2319NLCI, 233, 233LC, 233X, 233XV, 233XVI, 234, 234LCI, 2350, 2352, 2352LCI, 2353, 2353LC, 2353LM, 2353LMI, 2353WLMI, 2355, 2355XM, 2400, 2410, 2410WLMI, 2412LC, 2412LCI, 2412LM, 2412LMI, 2412NLC, 2412NLM, 2413LC, 2413LCI, 2413LM, 2413LMI, 2413NLC, 2413NLCI, 2413NLM, 2413NLMI, 2413NWLCI, 2413NWLM, 2413NWLMI, 2413WLC, 2413WLCI, 2413WLM, 2413WLMI, 2414LMI, 2414WLMI, 2414WLMI, 2419LCI, 2419NLCI, 2420, 2430, 2440, 2450, 2460, 2470, 2480, 2490, 2490WLMI, 260, 261, 261X, 261XC, 261XV, 270, 270XV, 272, 272LC, 272X, 272XV, 272XVI, 273, 273X, 273XV, 275, 275LC, 280, 281, 281XC, 281XV, 283, 283LC, 283XV, 283XVI, 290, 290D, 290E, 290LC, 290LCI, 290LMI, 290XMI, 290XVI, 291LCI, 291LCI-G, 291LMI, 291LMI-G, 291XCI, 291XCIX, 292LC, 292LCI, 292LM, 292LMI, 293LCI, 293LMI, 3000, 3000WTIC, 3000

WTMI, 3001ENWTNI, 3001NWTNI, 3001WTCTI, 3001WTMI, 3002ENWTNI, 3002LC, 3002NW
TNI, 3002WTCTI, 3002WTMI, 3002XCI, 3002XMI, 3003WTCTI, 3003WTMI, 3004WTCTI, 3004W
TMI, 3010, 3020, 3030, 3040, 310, 320, 3200, 3200XCI, 3200XMI, 3201, 3201NXCI, 3201XCI
, 3201XMI, 3202, 3202XCI, 3202XMI, 3204, 3204XCI, 3204XMI, 3205, 3205XMI, 3210, 3210
WXCI, 3210WXMI, 3210XCI, 3210XMI, 3210Z, 3211WXCI, 3211WXMI, 3212NWXC, 3212N
WXMI, 3212WXMI, 3212XCI, 3212XMI, 3213WXCI, 3213WXMI, 3220, 3220WXCI, 3220WXI,
3222WXCI, 3222WXMI, 3230, 3240, 3250, 3260, 3270, 3280, 3290, 3300, 340, 340T, 341, 3
41T, 342, 342T, 343, 343T, 345, 345T, 347, 347T, 350, 350TE, 350TE-N, 351, 351TE, 351TE
V, 352, 352TE, 353, 353TE, 353TEV, 354, 354TE, 354TEV, 360, 361, 361EVI, 364, 364ECI,
370, 370TCI, 370TI, 370TMI, 371, 371LCI, 371LMI, 371TCI, 371TCIXP, 371TI, 371TMI, 372,
372LCI, 372LMI, 372TC, 372TCI, 372TI, 372TM, 372TMI, 374, 374TCI, 380, 380LCI, 380TCI,
381, 381TC381TCI, 381TI, 382, 382LCI, 382TC, 382TCI, 382TI, 382TM, 382TMI, 383, 383T
CI, 4000, 4000LCI, 4000LMI, 4000NLCI, 4000WLCI, 4000WLMI, 4001, 4001LC, 4001LCI, 40
01LM, 4001LMI, 4001NLCI, 4001WLC, 4001WLCI, 4001WLM, 4001WLMI, 4001XCI, 4002, 4
002LC, 4002LCI, 4002LM, 4002LMI, 4002NLCI, 4002WLCI, 4002WLM, 4002WLMI, 4004, 40
04LMI, 4005, 4005LMI, 4005WLM, 4005WLMI, 4009, 4009LCI, 4010, 4010WLCI, 4011LCI, 4
011LMI, 4011WLCI, 4011WLMI, 4012NLCI, 4015LCI, 4015LMI, 4020, 4020NWLCI, 4020WL
CI, 4020WLMI, 4021, 4021LCI, 4021LMI, 4021NWLCI, 4021WLCI, 4021WLMI, 4022, 4022N
WLMI, 4022WLCI, 4024WLMI, 4025LCI, 4050, 4050LC, 4050LCI, 4050LM, 4050LMI, 4050W
LCI, 4050WLMI, 4051, 4051LC, 4051LCI, 4051LM, 4051LMI, 4051WLCI, 4051WLMI, 4052, 4
052LC, 4052LCI, 4052LM, 4052LMI, 4052NLCI, 4052WLCI, 4052WLMI, 4053, 4053LMI, 406
0, 4070, 4080, 4100, 4100LCI, 4100LMI, 4100WLM, 4100WLMI, 4101, 4101LCI, 4101LM, 41
01LMI, 4101WLC, 4101WLCI, 4101WLM, 4101WLMI, 4102, 4102LC, 4102LCI, 4102LM, 410
2LMI, 4102NLCI, 4102NLMI, 4102NWLCI, 4102NWLCI, 4102WLC, 4102WLCI, 4102WLM, 4
102WLMI, 4103, 4103LCI, 4103LMI, 4103WLCI, 4104, 4104WLMI, 4106, 4106WLMI, 4150, 4
150LC, 4150LCI, 4150LM, 4150LMI, 4150NLCI, 4150WLMI, 4151LC, 4151LCI, 4151LM, 415
1LMI, 4151NLCI, 4151WLCI, 4151WLMI, 4152LC, 4152LCI, 4152LM, 4152LMI, 4152NLC, 41
52NLCI, 4152WLMI, 4153LM, 4153LMI, 4154LM, 4154LMI, 4235, 4280, 4283WLMI, 4330, 43
35, 4500, 4500ALCI, 4500LCI, 4500LMI, 4500WLCI, 4500WLMI, 4501, 4501ALC, 4501ALCI,
4501LC, 4501LCI, 4501LMI, 4501WLC, 4501WLCI, 4501WLM, 4501WLMI, 4502, 4502ALCI,
4502LC, 4502LCI, 4502LMI, 4502WLCI, 4502WLM, 4502WLMI, 4503, 4503LCI, 4503LMI, 45
03WLMI, 4504, 4504LM, 4504LMI, 4520, 4530, 4600, 4601, 4601LC, 4601LCI, 4601LM, 460
1WLM, 4601WLMI, 4602, 4602LCI, 4602LMI, 4602WLMI, 4603, 4603WLCI, 4603WLMI, 4604
, 4604WLCI, 4604WLM, 4604WLMI, 4650, 4650LC, 4650LCI, 4650LM, 4650LMI, 4651LC, 46
51LCI, 4651LM, 4651LMI, 4651NLM, 4651WLMI, 4652LC, 4652LCI, 4652LM, 4652LMI, 4652
NLCI, 4652WLMI, 4654, 4654LM, 4654LMI, 4654WLMI, 4655LMI, 4670, 4720, 4730, 4740, 4
750, 4750Z, 5100, 5110, 512, 512DX, 512T, 512T-64, 512TE, 513, 513DX, 513T, 514, 514T,
514TXV, 515, 515TE, 516, 516TE, 517, 517TE, 520, 520IT, 521, 5210, 521TE, 521TEV, 521
TXV, 524, 524TE, 524TXV, 525, 525T, 525TE, 525TX, 525TXV, 527, 527TXVI, 528, 528TE,
529, 529ATXV, 529TX, 529TXVI, 530, 530LC, 530LCI, 530XC, 530XCI, 530XV, 530XVI, 531
0, 531LC, 531LCI, 531XC, 531XCI, 531XV, 5320, 5330, 533LC, 533LCI, 533XC, 533XCI, 533
XV, 533XVI, 5344, 534LC, 534LCI, 534TL, 534XC, 534XCI, 534XV, 535LC, 535LCI, 5360, 53
6LCI, 550, 550LC, 550LV, 550XV, 551, 5510, 551XV, 5520, 5520G, 5530, 5542, 5610, 5620,
5710, 5710G, 5720, 5720G, 5725, 5730, 5730G, 5735, 5740, 5742, 5744, 5744Z, 5760, 600,

6000, 6000LCI, 6001, 6002, 6002LCI, 6003LC, 6003LCI, 6003LM, 6003LMI, 6004, 6004LC, 6004LCI, 6004LMI, 600TER, 602, 602TER, 603, 603TER, 604, 604TER, 610, 610TX, 610TXC, 610TXI, 610TXV, 610TXVI, 611, 611TXC, 611TXCI, 611TXV, 612, 612TXC, 612TXCI, 612TXV, 612TXVI, 613, 613TXC, 613TXCI, 613TXV, 614, 614TXC, 614TXCI, 614TXV, 614TXVCI, 620, 621, 621LV, 621XC, 621XV, 623, 6231, 623LC, 623LCI, 6252, 6253, 6291, 6292, 6293, 630, 630XCI, 630XV, 632, 632XCI, 633, 633LCI, 6410, 6452, 6460, 6492, 6493, 6495T, 650, 650LC, 650XC, 650XCI, 653LC, 653LCI, 653XC, 653XCI, 653XV, 654LC, 654LCI, 654XC, 654XCI, 654XV, 655LCI, 6592, 6592G, 6593, 6593G, 660, 660LCI, 660LMI, 661LC, 661LCI, 661LM, 661LMI, 661XC, 661XCI, 661XVI, 662LC, 662LCI, 662LM, 662LMI, 662XCI, 663LCI, 663LM, 663LMI, 720, 720TX, 720TXV, 721TX, 722, 722ITX, 722ITXV, 722TX, 723, 723TX, 723TXVI, 730, 730TX, 730TXV, 732, 7320, 732TLV, 732TX, 732TXV, 734, 734TL, 734TXV, 735, 735TLV, 736, 736TL, 736TLV, 737, 737TLV, 738, 738TLV, 739, 739GLTV, 739TLV, 740, 740LVF, 741, 741LVF, 744, 744LCF, 7510, 7520, 7520G, 7530, 7720, 7720G, 7730, 7730G, 7740G, 7740Z, 7740ZG, 800, 8000, 8000LCI, 8000LMI, 8001, 8001LCIB, 8002, 8002LC, 8002LCI, 8002LCIB, 8002LMI, 8003, 8003LCI, 8003LCIB, 8003LM, 8003LMI, 8003LMIB, 8004, 8004LCI, 8004LCIB, 8004LM, 8004LMI, 8004LMIB, 8005, 8005LCI, 8005LCIB, 8005LMI, 8005LMIB, 8006, 8006LCI, 8006LM, 8006LMI, 8006LMIB, 800LC, 800LCI, 800LCIB, 800LM, 800LMI, 800LMIB, 800XC, 800XCI, 802LCI, 802LCIB, 802LMI, 802LMIB, 802XCI, 803LC, 803LCI, 803LCIB, 803LM, 803LMIB, 803XCI, 803XVI, 804LC, 804LCI, 804LCIB, 804LM, 804LMI, 804LMIB, 8100, 8101, 8101WLMI, 8102, 8102WLMI, 8102WLMI, 8103, 8103WLMI, 8104, 8104WLMI, 8104WLMI, 8106, 8106WLMI, 8210, 8371, 8471, 8472, 8472G, 8472T, 8472TG, 8572, 8572G, 8572T, 8572TG, T5600,

Emachines

D440, D442, D443, D520, D525, D528, D620, D640, D642, D720, D725, D727, D728, D729Z, D730, D732, D732Z, E430, E440, E442, E443, E510, E520, E525, E527, E528, E529, E620, E625, E627, E628, E630, E640, E642, E644, E720, E725, E727, E728, E729, E729Z, E730, E730Z, E732, E732Z, EME443, EME644, EME730, EME730Z, G420, G430, G443, G520, G525, G620, G625, G627, G630, G640, G720, G725, G729Z, G730, M2105, M2350, M2352, M2356, M5105, M5124, M5305, M5307, M5309, M5312, M5313, M5405, M5410, M5414, M6410, M6805, M6807, M6809, M6810, M6811, MX4624, MX4625, N-10, N-12, N-14, W4605, W4620, W4630,

Netbook series

250, 350, 355,

Packard Bell

Easy Note series

LJ65,

19V 2.1A 5.5mm*3.0mm

Aspire series

1425P, 1430, 1430Z, 1825PT, 1825PTZ, 1830, 1830T, 1830TZ, 1830Z, E11, ONE 521, ONE 522, ONE 532H, ONE 533, ONE 721, ONE 722, ONE 753, ONE D255, ONE D255E, ONE

D257, ONE D260, ONE HAPPY, ONE HAPPY2, V5,

Ferrari series

ONE 200,

Packard Bell

Dot series

S2, SE3,

19V1.58A 5.5mm*3.0mm

Aspire series

1420P, 1425P, 1810T, 1810TZ, 1820PT, 1820PTZ, 1825PT, 1825PTZ, ONE 531H, ONE 571H, ONE 751H, ONE 752, ONE A110, ONE A150, ONE D150, ONE D250, ONE E100, ONE P531H,

Aspire One series

A110, A110L, A110X, A150, A150L, A150X, AO533, AO533-13DRR, AOA110, AOA110-1295, AOA110-1722, AOA150, AOA150-1006, AOD150, AOD250, AODA110, AODA150, D150, D250, P531H,

Travelmate series

7530G,

Dell 19V1.58A

Inspiron Mini series

10, 1010, 1011, 1012, 1018, 10V, 12, 9, 910,

Vostro series

A90,

Packard Bell

Dot series

A, DOT, M, M - A, M - U, M-A, M-U, S, S2, SE, SE2, SPT, U, VR46,

EasyNote series

BUTTERFLY M, BUTTERFLY S, BUTTERFLY S2, BUTTERFLY T, BUTTERFLY TOUCH, BUTTERFLY XS,

EasyNote Butterfly series

M, S, S2, T, TOUCH, XS

END H10

Sony 19.5V4.7A 6.5mm*4.4mm 90W

Vaio Series

PCG-FR102, PCG-FR105, PCG-FR215E, PCG-FR215H, PCG-FR215M, PCG-FR215S,
 PCG-FR285E, PCG-FR285M, PCG-FR295MP, PCG-GRV516G, PCG-GRV616G,
 PCG-GRV616S, PCG-GRX315MK, PCG-GRX315MP, PCG-GRX316G, PCG-GRX316MK,
 PCG-GRX316MP, PCG-GRX316SK, PCG-GRX316SP, PCG-GRX415MK, PCG-GRX415MP,
 PCG-GRX416G, PCG-GRX416SK, PCG-GRX416SP, PCG-GRX516MD, PCG-GRX516SP,
 PCG-GRX616MK, PCG-GRX616MP, PCG-GRX616SP, PCG-GRZ515G, PCG-GRZ615G,
 PCG-GRZ615M, PCG-GRZ615S, PCG-NV309, PCG-R600HEK, PCG-R600HEP,
 PCG-R600HEPD, PCG-R600HFK, PCG-R600HFP, PCG-R600HFPD, PCG-R600HMK,
 PCG-R600HMKD, PCG-R600HMP, PCG-R600HMPD, PCG-R600MEP, PCG-R600MF,
 PCG-R600MX, VGH-FW170J/H, VGN-A115B, VGN-A115M, VGN-A115S, VGN-A115Z,
 VGN-A117S, VGN-A195EP, VGN-A195EP/E, VGN-A195EP/F, VGN-A195HP, VGN-A197VP,
 VGN-A197VP/E, VGN-A197VP/F, VGN-A197XP, VGN-A215M, VGN-A215Z, VGN-A217M,
 VGN-A217S, VGN-A295HP, VGN-A295HP/F, VGN-A297XP, VGN-A317M, VGN-A317S,
 VGN-A397XP, VGN-A417M, VGN-A417S, VGN-A497XP, VGN-A497XP/F, VGN-A517B,
 VGN-A517M, VGN-A517S, VGN-A617B, VGN-A617M, VGN-A617S, VGN-AX570G,
 VGN-BX194VP, VGN-BX195EP, VGN-BX195SP, VGN-BX195SPF, VGN-BX195VP,
 VGN-BX195VPF, VGN-BX195XP, VGN-BX195XPF, VGN-BX196SP, VGN-BX196VP,
 VGN-BX196VPF, VGN-BX196XP, VGN-BX197XP, VGN-BX197XPF, VGN-BX294VP,
 VGN-BX295SP, VGN-BX295VP, VGN-BX295VPF, VGN-BX296VP, VGN-BX296VPF,
 VGN-BX296XP, VGN-BX297XP, VGN-BX297XPF, VGN-BX394VP, VGN-BX396BP,
 VGN-BX396VP, VGN-BX396XP, VGN-BX397XP, VGN-BX41VN, VGN-BX41XN,
 VGN-BX51VN, VGN-BX51XP, VGN-BX541B, VGN-BX543B, VGN-BX546B, VGN-BX61MN,
 VGN-BX61VN, VGN-BX61XN, VGN-BZ1, VGN-BZ11EN, VGN-BZ11MN, VGN-BZ11VN,
 VGN-BZ11XN, VGN-BZ12EN, VGN-BZ12VN, VGN-BZ12XN, VGN-BZ13VN, VGN-BZ13XN,
 VGN-BZ2, VGN-BZ21VN, VGN-BZ21XN, VGN-BZ26M, VGN-BZ26V, VGN-BZ26X,
 VGN-BZ31VT, VGN-BZ31XT, VGN-BZ560, VGN-BZ562NAB, VGN-C140G/B, VGN-C150P/B,
 VGN-C190, VGN-C1S/G, VGN-C1S/H, VGN-C1S/P, VGN-C1S/W, VGN-C1Z/B, VGN-C1ZR/B,
 VGN-C2M/W, VGN-C2S/G, VGN-C2S/H, VGN-C2S/L, VGN-C2S/P, VGN-C2S/W,
 VGN-C2SR/G, VGN-C2SR/L, VGN-C2SR/P, VGN-C2Z/B, VGN-C2ZR/B, VGN-CR11S/L,
 VGN-CR11S/P, VGN-CR11S/W, VGN-CR11SR/L, VGN-CR11SR/P, VGN-CR11SR/W,
 VGN-CR11Z/R, VGN-CR11ZR/R, VGN-CR19VN/B, VGN-CR19XN/B, VGN-CR21E/L,
 VGN-CR21E/P, VGN-CR21E/W, VGN-CR21S/L, VGN-CR21S/P, VGN-CR21S/W,
 VGN-CR21SR/L, VGN-CR21SR/P, VGN-CR21SR/W, VGN-CR21Z/N, VGN-CR21Z/R,
 VGN-CR21ZR/R, VGN-CR29XN/B, VGN-CR31E/L, VGN-CR31E/P, VGN-CR31E/W,
 VGN-CR31S/L, VGN-CR31S/P, VGN-CR31S/W, VGN-CR31SR/L, VGN-CR31SR/P,
 VGN-CR31SR/W, VGN-CR31Z/N, VGN-CR31Z/R, VGN-CR31ZR/N, VGN-CR31ZR/R,
 VGN-CR41S/L, VGN-CR41S/P, VGN-CR41S/W, VGN-CR41SR/L, VGN-CR41SR/P,
 VGN-CR41SR/W, VGN-CR41Z/N, VGN-CR41Z/R, VGN-CR41ZR/N, VGN-CR41ZR/R,
 VGN-CR42S/B, VGN-CR42S/L, VGN-CR42S/P, VGN-CR42S/W, VGN-CR42Z/N,
 VGN-CR42Z/R, VGN-CS1, VGN-CS110E/S, VGN-CS11S/P, VGN-CS11S/Q, VGN-CS11S/W,

VGN-CS11SR/P, VGN-CS11SR/Q, VGN-CS11SR/W, VGN-CS11Z/R, VGN-CS11Z/T, VGN-CS11ZR/R, VGN-CS11ZR/T, VGN-CS16Z, VGN-CS190, VGN-CS2, VGN-CS21S/P, VGN-CS21S/R, VGN-CS21S/T, VGN-CS21S/V, VGN-CS21S/W, VGN-CS21S/W, VGN-CS21Z/Q, VGN-CS3, VGN-CS31MR/P, VGN-CS31MR/W, VGN-CS31S/P, VGN-CS31S/Q, VGN-CS31S/R, VGN-CS31S/T, VGN-CS31S/V, VGN-CS31S/W, VGN-CS31SR/P, VGN-CS31SR/Q, VGN-CS31SR/V, VGN-CS31SR/W, VGN-CS31ST/P, VGN-CS31ST/Q, VGN-CS31ST/R, VGN-CS31ST/T, VGN-CS31ST/V, VGN-CS31ST/W, VGN-CS31Z/Q, VGN-CS31ZR/R, VGN-CS31ZR/T, VGN-CS390, VGN-CS390JCP, VGN-CS390JCQ, VGN-CS390JCR, VGN-CS390JCW, VGN-CS390JDV, VGN-FE11H, VGN-FE11M, VGN-FE11MR, VGN-FE11S, VGN-FE11SR, VGN-FE21B, VGN-FE21H, VGN-FE21HR, VGN-FE21M, VGN-FE21S, VGN-FE21SR, VGN-FE28B, VGN-FE28H, VGN-FE31B, VGN-FE31H, VGN-FE31HR, VGN-FE31M, VGN-FE31Z, VGN-FE31ZR, VGN-FE39VP, VGN-FE41E, VGN-FE41M, VGN-FE41MR, VGN-FE41S, VGN-FE41Z, VGN-FE41ZR, VGN-FE48E, VGN-FE48M, VGN-FE49VN, VGN-FE570G, VGN-FE590, VGN-FE590GC, VGN-FE590P03, VGN-FE590PA, VGN-FE590PB, VGN-FE660G, VGN-FE670G, VGN-FE690, VGN-FE690GB, VGN-FE690PB, VGN-FE770G, VGN-FE790, VGN-FJ170P/B, VGN-FJ180P/G, VGN-FJ180P/L, VGN-FJ180P/R, VGN-FJ180P/W, VGN-FJ1S/L, VGN-FJ1S/R, VGN-FJ1S/W, VGN-FJ1SR/B, VGN-FJ1Z/W, VGN-FJ270P/B, VGN-FJ270P/BK1, VGN-FJ290, VGN-FJ290L1B, VGN-FJ290L1G, VGN-FJ290L1L, VGN-FJ290L1R, VGN-FJ290L1W, VGN-FJ290P1/G, VGN-FJ290P1/GK1, VGN-FJ290P1/L, VGN-FJ290P1/LK1, VGN-FJ290P1/R, VGN-FJ290P1/RK1, VGN-FJ290P1/W, VGN-FJ290P1/WK1, VGN-FJ290P1V, VGN-FJ3M/W, VGN-FJ3S/W, VGN-FJ3SR/B, VGN-FS115B, VGN-FS115E, VGN-FS115M, VGN-FS115MR, VGN-FS115S, VGN-FS115Z, VGN-FS115ZR, VGN-FS195VP, VGN-FS195VPF, VGN-FS195XP, VGN-FS215B, VGN-FS215E, VGN-FS215M, VGN-FS215MR, VGN-FS215S, VGN-FS215SR, VGN-FS215Z, VGN-FS285B, VGN-FS285E, VGN-FS285H, VGN-FS285M, VGN-FS295VP, VGN-FS295VPF, VGN-FS295XP, VGN-FS315B, VGN-FS315E, VGN-FS315H, VGN-FS315M, VGN-FS315MR, VGN-FS315S, VGN-FS315SR, VGN-FS315Z, VGN-FS395VP, VGN-FS415B, VGN-FS415E, VGN-FS415M, VGN-FS415MR, VGN-FS415S, VGN-FS485B, VGN-FS495VP, VGN-FS500, VGN-FS500B, VGN-FS500P, VGN-FS515B, VGN-FS515BR, VGN-FS515E, VGN-FS515H, VGN-FS520B, VGN-FS530B, VGN-FS540P, VGN-FS550, VGN-FS550F, VGN-FS550P, VGN-FS570, VGN-FS595VP, VGN-FS625B/W, VGN-FS630/W, VGN-FS635B/W, VGN-FS640/W, VGN-FS645P/H, VGN-FS660/W, VGN-FS675P/H, VGN-FS680/W, VGN-FS690, VGN-FS730/W, VGN-FS740/W, VGN-FS742/W, VGN-FS745P/H, VGN-FS750P/W, VGN-FS760/W, VGN-FS775P/H, VGN-FS780/W, VGN-FS790, VGN-FS7901, VGN-FS7902, VGN-FS840/W, VGN-FS875P/H, VGN-FS8900, VGN-FS8900M, VGN-FS8900P3, VGN-FS8900P4, VGN-FS8900P5, VGN-FS8900V, VGN-FS980, VGN-FS990, VGN-FW11, VGN-FW11E, VGN-FW11ER, VGN-FW11J, VGN-FW11L, VGN-FW11LR, VGN-FW11M, VGN-FW11MR, VGN-FW11S, VGN-FW11SR, VGN-FW11Z, VGN-FW11ZR, VGN-FW11ZU, VGN-FW139E/H, VGN-FW15T, VGN-FW17/B, VGN-FW17T/H, VGN-FW17W, VGN-FW19, VGN-FW21, VGN-FW21E, VGN-FW21ER, VGN-FW21J, VGN-FW21L, VGN-FW21M, VGN-FW21MR, VGN-FW21SR, VGN-FW21Z, VGN-FW21ZR, VGN-FW3, VGN-FW31E, VGN-FW31J, VGN-FW31M, VGN-FW31ZJ, VGN-FW32J, VGN-FW4, VGN-FW41E/H, VGN-FW41E/W, VGN-FW41ET/H, VGN-FW41J/H,

VGN-FW41M/H, VGN-FW41MR/H, VGN-FW41ZJ/H, VGN-FW44MR, VGN-FW465J/B, VGN-FW46M, VGN-FW46S, VGN-FW46Z, VGN-FW48E/H, VGN-FW490, VGN-FW490JEB, VGN-FW490JFT, VGN-FW4ZRJ/H, VGN-FW4ZTJ/H, VGN-FW5, VGN-FW51JF/H, VGN-FW51MF/H, VGN-FW51ZF/H, VGN-FW54E, VGN-FW54J, VGN-FW54M, VGN-FW54MR, VGN-FW54S, VGN-FW56E, VGN-FW56J, VGN-FW56M, VGN-FW56SR, VGN-FW56Z, VGN-FW56ZR, VGN-FW5ERF/H, VGN-FW5JTF/H, VGN-FW5MTF/H, VGN-FW5ZRF/H, VGN-FW5ZTF/H, VGN-FZ11E, VGN-FZ11L, VGN-FZ11M, VGN-FZ11MR, VGN-FZ11S, VGN-FZ11SR, VGN-FZ11Z, VGN-FZ11ZR, VGN-FZ18E, VGN-FZ18L, VGN-FZ18M, VGN-FZ19VN, VGN-FZ21E, VGN-FZ21J, VGN-FZ21M, VGN-FZ21MR, VGN-FZ21S, VGN-FZ21SR, VGN-FZ21Z, VGN-FZ21ZR, VGN-FZ29VN, VGN-FZ31E, VGN-FZ31ER, VGN-FZ31J, VGN-FZ31L, VGN-FZ31M, VGN-FZ31MR, VGN-FZ31S, VGN-FZ31SR, VGN-FZ31Z, VGN-FZ31ZR, VGN-FZ38M, VGN-FZ39VN, VGN-N11H/W, VGN-N11M/W, VGN-N11S/W, VGN-N11SR/W, VGN-N19EP/B, VGN-N19VP/B, VGN-N21E/W, VGN-N21M/W, VGN-N21S/W, VGN-N21Z/W, VGN-N21ZR/W, VGN-N29VN/B, VGN-N31L/W, VGN-N31M/W, VGN-N31S/W, VGN-N31Z/W, VGN-N31ZR/W, VGN-N38E/W, VGN-N38L/W, VGN-N38M/W, VGN-N38Z/W, VGN-NR10E/S, VGN-NR10M/S, VGN-NR11M/S, VGN-NR11S/S, VGN-NR11SR/S, VGN-NR11Z/S, VGN-NR11Z/T, VGN-NR21E/S, VGN-NR21J/S, VGN-NR21M/S, VGN-NR21MR/S, VGN-NR21S/S, VGN-NR21S/T, VGN-NR21S/W, VGN-NR21SR/S, VGN-NR21Z/S, VGN-NR21Z/T, VGN-NR22M/S, VGN-NR31E/S, VGN-NR31ER/S, VGN-NR31J/S, VGN-NR31MR/S, VGN-NR31S/S, VGN-NR31SR/S, VGN-NR31Z/S, VGN-NR31Z/T, VGN-NR31ZR/S, VGN-NR31ZR/T, VGN-NR32L/S, VGN-NR32M/S, VGN-NR32S/S, VGN-NR32Z/S, VGN-NR32Z/T, VGN-NR38E/S, VGN-NR38M/S, VGN-NR38S/S, VGN-NR38Z/S, VGN-NR38Z/T, VGN-NS10E/S, VGN-NS10J/S, VGN-NS10L/S, VGN-NS11E/S, VGN-NS11ER/S, VGN-NS11J/S, VGN-NS11L/S, VGN-NS11M/S, VGN-NS11MR/S, VGN-NS11S/S, VGN-NS11SR/S, VGN-NS11Z/S, VGN-NS11ZR/S, VGN-NS12M/S, VGN-NS12M/W, VGN-NS20E/P, VGN-NS20E/S, VGN-NS20J/S, VGN-NS20M/S, VGN-NS20S/S, VGN-NS20Z/S, VGN-NS21E/S, VGN-NS21ER/S, VGN-NS21M/P, VGN-NS21M/S, VGN-NS21M/W, VGN-NS21S/S, VGN-NS21S/W, VGN-NS21SR/S, VGN-NS21X/S, VGN-NS21Z/S, VGN-NS30E/P, VGN-NS30E/S, VGN-NS30E/W, VGN-NS30Z/S, VGN-NS31EH/S, VGN-NS31ER/S, VGN-NS31M/P, VGN-NS31M/S, VGN-NS31M/W, VGN-NS31MR/S, VGN-NS31MT/S, VGN-NS31S/S, VGN-NS31ST/S, VGN-NS36E, VGN-NS38E/S, VGN-NS38M/P, VGN-NS38M/S, VGN-NS38M/W, VGN-NW11S/S, VGN-NW11S/T, VGN-NW11SR/S, VGN-NW11Z/S, VGN-NW11Z/T, VGN-NW11ZR/S, VGN-NW12Z/S, VGN-NW12Z/T, VGN-NW20EF/P, VGN-NW20EF/S, VGN-NW20EF/W, VGN-NW20SF/P, VGN-NW20SF/S, VGN-NW20ZF/S, VGN-NW20ZF/T, VGN-NW21EF/S, VGN-NW21JF/S, VGN-NW21MF/P, VGN-NW21MF/S, VGN-NW21MF/W, VGN-NW21SF/S, VGN-NW21SF/T, VGN-NW21ZF/S, VGN-NW21ZF/T, VGN-NW24EG, VGN-NW24JG, VGN-NW24MG, VGN-NW24MR, VGN-NW24S, VGN-NW26E, VGN-NW26EG, VGN-NW26JG, VGN-NW26M, VGN-NW26MRG, VGN-NW2ERE/S, VGN-NW2ETF/S, VGN-NW2MRE/P, VGN-NW2MRE/S, VGN-NW2MTF/S, VGN-NW2SRF/S, VGN-NW2STF/T, VGN-NW2ZRF/N, VGN-NW31EF/S, VGN-NW31EF/W, VGN-NW31JF/S, VGN-S150, VGN-S150F, VGN-S150FP, VGN-S150P, VGN-S170, VGN-S170B, VGN-S170F, VGN-S170P, VGN-S240P, VGN-S250F, VGN-S250FP, VGN-S260, VGN-S260P, VGN-S270, VGN-S270B,

VGN-S270F, VGN-S270P, VGN-S2HP, VGN-S2HP/F, VGN-S2HRP, VGN-S2VP, VGN-S2XP, VGN-S2XRP, VGN-S350F, VGN-S350FP, VGN-S350P, VGN-S360, VGN-S360P, VGN-S370F, VGN-S380, VGN-S380B, VGN-S380B PROFESSIONAL, VGN-S380P, VGN-S3HP, VGN-S3HP/F, VGN-S3VP, VGN-S3XP, VGN-S430P/S, VGN-S460/B, VGN-S460P/B, VGN-S470P/S, VGN-S480, VGN-S4HP/B, VGN-S4HP/B/F, VGN-S4HRP/B, VGN-S4M/S, VGN-S4VP/B, VGN-S4XP/B, VGN-S4XRP/B, VGN-S4Z/S, VGN-S550P/S, VGN-S560P/B, VGN-S570P/S, VGN-S580, VGN-S5HP/B, VGN-S5HP/B/F, VGN-S5HRP/B, VGN-S5M/S, VGN-S5VP/B, VGN-S5XP/B, VGN-S5XRP/B, VGN-SR11M, VGN-SR11MR, VGN-SR19VN, VGN-SR19VRN, VGN-SR19XN, VGN-SR21M/S, VGN-SR21RM/H, VGN-SR21RM/S, VGN-SR220J, VGN-SR230J, VGN-SR29VN/S, VGN-SR29XN/S, VGN-SR2RVN/S, VGN-SR3, VGN-SR31M/S, VGN-SR37M, VGN-SR39VN/S, VGN-SR39XN/S, VGN-SR4, VGN-SR41M/P, VGN-SR41M/S, VGN-SR41M/W, VGN-SR420J/B, VGN-SR46Z, VGN-SR490, VGN-SR490JCN, VGN-SR490JCP, VGN-SR49VN/H, VGN-SR49VT/H, VGN-SR49XN/H, VGN-SR4MR/P, VGN-SR4MR/S, VGN-SR4MR/W, VGN-SR4VR/H, VGN-SR5, VGN-SR51MF/P, VGN-SR51MF/S, VGN-SR51MF/W, VGN-SR51RF/P, VGN-SR51RF/S, VGN-SR51RF/W, VGN-SR56XN, VGN-SR57S, VGN-SR57V, VGN-SR57X, VGN-SR59TG/H, VGN-SR59VG/H, VGN-SR59XG/H, VGN-SZ140, VGN-SZ140PC, VGN-SZ140PD, VGN-SZ160P/C, VGN-SZ1HP/B, VGN-SZ1HRP/B, VGN-SZ1M/B, VGN-SZ1VP/C, VGN-SZ1XP/C, VGN-SZ1XP/CF, VGN-SZ1XRP/C, VGN-SZ220/B, VGN-SZ230P/B, VGN-SZ240, VGN-SZ270P/C, VGN-SZ280P/C, VGN-SZ281P/X, VGN-SZ2HP/B, VGN-SZ2HRP/B, VGN-SZ2M/B, VGN-SZ2VP/X, VGN-SZ2XP/C, VGN-SZ2XP/CF, VGN-SZ2XRP/C, VGN-SZ320P/B, VGN-SZ330P/B, VGN-SZ340, VGN-SZ360P/C, VGN-SZ370P/C, VGN-SZ381P/X, VGN-SZ390, VGN-SZ3HP/B, VGN-SZ3HRP/B, VGN-SZ3HTP/B, VGN-SZ3VP/X, VGN-SZ3VWP/X, VGN-SZ3XP/C, VGN-SZ3XP/CF, VGN-SZ3XRP/C, VGN-SZ3XTP/C, VGN-SZ3XWP/C, VGN-SZ4MN/B, VGN-SZ4MRN/B, VGN-SZ4MTN/B, VGN-SZ4VN/X, VGN-SZ4VRN/X, VGN-SZ4VWN/X, VGN-SZ4XN/C, VGN-SZ4XN/CF, VGN-SZ4XRN/C, VGN-SZ4XTN/C, VGN-SZ4XWN/C, VGN-SZ5MN/B, VGN-SZ5MRN/B, VGN-SZ5MTN/B, VGN-SZ5VN/X, VGN-SZ5VRN/X, VGN-SZ5VWN/X, VGN-SZ5XN/C, VGN-SZ5XRN/C, VGN-SZ5XTN/C, VGN-SZ5XWN/C, VGN-SZ60MN/B, VGN-SZ60WN/C, VGN-SZ61MN/B, VGN-SZ61VN/X, VGN-SZ61WN/C, VGN-SZ61XN/C, VGN-SZ62MN/B, VGN-SZ62WN/C, VGN-SZ6AWN/C, VGN-SZ6RMN/B, VGN-SZ6RVN/X, VGN-SZ6RXN/C, VGN-SZ70M/B, VGN-SZ70WN/C, VGN-SZ71E/B, VGN-SZ71MN/B, VGN-SZ71VN/X, VGN-SZ71WN/C, VGN-SZ71XN/C, VGN-SZ72MN/B, VGN-SZ72WN/X, VGN-SZ7AWN/C, VGN-SZ7RMN/B, VGN-SZ7RVN/X, VGN-SZ7RXN/C, VGN-Z11AWN/B, VGN-Z11MN/B, VGN-Z11MRN/B, VGN-Z11VN/B, VGN-Z11VRN/B, VGN-Z11WN/B, VGN-Z11XN/B, VGN-Z11XRN/B, VGN-Z2, VGN-Z21MN/B, VGN-Z21MRN/B, VGN-Z21VN/X, VGN-Z21VRN/X, VGN-Z21WN/B, VGN-Z21WRN/B, VGN-Z21XN/B, VGN-Z21ZN/X, VGN-Z21ZRN/X, VGN-Z26VN, VGN-Z3, VGN-Z31MN/B, VGN-Z31VN/X, VGN-Z31VRN/X, VGN-Z31WN/B, VGN-Z31XN/B, VGN-Z31ZN/X, VGN-Z36XRN, VGN-Z4, VGN-Z41MD/B, VGN-Z41MRD/B, VGN-Z41VRD/X, VGN-Z41WD/B, VGN-Z41XD/B, VGN-Z41XRD/B, VGN-Z41XTD/B, VGN-Z41ZD/X, VGN-Z41ZRD/X, VGN-Z46VRN, VGN-Z46XRN, VGN-Z5, VGN-Z51MG/B, VGN-Z51MRG/B, VGN-Z51VRG/X, VGN-Z51WG/B, VGN-Z51XG/B, VGN-Z51XTG/B, VGN-Z56VG, VGN-Z56VRG, VGN-Z56XG, VGN-Z56XRG, VPCB11A7E, VPCB11V9E/B, VPCB11X9E/B, VPCCA1C5E, VPCCA1S1E/B, VPCCA1S1E/D,

VPCCA1S1E/G, VPCCA1S1E/P, VPCCA1S1E/W, VPCCA1S1R/B, VPCCA1S1R/D,
VPCCA1S1R/G, VPCCA1S1R/P, VPCCA1S1R/W, VPCCA2C5E, VPCCA2S0E/D,
VPCCA2S0E/G, VPCCA2S0E/L, VPCCA2S0E/P, VPCCA2S0E/R, VPCCA2S0E/W,
VPCCA2S1E/, VPCCA2S1E/D, VPCCA2S1E/G, VPCCA2S1E/L, VPCCA2S1E/P,
VPCCA2S1E/R, VPCCA2S1E/W, VPCCA2S1R/D, VPCCA2S1R/L, VPCCA2S1R/P,
VPCCA2S1R/R, VPCCA2S1R/W, VPCCA2Z0E/G, VPCCA2Z0E/L, VPCCA2Z0E/P,
VPCCA2Z0E/R, VPCCA2Z0E/W, VPCCA3C5E, VPCCA3E1E/D, VPCCA3E1E/G,
VPCCA3E1E/L, VPCCA3E1E/P, VPCCA3E1E/R, VPCCA3E1E/W, VPCCA3S1E/D,
VPCCA3S1E/G, VPCCA3S1E/L, VPCCA3S1E/P, VPCCA3S1E/R, VPCCA3S1E/W,
VPCCA3S1R/D, VPCCA3S1R/L, VPCCA3S1R/P, VPCCA3S1R/R, VPCCA3S1R/W,
VPCCA3X1R/BI, VPCCA3X1R/PI, VPCCB2C5E, VPCCB2M0E/B, VPCCB2M1E/B,
VPCCB2M1E/W, VPCCB2M8E/B, VPCCB2S1E/B, VPCCB2S1E/W, VPCCB2S1R/B,
VPCCB2S8E/B, VPCCB2Z8E/B, VPCCB3C5E, VPCCB3M1E/B, VPCCB3M1E/W,
VPCCB3P1E/B, VPCCB3S1E/B, VPCCB3S1E/W, VPCCB3S1R/B, VPCCB3S8E/B,
VPCCB3Z8E/B, VPCCW1, VPCCW1E1R/BU, VPCCW1E1R/WU, VPCCW1E8R/BU,
VPCCW1E8R/WU, VPCCW1S1E/B, VPCCW1S1E/L, VPCCW1S1E/P, VPCCW1S1E/R,
VPCCW1S1E/W, VPCCW1S1R/B, VPCCW1S1R/L, VPCCW1S1R/P, VPCCW1S1R/R,
VPCCW1S1R/W, VPCCW1S1T/B, VPCCW1S1T/L, VPCCW1S1T/P, VPCCW1S1T/R,
VPCCW1S1T/W, VPCCW1Z4E, VPCCW2C5E, VPCCW2S1E/B, VPCCW2S1E/L,
VPCCW2S1E/P, VPCCW2S1E/R, VPCCW2S1E/W, VPCCW2S1R/B, VPCCW2S1R/L,
VPCCW2S1R/P, VPCCW2S1R/R, VPCCW2S1R/W, VPCCW2S8E/B, VPCCW2S8E/W,
VPCCW2Z1E/B, VPCEA1C5E, VPCEA1S1E/B, VPCEA1S1E/G, VPCEA1S1E/L,
VPCEA1S1E/P, VPCEA1S1E/W, VPCEA1S1R/B, VPCEA1S1R/G, VPCEA1S1R/L,
VPCEA1S1R/P, VPCEA1S1R/W, VPCEA1Z1E/B, VPCEA2C5E, VPCEA2M1R/BJ,
VPCEA2M1R/PI, VPCEA2M1R/WI, VPCEA2S1E/B, VPCEA2S1E/G, VPCEA2S1E/L,
VPCEA2S1E/P, VPCEA2S1E/W, VPCEA2S1R/B, VPCEA2S1R/G, VPCEA2S1R/L,
VPCEA2S1R/P, VPCEA2S1R/W, VPCEA3A4E, VPCEA3B4E, VPCEA3C4E, VPCEA3C5E,
VPCEA3D4E, VPCEA3L1E/B, VPCEA3L1E/G, VPCEA3L1E/L, VPCEA3L1E/P,
VPCEA3L1E/V, VPCEA3L1E/W, VPCEA3M1E/B, VPCEA3M1E/G, VPCEA3M1E/L,
VPCEA3M1E/P, VPCEA3M1E/V, VPCEA3M1E/W, VPCEA3M1R/BJ, VPCEA3M1R/PI,
VPCEA3M1R/WI, VPCEA3S1E/B, VPCEA3S1E/G, VPCEA3S1E/L, VPCEA3S1E/P,
VPCEA3S1E/V, VPCEA3S1E/W, VPCEA3S1R/B, VPCEA3S1R/G, VPCEA3S1R/L,
VPCEA3S1R/P, VPCEA3S1R/V, VPCEA3S1R/W, VPCEA3Z1R/BQ, VPCEA3Z1R/N,
VPCEA4M1R/BJ, VPCEA4M1R/PI, VPCEA4M1R/WI, VPCEA4S1E/B, VPCEA4S1E/G,
VPCEA4S1E/L, VPCEA4S1E/P, VPCEA4S1E/V, VPCEA4S1E/W, VPCEB1A4E, VPCEB1B4E,
VPCEB1C5E, VPCEB1E0E/T, VPCEB1E0E/WI, VPCEB1E1E/WI, VPCEB1E1R/BJ,
VPCEB1E1R/T, VPCEB1E1R/WI, VPCEB1E8E/WI, VPCEB1E9E/BJ, VPCEB1E9J/BJ,
VPCEB1E9R/BJ, VPCEB1E9R/WI, VPCEB1J1E/WI, VPCEB1J8E/WI, VPCEB1M0E/WI,
VPCEB1M1E/BJ, VPCEB1M1E/T, VPCEB1M1E/WI, VPCEB1M1R/BJ, VPCEB1M1R/WI,
VPCEB1S0E/BJ, VPCEB1S0E/WI, VPCEB1S1E/BJ, VPCEB1S1E/WI, VPCEB1S1R/BJ,
VPCEB1S1R/T, VPCEB1S1R/WI, VPCEB1S8E/BJ, VPCEB1S8E/WI, VPCEB1Z0E/B,
VPCEB1Z1E/B, VPCEB1Z1R/B, VPCEB2A4E, VPCEB2B4E, VPCEB2C4E, VPCEB2C5E,
VPCEB2E1E/WI, VPCEB2E1R/BQ, VPCEB2E1R/WI, VPCEB2E4E, VPCEB2E9E/BQ,
VPCEB2E9R/BQ, VPCEB2E9R/WI, VPCEB2F4E, VPCEB2G4E, VPCEB2H4E,

VPCEB2L9E/BQ, VPCEB2M0E/PI, VPCEB2M0E/T, VPCEB2M0E/WI, VPCEB2M1E/BQ, VPCEB2M1E/PI, VPCEB2M1E/WI, VPCEB2M1R/BQ, VPCEB2M1R/PI, VPCEB2M1R/WI, VPCEB2S1E/BQ, VPCEB2S1E/PI, VPCEB2S1E/WI, VPCEB2S1R/BQ, VPCEB2S1R/PI, VPCEB2S1R/WI, VPCEB2Z0E/BQ, VPCEB2Z1E/BQ, VPCEB2Z1R/B, VPCEB3A4E, VPCEB3A4R, VPCEB3B4E, VPCEB3B4R, VPCEB3C4E, VPCEB3C4R, VPCEB3C5E, VPCEB3D4E, VPCEB3D4R, VPCEB3E1E/PI, VPCEB3E1E/WI, VPCEB3E1R/BQ, VPCEB3E1R/WI, VPCEB3E4E, VPCEB3E4R, VPCEB3E8E/WI, VPCEB3E9E/BQ, VPCEB3F4E, VPCEB3G4E, VPCEB3H4E, VPCEB3J0E/WI, VPCEB3J1E/BQ, VPCEB3J1E/T, VPCEB3J1E/WI, VPCEB3L0E/BQ, VPCEB3L1E/BQ, VPCEB3L1E/PI, VPCEB3L1E/T, VPCEB3L1E/WI, VPCEB3L9E/BQ, VPCEB3M1E/BQ, VPCEB3M1E/WI, VPCEB3M1R/BQ, VPCEB3M1R/T, VPCEB3M1R/WI, VPCEB3S1E/BQ, VPCEB3S1R/BQ, VPCEB3S1R/WI, VPCEB3Z1E/BQ, VPCEB3Z1R/B, VPCEB4A4E, VPCEB4B4E, VPCEB4C4E, VPCEB4C5E, VPCEB4D4E, VPCEB4E0E/PI, VPCEB4E0E/WI, VPCEB4E1E/WI, VPCEB4E1R/BQ, VPCEB4E1R/WI, VPCEB4E4E, VPCEB4E9E/BQ, VPCEB4E9R/BQ, VPCEB4F4E, VPCEB4J0E/WI, VPCEB4J1E/PI, VPCEB4J1E/WI, VPCEB4J1R/BQ, VPCEB4J1R/WI, VPCEB4L1E/BQ, VPCEB4L1E/T, VPCEB4L1E/WI, VPCEB4L1R/BQ, VPCEB4L1R/T, VPCEB4L1R/WI, VPCEB4L9E/BQ, VPCEB4M1E/BQ, VPCEB4M1E/PI, VPCEB4M1E/T, VPCEB4M1E/WI, VPCEB4M1R/BQ, VPCEB4S1E/BQ, VPCEB4S1E/WI, VPCEB4S1R/BQ, VPCEB4S1R/WI, VPCEB4X0E/BQ, VPCEB4X1E/BQ, VPCEB4X8E/BQ, VPCEB4Z0E/BQ, VPCEB4Z1E/BQ, VPCEB4Z1R/B, VPCEC1A4E, VPCEC1B4E, VPCEC1C4E, VPCEC1C5E, VPCEC1M1E/WI, VPCEC1M1R/WI, VPCEC1S1E/BJ, VPCEC1S1R/BJ, VPCEC1Z1E/BJ, VPCEC2A4E, VPCEC2C5E, VPCEC2E9E/BJ, VPCEC2M1E/WI, VPCEC2M1R/WI, VPCEC2S0E/WI, VPCEC2S1E/BJ, VPCEC2S1R/BJ, VPCEC3A4E, VPCEC3C5E, VPCEC3E9E/BJ, VPCEC3L1E/WI, VPCEC3M1E/BJ, VPCEC3M1R/WI, VPCEC3S0E/WI, VPCEC3S1E/BJ, VPCEC3S1R/BJ, VPCEC3Z1E/BJ, VPCEC4A4E, VPCEC4B4E, VPCEC4C5E, VPCEC4E9E/BJ, VPCEC4L1E/WI, VPCEC4M1E/BJ, VPCEC4M1R/WI, VPCEC4S0E/WI, VPCEC4S1E/BJ, VPCEC4S1R/BJ, VPCEE2E1E/WI, VPCEE2E1R/WI, VPCEE2M1E/WI, VPCEE2M1R/WI, VPCEE2S1E/BQ, VPCEE2S1E/WI, VPCEE2S1R/BQ, VPCEE3E0E/WI, VPCEE3E1E/WI, VPCEE3E1R/WI, VPCEE3J0E/BQ, VPCEE3J1E/WI, VPCEE3L0E/WI, VPCEE3M1E/BQ, VPCEE3M1E/WI, VPCEE3M1R/BQ, VPCEE3S1E/BQ, VPCEE3S1E/WI, VPCEE3Z0E/BQ, VPCEE4E1E/WI, VPCEE4E1R/BQ, VPCEE4E1R/WI, VPCEE4J1E/WI, VPCEE4M1E/BQ, VPCEE4M1R/BQ, VPCEF2E1E/WI, VPCEF2E1R/WI, VPCEF2S1E/BI, VPCEF2S1R/BI, VPCEF3E1E/WI, VPCEF3E1R/WI, VPCEF3S1E/BI, VPCEF3S1E/WI, VPCEF3S1R/BI, VPCEF4E1E/WI, VPCEF4E1R/WI, VPCEG1S1R/B, VPCEG1S1R/P, VPCEG1S1R/W, VPCEH1C5E, VPCEH1E1E/B, VPCEH1E1E/L, VPCEH1E1E/W, VPCEH1E1R/B, VPCEH1E1R/W, VPCEH1J1E/B, VPCEH1J1E/L, VPCEH1J1E/W, VPCEH1J8E/B, VPCEH1J8E/W, VPCEH1L0E/B, VPCEH1L0E/L, VPCEH1L0E/W, VPCEH1L1R/B, VPCEH1L1R/L, VPCEH1L1R/W, VPCEH1L8E/B, VPCEH1L8E/P, VPCEH1L8E/W, VPCEH1L9E/B, VPCEH1M0E/L, VPCEH1M1E/B, VPCEH1M1E/L, VPCEH1M1E/W, VPCEH1M1R/B, VPCEH1M1R/W, VPCEH1M8E/B, VPCEH1M8E/L, VPCEH1M8E/W, VPCEH1M9E/B, VPCEH1M9R/B, VPCEH1S0E/B, VPCEH1S0E/L, VPCEH1S0E/W, VPCEH1S1E/B, VPCEH1S1E/L, VPCEH1S1E/W, VPCEH1S1R/B, VPCEH1S1R/W, VPCEH1S8E/B, VPCEH1S8E/W, VPCEH1S9E/B, VPCEH1Z1E/B, VPCEH1Z1E/L, VPCEH1Z1R/B, VPCEH1Z8E/B, VPCEH1Z8E/L,

VPCEH2A9E, VPCEH2C0E/B, VPCEH2C0E/L, VPCEH2C0E/P, VPCEH2C0E/W,
VPCEH2C1E/B, VPCEH2C1E/W, VPCEH2C5E, VPCEH2D0E/B, VPCEH2D0E/W,
VPCEH2D1E/B, VPCEH2D1E/L, VPCEH2D1E/W, VPCEH2E0E/B, VPCEH2E0E/W,
VPCEH2E1R/B, VPCEH2E1R/W, VPCEH2F1E/B, VPCEH2F1E/W, VPCEH2H1E/B,
VPCEH2H1E/L, VPCEH2H1E/P, VPCEH2H1E/W, VPCEH2J1E/B, VPCEH2J1E/L,
VPCEH2J1E/W, VPCEH2J1R/B, VPCEH2J1R/L, VPCEH2J1R/W, VPCEH2J9R/B,
VPCEH2K1E/L, VPCEH2K1E/W, VPCEH2L1R/B, VPCEH2L1R/W, VPCEH2L9E/B,
VPCEH2M0E/L, VPCEH2M0E/W, VPCEH2M1E/B, VPCEH2M1E/L, VPCEH2M1E/W,
VPCEH2M1R/B, VPCEH2M1R/L, VPCEH2M1R/W, VPCEH2M9E/B, VPCEH2N1E/B,
VPCEH2N1E/L, VPCEH2N1E/P, VPCEH2N1E/W, VPCEH2P0E/B, VPCEH2P1E/B,
VPCEH2P1E/W, VPCEH2Q1E/B, VPCEH2Q1E/L, VPCEH2Q1E/W, VPCEH2S1E/B,
VPCEH2S1R/B, VPCEH2S9E/B, VPCEH2Z1E/B, VPCEH2Z1E/L, VPCEJ1C5E,
VPCEJ1E1E/B, VPCEJ1E1E/W, VPCEJ1E1R/W, VPCEJ1J1E/B, VPCEJ1J1E/W,
VPCEJ1L1E/B, VPCEJ1L1E/W, VPCEJ1L1R/W, VPCEJ1M1E/B, VPCEJ1M1E/W,
VPCEJ1M1R/B, VPCEJ1M9E/B, VPCEJ1S1E/B, VPCEJ1Z1E/B, VPCEJ1Z1E/W,
VPCEJ2A9E, VPCEJ2B1E/B, VPCEJ2B9E, VPCEJ2C5E, VPCEJ2D1E/B, VPCEJ2E1E/B,
VPCEJ2E1E/W, VPCEJ2J1E/B, VPCEJ2J1E/W, VPCEJ2L1E/B, VPCEJ2L1E/W,
VPCEJ2L1R/W, VPCEJ2M1E/B, VPCEJ2M1E/W, VPCEJ2M1R/W, VPCEJ2S1E/B,
VPCEJ2S1R/B, VPCEJ2S9E/B, VPCEJ2Z1E/B, VPCEL1E1E/B, VPCEL1E1E/W,
VPCEL1E1R/B, VPCEL1E1R/W, VPCEL2S1E/B, VPCEL2S1E/W, VPCEL2S1R/B,
VPCEL2S1R/W, VPCS11A7E, VPCS11B7E, VPCS11C5E, VPCS11D7E, VPCS11E7E,
VPCS11F7E, VPCS11G7E, VPCS11H7E, VPCS11J7E, VPCS11M1E/W, VPCS11M9R/B,
VPCS11V9E/B, VPCS11V9R/B, VPCS11X9E/B, VPCS11X9R/S, VPCS12A7E, VPCS12A7R,
VPCS12B7E, VPCS12C5E, VPCS12C7E, VPCS12D7E, VPCS12E7E, VPCS12F7E,
VPCS12J1E/W, VPCS12L9E/B, VPCS12M9E/B, VPCS12M9R/S, VPCS12V9E/B,
VPCS12V9R/B, VPCS12X9E/B, VPCS12X9R/B, VPCS13A7E, VPCS13B7E, VPCS13C5E,
VPCS13I7E, VPCS13L8E/B, VPCS13L9E/B, VPCS13M1E/W, VPCS13S8R/S,
VPCS13S9E/B, VPCS13S9R/S, VPCS13V9E/B, VPCS13X8E/B, VPCS13X9E/B,
VPCS13X9R/B, VPCS13Z9R/B, VPCSA1A7E, VPCSA1B7E, VPCSA2C5E, VPCSA2S9R/BI,
VPCSA2V9R/BI, VPCSA2Z9E/BI, VPCSA2Z9R/BI, VPCSA2Z9R/T, VPCSA3C5E,
VPCSA3J1E/XI, VPCSA3L9E/XI, VPCSA3M9E/XI, VPCSA3N9E/XI, VPCSA3Q9E/XI,
VPCSA3S9E/XI, VPCSA3S9R/XI, VPCSA3T9E/XI, VPCSA3V9E/XI, VPCSA3X9E/XI,
VPCSA3X9R/XI, VPCSA3Z9E/XI, VPCSA3Z9R/T, VPCSA3Z9R/XI, VPCSB1A7E,
VPCSB1A9E/B, VPCSB1A9R/B, VPCSB1B7E, VPCSB1B9E/B, VPCSB1C5E, VPCSB1C7E,
VPCSB1D7E, VPCSB1H7E, VPCSB1Q1E/S, VPCSB1S1E/S, VPCSB1S1E/W,
VPCSB1V9E/B, VPCSB1V9R/B, VPCSB1V9R/S, VPCSB1X9E/B, VPCSB1X9E/S,
VPCSB1Z9E/B, VPCSB1Z9R/B, VPCSB2A7E, VPCSB2A7R, VPCSB2B7E, VPCSB2C5E,
VPCSB2C7E, VPCSB2J9E/P, VPCSB2J9E/W, VPCSB2L1E/S, VPCSB2L1E/W,
VPCSB2L1R/L, VPCSB2L1R/P, VPCSB2L1R/W, VPCSB2M9E/B, VPCSB2M9E/S,
VPCSB2P9E/B, VPCSB2S9E/B, VPCSB2S9E/W, VPCSB2V9E/B, VPCSB2X9R/B,
VPCSB2X9R/S, VPCSB2Z9R/B, VPCSB3C5E, VPCSB3L9E/R, VPCSB3L9E/S,
VPCSB3L9E/W, VPCSB3M1R/L, VPCSB3M1R/P, VPCSB3M1R/R, VPCSB3M1R/W,
VPCSB3M9E/B, VPCSB3M9E/S, VPCSB3N9E/B, VPCSB3N9E/S, VPCSB3Q9E/P,
VPCSB3Q9E/S, VPCSB3Q9E/W, VPCSB3S9E/B, VPCSB3T9E/R, VPCSB3V9E/B,

VPCSB3V9R/B, VPCSB3V9R/S, VPCSB3X9E/B, VPCSB3Z9E/B, VPCSB3Z9R/B, VPCX11, VPCX11S1E/B, VPCX11S1R/B, VPCX11S1T/B, VPCX11X6E, VPCX11Z1E/X, VPCX11Z1R/X, VPCX11Z6E, VPCX11Z6R, VPCX13A7E, VPCX13C5E, VPCX13C7E, VPCX13D7E, VPCX13F7E, VPCX13G7E, VPCX13J7E, VPCX13K7E, VPCX13L7E, VPCYA1C5E, VPCYA1V9E/B, VPCYA1V9R/B, VPCYB1S1E/S, VPCYB1S1R/S, VPCYB2L1R/B, VPCYB2L1R/G, VPCYB2L1R/P, VPCYB2L1R/S, VPCYB2M1E/G, VPCYB2M1E/P, VPCYB2M1E/S, VPCYB3Q1R/B, VPCYB3Q1R/G, VPCYB3Q1R/P, VPCYB3Q1R/S, VPCYB3V1E/G, VPCYB3V1E/P, VPCYB3V1E/S, VPCZ11A7E, VPCZ11A7R, VPCZ11C5E, VPCZ11C7E, VPCZ11D7E, VPCZ11E7E, VPCZ11V9R/B, VPCZ11X9E/B, VPCZ11X9R/B, VPCZ11X9R/S, VPCZ11Z9E/B, VPCZ11Z9R/B, VPCZ12A7E, VPCZ12B7E, VPCZ12C5E, VPCZ12C7E, VPCZ12D7E, VPCZ12E7E, VPCZ12F7E, VPCZ12G7E, VPCZ12H7E, VPCZ12I7E, VPCZ12J7E, VPCZ12L9E/B, VPCZ12M9E/B, VPCZ12S9R/B, VPCZ12S9R/S, VPCZ12V9E/X, VPCZ12V9R/X, VPCZ12X9E/X, VPCZ12X9R/B, VPCZ12Z9E/X, VPCZ12Z9R/XQ, VPCZ13A7E, VPCZ13B7E, VPCZ13C5E, VPCZ13C7E, VPCZ13D7E, VPCZ13M9E/B, VPCZ13S9R/B, VPCZ13V9E/X, VPCZ13V9R/X, VPCZ13X9R/B, VPCZ13Z9E/X, VPCZ13Z9R/XQ, VPCZ21A9E/B, VPCZ21C5E, VPCZ21L9E/B, VPCZ21M9E/B, VPCZ21Q9E/B, VPCZ21S9E/B, VPCZ21V9E/B, VPCZ21V9R/X, VPCZ21X9E/B, VPCZ21X9R/B, VPCZ21X9R/N, VPCZ21Z9R/X,

Sony 19.5V3.9A 6.5mm*4.4mm 76W

Sony

Vaio series

PCG-735, PCG-737, PCG-745, PCG-747, PCG-F104K, PCG-F150, PCG-F160, PCG-F190, PCG-F212, PCG-F250, PCG-F270, PCG-F290, PCG-F304, PCG-F305, PCG-F309, PCG-F400, PCG-F403, PCG-F409/K, PCG-F701, PCG-F707, PCG-F709/K, PCG-F801A, PCG-F807K, PCG-F808K, PCG-F809K, PCG-FX101, PCG-FX103/K, PCG-FX105K, PCG-FX108K, PCG-FX109K, PCG-FX200, PCG-FX201, PCG-FX202, PCG-FX203/K, PCG-FX205K, PCG-FX209K, PCG-FX301, PCG-FX302K, PCG-FX401, PCG-FX403, PCG-FX404, PCG-FX405, PCG-FX501, PCG-FX502, PCG-FX503, PCG-FX505, PCG-FX601, PCG-FX602, PCG-FX604, PCG-FX605, PCG-FX701, PCG-FX702, PCG-FX705, PCG-FX801, PCG-FX802P, PCG-FX804, PCG-FX805, PCG-FX902P, PCG-FX905P, PCG-N505SN, PCG-N505X, PCG-NV105, PCG-NV109M, PCG-NV205, PCG-NV209, PCG-QR10, PCG-QR20, PCG-X18, PCG-X29, PCG-X9, PCG-Z600HEK, PCG-Z600LEK, PCG-Z600NE/K, PCG-Z600RE/K, PCG-Z600TEK, VGN-FE570G, VGN-FE590, VGN-FE590GC, VGN-FE590P03, VGN-FE590PA, VGN-FE590PB, VGN-FE600, VGN-FE650G, VGN-FE660G, VGN-FE670G, VGN-FE690, VGN-FE690GB, VGN-FE690PB, VGN-FE770G, VGN-FE790, VGN-FJ170P/B, VGN-FJ180P/G, VGN-FJ180P/L, VGN-FJ180P/R, VGN-FJ180P/W, VGN-FJ200, VGN-FJ2230F, VGN-FJ240FP, VGN-FJ250F, VGN-FJ250FP, VGN-FJ250FPB, VGN-FJ250FPB, VGN-FJ260FP, VGN-FJ270, VGN-FJ270B, VGN-FJ270P/B, VGN-FJ270P/BK1, VGN-FJ270Q, VGN-FJ290, VGN-FJ290FP, VGN-FJ290L1B, VGN-FJ290L1G, VGN-FJ290L1L, VGN-FJ290L1R, VGN-FJ290L1W, VGN-FJ290P, VGN-FJ290P1/G, VGN-FJ290P1/GK1, VGN-FJ290P1/L, VGN-FJ290P1/LK1, VGN-FJ290P1/R, VGN-FJ290P1/RK1, VGN-FJ290P1/W, VGN-FJ290P1/WK1,

VGN-FJ290P1V, VGN-FS520B, VGN-FS530B, VGN-FS540P, VGN-FS550, VGN-FS550F, VGN-FS550P, VGN-FS570, VGN-FS625B/W, VGN-FS630/W, VGN-FS635B/W, VGN-FS640/W, VGN-FS645P/H, VGN-FS660/W, VGN-FS675P/H, VGN-FS680/W, VGN-FS690, VGN-FS730/W, VGN-FS740/W, VGN-FS742/W, VGN-FS745P/H, VGN-FS750P/W, VGN-FS760/W, VGN-FS775P/H, VGN-FS780/W, VGN-FS790, VGN-FS7901, VGN-FS7902, VGN-FS840/W, VGN-FS875P/H, VGN-FS8900, VGN-FS8900M, VGN-FS8900P3, VGN-FS8900P4, VGN-FS8900P5, VGN-FS8900V, VGN-FS980, VGN-FS990, VGN-FZ100, VGN-FZ11, VGN-FZ11E, VGN-FZ11M, VGN-FZ11S, VGN-FZ11Z, VGN-FZ130E, VGN-FZ130E/B, VGN-FZ130EB, VGN-FZ140E, VGN-FZ140E/B, VGN-FZ140EB, VGN-FZ140N, VGN-FZ140N/B, VGN-FZ145E, VGN-FZ145E, VGN-FZ145E/B, VGN-FZ145N/B, VGN-FZ15, VGN-FZ150B/C, VGN-FZ150E, VGN-FZ150E/B, VGN-FZ150EBC, VGN-FZ150F/E, VGN-FZ15G, VGN-FZ15L, VGN-FZ15M, VGN-FZ15S, VGN-FZ15T, VGN-FZ160, VGN-FZ160E, VGN-FZ160E/B, VGN-FZ160EB, VGN-FZ17, VGN-FZ17G, VGN-FZ17L, VGN-FZ18, VGN-FZ180E, VGN-FZ180E/B, VGN-FZ180EB, VGN-FZ180U, VGN-FZ180UB, VGN-FZ18G, VGN-FZ18ME, VGN-FZ18S, VGN-FZ18T, VGN-FZ19, VGN-FZ190, VGN-FZ190E, VGN-FZ190EB, VGN-FZ190N, VGN-FZ190U, VGN-FZ19L, VGN-FZ19VN, VGN-FZ210CE, VGN-FZ21E, VGN-FZ21M, VGN-FZ21Z, VGN-FZ220, VGN-FZ220E, VGN-FZ220EB, VGN-FZ220U, VGN-FZ220UB, VGN-FZ230E, VGN-FZ230EB, VGN-FZ240, VGN-FZ240E, VGN-FZ240EB, VGN-FZ240N, VGN-FZ240NB, VGN-FZ25, VGN-FZ250, VGN-FZ250E, VGN-FZ260, VGN-FZ260E, VGN-FZ27, VGN-FZ28, VGN-FZ280E, VGN-FZ280EB, VGN-FZ283BN, VGN-FZ285U, VGN-FZ285UB, VGN-FZ288, VGN-FZ290, VGN-FZ290E, VGN-FZ290EGB, VGN-FZ290EGC, VGN-FZ290EGE, VGN-FZ290EGS, VGN-FZ290N, VGN-FZ290U, VGN-FZ29VN, VGN-FZ320EB, VGN-FZ340, VGN-FZ340E, VGN-FZ340N, VGN-FZ345E, VGN-FZ345EB, VGN-FZ348E, VGN-FZ348EB, VGN-FZ380, VGN-FZ390, VGN-FZ390EBB, VGN-FZ400, VGN-FZ410E, VGN-FZ410EB, VGN-FZ420E, VGN-FZ430E, VGN-FZ430EB, VGN-FZ440E, VGN-FZ440N, VGN-FZ445E, VGN-FZ445EB, VGN-FZ455E, VGN-FZ455EB, VGN-FZ460E, VGN-FZ460EB, VGN-FZ470, VGN-FZ470E, VGN-FZ470EB, VGN-FZ480, VGN-FZ480E, VGN-FZ480EB, VGN-FZ485U, VGN-FZ485UB, VGN-FZ490, VGN-FZ490EAB, VGN-FZ50B, VGN-FZ70B, VGN-FZ90HS, VGN-FZ90NS, VGN-FZ90S, VGN-S380, VGN-S380B, VGN-S380B PROFESSIONAL, VGN-S380P, VGN-S430P/S, VGN-S460/B, VGN-S460P/B, VGN-S470P/S, VGN-S480, VGN-S550P/S, VGN-S560P/B, VGN-S570P/S, VGN-S580,

Sony 19.5V2.15A 6.5mm*4.4mm 42W

Sony

Vaio series

PCG-700, PCG-701, PCG-705, PCG-705C, PCG-707, PCG-707C, PCG-709, PCG-711, PCG-717, PCG-717C, PCG-719, PCG-719C, PCG-721C, PCG-729, PCG-729C, PCG-731, PCG-735, PCG-737, PCG-745, PCG-747, PCG-748, PCG-800, PCG-808, PCG-812, PCG-818, PCG-838, PCG-F104K, PCG-F150, PCG-F160, PCG-F180, PCG-F190, PCG-F200, PCG-F212, PCG-F250, PCG-F270, PCG-F280, PCG-F290, PCG-F304, PCG-F305, PCG-F309, PCG-F340, PCG-F350, PCG-F360, PCG-F370, PCG-F390, PCG-F400, PCG-F403, PCG-F405, PCG-F409, PCG-F420, PCG-F430, PCG-F450, PCG-F480,

PCG-F480K, PCG-F490, PCG-F490K, PCG-F520, PCG-F540, PCG-F540K, PCG-F560, PCG-F560K, PCG-F570, PCG-F580, PCG-F580K, PCG-F590, PCG-F590K, PCG-F610, PCG-F630, PCG-F640, PCG-F650, PCG-F650K, PCG-F670T, PCG-F676, PCG-F680, PCG-F680K, PCG-F690, PCG-F690K, PCG-F701, PCG-F707, PCG-F709, PCG-F709K, PCG-F737, PCG-F801, PCG-F801A, PCG-F807, PCG-F807K, PCG-F808K, PCG-F809K, PCG-FX101, PCG-FX103, PCG-FX103/K, PCG-FX105K, PCG-FX108K, PCG-FX109K, PCG-FX120, PCG-FX120K, PCG-FX140, PCG-FX140K, PCG-FX150, PCG-FX150K, PCG-FX170, PCG-FX170K, PCG-FX180, PCG-FX180K, PCG-FX190, PCG-FX190K, PCG-FX200, PCG-FX200K, PCG-FX201, PCG-FX202, PCG-FX203, PCG-FX203/K, PCG-FX203K, PCG-FX205, PCG-FX205K, PCG-FX209, PCG-FX209K, PCG-FX210, PCG-FX215, PCG-FX220, PCG-FX220K, PCG-FX240, PCG-FX240K, PCG-FX250, PCG-FX250K, PCG-FX270, PCG-FX270K, PCG-FX290, PCG-FX290K, PCG-FX300, PCG-FX300K, PCG-FX300P, PCG-FX301, PCG-FX302K, PCG-FX304, PCG-FX310, PCG-FX310K, PCG-FX310P, PCG-FX340, PCG-FX340K, PCG-FX340P, PCG-FX370, PCG-FX370K, PCG-FX370P, PCG-FX390, PCG-FX390K, PCG-FX390P, PCG-FX401, PCG-FX403, PCG-FX404, PCG-FX405, PCG-FX410, PCG-FX430K, PCG-FX501, PCG-FX502, PCG-FX503, PCG-FX505, PCG-FX601, PCG-FX602, PCG-FX604, PCG-FX605, PCG-FX701, PCG-FX702, PCG-FX705, PCG-FX770, PCG-FX770K, PCG-FX776, PCG-FX800, PCG-FX801, PCG-FX802, PCG-FX802P, PCG-FX804, PCG-FX805, PCG-FX876, PCG-FX880, PCG-FX880K, PCG-FX900, PCG-FX902P, PCG-FX905P, PCG-FX950, PCG-R505, PCG-R505BF, PCG-R505CT, PCG-R505CTS, PCG-R505D, PCG-R505DCP, PCG-R505DF, PCG-R505DFK, PCG-R505DFP, PCG-R505DL, PCG-R505DLK, PCG-R505DLP, PCG-R505DS, PCG-R505DSK, PCG-R505DSP, PCG-R505DT, PCG-R505DX, PCG-R505E, PCG-R505EC, PCG-R505ECK, PCG-R505ECP, PCG-R505EL, PCG-R505ELK, PCG-R505ELP, PCG-R505ES, PCG-R505ESK, PCG-R505ESP, PCG-R505EX, PCG-R505G, PCG-R505GC, PCG-R505GCK, PCG-R505GCP, PCG-R505GK, PCG-R505GL, PCG-R505GLK, PCG-R505GLP, PCG-R505JE, PCG-R505JEK, PCG-R505JEP, PCG-R505JL, PCG-R505JLC, PCG-R505JLK, PCG-R505JLP, PCG-R505JS, PCG-R505JSK, PCG-R505JSP, PCG-R505MF, PCG-R505R, PCG-R505RJL, PCG-R505S, PCG-R505TE, PCG-R505TEK, PCG-R505TF, PCG-R505TL, PCG-R505TLK, PCG-R505TS, PCG-R505TSK, PCG-XG18, PCG-XG19, PCG-XG28, PCG-XG28K, PCG-XG29, PCG-XG29K, PCG-XG38, PCG-XG38K, PCG-XG39, PCG-XG39K, PCG-XG500, PCG-XG500K, PCG-XG700, PCG-XG700K, PCG-XG9, PCG-Z505, PCG-Z505FA, PCG-Z505GA, PCG-Z505GAH, PCG-Z505GAM, PCG-Z505HE, PCG-Z505HS, PCG-Z505HSK, PCG-Z505JE, PCG-Z505JEK, PCG-Z505JS, PCG-Z505JSK, PCG-Z505LE, PCG-Z505LEK, PCG-Z505LS, PCG-Z505LSK, PCG-Z505R, PCG-Z505RX, PCG-Z505RXS, PCG-Z505S, PCG-Z505SX, VPC-M12M1E, VPC-M13M1E, VPC-Y21S1E, VPC-Y22X5E, VPCM11M1E/B, VPCM11M1E/W, VPCM12M1E, VPCM12M1E/L, VPCM12M1E/P, VPCM12M1E/W, VPCM12M1R/L, VPCM12M1R/P, VPCM12M1R/W, VPCM13M1E, VPCM13M1E/L, VPCM13M1E/P, VPCM13M1E/W, VPCM13M1R/L, VPCM13M1R/P, VPCM13M1R/W, VPCW11S1E/P, VPCW11S1E/T, VPCW11S1E/W, VPCW11S1R/P, VPCW11S1R/T, VPCW11S1R/W, VPCW12J1E/P, VPCW12J1E/T, VPCW12J1E/W, VPCW12M1E/P, VPCW12M1E/T, VPCW12M1E/W, VPCW12S1E/P, VPCW12S1E/T, VPCW12S1E/W, VPCW12S1E/WZ, VPCW12S1R/P, VPCW12S1R/T, VPCW12S1R/W,

VPCW12Z1R/P, VPCW12Z1R/T, VPCW12Z1R/W, VPCW12Z1R/WZ, VPCW12Z1T/T,
VPCW21A7E, VPCW21B7E, VPCW21C5E, VPCW21C7E, VPCW21M1E/P, VPCW21M1E/T,
VPCW21M1E/W, VPCW21M2E/WI, VPCW21S1E/P, VPCW21S1E/T, VPCW21S1E/W,
VPCW21S1R/L, VPCW21S1R/P, VPCW21S1R/T, VPCW21S1R/W, VPCW21Z1E/L,
VPCW21Z1E/W, VPCW21Z1R/L, VPCW21Z1R/T, VPCW22M1E/L, VPCW22M1E/W,
VPCW22Z1R/L, VPCW22Z1R/T, VPCY11M1E/S, VPCY11M1R/S, VPCY11S1E/S,
VPCY11V9E/S, VPCY21A7E, VPCY21B7E, VPCY21C5E, VPCY21M1R/G, VPCY21M1R/L,
VPCY21M1R/P, VPCY21M1R/SI, VPCY21M1R/V, VPCY21S1E, VPCY21S1E/G,
VPCY21S1E/L, VPCY21S1E/P, VPCY21S1E/SI, VPCY21V9E/B, VPCY22C5E, VPCY22X5E

END H11

H12

Lenovo/IBM 20V4.5A YOGA USB 90W

Lenovo

Z51-70,

IdeaPad series

700-15ISK, Y40, Y40-70, Y40-80, Y50, Y50 TOUCH, Y50-70, Y50-70 TOUCH, Y50-80, Y50-80 TOUCH, Z510, Z710,

Thinkpad series

HELIX, L440, L540, S440, S5, S531, S540, T440, T440P, T440S, T540P, X1 CARBON, X240, YOGA,

ThinkPad Edge series

E431, E440, E531, E540,

Lenovo/IBM 20V3.25A YOGA USB 65W

Lenovo

A3200, A3200-B101, A3200-B102, A3200-B103, B4400S, B5400, FLEX2, G50-80, G70-70, G70-80, YOGA2 PRO, Z51-70,

IdeaPad series

G400, G400S, G405S, G500, G500S, G505, G505S, G510, G700, M5400, S500, U330, U330 TOUCH, U330P, U430, U430P, U530, U530 TOUCH, Z710,

IdeaPad Yoga series

13,

Thinkpad series

E431, E531, HELIX, L540, S3, S431, S440, S531, S540, T431S, T440, T440S, X1, X1 CARBON, X240,

ThinkPad Edge series

E431, E440, E531, E540,

Lenovo/IBM 20V2.25A YOGA USB 45W

Lenovo

B40, B40-30, B40-45, B40-70, B50, B50-30, B50-70, G50-30, G70-80, N20 CHROMEBOOK, N20P CHROMEBOOK, N40, N50, S20 TOUCH,

IdeaPad series

G40, G40-30, G40-45, G40-70, G40-70M, G50, G50-30, G50-45, G50-70, G50-70M, S210, S215, S410P, S510P, Z40, Z50,

IdeaPad Flex series

14, 14M, 15, 15M, 2,

IdeaPad Yoga series

11, 11.6, 11S, 2, 2 PRO,

Thinkpad series

11E, 11E CHROMEBOOK, HELIX, S431, T431S, X240S, YOGA 11E, YOGA 11E CHROMEBOOK,

Yoga series

500-14IBD

END H12

H13

Lenovo/IBM 20V4.5A 7.9mm*5.5mm

IBM

ThinkPad Series

ADVANCED MINI DOCK T, ESSENTIAL PORT REPLICATOR, EXTERNAL BATTERY CHARGER, R60, T60, X60, Z60, Z60M, Z60T, Z61E, Z61M, Z61P,

Lenovo

3000 series

3000, C100, N100, N200, V100,

Thinkpad series

R400, R500, SL300, SL400, SL410, SL410K, SL500, SL510, T400 14" WIDE, T430, T430S, T430U, T500, T510, T510I, T520, T530, W500, W510, X140E,

ThinkPad Edge series

E545,

Lenovo/IBM 20V3.25A 7.9mm*5.5mm

IBM

ThinkPad series

R60, R60, R61, T60, T60P, T61, X60, X60 TABLET, X60S, X61, X61 TABLET, X61S, Z60M, Z61E, Z61M,

Lenovo

3000 Series

C100, C200, ESSENTIAL PORT REPLICATOR, N100, N200, V100, V200,

Thinkpad series

L410, L412,L420, L421,L510, L510, L510, L510, L520, R400, R500, R61, R61E, R61I (14.1 "I 15.4"), SL300, SL410, SL410 "WIDE, T410S, T410SI, T410S, T410SI, T420S, T410SI, T420S, T510, T510, T510I, T520, T61, T61P, X1, X100E, X121E, X200, X201, , X201S, X201T, X220, X220 TABLET, X220T TABLET, X230, X300, X301, X60 TABLET, X61 TABLET,

ThinkPad Edge series

11, 11 ", 12.5", 13, 13 ", 14, 14", 15, 15 ", 15.6", E10, E120, E220S, E30, E420, E420, E525

END H13

H13D

Dell 19.5V 4.62A 7.4mm*5.0mm 90W

Alienware Series

M11X,

Inspiron Series

1100, 1120, 1150, 11Z (1110), 1200, 13 (1318), 1300, 1318, 13R (N3010), 13Z (5323), 14 (1440), 14 (3421), 14 (3437), 1410, 1420, 1425, 1464, 14R, 14R (5420), 14R (5421), 14R (5437), 14R (N4010), 14R (N4110), 14Z (1470), 14Z (5423), 14Z (N411Z), 15, 15 (1525), 15 (1526), 15 (1545), 15 (1564), 15 (3520), 15 (3521), 15 (3537), 15 (7537), 1501, 1520, 1521, 1525, 1526, 1545, 1546, 1564, 15R, 15R (5520), 15R (5521), 15R (5537), 15R (7520), 15R (N5010), 15R (N5110), 15Z (1570), 15Z (5523), 17, 17 (1750), 17 (1764), 17 (3721), 17 (3737), 17 (7737), 1720, 1721, 17R, 17R (5720), 17R (5721), 17R (5737), 17R (7720), 17R (N7010), 17R (N7110), 2200, 2650, 300M, 400M, 4100, 500M, 505M, 5100, 510M, 6000, 6000D, 600M, 610M, 630M, 6400, 640M, 700M, 710M, 8200, 8500, 8600, 8600C, 9200, 9300, 9400, B120, B130, E1405, E1501, E1505, E1705, M101Z, M301Z, M4110, M5010, M501R, M5030, M5110, N4020, N4030, N5030, N5040, N5050,

Inspiron Mini Series

10 (1010), 10 (1012), 10 (1018), 10V (1011), 12 (1210), 9 (910),

Latitude Series

10 (ST2), 10 (ST2E), 110L, 12 (7204), 120L, 13, 131L, 14 (7404), 2100, 2110, 2120, 3330, 3340, 3440, 3450, 3540, 3550, 6430U, ATG, D400, D410, D420, D430, D500, D505, D510, D520, D530, D531, D600, D610, D620, D630, D630 XFR, D631, D800, D810, D820, D830, E4200, E4300, E4310, E5250, E5400, E5410, E5420, E5420M, E5430, E5440, E5450, E5500, E5510, E5520, E5520M, E5530, E5540, E5550, E6220, E6230, E6320, E6330, E6400, E6400 ATG, E6400 XFR, E6410, E6410 ATG, E6420, E6420 ATG, E6420 XFR, E6430, E6430 ATG, E6430S, E6440, E6500, E6510, E6520, E6530, E6540, E7240, E7440, E7440 XT, L13, ST, X1, X300, XT, XT2, XT2 XFR, XT3, Z, Z600,

Precision Series

M20, M2300, M2400, M4300, M4400, M4500, M4600, M4700, M50, M60, M6300, M6400, M65, M6500, M6600, M6700, M70, M90,

Studio Series

13, 13 (M1340), 1435, 1436, 1440, 1450, 1457, 1458, 14Z, 15, 15 (1537), 1535, 1536, 1537, 1555, 1557, 1558, 1569, 16, 16 (1640), 16 (1645), 16 (1647), 17, 1735, 1737, 1745, 1747, 1749, XPS 13, XPS 1340, XPS 16, XPS 1640, XPS 1645,

Vostro Series

1000, 1014, 1015, 1088, 1200, 1220, 1310, 1320, 1400, 1440, 1500, 1510, 1520, 1540, 1700, 1710, 1720, 2420, 2510, 2520, 3300, 3350, 3360, 3400, 3450, 3460, 3500, 3550, 3555, 3560,

3700, 3750, 500, A840, A860, A90, V13, V130, V131,

XPS Series

10, 12, 13, 14 (L401X), 14 (L412Z), 14 (L421X), 15 (L501X), 15 (L502X), 15 (L521X), 15Z, 17 (L701X), 17 (L702X), GEN 2, M1210, M1330, M1350, M140, M1530, M170, M1710, M1730, M2010,

Dell 19.5V 3.34A 7.4mm*5.0mm 65W

Dell

Chromebook series

11, 3120,

Inspiron series

11 (3135), 11 (3137), 11 (3138), 1120, 13 (7348), 1318, 13R, 13Z (5323), 14 (3421), 14 (3437), 14 (5458), 1420, 1464, 14R, 14R (5421), 14R (5437), 14Z (5423), 15, 15 (3520), 15 (3521), 15 (3537), 15 (7537), 1501, 1520, 1521, 1525, 1526, 1545, 1564, 15R, 15R (5520), 15R (5521), 15R (5537), 15R (7520), 15Z (1570), 15Z (5523), 17 (3721), 17 (3737), 17 (7548), 17 (7737), 17 (7746), 17R (5720), 17R (5721), 17R (5737), 300M, 400M, 500M, 505M, 510M, 5755, 5758, 5R (7520), 6000, 6000D, 600M, 610M, 630M, 6400, 640M, 700M, 710M, 7558, E1405, E1501, E1505, E1705, M301Z, M5010,

Latitude series

12 (7204), 13, 131L, 14 (7404), 2120, 3150, 3160, 3330, 3340, 3440, 3450, 3540, 3550, 6430U, ATG, D400, D410, D420, D430, D500, D505, D510, D520, D530, D531, D600, D610, D620, D630, E5250, E5400, E5404, E5420, E5420M, E5430, E5440, E5450, E5520, E5520M, E5530, E5540, E5550, E6220, E6230, E6320, E6330, E6430, E6430 ATG, E6430S, E6440, E6530, E6540, E7240, E7440, ST, X300, XT, XT2, XT3, Z600,

Precision series

M6400, M65,

Studio series

1450, 14Z, XPS 13, XPS 1645,

Vostro series

1000, 1014, 1015, 1088, 1200, 1220, 1310, 1320, 1510, 1520, 1710, 2420, 2520, 3300, 3350, 3360, 3400, 3450, 3460, 3500, 3550, 3560, 500, A840, A860, V130,

XPS series

14 (L421X), M1210, M1330, M1350,

Dell 19.5V 2.31A 7.4mm*5.0mm 45W

Dell

Inspiron series

13 (7348), 14 (5458), 17 (7548), 17 (7746), 5755, 5758, 7558,

Latitude series

7350, E4200, XT, XT2, Z600

END H13D

H14

19V 4.74A HP 7.4mm*5.0mm 90W

Compaq

Presario series

320, 321, 325, 326, 420, 421, 621, CQ32, CQ35, CQ40, CQ41, CQ42, CQ45, CQ50, CQ50Z, CQ60, CQ61, CQ62, CQ70, CQ71, CQ72,

HP

Business Notebook series

2210B, 2510P, 2710P, 6510B, 6515B, 6520S, 6530B, 6530S, 6531S, 6535B, 6535S, 6710B, 6710S, 6715B, 6715S, 6730B, 6730S, 6735B, 6735S, 6830S, 6910P, 8510P, 8510W, 8710P, 8710W, NC2400, NC4400, NC6220, NC6230, NC6320, NC6400, NC8430, NW8440, NW9440, NX6310, NX6315, NX6320, NX6325, NX7300, NX7400, NX9420,

EliteBook series

2530P, 2730P, 6930P, 8440P, 8440W, 8460P, 8460W, 8530P, 8530W, 8540P, 8540W, 8730P,

Envy series

13, 14, 14-1000XX, 14-1001TX, 14-1010NR, 14-1011NR, 14-1110NR, 14-1111NR, 14-1150CA, 14-1154CA, 14-1155CA, 14-1160SE, 14-1163SE, 14-1210NR, 14-1211NR, 14-1260SE, 14-2001XX, 14-2020NR, 14-2050SE, 14-2054SE, 14-2070NR, 14-2090CA, 14-2130NR, 14-2160CA, 14-2160SE, 14-2161SE, 14T-1000, 14T-1100, 14T-1200, 14T-2000, 15, 17,

HDX series

X16-1001XX, X16-1004TX, X16-1006TX, X16-1008TX, X16-1009TX, X16-1011TX, X16-1012TX, X16-1013TX, X16-1014TX, X16-1015TX, X16-1025NR, X16-1040US, X16-1044NR, X16-1056CA, X16-1140US, X16-1145DX, X16-1155CA, X16-1160US, X16-1201TX, X16-1202TX, X16-1203TX, X16-1301TX, X16-1370US, X16-1375DX, X16T-1000, X16T-1100, X16T-1200,

Pavilion series

DM1, DM1-1004TU, DM1-1005TU, DM1-1006TU, DM1-1010EO, DM1-1020ED, DM1-1020SA, DM1-1022TU, DM1-1023TU, DM1-1025TU, DM1-1029TU, DM1-1030SA, DM1-1031TU, DM1-1117TU, DM1-1118TU, DM1-1121TU, DM1-1122TU, DM1-1126TU, DM1-1128TU, DM1-1130TU, DM1-1190EE, DM1-2001AU, DM1-2001XX, DM1-2002AU, DM1-2002NR, DM1-2004AU, DM1-2005AU, DM1-2010NR, DM1-2011NR, DM1-2140CA, DM1-3005XX, DM1-3010NR, DM1-3011NR, DM1-3020US, DM1-3023NR, DM1-3025DX, DM1-3040CA, DM1-3210US, DM1-3214NR, DM1-3240CA, DM1-3245CA, DM1-3248CA, DM1-4001XX, DM1-4010US, DM1-4013NR, DM1-4018CA, DM1-4050US, DM1-4051XX, DM1-4054NR, DM1-4170US, DM1Z-2000, DM1Z-2100, DM1Z-3000, DM1Z-3200, DM1Z-4000, DM1Z-4100, DM3, DM3-1001AU, DM3-1001TU, DM3-1002AX, DM3-1004XX, DM3-1006AX, DM3-1007AU, DM3-1007AX, DM3-1007TU, DM3-1008AX, DM3-1008TU, DM3-1009AX, DM3-1009TU,

DM3-1011TX, DM3-1012TX, DM3-1013AX, DM3-1016TU, DM3-1017TX, DM3-1018TX,
DM3-1019TX, DM3-1020AX, DM3-1022AX, DM3-1026TX, DM3-1030US, DM3-1034TX,
DM3-1035DX, DM3-1039WM, DM3-1040US, DM3-1044NR, DM3-1047CL, DM3-1047NR,
DM3-1053XX, DM3-1058NR, DM3-1103AU, DM3-1105AU, DM3-1105AX, DM3-1107AU,
DM3-1107AX, DM3-1108AX, DM3-1108TU, DM3-1109AX, DM3-1110TX, DM3-1112AX,
DM3-1113TX, DM3-1114AX, DM3-1115AX, DM3-1116TX, DM3-1121AX, DM3-1124CA,
DM3-1124TX, DM3-1125TX, DM3-1126AX, DM3-1126TX, DM3-1130US, DM3-1131NR,
DM3-1140US, DM3-1148LA, DM3-1150EE, DM3-1180EE, DM3-1190EE, DM3-2001AX,
DM3-2010US, DM3-3001XX, DM3-3004XX, DM3-3010CA, DM3-3010US, DM3-3011NR,
DM3-3012NR, DM3-3027CL, DM3-3110US, DM3-3112NR, DM3-3130CA, DM3T-1000,
DM3T-1100, DM3T-3000, DM3Z-1000, DM3Z-1100, DM3Z-2000, DM4, DM4-1001TU,
DM4-1001TX, DM4-1002TU, DM4-1003XX, DM4-1004TU, DM4-1004XX, DM4-1018TX,
DM4-1060US, DM4-1062NR, DM4-1063CL, DM4-1063HE, DM4-1065DX, DM4-1150CA,
DM4-1160US, DM4-1162US, DM4-1164NR, DM4-1165DX, DM4-1173CL, DM4-1201US,
DM4-1250CA, DM4-1253CL, DM4-1265DX, DM4-1273CA, DM4-1275CA, DM4-1277SB,
DM4-2015DX, DM4-2033CL, DM4-2050US, DM4-2053CA, DM4-2055CA, DM4-2058CA,
DM4-2070US, DM4-2074NR, DM4-2153CA, DM4-2165DX, DM4-2180CA, DM4-2180US,
DM4-2181NR, DM4-2184NR, DM4-2185CA, DM4-2191US, DM4-3007XX, DM4-3050US,
DM4-3055DX, DM4-3090SE, DM4T-1000, DM4T-1100, DM4T-1200, DM4T-2000,
DM4T-2100, DM4T-3000, DV2, DV2-1001XX, DV2-1003AU, DV2-1005AU, DV2-1007AU,
DV2-1008AU, DV2-1011AX, DV2-1013AX, DV2-1014AX, DV2-1015AX, DV2-1016AX,
DV2-1017AX, DV2-1018AX, DV2-1019AX, DV2-1020AX, DV2-1021AX, DV2-1024AX,
DV2-1025AX, DV2-1026AX, DV2-1027AX, DV2-1028AX, DV2-1029AX, DV2-1030AX,
DV2-1030US, DV2-1031AX, DV2-1033CL, DV2-1039WM, DV2-1110US, DV2-1118AX,
DV2-1118NR, DV2-1119AX, DV2-1120AX, DV2-1121AX, DV2-1126AX, DV2-1134NR,
DV2-1156XX, DV2-1199US, DV2-1201AU, DV2-1201AX, DV2-1202AU, DV2-1203AU,
DV2-1206AU, DV2-1208AU, DV2-1209AU, DV2-1209AX, DV2-1210AX, DV2-1215AX,
DV2Z-1100, DV3-1051XX, DV3-1052XX, DV3-1073CL, DV3-1075CA, DV3-1075US,
DV3-1077CA, DV3-1253NR, DV3-2001TU, DV3-2001XX, DV3-2017TX, DV3-2023TX,
DV3-2025TX, DV3-2028TX, DV3-2029TX, DV3-2035TX, DV3-2123TX, DV3-2150TX,
DV3-2150US, DV3-2155MX, DV3-2157CL, DV3-2202TU, DV3-2203TU, DV3-2204TU,
DV3-2209TX, DV3-2214TX, DV3-2216TX, DV3-2217TX, DV3-2219TX, DV3-2220EF,
DV3-2228TX, DV3-2230TX, DV3-2231TX, DV3-2234TX, DV3-2237TX, DV3-2238TX,
DV3-2239TX, DV3-2242TX, DV3-2244TX, DV3-2250EW, DV3-2302TU, DV3-2302TX,
DV3-2303TU, DV3-2307TX, DV3-2309TX, DV3-2310TX, DV3-2312TX, DV3-2313TX,
DV3-2314TX, DV3-2315TX, DV3-2316TX, DV3-2320TX, DV3-2328TX, DV3-2331TX,
DV3-2350EE, DV3-2355EE, DV3-4001TX, DV3-4007TX, DV3-4010TX, DV3-4019TX,
DV3-4020TX, DV3000, DV3001TX, DV3002TX, DV3003TX, DV3004TX, DV3005TX,
DV3005XX, DV3006TX, DV3006XX, DV3007TX, DV3007XX, DV3008TX, DV3009TX,
DV3010TX, DV3011TX, DV3012TX, DV3013TX, DV3014TX, DV3015TX, DV3016TX,
DV3017TX, DV3018TX, DV3019TX, DV3020TX, DV3021TX, DV3022TX, DV3023TX,
DV3024TX, DV3025TX, DV3026TX, DV3027TX, DV3028TX, DV3029TX, DV3030TX,
DV3100, DV3101TX, DV3102TX, DV3103TX, DV3104TX, DV3105TX, DV3106TX,
DV3107TX, DV3108TX, DV3109TX, DV3110TX, DV3111TX, DV3112TX, DV3113TX,

DV3114TX, DV3115TX, DV3116TX, DV3117TX, DV3118TX, DV3119TX, DV3120TX, DV3500, DV3500EA, DV3500EN, DV3500ER, DV3500T, DV3501TX, DV3502TX, DV3503TX, DV3504TX, DV3505EA, DV3505XX, DV3506LA, DV3506TX, DV3507EA, DV3507TX, DV3508BR, DV3508TX, DV3509TX, DV3510ER, DV3510NR, DV3510TX, DV3511TX, DV3512TX, DV3513TX, DV3514TX, DV3515EE, DV3515EF, DV3515EI, DV3515TX, DV3516TX, DV3517TX, DV3518TX, DV3519TX, DV3520ER, DV3520TX, DV3521TX, DV3522TX, DV3523TX, DV3524TX, DV3525EF, DV3525TX, DV3526TX, DV3527TX, DV3528TX, DV3529TX, DV3530ES, DV3530ET, DV3530TX, DV3531TX, DV3532TX, DV3533TX, DV3534TX, DV3535TX, DV3536TX, DV3537TX, DV3538TX, DV3539TX, DV3540ES, DV3540TX, DV3541TX, DV3542TX, DV3543TX, DV3544TX, DV3545EI, DV3545TX, DV3550EE, DV3550EG, DV3550EL, DV3550EO, DV3550EP, DV3550ES, DV3550EZ, DV3560EP, DV3560EV, DV3570EI, DV3600, DV3600EC, DV3600EG, DV3600EO, DV3600T, DV3601TX, DV3602TX, DV3603TX, DV3604LA, DV3604TX, DV3605TX, DV3606TX, DV3607TX, DV3608TX, DV3609TX, DV3610EA, DV3610EO, DV3610T, DV3610TX, DV3611TX, DV3612TX, DV3613TX, DV3614TX, DV3615TX, DV3616TX, DV3617TX, DV3618TX, DV3619TX, DV3620EF, DV3620TX, DV3621TX, DV3622TX, DV3623TX, DV3624TX, DV3625EE, DV3625EI, DV3625TX, DV3626TX, DV3627TX, DV3628TX, DV3629EB, DV3629TX, DV3630TX, DV3631TX, DV3632TX, DV3633TX, DV3634TX, DV3635TX, DV3636TX, DV3637TX, DV3640EW, DV3650EF, DV3650EG, DV3650EI, DV3650EK, DV3650EL, DV3650EP, DV3650EZ, DV3655EE, DV3660EI, DV3660EJ, DV3660EW, DV3680ES, DV3699EF, DV3700, DV3701TX, DV3702TX, DV3703TX, DV3704TX, DV3705TX, DV3706TX, DV3707TX, DV3800, DV3888NR, DV3T-2000, DV3Z-1000, DV4, DV4-1000, DV4-1001AX, DV4-1001XX, DV4-1002AX, DV4-1002XX, DV4-1004TU, DV4-1004TX, DV4-1005TX, DV4-1006TX, DV4-1007TX, DV4-1008TX, DV4-1009TX, DV4-1010TX, DV4-1011TX, DV4-1012TX, DV4-1013TX, DV4-1014, DV4-1014N, DV4-1014NR, DV4-1014TX, DV4-1015, DV4-1016, DV4-1019TX, DV4-1020, DV4-1020TX, DV4-1020US, DV4-1022TX, DV4-1023TX, DV4-1024TX, DV4-1025TX, DV4-1026TX, DV4-1027TX, DV4-1028, DV4-1028TX, DV4-1028US, DV4-1029TX, DV4-1030, DV4-1030TX, DV4-1031TX, DV4-1032TX, DV4-1033TX, DV4-1034TX, DV4-1036TX, DV4-1040, DV4-1046TX, DV4-1047TX, DV4-1048TX, DV4-1049TX, DV4-1050, DV4-1051TX, DV4-1051XX, DV4-1052TX, DV4-1052XX, DV4-1053XX, DV4-1055TX, DV4-1070, DV4-1101XX, DV4-1102XX, DV4-1107TX, DV4-1108TX, DV4-1109TX, DV4-1110TX, DV4-1114NR, DV4-1116TX, DV4-1117CA, DV4-1117NR, DV4-1118CA, DV4-1118TX, DV4-1120, DV4-1120US, DV4-1121BR, DV4-1121CA, DV4-1123US, DV4-1124NR, DV4-1125, DV4-1125NR, DV4-1127TX, DV4-1129TX, DV4-1130TX, DV4-1132TX, DV4-1134TX, DV4-1139TX, DV4-1140GO, DV4-1140TX, DV4-1142TX, DV4-1143GO, DV4-1143TX, DV4-1144TX, DV4-1144US, DV4-1145, DV4-1145GO, DV4-1145TX, DV4-1146TX, DV4-1147CL, DV4-1147TX, DV4-1148TX, DV4-1149TX, DV4-1150TX, DV4-1153TX, DV4-1154TX, DV4-1155, DV4-1155SE, DV4-1155TX, DV4-1157TX, DV4-1159TX, DV4-1161TX, DV4-1163TX, DV4-1164TX, DV4-1165TX, DV4-1166CA, DV4-1166TX, DV4-1168TX, DV4-1169TX, DV4-1201AU, DV4-1201TX, DV4-1202AU, DV4-1202TX, DV4-1203AU, DV4-1203TX, DV4-1204AU, DV4-1204TX, DV4-1205TU, DV4-1206TU, DV4-1207TU, DV4-1208TU, DV4-1209TU, DV4-1210TU, DV4-1212TU, DV4-1212TX, DV4-1213TU, DV4-1213TX,

DV4-1214TU, DV4-1214TX, DV4-1215TU, DV4-1215TX, DV4-1216TX, DV4-1217TX,
DV4-1218TX, DV4-1219TX, DV4-1220TX, DV4-1220US, DV4-1221TX, DV4-1222NR,
DV4-1222TX, DV4-1223TX, DV4-1224TX, DV4-1225DX, DV4-1225TX, DV4-1226TX,
DV4-1227TX, DV4-1227US, DV4-1229TX, DV4-1230TX, DV4-1233TX, DV4-1234TX,
DV4-1235TX, DV4-1236TX, DV4-1237TX, DV4-1238TX, DV4-1239TX, DV4-1243TX,
DV4-1244TX, DV4-1245TX, DV4-1246TX, DV4-1247TX, DV4-1249TX, DV4-1250TX,
DV4-1251TX, DV4-1252TX, DV4-1253TX, DV4-1254TX, DV4-1256TX, DV4-1257TX,
DV4-1260TX, DV4-1261TX, DV4-1265DX, DV4-1272CM, DV4-1275MX, DV4-1280US,
DV4-1281US, DV4-1282CM, DV4-1283CL, DV4-1287CL, DV4-1292CM, DV4-1302TX,
DV4-1303TX, DV4-1304TU, DV4-1304TX, DV4-1305TU, DV4-1306TU, DV4-1307TU,
DV4-1308TU, DV4-1309TU, DV4-1310TU, DV4-1311TU, DV4-1312TU, DV4-1313DX,
DV4-1313TU, DV4-1314TU, DV4-1315TU, DV4-1316TU, DV4-1316TX, DV4-1317TU,
DV4-1317TX, DV4-1318TX, DV4-1319TX, DV4-1322TX, DV4-1322US, DV4-1323TX,
DV4-1324TX, DV4-1325TX, DV4-1327TX, DV4-1329TX, DV4-1330TX, DV4-1331TX,
DV4-1332TX, DV4-1365DX, DV4-1379NR, DV4-1404TX, DV4-1412TU, DV4-1413LA,
DV4-1415TU, DV4-1424LA, DV4-1427NR, DV4-1428DX, DV4-1428TX, DV4-1430US,
DV4-1431US, DV4-1432TX, DV4-1433SB, DV4-1433US, DV4-1434TX, DV4-1435DX,
DV4-1437TX, DV4-1438TX, DV4-1442TX, DV4-1443TX, DV4-1444DX, DV4-1502TU,
DV4-1506TX, DV4-1509TX, DV4-1511TX, DV4-1514DX, DV4-1520BR, DV4-1526TX,
DV4-1528TX, DV4-1530BR, DV4-1531TX, DV4-1540US, DV4-1541US, DV4-1543SB,
DV4-1547SB, DV4-1548DX, DV4-1548NR, DV4-1551DX, DV4-1555DX, DV4-1580BR,
DV4-1601TU, DV4-2012BR, DV4-2014BR, DV4-2016BR, DV4-2040US, DV4-2041NR,
DV4-2045DX, DV4-2046NR, DV4-2049US, DV4-2049WM, DV4-2051XX, DV4-2058NR,
DV4-2103TU, DV4-2103TX, DV4-2104TU, DV4-2105TU, DV4-2106TX, DV4-2107TX,
DV4-2108TX, DV4-2113LA, DV4-2114TX, DV4-2116TX, DV4-2118TX, DV4-2119TX,
DV4-2124TX, DV4-2125TX, DV4-2140US, DV4-2141NR, DV4-2142NR, DV4-2145DX,
DV4-2148CA, DV4-2153CL, DV4-2155DX, DV4-2160US, DV4-2161NR, DV4-2162NR,
DV4-2164US, DV4-2165DX, DV4-2167SB, DV4-2169NR, DV4-2170US, DV4-4001XX,
DV4-4004XX, DV4-4030US, DV4-4031HE, DV4-4032NR, DV4-4033NR, DV4-4038CA,
DV4-4048CA, DV4-4140US, DV4-4141US, DV4-4270US, DV4I-2100, DV4T, DV4T-1000,
DV4T-1100, DV4T-1200, DV4T-1200SE, DV4T-1300, DV4T-1300SE, DV4T-1400,
DV4T-1500, DV4T-1600, DV4T-4000, DV4T-4100, DV4T-4200, DV4Z-1000, DV4Z-1100,
DV4Z-1200, DV5, DV5-1000, DV5-1000T, DV5-1000US, DV5-1000Z, DV5-1001AU,
DV5-1001TU, DV5-1001TX, DV5-1001XX, DV5-1002, DV5-1002AX, DV5-1002NR,
DV5-1002TX, DV5-1002US, DV5-1002XX, DV5-1003CL, DV5-1003NR, DV5-1003XX,
DV5-1004NR, DV5-1004TU, DV5-1004TX, DV5-1004XX, DV5-1005TU, DV5-1006AX,
DV5-1006TU, DV5-1007, DV5-1007AX, DV5-1007CA, DV5-1007CL, DV5-1007TU,
DV5-1008AX, DV5-1008CA, DV5-1008TU, DV5-1008TX, DV5-1009TU, DV5-1010,
DV5-1010TU, DV5-1010US, DV5-1011, DV5-1011TX, DV5-1012TX, DV5-1013TX,
DV5-1014TX, DV5-1015NR, DV5-1017NR, DV5-1017TX, DV5-1018TX, DV5-1019, DV5-1020,
DV5-1022TX, DV5-1023TX, DV5-1024TX, DV5-1025TX, DV5-1026TX, DV5-1027TX,
DV5-1028CA, DV5-1028TX, DV5-1029TX, DV5-1030, DV5-1030TX, DV5-1031TX, DV5-1032,
DV5-1032TX, DV5-1033TX, DV5-1034CA, DV5-1034TX, DV5-1037TX, DV5-1038TX,
DV5-1039TX, DV5-1040EW, DV5-1040TX, DV5-1041TX, DV5-1042TX, DV5-1043TX,

DV5-1044CA, DV5-1044TX, DV5-1045TX, DV5-1046TX, DV5-1053TX, DV5-1054TX,
DV5-1055TX, DV5-1056TX, DV5-1057TX, DV5-1058TX, DV5-1059TX, DV5-1062TX,
DV5-1063TX, DV5-1064TX, DV5-1093XX, DV5-1094XX, DV5-1096XX, DV5-1098NR,
DV5-1098XX, DV5-1099NR, DV5-1099XX, DV5-1100, DV5-1100Z, DV5-1102AX,
DV5-1102TX, DV5-1103TU, DV5-1103TX, DV5-1104TX, DV5-1105AX, DV5-1105TU,
DV5-1105TX, DV5-1107AX, DV5-1109AX, DV5-1111CA, DV5-1112AX, DV5-1112CA,
DV5-1113, DV5-1113US, DV5-1114AX, DV5-1114TX, DV5-1115TX, DV5-1116, DV5-1116US,
DV5-1118CA, DV5-1119NR, DV5-1119TX, DV5-1120, DV5-1120US, DV5-1121CA,
DV5-1122TX, DV5-1123TX, DV5-1124TX, DV5-1125NR, DV5-1125TX, DV5-1126TX,
DV5-1127CL, DV5-1128CA, DV5-1130CA, DV5-1130TX, DV5-1132, DV5-1132US,
DV5-1133CA, DV5-1135CA, DV5-1135TX, DV5-1136TX, DV5-1137TX, DV5-1138CA,
DV5-1138NR, DV5-1140, DV5-1140US, DV5-1143TX, DV5-1150, DV5-1150US, DV5-1157CA,
DV5-1159SE, DV5-1160, DV5-1160US, DV5-1166, DV5-1166US, DV5-1174CA, DV5-1183CL,
DV5-1196XX, DV5-1197XX, DV5-1198XX, DV5-1199XX, DV5-1201AX, DV5-1201TU,
DV5-1201TX, DV5-1202AU, DV5-1202AX, DV5-1202TU, DV5-1202TX, DV5-1203AU,
DV5-1203TX, DV5-1204AX, DV5-1204TU, DV5-1205AU, DV5-1205AX, DV5-1205TU,
DV5-1206AU, DV5-1206AX, DV5-1206TU, DV5-1207AU, DV5-1207TU, DV5-1208AU,
DV5-1208TU, DV5-1209AX, DV5-1210AX, DV5-1211AX, DV5-1212AX, DV5-1213AX,
DV5-1214AX, DV5-1215AX, DV5-1215CA, DV5-1216AX, DV5-1216TX, DV5-1217TX,
DV5-1218AX, DV5-1220TX, DV5-1224TX, DV5-1225CA, DV5-1225TX, DV5-1227TX,
DV5-1228TX, DV5-1229TX, DV5-1230TX, DV5-1230US, DV5-1231TX, DV5-1233SE,
DV5-1234SE, DV5-1234TX, DV5-1235DX, DV5-1236TX, DV5-1237TX, DV5-1238TX,
DV5-1250US, DV5-1251NR, DV5-1253CL, DV5-1387NR, DV5-1388US, DV5-1392NR,
DV5-2003XX, DV5-2035DX, DV5-2043CL, DV5-2045DX, DV5-2051XX, DV5-2052XX,
DV5-2070US, DV5-2072NR, DV5-2073NR, DV5-2074DX, DV5-2075NR, DV5-2077CL,
DV5-2080BR, DV5-2129WM, DV5-2130US, DV5-2132DX, DV5-2134CA, DV5-2134US,
DV5-2135DX, DV5-2138CA, DV5-2144CA, DV5-2155DX, DV5-2230US, DV5-2231NR,
DV5-2238NR, DV5-2268CA, DV5105EU, DV5118EU, DV5T, DV5T-1000, DV5T-1100,
DV5T-1200SE, DV5T-2000, DV5T-2100, DV5T-2200, DV5TSE-1100, DV5Z, DV5Z-1000,
DV5Z-1100, DV5Z-1200, DV6, DV6-1001TX, DV6-1001XX, DV6-1004TX, DV6-1005TX,
DV6-1006TX, DV6-1007TX, DV6-1008TX, DV6-1010TX, DV6-1014TX, DV6-1015TX,
DV6-1027NR, DV6-1030CA, DV6-1030US, DV6-1038CA, DV6-1050US, DV6-1051XX,
DV6-1053CL, DV6-1054CL, DV6-1101AU, DV6-1102AU, DV6-1102TU, DV6-1103AU,
DV6-1103TU, DV6-1104AU, DV6-1104TU, DV6-1105AU, DV6-1105TU, DV6-1106AU,
DV6-1107AU, DV6-1107AX, DV6-1108AU, DV6-1108AX, DV6-1109AU, DV6-1109AX,
DV6-1110AU, DV6-1111AX, DV6-1112AX, DV6-1113TX, DV6-1114TX, DV6-1115TX,
DV6-1116TX, DV6-1117TX, DV6-1118TX, DV6-1119TX, DV6-1120TX, DV6-1122US,
DV6-1127TX, DV6-1131TX, DV6-1133TX, DV6-1149WM, DV6-1158TX, DV6-1201AU,
DV6-1202AU, DV6-1202TU, DV6-1203AU, DV6-1203AX, DV6-1203TU, DV6-1203TX,
DV6-1204TX, DV6-1206AU, DV6-1207AU, DV6-1207AX, DV6-1208AU, DV6-1221AX,
DV6-1221TX, DV6-1222AX, DV6-1230US, DV6-1234NR, DV6-1234TX, DV6-1238NR,
DV6-1240US, DV6-1241TX, DV6-1243CL, DV6-1244SB, DV6-1247CL, DV6-1250US,
DV6-1253CL, DV6-1255TX, DV6-1256TX, DV6-1259DX, DV6-1260SE, DV6-1261TX,
DV6-1263CL, DV6-1264TX, DV6-1265TX, DV6-1266TX, DV6-1268NR, DV6-1268TX,

DV6-1270LA, DV6-1280US, DV6-1299LX, DV6-1303TU, DV6-1306EW, DV6-1308EW,
DV6-1309TX, DV6-1310EQ, DV6-1310SL, DV6-1310TX, DV6-1314TX, DV6-1315TX,
DV6-1316TX, DV6-1318TX, DV6-1320EQ, DV6-1320SL, DV6-1320SP, DV6-1322TX,
DV6-1325TX, DV6-1330EA, DV6-1330EP, DV6-1330EQ, DV6-1330SP, DV6-1330TX,
DV6-1331TX, DV6-1334TX, DV6-1334US, DV6-1335TX, DV6-1340EA, DV6-1340SL,
DV6-1350SL, DV6-1350US, DV6-1351NR, DV6-1352DX, DV6-1353CL, DV6-1354US,
DV6-1355DX, DV6-1359WM, DV6-1360US, DV6-1361SB, DV6-1362NR, DV6-1363CL,
DV6-1375DX, DV6-1380EK, DV6-1441EE, DV6-1444EE, DV6-1446EE, DV6-1460EL,
DV6-2001XX, DV6-2005AU, DV6-2005SF, DV6-2005SP, DV6-2006AU, DV6-2006TX,
DV6-2007AU, DV6-2007AX, DV6-2010EA, DV6-2010EP, DV6-2010EQ, DV6-2010SL,
DV6-2012AX, DV6-2015SL, DV6-2018AX, DV6-2019AX, DV6-2020SL, DV6-2025SL,
DV6-2043US, DV6-2044DX, DV6-2051XX, DV6-2057CL, DV6-2066DX, DV6-2088DX,
DV6-2090EP, DV6-2101AU, DV6-2101TU, DV6-2109AX, DV6-2109TX, DV6-2110AX,
DV6-2110EL, DV6-2110SB, DV6-2111AX, DV6-2111TX, DV6-2112EL, DV6-2112TX,
DV6-2115SL, DV6-2116EL, DV6-2117AX, DV6-2118EL, DV6-2119EL, DV6-2120EB,
DV6-2120EE, DV6-2120SL, DV6-2123EL, DV6-2124EL, DV6-2125TX, DV6-2126EL,
DV6-2126TX, DV6-2127EL, DV6-2127TX, DV6-2128CA, DV6-2129EL, DV6-2129TX,
DV6-2130EL, DV6-2131EE, DV6-2131EL, DV6-2134EE, DV6-2134TX, DV6-2135EE,
DV6-2136EL, DV6-2137EL, DV6-2137SL, DV6-2138EE, DV6-2141SL, DV6-2142SL,
DV6-2143TX, DV6-2144NR, DV6-2144TX, DV6-2145EL, DV6-2150US, DV6-2151CL,
DV6-2151EE, DV6-2152NR, DV6-2154EE, DV6-2155DX, DV6-2155SE, DV6-2156TX,
DV6-2157EL, DV6-2157SB, DV6-2157TX, DV6-2157US, DV6-2157WM, DV6-2158EE,
DV6-2158NR, DV6-2158TX, DV6-2159EE, DV6-2159TX, DV6-2160EL, DV6-2162NR,
DV6-2162SL, DV6-2163SL, DV6-2163TX, DV6-2164CA, DV6-2164EE, DV6-2164SL,
DV6-2166SB, DV6-2168SL, DV6-2170SL, DV6-2170US, DV6-2171EE, DV6-2171NR,
DV6-2171SL, DV6-2173CL, DV6-2175TX, DV6-2176TX, DV6-2180US, DV6-2182NR,
DV6-2190EP, DV6-2190US, DV6-2192EL, DV6-3001AU, DV6-3001TX, DV6-3001XX,
DV6-3002AU, DV6-3002XX, DV6-3003TU, DV6-3003XX, DV6-3004AX, DV6-3004TX,
DV6-3006AX, DV6-3006TU, DV6-3007AX, DV6-3008TX, DV6-3010US, DV6-3012HE,
DV6-3013CL, DV6-3013NR, DV6-3015TX, DV6-3016TX, DV6-3017NR, DV6-3019WM,
DV6-3020US, DV6-3022US, DV6-3023NR, DV6-3023TX, DV6-3024TX, DV6-3025DX,
DV6-3030US, DV6-3031NR, DV6-3031TX, DV6-3032NR, DV6-3033CL, DV6-3033HE,
DV6-3033TX, DV6-3034NR, DV6-3034TX, DV6-3035TX, DV6-3036TX, DV6-3037NR,
DV6-3037SB, DV6-3037TX, DV6-3040TX, DV6-3040US, DV6-3041TX, DV6-3049TX,
DV6-3050US, DV6-3051XX, DV6-3053HE, DV6-3053TX, DV6-3055DX, DV6-3108CA,
DV6-3109CA, DV6-3114CA, DV6-3118CA, DV6-3120US, DV6-3121NR, DV6-3122US,
DV6-3123CL, DV6-3124NR, DV6-3127DX, DV6-3129NR, DV6-3130US, DV6-3131NR,
DV6-3132NR, DV6-3133NR, DV6-3134CA, DV6-3134NR, DV6-3138CA, DV6-3140US,
DV6-3143CA, DV6-3143CL, DV6-3143US, DV6-3144CA, DV6-3145DX, DV6-3147CA,
DV6-3147SB, DV6-3150US, DV6-3152NR, DV6-3153NR, DV6-3155DX, DV6-3158CA,
DV6-3160US, DV6-3163CL, DV6-3163NR, DV6-3167CA, DV6-3170CA, DV6-3174CA,
DV6-3181NR, DV6-3194CA, DV6-3210US, DV6-3212NR, DV6-3216US, DV6-3217CL,
DV6-3223CL, DV6-3225DX, DV6-3227CL, DV6-3230US, DV6-3231NR, DV6-3232NR,
DV6-3234NR, DV6-3236NR, DV6-3237NR, DV6-3238NR, DV6-3240CA, DV6-3240US,

DV6-3243CL, DV6-3250US, DV6-3257CL, DV6-3257SB, DV6-3259WM, DV6-3263CL,
DV6-3264CA, DV6-3267CL, DV6-3268CA, DV6-3270CA, DV6-3275CA, DV6-3278CA,
DV6-3280CA, DV6-3284CA, DV6-3286CA, DV6-3287CL, DV6-3370CA, DV6-3375CA,
DV6-4001XX, DV6-4051NR, DV6-4052NR, DV6-4053CA, DV6-6013CL, DV6-6020CA,
DV6-6033CL, DV6-6040CA, DV6-6047CL, DV6-6051XX, DV6-6070CA, DV6-6090US,
DV6-6091NR, DV6-6096NR, DV6-6097NR, DV6-6104CA, DV6-6104NR, DV6-6106NR,
DV6-6108US, DV6-6110US, DV6-6111NR, DV6-6112NR, DV6-6113CL, DV6-6115NR,
DV6-6116NR, DV6-6117DX, DV6-6118NR, DV6-6119WM, DV6-6120US, DV6-6121HE,
DV6-6123CL, DV6-6123NR, DV6-6124CA, DV6-6126NR, DV6-6127CL, DV6-6128CA,
DV6-6128NR, DV6-6130CA, DV6-6130US, DV6-6131US, DV6-6135CA, DV6-6135DX,
DV6-6136NR, DV6-6138NR, DV6-6140US, DV6-6144CA, DV6-6145CA, DV6-6145DX,
DV6-6148CA, DV6-6148NR, DV6-6149NR, DV6-6150US, DV6-6152NR, DV6-6153CA,
DV6-6153CL, DV6-6154NR, DV6-6155CA, DV6-6157NR, DV6-6158NR, DV6-6159US,
DV6-6161HE, DV6-6163CL, DV6-6167CL, DV6-6169US, DV6-6170US, DV6-6172NR,
DV6-6173CL, DV6-6175CA, DV6-6178CA, DV6-6180US, DV6-6181NR, DV6-6182NR,
DV6-6183NR, DV6-6184CA, DV6-6185NR, DV6-6186NR, DV6-6188CA, DV6-6190US,
DV6-6193CA, DV6-6195CA, DV6-6B19WM, DV6-6B21HE, DV6-6B22HE, DV6-6B27NR,
DV6-6B47DX, DV6-6B48NR, DV6-6B51NR, DV6-6B75CA, DV6-6B83CA, DV6-6C10US,
DV6-6C13CL, DV6-6C14NR, DV6-6C15NR, DV6-6C40CA, DV6-6C40US, DV6-6C43CL,
DV6-6C50CA, DV6-6C50US, DV6-6C53CL, DV6-6C53NR, DV6327CA, DV6327CL,
DV6T-1000, DV6T-1100, DV6T-1200, DV6T-1300, DV6T-2000, DV6T-2300, DV6T-3000,
DV6T-3100, DV6T-3200, DV6T-4000, DV6T-6000, DV6T-6100, DV6T-6B00, DV6T-6C00,
DV6Z-1000, DV6Z-1100, DV6Z-2000, DV6Z-2100, DV6Z-3000, DV6Z-3100, DV6Z-3200,
DV6Z-6100, DV6Z-6B00, DV6Z-6C00, DV7, DV7-1000, DV7-1001, DV7-1001TX,
DV7-1001XX, DV7-1002, DV7-1002XX, DV7-1003, DV7-1003TX, DV7-1003XX, DV7-1004,
DV7-1004TX, DV7-1005, DV7-1006, DV7-1006TX, DV7-1007, DV7-1008, DV7-1008TX,
DV7-1009, DV7-1009TX, DV7-1010, DV7-1010, DV7-1010TX, DV7-1011, DV7-1011TX,
DV7-1012, DV7-1012TX, DV7-1013, DV7-1013TX, DV7-1014, DV7-1014CA, DV7-1015,
DV7-1016, DV7-1016NR, DV7-1016TX, DV7-1017, DV7-1017TX, DV7-1018, DV7-1018TX,
DV7-1019, DV7-1020, DV7-1020TX, DV7-1021, DV7-1021TX, DV7-1022, DV7-1023,
DV7-1023CL, DV7-1023TX, DV7-1024, DV7-1024TX, DV7-1025, DV7-1025NR, DV7-1025TX,
DV7-1026, DV7-1027, DV7-1027CA, DV7-1027TX, DV7-1029, DV7-1030, DV7-1030TX,
DV7-1031, DV7-1034, DV7-1034CA, DV7-1034TX, DV7-1035, DV7-1038, DV7-1038CA,
DV7-1040, DV7-1045, DV7-1050, DV7-1051, DV7-1051XX, DV7-1052, DV7-1052XX,
DV7-1053, DV7-1053XX, DV7-1055, DV7-1060, DV7-1065, DV7-1070, DV7-1075, DV7-1080,
DV7-1090, DV7-1093, DV7-1094, DV7-1095, DV7-1098, DV7-1099, DV7-1100, DV7-1101XX,
DV7-1102TX, DV7-1102XX, DV7-1103TX, DV7-1103XX, DV7-1123CA, DV7-1127CL,
DV7-1128CA, DV7-1129WM, DV7-1130, DV7-1130US, DV7-1132NR, DV7-1133CL, DV7-1134,
DV7-1134US, DV7-1135NR, DV7-1137, DV7-1137US, DV7-1150, DV7-1151XX, DV7-1153CA,
DV7-1157CL, DV7-1170, DV7-1170US, DV7-1174CA, DV7-1175NR, DV7-1177CA,
DV7-1183CL, DV7-1201TX, DV7-1201XX, DV7-1206TX, DV7-1207TX, DV7-1208TX,
DV7-1209TX, DV7-1210TX, DV7-1214TX, DV7-1215TX, DV7-1216TX, DV7-1223CA,
DV7-1228CA, DV7-1232NR, DV7-1240US, DV7-1243CL, DV7-1245CA, DV7-1245DX,
DV7-1247CL, DV7-1253CA, DV7-1261WM, DV7-1262US, DV7-1264NR, DV7-1267CL,

DV7-1270CA, DV7-1270US, DV7-1273CL, DV7-1275DX, DV7-1279WM, DV7-1285DX,
DV7-1424NR, DV7-1426NR, DV7-1444US, DV7-1448DX, DV7-1450US, DV7-1451NR,
DV7-1464NR, DV7-1468NR, DV7-2001XX, DV7-2003TX, DV7-2012TX, DV7-2013TX,
DV7-2016TX, DV7-2021TX, DV7-2040CA, DV7-2040US, DV7-2043CL, DV7-2107TX,
DV7-2110TX, DV7-2111US, DV7-2114TX, DV7-2122TX, DV7-2123TX, DV7-2124TX,
DV7-2125TX, DV7-2126TX, DV7-2128TX, DV7-2170US, DV7-2173CL, DV7-2177CL,
DV7-2180US, DV7-2185DX, DV7-2204TX, DV7-2206TX, DV7-2210TX, DV7-2211TX,
DV7-2212EF, DV7-2212SF, DV7-2212TX, DV7-2230EA, DV7-2270EF, DV7-2270US,
DV7-2273CL, DV7-2277CL, DV7-2301NR, DV7-3001XX, DV7-3002TX, DV7-3003TX,
DV7-3010EW, DV7-3020EW, DV7-3025SF, DV7-3030EW, DV7-3051XX, DV7-3057NR,
DV7-3060US, DV7-3061NR, DV7-3063CL, DV7-3065DX, DV7-3067CL, DV7-3067NR,
DV7-3069WM, DV7-3078NR, DV7-3079NR, DV7-3079WM, DV7-3080ED, DV7-3080US,
DV7-3085DX, DV7-3089NR, DV7-3090ED, DV7-3101TX, DV7-3108TX, DV7-3112TX,
DV7-3113TX, DV7-3114TX, DV7-3115TX, DV7-3116TX, DV7-3118TX, DV7-3120TX,
DV7-3126TX, DV7-3127TX, DV7-3130SB, DV7-3133EL, DV7-3140EB, DV7-3148CA,
DV7-3155EB, DV7-3155EL, DV7-3160EB, DV7-3160EL, DV7-3160EP, DV7-3160US,
DV7-3162NR, DV7-3163CL, DV7-3164CL, DV7-3165DX, DV7-3165EB, DV7-3165EL,
DV7-3166EB, DV7-3166NR, DV7-3167NR, DV7-3169WM, DV7-3171NR, DV7-3173NR,
DV7-3174CA, DV7-3174NR, DV7-3180US, DV7-3183CL, DV7-3183NR, DV7-3186CL,
DV7-3187CL, DV7-3188CL, DV7-4001TX, DV7-4003TX, DV7-4003XX, DV7-4007TX,
DV7-4009TX, DV7-4010TX, DV7-4013TX, DV7-4021TX, DV7-4022TX, DV7-4051NR,
DV7-4053CL, DV7-4060US, DV7-4061NR, DV7-4065DX, DV7-4069WM, DV7-4070US,
DV7-4071NR, DV7-4073NR, DV7-4077CL, DV7-4080US, DV7-4083CL, DV7-4087CL,
DV7-4101XX, DV7-4104CA, DV7-4127CA, DV7-4138CA, DV7-4148CA, DV7-4151NR,
DV7-4153CL, DV7-4154CA, DV7-4157CL, DV7-4165DX, DV7-4167CA, DV7-4169WM,
DV7-4170US, DV7-4171US, DV7-4173US, DV7-4174CA, DV7-4177CA, DV7-4177NR,
DV7-4178CA, DV7-4178NR, DV7-4179NR, DV7-4180US, DV7-4182NR, DV7-4183CL,
DV7-4190US, DV7-4191NR, DV7-4197CL, DV7-4198CA, DV7-4223CA, DV7-4248CA,
DV7-4260CA, DV7-4263CL, DV7-4264CA, DV7-4267CL, DV7-4269WM, DV7-4270US,
DV7-4272US, DV7-4273US, DV7-4274NR, DV7-4276NR, DV7-4277NR, DV7-4278NR,
DV7-4280US, DV7-4283CL, DV7-4285DX, DV7-4287CL, DV7-4288CA, DV7-4289US,
DV7-4290US, DV7-4293NR, DV7-4294NR, DV7-4295US, DV7-4296NR, DV7-4297CL,
DV7-5001XX, DV7-5070CA, DV7-6001XX, DV7-6070CA, DV7-6113CL, DV7-6123CL,
DV7-6135DX, DV7-6143CL, DV7-6153NR, DV7-6154NR, DV7-6156NR, DV7-6157CL,
DV7-6157NR, DV7-6158CA, DV7-6160CA, DV7-6163CL, DV7-6163US, DV7-6165US,
DV7-6166NR, DV7-6168NR, DV7-6169NR, DV7-6175US, DV7-6178US, DV7-6179US,
DV7-6184CA, DV7-6185US, DV7-6187CL, DV7-6188CA, DV7-6191NR, DV7-6193CA,
DV7-6195US, DV7-6197CA, DV7-6199US, DV7-6B01XX, DV7-6B32US, DV7-6B55DX,
DV7-6B56NR, DV7-6B57NR, DV7-6B63US, DV7-6B71NR, DV7-6B73NR, DV7-6B75NR,
DV7-6B77DX, DV7-6B78US, DV7-6B91NR, DV7-6C20US, DV7-6C23CL, DV7-6C43CL,
DV7-6C50CA, DV7-6C60US, DV7-6C63NR, DV7-6C70CA, DV7-6C80US, DV7-6C90US,
DV7T, DV7T-1000, DV7T-1100, DV7T-1200, DV7T-2000, DV7T-2200, DV7T-3000,
DV7T-3300, DV7T-4000, DV7T-4100, DV7T-5000, DV7T-6000, DV7T-6100, DV7T-6B00,
DV7T-6C00, DV7Z, DV7Z-1000, DV7Z-1100, DV8-1000EB, DV8-1001XX, DV8-1003TX,

DV8-1010TX, DV8-1080ED, DV8-1100EB, DV8-1107TX, DV8-1108TX, DV8-1200, DV8T-1000, DV8T-1100, DV8T-1200, G32, G4-1010U, G4-1011N, G4-1015D, G4-1016D, G4-1020U, G4-1021C, G4-1022C, G4-1051X, G4-1104D, G4-1107N, G4-1117D, G4-1117N, G4-1118N, G4-1125D, G4-1135D, G4-1137C, G4-1164C, G4-1167C, G4-1204N, G4-1207N, G4-1213N, G4-1215D, G4-1226N, G4-1229D, G4-1264C, G4-1311N, G42, G42-101XX, G42-200XX, G42-230US, G42-232NR, G42-240US, G42-241HE, G42-243CL, G42-247SB, G42-250BR, G42-301NR, G42-303DX, G42-328CA, G42-367CL, G42-410US, G42-415DX, G42-475DX, G42T-200, G42T-300, G42T-400, G4T-1000, G4T-1100, G4T-1200, G4T-1300, G50, G50-100, G50-102CA, G50-102NR, G50-103CA, G50-103NR, G50-104CA, G50-104NR, G50-106NR, G50-108NR, G50-109NR, G50-111NR, G50-112NR, G50-113CA, G50-113NR, G50-116CA, G50-118NR, G50-120CA, G50-121CA, G50-122CA, G50-123NR, G50-124NR, G50-126NR, G50-133US, G50-201CA, G50-209CA, G50-211CA, G50-213CA, G50-215CA, G50-219CA, G56, G56-100XX, G56-118CA, G56-122US, G56-123NR, G56-125NR, G56-126NR, G56-127NR, G56-128CA, G56-129WM, G56-141US, G56-151XX, G6-1A01, G6-1A19W, G6-1A20C, G6-1A21C, G6-1A22C, G6-1A30U, G6-1A31N, G6-1A32N, G6-1A35C, G6-1A40C, G6-1A43C, G6-1A44C, G6-1A45C, G6-1A46C, G6-1A50C, G6-1A50U, G6-1A52N, G6-1A53N, G6-1A55C, G6-1A59W, G6-1A60U, G6-1A65U, G6-1A66N, G6-1A67N, G6-1A69U, G6-1A71N, G6-1A75D, G6-1B22C, G6-1B23C, G6-1B28C, G6-1B33C, G6-1B34C, G6-1B35C, G6-1B37C, G6-1B38C, G6-1B39W, G6-1B49W, G6-1B50U, G6-1B53C, G6-1B54C, G6-1B55C, G6-1B58C, G6-1B59C, G6-1B59W, G6-1B60U, G6-1B61C, G6-1B61N, G6-1B66N, G6-1B67C, G6-1B68N, G6-1B70U, G6-1B71H, G6-1B74C, G6-1B75C, G6-1B76U, G6-1B78N, G6-1B79C, G6-1B79D, G6-1B79U, G6-1B81C, G6-1B87C, G6-1B97C, G6-1C13C, G6-1C31N, G6-1C32N, G6-1C33C, G6-1C35D, G6-1C36H, G6-1C37C, G6-1C39C, G6-1C40C, G6-1C41C, G6-1C43N, G6-1C44W, G6-1C45D, G6-1C51N, G6-1C53N, G6-1C54W, G6-1C55C, G6-1C55N, G6-1C56N, G6-1C57D, G6-1C58C, G6-1C58D, G6-1C59N, G6-1C60C, G6-1C61C, G6-1C62U, G6-1C64C, G6-1C70C, G6-1C71C, G6-1C74C, G6-1C75C, G6-1C77N, G6-1C79N, G6-1C81N, G6-1C87N, G6-1D40CA, G6-1D60CA, G6-1D60U, G6-1D62N, G6-1D72N, G60, G60-100, G60-101CA, G60-101TU, G60-102XX, G60-103XX, G60-104CA, G60-104XX, G60-108CA, G60-117US, G60-118NR, G60-119OM, G60-120CA, G60-120US, G60-121CA, G60-121WM, G60-123CL, G60-125CA, G60-125NR, G60-126CA, G60-127CL, G60-127NR, G60-128CA, G60-129CA, G60-146CA, G60-201TU, G60-202TU, G60-203TU, G60-208CA, G60-219CA, G60-225CA, G60-228CA, G60-230CA, G60-230US, G60-231WM, G60-233CA, G60-233NR, G60-234CA, G60-235CA, G60-235DX, G60-235WM, G60-236US, G60-237NR, G60-237US, G60-238CA, G60-243CL, G60-243DX, G60-244DX, G60-247CL, G60-249CA, G60-249WM, G60-438NR, G60-440US, G60-441US, G60-442OM, G60-443CL, G60-443NR, G60-445DX, G60-447CL, G60-453NR, G60-458DX, G60-471NR, G60-501NR, G60-506US, G60-507DX, G60-508US, G60-513NR, G60-519WM, G60-526NR, G60-530US, G60-531NR, G60-533CL, G60-535DX, G60-536NR, G60-549DX, G60-552NR, G60-553NR, G60-630US, G60-633NR, G60-635DX, G60-637CL, G60-642NR, G60-645NR, G60-647NR, G60T-200, G60T-500, G60T-600, G61, G61-101TU, G61-102TU, G61-103TU, G61-104TU, G61-110EA, G61-202TU, G61-203TU, G61-204TU, G61-301TU, G61-302TU, G61-304NR, G61-306NR, G61-320US, G61-321NR, G61-322NR, G61-327CL, G61-336NR, G61-400EP, G61-400SL, G61-405EL, G61-405SL, G61-407SL, G61-410EB, G61-410EL, G61-415EL, G61-415SB, G61-420EB,

G61-420SL, G61-424CA, G61-425EL, G61-429WM, G61-430EL, G61-435SL, G61-440EL, G61-450EE, G61-451EE, G61-452EE, G61-453EE, G61-454EE, G61-465SL, G61-511WM, G61-631NR, G61-632NR, G62, G62-100EB, G62-100EE, G62-100SL, G62-101TU, G62-101XX, G62-103XX, G62-110EE, G62-120EL, G62-120SL, G62-120SW, G62-125SL, G62-130SL, G62-140EL, G62-140US, G62-143CL, G62-144DX, G62-145NR, G62-147NR, G62-149WM, G62-165SL, G62-166SB, G62-200XX, G62-201XX, G62-219CA, G62-219WM, G62-220US, G62-222US, G62-223CL, G62-224HE, G62-225DX, G62-225NR, G62-226NR, G62-227CL, G62-228CL, G62-228NR, G62-229NR, G62-229WM, G62-231NR, G62-233NR, G62-234DX, G62-236NR, G62-237US, G62-238NR, G62-251TU, G62-251XX, G62-318CA, G62-320CA, G62-323CA, G62-325CA, G62-327CA, G62-337NR, G62-339WM, G62-340US, G62-341NR, G62-343NR, G62-346NR, G62-347CL, G62-347NR, G62-348CA, G62-348NR, G62-352CA, G62-352US, G62-353NR, G62-354CA, G62-355CA, G62-355DX, G62-357CA, G62-358CA, G62-358NR, G62-359CA, G62-363NR, G62-364DX, G62-365CA, G62-367DX, G62-371DX, G62-372US, G62-373DX, G62-374CA, G62-378CA, G62-404NR, G62-407DX, G62-415NR, G62-420CA, G62-423CA, G62-435DX, G62-448CA, G62-454CA, G62-455DX, G62-457CA, G62-457DX, G62-465DX, G62-470CA, G62-474CA, G62-478CA, G62-A21EZ, G62-A35ET, G62M-300, G62T-100, G62T-250, G62T-350, G62X-400, G6T-1A00, G6T-1B00, G6T-1C00, G6T-1D00, G6Z-1C00, G7-1001X, G7-1017C, G7-1019W, G7-1033C, G7-1051X, G7-1070U, G7-1073N, G7-1075D, G7-1075N, G7-1076N, G7-1077N, G7-1081N, G7-1083N, G7-1084N, G7-1085N, G7-1086N, G7-1101X, G7-1113C, G7-1117C, G7-1139W, G7-1149W, G7-1150U, G7-1153N, G7-1154N, G7-1156N, G7-1158N, G7-1167D, G7-1173C, G7-1173D, G7-1174C, G7-1175C, G7-1178C, G7-1219W, G7-1222N, G7-1227N, G7-1237D, G7-1255D, G7-1257D, G7-1260C, G7-1260U, G7-1261N, G7-1263C, G7-1263N, G7-1264N, G7-1265N, G7-1269N, G7-1270C, G7-1272N, G7-1273N, G7-1277D, G7-1279D, G7-1281N, G7-1310U, G7-1312N, G7-1320C, G7-1330C, G70, G70-246US, G70-250CA, G70-250US, G70-257CL, G70-258US, G70-460US, G70-463CL, G70-467CL, G70-468NR, G70-481NR, G70T-200, G71, G71-329WM, G71-333NR, G71-340US, G71-343US, G71-345CL, G71-347CL, G71-349WM, G71-358NR, G71-441NR, G71-442NR, G71-445US, G71-447US, G71-448CL, G71-449WM, G71T-300, G71T-400, G72, G72-130SB, G72-227WM, G72-250US, G72-251NR, G72-251XX, G72-252US, G72-253NR, G72-257CL, G72-259WM, G72-260US, G72-261US, G72-262NR, G72-A30EM, G72-B27CL, G72-B49WM, G72-B50US, G72-B53NR, G72-B54NR, G72-B57CL, G72-B60US, G72-B61NR, G72-B62US, G72-B63NR, G72-B66US, G72-B67CA, G72-B67US, G72-C55DX, G72T-200, G72T-B00, G7T-1000, G7T-1100, G7T-1200, HDX16, HDX18,

ProBook series

4230 S, 4310S, 4311S, 4320S, 4320T, 4321S, 4325S, 4326S, 4330S, 4331S, 4410S, 4411S, 4415S, 4416S, 4420S, 4421S, 4425S, 4430S, 4431S, 4435S, 4436S, 4510S, 4510S/CT, 4515S, 4515S/CT, 4520, 4520S, 4525S, 4530S, 4535S, 4710S, 4710S/CT, 4720S, 4730S, 5220M, 5310M, 5320M, 5330M, 6360B, 6440B, 6445B, 6450B, 6455B, 6460B, 6465B, 6470B, 6475B, 6540B, 6545B, 6550B, 6555B, 6560B, 6565B, 6570B,

Tablet PC series

TC4400,

TouchSmart Series

TM2, TX2,

18.5V 3.5A HP 7.4mm*5.0mm 65W

Compaq

Presario series

320, 321, 325, 326, 420, 421, 435, 436, 610, 615, 621, CQ20-100, CQ32, CQ32-10TX, CQ35, CQ35-101TU, CQ35-102TX, CQ35-103TX, CQ35-104TX, CQ35-105TU, CQ35-109TX, CQ35-110TX, CQ35-111TU, CQ35-112TU, CQ35-113TU, CQ35-113TX, CQ35-114TU, CQ35-114TX, CQ35-115TU, CQ35-116TU, CQ35-117TU, CQ35-121TX, CQ35-126TX, CQ35-127TX, CQ35-128TX, CQ35-129TX, CQ35-202TX, CQ35-207TU, CQ35-213TX, CQ35-217TU, CQ35-218TU, CQ35-220TU, CQ35-221TU, CQ35-224TX, CQ35-225TX, CQ35-226TX, CQ35-227TX, CQ35-229TX, CQ35-230TX, CQ35-233TX, CQ35-242TX, CQ35-243TX, CQ35-303TX, CQ35-304TU, CQ35-305TU, CQ35-313TX, CQ35-314TX, CQ35-320TX, CQ35-321TX, CQ35-332TX, CQ35-336TX, CQ35-337TX, CQ35-406TU, CQ35-406TX, CQ35-408TX, CQ36-103TX, CQ36-104TX, CQ36-105TX, CQ36-106TX, CQ36-108TX, CQ36-109TX, CQ36-117TX, CQ40, CQ40-100, CQ40-101AU, CQ40-101TU, CQ40-101XX, CQ40-102AX, CQ40-102TU, CQ40-103AU, CQ40-103AX, CQ40-103TU, CQ40-104AU, CQ40-105AU, CQ40-105AX, CQ40-105TU, CQ40-106AU, CQ40-106AX, CQ40-107TU, CQ40-108AU, CQ40-108AX, CQ40-109AU, CQ40-109AX, CQ40-109TU, CQ40-110AU, CQ40-111AU, CQ40-111AX, CQ40-112AX, CQ40-112TU, CQ40-114AU, CQ40-114AX, CQ40-114TU, CQ40-115AU, CQ40-115AX, CQ40-115TU, CQ40-116AX, CQ40-117AX, CQ40-117TU, CQ40-118AX, CQ40-118TU, CQ40-119AX, CQ40-119TU, CQ40-120AU, CQ40-120AX, CQ40-120TU, CQ40-121AU, CQ40-122AU, CQ40-122TU, CQ40-123AU, CQ40-124AU, CQ40-125AU, CQ40-125AX, CQ40-126AX, CQ40-126TU, CQ40-128AU, CQ40-129AU, CQ40-129TU, CQ40-130TU, CQ40-131TU, CQ40-132TU, CQ40-134TU, CQ40-135TU, CQ40-138TU, CQ40-139TU, CQ40-140TU, CQ40-141TU, CQ40-143TU, CQ40-146TU, CQ40-147TU, CQ40-148TU, CQ40-150TU, CQ40-151XX, CQ40-152XX, CQ40-200, CQ40-201XX, CQ40-215WWM, CQ40-300, CQ40-302AX, CQ40-303AX, CQ40-303TU, CQ40-304AX, CQ40-304TU, CQ40-305AX, CQ40-306AX, CQ40-308AX, CQ40-309AX, CQ40-310AX, CQ40-310TU, CQ40-311AU, CQ40-311AX, CQ40-312AU, CQ40-314AX, CQ40-315TU, CQ40-317AX, CQ40-318AX, CQ40-318TU, CQ40-319AX, CQ40-320AX, CQ40-321TU, CQ40-322AX, CQ40-322TU, CQ40-323AX, CQ40-323TU, CQ40-325AX, CQ40-326TU, CQ40-331TU, CQ40-334TU, CQ40-343TU, CQ40-346TU, CQ40-404AX, CQ40-408AU, CQ40-409TU, CQ40-416TU, CQ40-417TU, CQ40-421AX, CQ40-513TX, CQ40-518AU, CQ40-520AU, CQ40-521TU, CQ40-521TX, CQ40-522TX, CQ40-528TU, CQ40-536TX, CQ40-537TX, CQ40-541TX, CQ40-555TU, CQ40-556TU, CQ40-601AX, CQ40-603TU, CQ40-605TU, CQ40-606AU, CQ40-606AX, CQ40-607AU, CQ40-607AX, CQ40-609AX, CQ40-609TX, CQ40-610TX, CQ40-611AX, CQ40-611BR, CQ40-611TX, CQ40-612BR, CQ40-614BR, CQ40-614TX, CQ40-615TX, CQ40-616TX, CQ40-618AX, CQ40-619AX, CQ40-620AX, CQ40-622AU, CQ40-622BR, CQ40-623AU, CQ40-623AX, CQ40-623TU, CQ40-624AU, CQ40-624AX, CQ40-624TX, CQ40-626AU, CQ40-627AX, CQ40-627LA, CQ40-630TX, CQ40-633TU, CQ40-634TX, CQ40-636TX, CQ40-637TX, CQ40-638TX, CQ40-639TX, CQ40-640TX, CQ40-641TX, CQ40-642TX, CQ40-643TX, CQ40-704TX, CQ40-705TX, CQ40-706TX, CQ40-707TU, CQ40-707TX, CQ40-708TU, CQ40-708TX, CQ40-709TU, CQ40-709TX, CQ40-710TX, CQ40-711TX, C

Q40-713TU, CQ40-716TX, CQ40-717TU, CQ40-717TX, CQ40-719TU, CQ40-725TU, CQ40-734TU, CQ40-735TU, CQ40-747TU, CQ40-748TU, CQ41, CQ41-204AU, CQ41-204TX, CQ41-205AX, CQ41-205TX, CQ41-206AU, CQ41-206AX, CQ41-206TX, CQ41-207AX, CQ41-207TX, CQ41-208AX, CQ41-208TU, CQ41-208TX, CQ41-209AU, CQ41-209AX, CQ41-209TU, CQ41-209TX, CQ41-210AU, CQ41-210TU, CQ41-211TU, CQ41-211TX, CQ41-212TX, CQ41-213AU, CQ41-213TU, CQ41-214AU, CQ41-215AU, CQ41-217TU, CQ41-218AU, CQ41-218AX, CQ41-222AU, CQ41-223TX, CQ41-224TX, CQ41-225AU, CQ41-225TX, CQ42, CQ42-103TU, CQ42-105TU, CQ42-109TU, CQ42-111TU, CQ42-119TU, CQ42-125TU, CQ42-126TU, CQ42-133TU, CQ42-134TU, CQ42-135TU, CQ42-140TU, CQ42-151TX, CQ42-152TU, CQ42-152TX, CQ42-153TX, CQ42-154TX, CQ42-158TX, CQ42-160TU, CQ42-160TX, CQ42-163TX, CQ42-165TX, CQ42-167TU, CQ42-168TU, CQ42-169TU, CQ42-173TU, CQ42-173TX, CQ42-189TX, CQ42-195TX, CQ42-201TU, CQ42-203AU, CQ42-205AU, CQ42-210AU, CQ42-215TU, CQ42-216TU, CQ42-218AX, CQ42-219AX, CQ42-220AX, CQ42-251TU, CQ42-254TU, CQ42-254TX, CQ42-255TX, CQ42-256TX, CQ42-257TU, CQ42-257TX, CQ42-258TU, CQ42-263TU, CQ42-268TX, CQ42-269TX, CQ42-275TX, CQ42-276TU, CQ42-320CA, CQ45, CQ45-100, CQ45-101AU, CQ45-101XX, CQ45-102AU, CQ45-102TX, CQ45-102XX, CQ45-103TU, CQ45-103TX, CQ45-104TU, CQ45-105AU, CQ45-105TU, CQ45-105TX, CQ45-107AU, CQ45-108AU, CQ45-108TU, CQ45-109AU, CQ45-109TU, CQ45-110AU, CQ45-110TU, CQ45-110TX, CQ45-111AU, CQ45-111TX, CQ45-112TX, CQ45-113AU, CQ45-113TX, CQ45-114AU, CQ45-114TX, CQ45-115AU, CQ45-115TX, CQ45-116TX, CQ45-117TX, CQ45-118TX, CQ45-120, CQ45-120TX, CQ45-121TX, CQ45-123TX, CQ45-124TX, CQ45-125TX, CQ45-126TX, CQ45-127TX, CQ45-128TX, CQ45-129TX, CQ45-130TX, CQ45-131TX, CQ45-132TX, CQ45-133TX, CQ45-134TX, CQ45-135TX, CQ45-136TX, CQ45-148TX, CQ45-151XX, CQ45-152XX, CQ45-200, CQ45-201TU, CQ45-201TX, CQ45-202TU, CQ45-204AU, CQ45-204TU, CQ45-205TX, CQ45-206TX, CQ45-207TX, CQ45-208TU, CQ45-209TU, CQ45-209TX, CQ45-210TU, CQ45-210TX, CQ45-211TU, CQ45-211TX, CQ45-212TU, CQ45-212TX, CQ45-213TU, CQ45-213TX, CQ45-214TU, CQ45-214TX, CQ45-215TU, CQ45-216TU, CQ45-217TU, CQ45-218TU, CQ45-219TU, CQ45-220TU, CQ45-220TX, CQ45-221TU, CQ45-221TX, CQ45-222TU, CQ45-222TX, CQ45-223TX, CQ45-301TU, CQ45-302TU, CQ45-302TX, CQ45-303TU, CQ45-304TU, CQ45-305TU, CQ45-306TU, CQ45-307TU, CQ45-309TU, CQ45-309TX, CQ45-310TX, CQ45-311TX, CQ45-312TX, CQ45-314TX, CQ45-315TX, CQ45-318TX, CQ45-320TX, CQ45-321TX, CQ45-322TX, CQ45-323TX, CQ45-324TX, CQ45-325TX, CQ45-326TX, CQ45-327TX, CQ45-328TX, CQ45-329TX, CQ45-330TX, CQ45-331TX, CQ45-401TU, CQ45-402TU, CQ45-403TU, CQ45-409TX, CQ45-410TX, CQ45-411TX, CQ45-413TX, CQ45-415TX, CQ45-416TX, CQ45-417TX, CQ45-418TX, CQ50, CQ50-100CA, CQ50-101XX, CQ50-102XX, CQ50-103AU, CQ50-103NR, CQ50-103XX, CQ50-104AU, CQ50-104CA, CQ50-104NR, CQ50-104XX, CQ50-105AU, CQ50-105NR, CQ50-106CA, CQ50-107CL, CQ50-107NR, CQ50-108AU, CQ50-108CA, CQ50-108NR, CQ50-109AU, CQ50-109CA, CQ50-110AU, CQ50-110US, CQ50-111AU, CQ50-112AU, CQ50-113AU, CQ50-113CA, CQ50-115NR, CQ50-116AU, CQ50-117AU, CQ50-128NR, CQ50-133US, CQ50-139NR, CQ50-139WM, CQ50-140US, CQ50-142US, CQ50-204CA, CQ50-209CA, CQ50-209NR, CQ50-209WM, CQ50-210US, CQ50-211NR, CQ50-215CA, CQ50-215NR, CQ50-217CL, CQ50-217NR, CQ50-225LA, CQ50T-100, CQ50Z, CQ50Z-100, CQ56-100XX, CQ56-104CA, CQ56-109WM, CQ56-110US, CQ56-112NR, CQ56-115DX, CQ56-122NR, CQ56-124CA, CQ56-129NR, CQ56-134CA, CQ56

-148CA, CQ56-154CA, CQ56-201NR, CQ56-204CA, CQ56-219WM, CQ56-220CA, CQ56-240CA, CQ56Z-200, CQ57-210US, CQ57-212NR, CQ57-214NR, CQ57-218NR, CQ57-229WM, CQ57-310US, CQ57-314NR, CQ57-315NR, CQ57-319WM, CQ57-410US, CQ57-439WM, CQ60, CQ60-100, CQ60-101XX, CQ60-102TU, CQ60-102TX, CQ60-102XX, CQ60-103AU, CQ60-103XX, CQ60-105AU, CQ60-105TU, CQ60-106TU, CQ60-106XX, CQ60-107TU, CQ60-107TX, CQ60-108TU, CQ60-108TX, CQ60-109AU, CQ60-109TU, CQ60-109TX, CQ60-110AU, CQ60-110TX, CQ60-111TU, CQ60-111TX, CQ60-112TU, CQ60-112TX, CQ60-113TX, CQ60-114TU, CQ60-114TX, CQ60-115TU, CQ60-116TX, CQ60-117TU, CQ60-118TU, CQ60-122TU, CQ60-144US, CQ60-202TU, CQ60-202US, CQ60-203AU, CQ60-203NR, CQ60-204AU, CQ60-204NR, CQ60-204TX, CQ60-205TX, CQ60-206AU, CQ60-206TU, CQ60-206US, CQ60-207AU, CQ60-207TX, CQ60-208AU, CQ60-208CA, CQ60-208TU, CQ60-209AU, CQ60-209TX, CQ60-210AU, CQ60-210CA, CQ60-210US, CQ60-211DX, CQ60-211TU, CQ60-212TU, CQ60-212US, CQ60-214DX, CQ60-214TU, CQ60-214TX, CQ60-215DX, CQ60-215TU, CQ60-215TX, CQ60-216DX, CQ60-216TU, CQ60-217TU, CQ60-218CA, CQ60-218TU, CQ60-220TU, CQ60-220TX, CQ60-220US, CQ60-221TU, CQ60-224CA, CQ60-224NR, CQ60-227CA, CQ60-228US, CQ60-249US, CQ60-304AU, CQ60-306AU, CQ60-307AU, CQ60-310AU, CQ60-311AU, CQ60-315AU, CQ60-316AU, CQ60-407AU, CQ60-409AU, CQ60-410AU, CQ60-410US, CQ60-413AU, CQ60-413NR, CQ60-416AU, CQ60-417DX, CQ60-417NR, CQ60-418DX, CQ60-419AU, CQ60-419WM, CQ60-420AU, CQ60-420US, CQ60-421NR, CQ60-422DX, CQ60-423DX, CQ60-427NR, CQ60-433US, CQ60-514NR, CQ60-615DX, CQ60Z-200, CQ61, CQ61-103TU, CQ61-108TU, CQ61-110TU, CQ61-110TX, CQ61-111TX, CQ61-112TX, CQ61-113TU, CQ61-117TX, CQ61-118TX, CQ61-124TU, CQ61-125TU, CQ61-126TU, CQ61-131TU, CQ61-134TU, CQ61-135TU, CQ61-205TU, CQ61-213TU, CQ61-221TX, CQ61-222TX, CQ61-223TU, CQ61-223TX, CQ61-224TX, CQ61-226TU, CQ61-227TU, CQ61-227TX, CQ61-231TU, CQ61-232TU, CQ61-235TU, CQ61-303XX, CQ61-305TX, CQ61-306AX, CQ61-306TX, CQ61-307AU, CQ61-309TU, CQ61-310US, CQ61-311TU, CQ61-312SL, CQ61-312TX, CQ61-313AX, CQ61-313NR, CQ61-313TU, CQ61-313TX, CQ61-313US, CQ61-314US, CQ61-315TU, CQ61-318TX, CQ61-319WM, CQ61-320EA, CQ61-324SP, CQ61-325TU, CQ61-326TU, CQ61-327SF, CQ61-327TU, CQ61-327TX, CQ61-328TU, CQ61-328TX, CQ61-329TU, CQ61-404AU, CQ61-405AU, CQ61-405EB, CQ61-410EM, CQ61-410SB, CQ61-410TX, CQ61-410US, CQ61-411TU, CQ61-411WM, CQ61-412AX, CQ61-412NR, CQ61-414NR, CQ61-414TU, CQ61-415TU, CQ61-416TU, CQ61-417TU, CQ61-420US, CQ61-429US, CQ61-441SE, CQ61-457EE, CQ61-488EE, CQ61-489EE, CQ61Z-300, CQ61Z-400, CQ62, CQ70, CQ70-100, CQ70-101XX, CQ70-102TU, CQ70-102XX, CQ70-103TU, CQ70-111CA, CQ70-117CA, CQ70-118CA, CQ70-118NR, CQ70-119CA, CQ70-120US, CQ70-124CA, CQ70-126NR, CQ70-127NR, CQ70-128NR, CQ70-134CA, CQ71, CQ71-101XX, CQ71-350EK, CQ71-420EM, CQ71-420SB, CQ71-440EB, CQ71-466SB, CQ72,

HP

Business Notebook series

2210B, 2230S, 2510, 2510P, 2710B, 2710P, 6510B, 6515B, 6520S, 6530B, 6530S, 6531S, 6535B, 6535S, 6710B, 6710S, 6715B, 6715S, 6730B, 6730S, 6730SK, 6735B, 6735S, 6830S, 6910B, 6910P, 8510B, 8510W, 8710B, 8710W, NC2400, NC4400, NC6320, NC6400, NC8430, NX6310, NX6315, NX6320, NX6325, NX7300, NX7400,

EliteBook series

2530P, 2540P, 2560P, 2730P, 2740P, 2760P, 6930P,

Envy series

13, 13-1002TX, 13-1003XX, 13-1030NR, 13-1050EA, 13-1099XL, 13-1104TX, 13-1130NR, 13T-1000, 13T-1100, 14,

Notebook PC series

420, 421, 425, 430, 431, 435, 620, 625, 630, 631, 635,

Pavilion series

DM1, DM1-1004TU, DM1-1005TU, DM1-1006TU, DM1-1010EO, DM1-1020ED, DM1-1020S A, DM1-1022TU, DM1-1023TU, DM1-1025TU, DM1-1029TU, DM1-1030SA, DM1-1031TU, DM1-1117TU, DM1-1118TU, DM1-1121TU, DM1-1122TU, DM1-1126TU, DM1-1128TU, DM1-1130TU, DM1-1190EE, DM1-2001AU, DM1-2001XX, DM1-2002AU, DM1-2002NR, DM1-2004AU, DM1-2005AU, DM1-2010NR, DM1-2011NR, DM1-2140CA, DM1-3005XX, DM1-3010NR, DM1-3011NR, DM1-3020US, DM1-3023NR, DM1-3025DX, DM1-3040CA, DM1-3210US, DM1-3214NR, DM1-3240CA, DM1-3245CA, DM1-3248CA, DM1-4001XX, DM1-4010US, DM1-4013NR, DM1-4018CA, DM1-4050US, DM1-4051XX, DM1-4054NR, DM1-4170US, DM1Z-2000, DM1Z-2100, DM1Z-3000, DM1Z-3200, DM1Z-4000, DM1Z-4100, DM3, DM3-1001AU, DM3-1001TU, DM3-1002AX, DM3-1004XX, DM3-1006AX, DM3-1007AU, DM3-1007AX, DM3-1007TU, DM3-1008AX, DM3-1008TU, DM3-1009AX, DM3-1009TU, DM3-1011TX, DM3-1012TX, DM3-1013AX, DM3-1016TU, DM3-1017TX, DM3-1018TX, DM3-1019TX, DM3-1020AX, DM3-1022AX, DM3-1026TX, DM3-1030US, DM3-1034TX, DM3-1035DX, DM3-1039WM, DM3-1040US, DM3-1044NR, DM3-1047CL, DM3-1047NR, DM3-1053XX, DM3-1058NR, DM3-1103AU, DM3-1105AU, DM3-1105AX, DM3-1107AU, DM3-1107AX, DM3-1108AX, DM3-1108TU, DM3-1109AX, DM3-1110TX, DM3-1112AX, DM3-1113TX, DM3-1114AX, DM3-1115AX, DM3-1116TX, DM3-1121AX, DM3-1124CA, DM3-1124TX, DM3-1125TX, DM3-1126AX, DM3-1126TX, DM3-1130US, DM3-1131NR, DM3-1140US, DM3-1148LA, DM3-1150EE, DM3-1180EE, DM3-1190EE, DM3-2001AX, DM3-2010US, DM3-3001XX, DM3-3004XX, DM3-3010CA, DM3-3010US, DM3-3011NR, DM3-3012NR, DM3-3027CL, DM3-3110US, DM3-3112NR, DM3-3130CA, DM3T-1000, DM3T-1100, DM3T-3000, DM3Z-1000, DM3Z-1100, DM3Z-2000, DV2, DV2-1001XX, DV2-1003AU, DV2-1005AU, DV2-1007AU, DV2-1008AU, DV2-1011AX, DV2-1013AX, DV2-1014AX, DV2-1015AX, DV2-1016AX, DV2-1017AX, DV2-1018AX, DV2-1019AX, DV2-1020AX, DV2-1021AX, DV2-1024AX, DV2-1025AX, DV2-1026AX, DV2-1027AX, DV2-1028AX, DV2-1029AX, DV2-1030AX, DV2-1030US, DV2-1031AX, DV2-1033CL, DV2-1039WM, DV2-1110US, DV2-1118AX, DV2-1118NR, DV2-1119AX, DV2-1120AX, DV2-1121AX, DV2-1126AX, DV2-1134NR, DV2-1156XX, DV2-1199US, DV2-1201AU, DV2-1201AX, DV2-1202AU, DV2-1203AU, DV2-1206AU, DV2-1208AU, DV2-1209AU, DV2-1209AX, DV2-1210AX, DV2-1215AX, DV2Z-1100, DV3-1051XX, DV3-1052XX, DV3-1073CL, DV3-1075CA, DV3-1075US, DV3-1077CA, DV3-1253NR, DV3-2001TU, DV3-2001XX, DV3-2017TX, DV3-2023TX, DV3-2025TX, DV3-2028TX, DV3-2029TX, DV3-2035TX, DV3-2123TX, DV3-2150TX, DV3-2150US, DV3-2155MX, DV3-2157CL, DV3-2202TU, DV3-2203TU, DV3-2204TU, DV3-2209TX, DV3-2214TX, DV3-2216TX, DV3-2217TX, DV3-2219TX, DV3-2220EF, DV3-2228TX,

DV3-2230TX, DV3-2231TX, DV3-2234TX, DV3-2237TX, DV3-2238TX, DV3-2239TX, DV3-2242TX, DV3-2244TX, DV3-2250EW, DV3-2302TU, DV3-2302TX, DV3-2303TU, DV3-2307TX, DV3-2309TX, DV3-2310TX, DV3-2312TX, DV3-2313TX, DV3-2314TX, DV3-2315TX, DV3-2316TX, DV3-2320TX, DV3-2328TX, DV3-2331TX, DV3-2350EE, DV3-2355EE, DV3-4001TX, DV3-4007TX, DV3-4010TX, DV3-4019TX, DV3-4020TX, DV3000, DV3001TX, DV3002TX, DV3003TX, DV3004TX, DV3005XX, DV3006XX, DV3007XX, DV3008TX, DV3009TX, DV3010TX, DV3015TX, DV3016TX, DV3017TX, DV3018TX, DV3019TX, DV3020TX, DV3023TX, DV3024TX, DV3026TX, DV3027TX, DV3030TX, DV3101TX, DV3102TX, DV3108TX, DV3111TX, DV3115TX, DV3116TX, DV3117TX, DV3119TX, DV3500, DV3500T, DV3501TX, DV3505XX, DV3510NR, DV3510TX, DV3511TX, DV3514TX, DV3515TX, DV3516TX, DV3517TX, DV3518TX, DV3519TX, DV3520TX, DV3521TX, DV3522TX, DV3523TX, DV3524TX, DV3526TX, DV3527TX, DV3531TX, DV3532TX, DV3533TX, DV3536TX, DV3538TX, DV3541TX, DV3542TX, DV3543TX, DV3600T, DV3601TX, DV3603TX, DV3604TX, DV3606TX, DV3608TX, DV3610TX, DV3611TX, DV3613TX, DV3617TX, DV3618TX, DV3627TX, DV3629TX, DV3630TX, DV3631TX, DV3632TX, DV3633TX, DV3634TX, DV3635TX, DV3637TX, DV3702TX, DV3703TX, DV3704TX, DV3705TX, DV3706TX, DV3707TX, DV3888NR, DV3T-2000, DV3Z-1000, DV4, DV4-1000, DV4-1001AX, DV4-1001XX, DV4-1002AX, DV4-1002XX, DV4-1004TU, DV4-1004TX, DV4-1005TX, DV4-1006TX, DV4-1007TX, DV4-1008TX, DV4-1009TX, DV4-1010TX, DV4-1011TX, DV4-1012TX, DV4-1013TX, DV4-1014, DV4-1014N, DV4-1014NR, DV4-1014TX, DV4-1015, DV4-1016, DV4-1019TX, DV4-1020, DV4-1020TX, DV4-1020US, DV4-1022TX, DV4-1023TX, DV4-1024TX, DV4-1025TX, DV4-1026TX, DV4-1027TX, DV4-1028, DV4-1028TX, DV4-1028US, DV4-1029TX, DV4-1030, DV4-1030TX, DV4-1031TX, DV4-1032TX, DV4-1033TX, DV4-1034TX, DV4-1036TX, DV4-1040, DV4-1046TX, DV4-1047TX, DV4-1048TX, DV4-1049TX, DV4-1050, DV4-1051TX, DV4-1051XX, DV4-1052TX, DV4-1052XX, DV4-1053XX, DV4-1055TX, DV4-1070, DV4-1101XX, DV4-1102XX, DV4-1107TX, DV4-1108TX, DV4-1109TX, DV4-1110TX, DV4-1114NR, DV4-1116TX, DV4-1117CA, DV4-1117NR, DV4-1118CA, DV4-1118TX, DV4-1120, DV4-1120US, DV4-1121BR, DV4-1121CA, DV4-1123US, DV4-1124NR, DV4-1125, DV4-1125NR, DV4-1127TX, DV4-1129TX, DV4-1130TX, DV4-1132TX, DV4-1134TX, DV4-1139TX, DV4-1140GO, DV4-1140TX, DV4-1142TX, DV4-1143GO, DV4-1143TX, DV4-1144TX, DV4-1144US, DV4-1145, DV4-1145GO, DV4-1145TX, DV4-1146TX, DV4-1147CL, DV4-1147TX, DV4-1148TX, DV4-1149TX, DV4-1150TX, DV4-1153TX, DV4-1154TX, DV4-1155, DV4-1155SE, DV4-1155TX, DV4-1157TX, DV4-1159TX, DV4-1161TX, DV4-1163TX, DV4-1164TX, DV4-1165TX, DV4-1166CA, DV4-1166TX, DV4-1168TX, DV4-1169TX, DV4-1201AU, DV4-1201TX, DV4-1202AU, DV4-1202TX, DV4-1203AU, DV4-1203TX, DV4-1204AU, DV4-1204TX, DV4-1205TU, DV4-1206TU, DV4-1207TU, DV4-1208TU, DV4-1209TU, DV4-1210TU, DV4-1212TU, DV4-1212TX, DV4-1213TU, DV4-1213TX, DV4-1214TU, DV4-1214TX, DV4-1215TU, DV4-1215TX, DV4-1216TX, DV4-1217TX, DV4-1218TX, DV4-1219TX, DV4-1220TX, DV4-1220US, DV4-1221TX, DV4-1222NR, DV4-1222TX, DV4-1223TX, DV4-1224TX, DV4-1225DX, DV4-1225TX, DV4-1226TX, DV4-1227TX, DV4-1227US, DV4-1229TX, DV4-1230TX, DV4-1233TX, DV4-1234TX, DV4-1235TX, DV4-1236TX, DV4-1237TX, DV4-1238TX, DV4-1239TX, DV4-1243TX, DV4-1244TX, DV4-1245TX, DV4-1246TX, DV4-1247TX, DV4-1249TX, DV4-1250TX, DV4-1251TX, DV4-1252TX, DV4-1253TX, DV4-1254TX, DV4-1256TX, DV4-1257TX, DV4-1260TX, DV4-1261TX, DV4-1265DX, DV4-1272CM, DV4-1275MX, DV4-1280US, DV4-1281US, DV4-1282CM, DV4-1283CL, DV4-1287CL, DV4-1292

CM, DV4-1302TX, DV4-1303TX, DV4-1304TU, DV4-1304TX, DV4-1305TU, DV4-1306TU, DV4-1307TU, DV4-1308TU, DV4-1309TU, DV4-1310TU, DV4-1311TU, DV4-1312TU, DV4-1313DX, DV4-1313TU, DV4-1314TU, DV4-1315TU, DV4-1316TU, DV4-1316TX, DV4-1317TU, DV4-1317TX, DV4-1318TX, DV4-1319TX, DV4-1322TX, DV4-1322US, DV4-1323TX, DV4-1324TX, DV4-1325TX, DV4-1327TX, DV4-1329TX, DV4-1330TX, DV4-1331TX, DV4-1332TX, DV4-1365DX, DV4-1379NR, DV4-1404TX, DV4-1412TU, DV4-1413LA, DV4-1415TU, DV4-1424LA, DV4-1427NR, DV4-1428DX, DV4-1428TX, DV4-1430US, DV4-1431US, DV4-1432TX, DV4-1433SB, DV4-1433US, DV4-1434TX, DV4-1435DX, DV4-1437TX, DV4-1438TX, DV4-1442TX, DV4-1443TX, DV4-1444DX, DV4-1502TU, DV4-1506TX, DV4-1509TX, DV4-1511TX, DV4-1514DX, DV4-1520BR, DV4-1526TX, DV4-1528TX, DV4-1530BR, DV4-1531TX, DV4-1540US, DV4-1541US, DV4-1543SB, DV4-1547SB, DV4-1548DX, DV4-1548NR, DV4-1551DX, DV4-1555DX, DV4-1580BR, DV4-1601TU, DV4-2012BR, DV4-2014BR, DV4-2016BR, DV4-2040US, DV4-2041NR, DV4-2045DX, DV4-2046NR, DV4-2049US, DV4-2049WM, DV4-2051XX, DV4-2058NR, DV4-2103TU, DV4-2103TX, DV4-2104TU, DV4-2105TU, DV4-2106TX, DV4-2107TX, DV4-2108TX, DV4-2113LA, DV4-2114TX, DV4-2116TX, DV4-2118TX, DV4-2119TX, DV4-2124TX, DV4-2125TX, DV4-2140US, DV4-2141NR, DV4-2142NR, DV4-2145DX, DV4-2148CA, DV4-2153CL, DV4-2155DX, DV4-2160US, DV4-2161NR, DV4-2162NR, DV4-2164US, DV4-2165DX, DV4-2167SB, DV4-2169NR, DV4-2170US, DV4-4001XX, DV4-4004XX, DV4-4030US, DV4-4031HE, DV4-4032NR, DV4-4033NR, DV4-4038CA, DV4-4048CA, DV4-4140US, DV4-4141US, DV4-4270US, DV4-2100, DV4T, DV4T-1000, DV4T-1100, DV4T-1200, DV4T-1200SE, DV4T-1300, DV4T-1300SE, DV4T-1400, DV4T-1500, DV4T-1600, DV4T-4000, DV4T-4100, DV4T-4200, DV4Z-1000, DV4Z-1100, DV4Z-1200, DV5, DV5-1000, DV5-1000T, DV5-1000US, DV5-1000Z, DV5-1001AU, DV5-1001TU, DV5-1001TX, DV5-1001XX, DV5-1002, DV5-1002AX, DV5-1002NR, DV5-1002TX, DV5-1002US, DV5-1002XX, DV5-1003CL, DV5-1003NR, DV5-1003XX, DV5-1004NR, DV5-1004TU, DV5-1004TX, DV5-1004XX, DV5-1005TU, DV5-1006AX, DV5-1006TU, DV5-1007, DV5-1007AX, DV5-1007CA, DV5-1007CL, DV5-1007TU, DV5-1008AX, DV5-1008CA, DV5-1008TU, DV5-1008TX, DV5-1009TU, DV5-1010, DV5-1010TU, DV5-1010US, DV5-1011, DV5-1011TX, DV5-1012TX, DV5-1013TX, DV5-1014TX, DV5-1015NR, DV5-1017NR, DV5-1017TX, DV5-1018TX, DV5-1019, DV5-1020, DV5-1022TX, DV5-1023TX, DV5-1024TX, DV5-1025TX, DV5-1026TX, DV5-1027TX, DV5-1028CA, DV5-1028TX, DV5-1029TX, DV5-1030, DV5-1030TX, DV5-1031TX, DV5-1032, DV5-1032TX, DV5-1033TX, DV5-1034CA, DV5-1034TX, DV5-1037TX, DV5-1038TX, DV5-1039TX, DV5-1040EW, DV5-1040TX, DV5-1041TX, DV5-1042TX, DV5-1043TX, DV5-1044CA, DV5-1044TX, DV5-1045TX, DV5-1046TX, DV5-1053TX, DV5-1054TX, DV5-1055TX, DV5-1056TX, DV5-1057TX, DV5-1058TX, DV5-1059TX, DV5-1062TX, DV5-1063TX, DV5-1064TX, DV5-1093XX, DV5-1094XX, DV5-1096XX, DV5-1098NR, DV5-1098XX, DV5-1099NR, DV5-1099XX, DV5-1100, DV5-1100Z, DV5-1102AX, DV5-1102TX, DV5-1103TU, DV5-1103TX, DV5-1104TX, DV5-1105AX, DV5-1105TU, DV5-1105TX, DV5-1107AX, DV5-1109AX, DV5-1111CA, DV5-1112AX, DV5-1112CA, DV5-1113, DV5-1113US, DV5-1114AX, DV5-1114TX, DV5-1115TX, DV5-1116, DV5-1116US, DV5-1118CA, DV5-1119NR, DV5-1119TX, DV5-1120, DV5-1120US, DV5-1121CA, DV5-1122TX, DV5-1123TX, DV5-1124TX, DV5-1125NR, DV5-1125TX, DV5-1126TX, DV5-1127CL, DV5-1128CA, DV5-1130CA, DV5-1130TX, DV5-1132, DV5-1132US, DV5-1133CA, DV5-1135CA, DV5-1135TX, DV5-1136TX, DV5-1137TX, DV5-1138CA, DV5-1138NR, DV5-1140, DV5-1140US, DV5-1143TX, DV5-1150, DV5-1150US, DV5-115

7CA, DV5-1159SE, DV5-1160, DV5-1160US, DV5-1166, DV5-1166US, DV5-1174CA, DV5-1183CL, DV5-1196XX, DV5-1197XX, DV5-1198XX, DV5-1199XX, DV5-1201AX, DV5-1201TU, DV5-1201TX, DV5-1202AU, DV5-1202AX, DV5-1202TU, DV5-1202TX, DV5-1203AU, DV5-1203TX, DV5-1204AX, DV5-1204TU, DV5-1205AU, DV5-1205AX, DV5-1205TU, DV5-1206AU, DV5-1206AX, DV5-1206TU, DV5-1207AU, DV5-1207TU, DV5-1208AU, DV5-1208TU, DV5-1209AX, DV5-1210AX, DV5-1211AX, DV5-1212AX, DV5-1213AX, DV5-1214AX, DV5-1215AX, DV5-1215CA, DV5-1216AX, DV5-1216TX, DV5-1217TX, DV5-1218AX, DV5-1220TX, DV5-1224TX, DV5-1225CA, DV5-1225TX, DV5-1227TX, DV5-1228TX, DV5-1229TX, DV5-1230TX, DV5-1230US, DV5-1231TX, DV5-1233SE, DV5-1234SE, DV5-1234TX, DV5-1235DX, DV5-1236TX, DV5-1237TX, DV5-1238TX, DV5-1250US, DV5-1251NR, DV5-1253CL, DV5-1387NR, DV5-1388US, DV5-1392NR, DV5-2003XX, DV5-2035DX, DV5-2043CL, DV5-2045DX, DV5-2051XX, DV5-2052XX, DV5-2070US, DV5-2072NR, DV5-2073NR, DV5-2074DX, DV5-2075NR, DV5-2077CL, DV5-2080BR, DV5-2129WM, DV5-2130US, DV5-2132DX, DV5-2134CA, DV5-2134US, DV5-2135DX, DV5-2138CA, DV5-2144CA, DV5-2155DX, DV5-2230US, DV5-2231NR, DV5-2238NR, DV5-2268CA, DV5105EU, DV5118EU, DV5T, DV5T-1000, DV5T-1100, DV5T-1200SE, DV5T-2000, DV5T-2100, DV5T-2200, DV5TSE-1100, DV5Z, DV5Z-1000, DV5Z-1100, DV5Z-1200, DV6, DV6-1001TX, DV6-1001XX, DV6-1004TX, DV6-1005TX, DV6-1006TX, DV6-1007TX, DV6-1008TX, DV6-1010TX, DV6-1014TX, DV6-1015TX, DV6-1027NR, DV6-1030CA, DV6-1030US, DV6-1038CA, DV6-1050US, DV6-1051XX, DV6-1053CL, DV6-1054CL, DV6-1101AU, DV6-1102AU, DV6-1102TU, DV6-1103AU, DV6-1103TU, DV6-1104AU, DV6-1104TU, DV6-1105AU, DV6-1105TU, DV6-1106AU, DV6-1107AU, DV6-1107AX, DV6-1108AU, DV6-1108AX, DV6-1109AU, DV6-1109AX, DV6-1110AU, DV6-1111AX, DV6-1112AX, DV6-1113TX, DV6-1114TX, DV6-1115TX, DV6-1116TX, DV6-1117TX, DV6-1118TX, DV6-1119TX, DV6-1120TX, DV6-1122US, DV6-1127TX, DV6-1131TX, DV6-1133TX, DV6-1149WM, DV6-1158TX, DV6-1201AU, DV6-1202AU, DV6-1202TU, DV6-1203AU, DV6-1203AX, DV6-1203TU, DV6-1203TX, DV6-1204TX, DV6-1206AU, DV6-1207AU, DV6-1207AX, DV6-1208AU, DV6-1221AX, DV6-1221TX, DV6-1222AX, DV6-1230US, DV6-1234NR, DV6-1234TX, DV6-1238NR, DV6-1240US, DV6-1241TX, DV6-1243CL, DV6-1244SB, DV6-1247CL, DV6-1250US, DV6-1253CL, DV6-1255TX, DV6-1256TX, DV6-1259DX, DV6-1260SE, DV6-1261TX, DV6-1263CL, DV6-1264TX, DV6-1265TX, DV6-1266TX, DV6-1268NR, DV6-1268TX, DV6-1270LA, DV6-1280US, DV6-1299LX, DV6-1303TU, DV6-1306EW, DV6-1308EW, DV6-1309TX, DV6-1310EQ, DV6-1310SL, DV6-1310TX, DV6-1314TX, DV6-1315TX, DV6-1316TX, DV6-1318TX, DV6-1320EQ, DV6-1320SL, DV6-1320SP, DV6-1322TX, DV6-1325TX, DV6-1330EA, DV6-1330EP, DV6-1330EQ, DV6-1330SP, DV6-1330TX, DV6-1331TX, DV6-1334TX, DV6-1334US, DV6-1335TX, DV6-1340EA, DV6-1340SL, DV6-1350SL, DV6-1350US, DV6-1351NR, DV6-1352DX, DV6-1353CL, DV6-1354US, DV6-1355DX, DV6-1359WM, DV6-1360US, DV6-1361SB, DV6-1362NR, DV6-1363CL, DV6-1375DX, DV6-1380EK, DV6-1441EE, DV6-1444EE, DV6-1446EE, DV6-1460EL, DV6-2001XX, DV6-2005AU, DV6-2005SF, DV6-2005SP, DV6-2006AU, DV6-2006TX, DV6-2007AU, DV6-2007AX, DV6-2010EA, DV6-2010EP, DV6-2010EQ, DV6-2010SL, DV6-2012AX, DV6-2015SL, DV6-2018AX, DV6-2019AX, DV6-2020SL, DV6-2025SL, DV6-2043US, DV6-2044DX, DV6-2051XX, DV6-2057CL, DV6-2066DX, DV6-2088DX, DV6-2090EP, DV6-2101AU, DV6-2101TU, DV6-2109AX, DV6-2109TX, DV6-2110AX, DV6-2110EL, DV6-2110SB, DV6-2111AX, DV6-2111TX, DV6-2112EL, DV6-2112TX, DV6-2115SL, DV6-2116EL, DV6-2117AX, DV6-2118EL, DV6-2119EL, DV6-2120EB, DV

6-2120EE, DV6-2120SL, DV6-2123EL, DV6-2124EL, DV6-2125TX, DV6-2126EL, DV6-2126TX, DV6-2127EL, DV6-2127TX, DV6-2128CA, DV6-2129EL, DV6-2129TX, DV6-2130EL, DV6-2131EE, DV6-2131EL, DV6-2134EE, DV6-2134TX, DV6-2135EE, DV6-2136EL, DV6-2137EL, DV6-2137SL, DV6-2138EE, DV6-2141SL, DV6-2142SL, DV6-2143TX, DV6-2144NR, DV6-2144TX, DV6-2145EL, DV6-2150US, DV6-2151CL, DV6-2151EE, DV6-2152NR, DV6-2154EE, DV6-2155DX, DV6-2155SE, DV6-2156TX, DV6-2157EL, DV6-2157SB, DV6-2157TX, DV6-2157US, DV6-2157WM, DV6-2158EE, DV6-2158NR, DV6-2158TX, DV6-2159EE, DV6-2159TX, DV6-2160EL, DV6-2162NR, DV6-2162SL, DV6-2163SL, DV6-2163TX, DV6-2164CA, DV6-2164EE, DV6-2164SL, DV6-2166SB, DV6-2168SL, DV6-2170SL, DV6-2170US, DV6-2171EE, DV6-2171NR, DV6-2171SL, DV6-2173CL, DV6-2175TX, DV6-2176TX, DV6-2180US, DV6-2182NR, DV6-2190EP, DV6-2190US, DV6-2192EL, DV6-3001AU, DV6-3001TX, DV6-3001XX, DV6-3002AU, DV6-3002XX, DV6-3003TU, DV6-3003XX, DV6-3004AX, DV6-3004TX, DV6-3006AX, DV6-3006TU, DV6-3007AX, DV6-3008TX, DV6-3010US, DV6-3012HE, DV6-3013CL, DV6-3013NR, DV6-3015TX, DV6-3016TX, DV6-3017NR, DV6-3019WM, DV6-3020US, DV6-3022US, DV6-3023NR, DV6-3023TX, DV6-3024TX, DV6-3025DX, DV6-3030US, DV6-3031NR, DV6-3031TX, DV6-3032NR, DV6-3033CL, DV6-3033HE, DV6-3033TX, DV6-3034NR, DV6-3034TX, DV6-3035TX, DV6-3036TX, DV6-3037NR, DV6-3037SB, DV6-3037TX, DV6-3040TX, DV6-3040US, DV6-3041TX, DV6-3049TX, DV6-3050US, DV6-3051XX, DV6-3053HE, DV6-3053TX, DV6-3055DX, DV6-3108CA, DV6-3109CA, DV6-3114CA, DV6-3118CA, DV6-3120US, DV6-3121NR, DV6-3122US, DV6-3123CL, DV6-3124NR, DV6-3127DX, DV6-3129NR, DV6-3130US, DV6-3131NR, DV6-3132NR, DV6-3133NR, DV6-3134CA, DV6-3134NR, DV6-3138CA, DV6-3140US, DV6-3143CA, DV6-3143CL, DV6-3143US, DV6-3144CA, DV6-3145DX, DV6-3147CA, DV6-3147SB, DV6-3150US, DV6-3152NR, DV6-3153NR, DV6-3155DX, DV6-3158CA, DV6-3160US, DV6-3163CL, DV6-3163NR, DV6-3167CA, DV6-3170CA, DV6-3174CA, DV6-3181NR, DV6-3194CA, DV6-3210US, DV6-3212NR, DV6-3216US, DV6-3217CL, DV6-3223CL, DV6-3225DX, DV6-3227CL, DV6-3230US, DV6-3231NR, DV6-3232NR, DV6-3234NR, DV6-3236NR, DV6-3237NR, DV6-3238NR, DV6-3240CA, DV6-3240US, DV6-3243CL, DV6-3250US, DV6-3257CL, DV6-3257SB, DV6-3259WM, DV6-3263CL, DV6-3264CA, DV6-3267CL, DV6-3268CA, DV6-3270CA, DV6-3275CA, DV6-3278CA, DV6-3280CA, DV6-3284CA, DV6-3286CA, DV6-3287CL, DV6-3370CA, DV6-3375CA, DV6-4001XX, DV6-4051NR, DV6-4052NR, DV6-4053CA, DV6-6013CL, DV6-6020CA, DV6-6033CL, DV6-6040CA, DV6-6047CL, DV6-6051XX, DV6-6070CA, DV6-6090US, DV6-6091NR, DV6-6096NR, DV6-6097NR, DV6-6104CA, DV6-6104NR, DV6-6106NR, DV6-6108US, DV6-6110US, DV6-6111NR, DV6-6112NR, DV6-6113CL, DV6-6115NR, DV6-6116NR, DV6-6117DX, DV6-6118NR, DV6-6119WM, DV6-6120US, DV6-6121HE, DV6-6123CL, DV6-6123NR, DV6-6124CA, DV6-6126NR, DV6-6127CL, DV6-6128CA, DV6-6128NR, DV6-6130CA, DV6-6130US, DV6-6131US, DV6-6135CA, DV6-6135DX, DV6-6136NR, DV6-6138NR, DV6-6140US, DV6-6144CA, DV6-6145CA, DV6-6145DX, DV6-6148CA, DV6-6148NR, DV6-6149NR, DV6-6150US, DV6-6152NR, DV6-6153CA, DV6-6153CL, DV6-6154NR, DV6-6155CA, DV6-6157NR, DV6-6158NR, DV6-6159US, DV6-6161HE, DV6-6163CL, DV6-6167CL, DV6-6169US, DV6-6170US, DV6-6172NR, DV6-6173CL, DV6-6175CA, DV6-6178CA, DV6-6180US, DV6-6181NR, DV6-6182NR, DV6-6183NR, DV6-6184CA, DV6-6185NR, DV6-6186NR, DV6-6188CA, DV6-6190US, DV6-6193CA, DV6-6195CA, DV6-6B19WM, DV6-6B21HE, DV6-6B22HE, DV6-6B27NR, DV6-6B47DX, DV6-6B48NR, DV6-6B51NR, DV6-6B75CA, DV6-6B83CA, DV6-6C10US, DV6-6C

13CL, DV6-6C14NR, DV6-6C15NR, DV6-6C40CA, DV6-6C40US, DV6-6C43CL, DV6-6C50C
A, DV6-6C50US, DV6-6C53CL, DV6-6C53NR, DV6327CA, DV6327CL, DV6T-1000, DV6T-1
100, DV6T-1200, DV6T-1300, DV6T-2000, DV6T-2300, DV6T-3000, DV6T-3100, DV6T-3200
, DV6T-4000, DV6T-6000, DV6T-6100, DV6T-6B00, DV6T-6C00, DV6Z-1000, DV6Z-1100, D
V6Z-2000, DV6Z-2100, DV6Z-3000, DV6Z-3100, DV6Z-3200, DV6Z-6100, DV6Z-6B00, DV6
Z-6C00, DV7, DV7-1000, DV7-1001, DV7-1001TX, DV7-1001XX, DV7-1002, DV7-1002XX, D
V7-1003, DV7-1003TX, DV7-1003XX, DV7-1004, DV7-1004TX, DV7-1005, DV7-1006, DV7-1
006TX, DV7-1007, DV7-1008, DV7-1008TX, DV7-1009, DV7-1009TX, DV7-1010, DV7-1010,
DV7-1010TX, DV7-1011, DV7-1011TX, DV7-1012, DV7-1012TX, DV7-1013, DV7-1013TX, D
V7-1014, DV7-1014CA, DV7-1015, DV7-1016, DV7-1016NR, DV7-1016TX, DV7-1017, DV7-
1017TX, DV7-1018, DV7-1018TX, DV7-1019, DV7-1020, DV7-1020TX, DV7-1021, DV7-1021
TX, DV7-1022, DV7-1023, DV7-1023CL, DV7-1023TX, DV7-1024, DV7-1024TX, DV7-1025,
DV7-1025NR, DV7-1025TX, DV7-1026, DV7-1027, DV7-1027CA, DV7-1027TX, DV7-1029, D
V7-1030, DV7-1030TX, DV7-1031, DV7-1034, DV7-1034CA, DV7-1034TX, DV7-1035, DV7-1
038, DV7-1038CA, DV7-1040, DV7-1045, DV7-1050, DV7-1051, DV7-1051XX, DV7-1052, D
V7-1052XX, DV7-1053, DV7-1053XX, DV7-1055, DV7-1060, DV7-1065, DV7-1070, DV7-107
5, DV7-1080, DV7-1090, DV7-1093, DV7-1094, DV7-1095, DV7-1098, DV7-1099, DV7-1100,
DV7-1101XX, DV7-1102TX, DV7-1102XX, DV7-1103TX, DV7-1103XX, DV7-1123CA, DV7-1
127CL, DV7-1128CA, DV7-1129WM, DV7-1130, DV7-1130US, DV7-1132NR, DV7-1133CL,
DV7-1134, DV7-1134US, DV7-1135NR, DV7-1137, DV7-1137US, DV7-1150, DV7-1151XX,
DV7-1153CA, DV7-1157CL, DV7-1170, DV7-1170US, DV7-1174CA, DV7-1175NR, DV7-117
7CA, DV7-1183CL, DV7-1201TX, DV7-1201XX, DV7-1206TX, DV7-1207TX, DV7-1208TX, D
V7-1209TX, DV7-1210TX, DV7-1214TX, DV7-1215TX, DV7-1216TX, DV7-1223CA, DV7-122
8CA, DV7-1232NR, DV7-1240US, DV7-1243CL, DV7-1245CA, DV7-1245DX, DV7-1247CL,
DV7-1253CA, DV7-1261WM, DV7-1262US, DV7-1264NR, DV7-1267CL, DV7-1270CA, DV7-
1270US, DV7-1273CL, DV7-1275DX, DV7-1279WM, DV7-1285DX, DV7-1424NR, DV7-1426
NR, DV7-1444US, DV7-1448DX, DV7-1450US, DV7-1451NR, DV7-1464NR, DV7-1468NR,
DV7-2001XX, DV7-2003TX, DV7-2012TX, DV7-2013TX, DV7-2016TX, DV7-2021TX, DV7-20
40CA, DV7-2040US, DV7-2043CL, DV7-2107TX, DV7-2110TX, DV7-2111US, DV7-2114TX,
DV7-2122TX, DV7-2123TX, DV7-2124TX, DV7-2125TX, DV7-2126TX, DV7-2128TX, DV7-21
70US, DV7-2173CL, DV7-2177CL, DV7-2180US, DV7-2185DX, DV7-2204TX, DV7-2206TX,
DV7-2210TX, DV7-2211TX, DV7-2212EF, DV7-2212SF, DV7-2212TX, DV7-2230EA, DV7-22
70EF, DV7-2270US, DV7-2273CL, DV7-2277CL, DV7-2301NR, DV7-3001XX, DV7-3002TX,
DV7-3003TX, DV7-3010EW, DV7-3020EW, DV7-3025SF, DV7-3030EW, DV7-3051XX, DV7-
3057NR, DV7-3060US, DV7-3061NR, DV7-3063CL, DV7-3065DX, DV7-3067CL, DV7-3067N
R, DV7-3069WM, DV7-3078NR, DV7-3079NR, DV7-3079WM, DV7-3080ED, DV7-3080US,
DV7-3085DX, DV7-3089NR, DV7-3090ED, DV7-3101TX, DV7-3108TX, DV7-3112TX, DV7-3
113TX, DV7-3114TX, DV7-3115TX, DV7-3116TX, DV7-3118TX, DV7-3120TX, DV7-3126TX,
DV7-3127TX, DV7-3130SB, DV7-3133EL, DV7-3140EB, DV7-3148CA, DV7-3155EB, DV7-3
155EL, DV7-3160EB, DV7-3160EL, DV7-3160EP, DV7-3160US, DV7-3162NR, DV7-3163CL,
DV7-3164CL, DV7-3165DX, DV7-3165EB, DV7-3165EL, DV7-3166EB, DV7-3166NR, DV7-3
167NR, DV7-3169WM, DV7-3171NR, DV7-3173NR, DV7-3174CA, DV7-3174NR, DV7-3180
US, DV7-3183CL, DV7-3183NR, DV7-3186CL, DV7-3187CL, DV7-3188CL, DV7-4001TX, DV
7-4003TX, DV7-4003XX, DV7-4007TX, DV7-4009TX, DV7-4010TX, DV7-4013TX, DV7-4021

TX, DV7-4022TX, DV7-4051NR, DV7-4053CL, DV7-4060US, DV7-4061NR, DV7-4065DX, DV7-4069WM, DV7-4070US, DV7-4071NR, DV7-4073NR, DV7-4077CL, DV7-4080US, DV7-4083CL, DV7-4087CL, DV7-4101XX, DV7-4104CA, DV7-4127CA, DV7-4138CA, DV7-4148CA, DV7-4151NR, DV7-4153CL, DV7-4154CA, DV7-4157CL, DV7-4165DX, DV7-4167CA, DV7-4169WM, DV7-4170US, DV7-4171US, DV7-4173US, DV7-4174CA, DV7-4177CA, DV7-4177NR, DV7-4178CA, DV7-4178NR, DV7-4179NR, DV7-4180US, DV7-4182NR, DV7-4183CL, DV7-4190US, DV7-4191NR, DV7-4197CL, DV7-4198CA, DV7-4223CA, DV7-4248CA, DV7-4260CA, DV7-4263CL, DV7-4264CA, DV7-4267CL, DV7-4269WM, DV7-4270US, DV7-4272US, DV7-4273US, DV7-4274NR, DV7-4276NR, DV7-4277NR, DV7-4278NR, DV7-4280US, DV7-4283CL, DV7-4285DX, DV7-4287CL, DV7-4288CA, DV7-4289US, DV7-4290US, DV7-4293NR, DV7-4294NR, DV7-4295US, DV7-4296NR, DV7-4297CL, DV7-5001XX, DV7-5070CA, DV7-6001XX, DV7-6070CA, DV7-6113CL, DV7-6123CL, DV7-6135DX, DV7-6143CL, DV7-6153NR, DV7-6154NR, DV7-6156NR, DV7-6157CL, DV7-6157NR, DV7-6158CA, DV7-6160CA, DV7-6163CL, DV7-6163US, DV7-6165US, DV7-6166NR, DV7-6168NR, DV7-6169NR, DV7-6175US, DV7-6178US, DV7-6179US, DV7-6184CA, DV7-6185US, DV7-6187CL, DV7-6188CA, DV7-6191NR, DV7-6193CA, DV7-6195US, DV7-6197CA, DV7-6199US, DV7-6B01XX, DV7-6B32US, DV7-6B55DX, DV7-6B56NR, DV7-6B57NR, DV7-6B63US, DV7-6B71NR, DV7-6B73NR, DV7-6B75NR, DV7-6B77DX, DV7-6B78US, DV7-6B91NR, DV7-6C20US, DV7-6C23CL, DV7-6C43CL, DV7-6C50CA, DV7-6C60US, DV7-6C63NR, DV7-6C70CA, DV7-6C80US, DV7-6C90US, DV7T, DV7T-1000, DV7T-1100, DV7T-1200, DV7T-2000, DV7T-2200, DV7T-3000, DV7T-3300, DV7T-4000, DV7T-4100, DV7T-5000, DV7T-6000, DV7T-6100, DV7T-6B00, DV7T-6C00, DV7Z, DV7Z-1000, DV7Z-1100, DV8-1000EB, DV8-1001XX, DV8-1003TX, DV8-1010TX, DV8-1080ED, DV8-1100EB, DV8-1107TX, DV8-1108TX, DV8-1200, DV8T-1000, DV8T-1100, DV8T-1200, G32, G4-1010U, G4-1011N, G4-1015D, G4-1016D, G4-1020U, G4-1021C, G4-1022C, G4-1051X, G4-1104D, G4-1107N, G4-1117D, G4-1117N, G4-1118N, G4-1125D, G4-1135D, G4-1137C, G4-1164C, G4-1167C, G4-1204N, G4-1207N, G4-1213N, G4-1215D, G4-1226N, G4-1229D, G4-1264C, G4-1311N, G42, G4T-1000, G4T-1100, G4T-1200, G4T-1300, G50, G56, G6-1A01, G6-1A19W, G6-1A20C, G6-1A21C, G6-1A22C, G6-1A30U, G6-1A31N, G6-1A32N, G6-1A35C, G6-1A40C, G6-1A43C, G6-1A44C, G6-1A45C, G6-1A46C, G6-1A50C, G6-1A50U, G6-1A52N, G6-1A53N, G6-1A55C, G6-1A59W, G6-1A60U, G6-1A65U, G6-1A66N, G6-1A67N, G6-1A69U, G6-1A71N, G6-1A75D, G6-1B22C, G6-1B23C, G6-1B28C, G6-1B33C, G6-1B34C, G6-1B35C, G6-1B37C, G6-1B38C, G6-1B39W, G6-1B49W, G6-1B50U, G6-1B53C, G6-1B54C, G6-1B55C, G6-1B58C, G6-1B59C, G6-1B59W, G6-1B60U, G6-1B61C, G6-1B61N, G6-1B66N, G6-1B67C, G6-1B68N, G6-1B70U, G6-1B71H, G6-1B74C, G6-1B75C, G6-1B76U, G6-1B78N, G6-1B79C, G6-1B79D, G6-1B79U, G6-1B81C, G6-1B87C, G6-1B97C, G6-1C13C, G6-1C31N, G6-1C32N, G6-1C33C, G6-1C35D, G6-1C36H, G6-1C37C, G6-1C39C, G6-1C40C, G6-1C41C, G6-1C43N, G6-1C44W, G6-1C45D, G6-1C51N, G6-1C53N, G6-1C54W, G6-1C55C, G6-1C55N, G6-1C56N, G6-1C57D, G6-1C58C, G6-1C58D, G6-1C59N, G6-1C60C, G6-1C61C, G6-1C62U, G6-1C64C, G6-1C70C, G6-1C71C, G6-1C74C, G6-1C75C, G6-1C77N, G6-1C79N, G6-1C81N, G6-1C87N, G6-1D40CA, G6-1D60CA, G6-1D60U, G6-1D62N, G6-1D72N, G60, G61, G62, G62-120SW, G6T-1A00, G6T-1B00, G6T-1C00, G6T-1D00, G6Z-1C00, G7-1001X, G7-1017C, G7-1019W, G7-1033C, G7-1051X, G7-1070U, G7-1073N, G7-1075D, G7-1075N, G7-1076N, G7-1077N, G7-1081N, G7-1083N, G7-1084N, G7-1085N, G7-1086N, G7-1101X, G7-1113C, G7-1117C, G7-1139W, G7-1149

W, G7-1150U, G7-1153N, G7-1154N, G7-1156N, G7-1158N, G7-1167D, G7-1173C, G7-1173D, G7-1174C, G7-1175C, G7-1178C, G7-1219W, G7-1222N, G7-1227N, G7-1237D, G7-1255D, G7-1257D, G7-1260C, G7-1260U, G7-1261N, G7-1263C, G7-1263N, G7-1264N, G7-1265N, G7-1269N, G7-1270C, G7-1272N, G7-1273N, G7-1277D, G7-1279D, G7-1281N, G7-1310U, G7-1312N, G7-1320C, G7-1330C, G71, G7T-1000, G7T-1100, G7T-1200, HDX16, HDX18,

ProBook series

4230S, 4310S, 4311S, 4320S, 4320T, 4321S, 4325S, 4326S, 4330S, 4331S, 4410S, 4411S, 4415S, 4416S, 4420S, 4421S, 4425S, 4430S, 4431S, 4435S, 4436S, 4510S, 4510S/CT, 4515S, 4515S/CT, 4520, 4520S, 4525S, 4530S, 4535S, 4710S, 4710S/CT, 4720S, 4730S, 5220M, 5310M, 5320M, 5330M, 6360B, 6440B, 6445B, 6450B, 6455B, 6460B, 6465B, 6540B, 6545B, 6550B, 6555B, 6560B, 6565B,

Rugged series

NR3600, NR3610,

Tablet PC series

TC4400,

TouchSmart series

TM2, TM2-1000EE, TM2-1001XX, TM2-1004TX, TM2-1005TX, TM2-1010EE, TM2-1012TX, TM2-1013TX, TM2-1014TX, TM2-1016TX, TM2-1018TX, TM2-1019TX, TM2-1020TX, TM2-1070US, TM2-1072NR, TM2-1073NR, TM2-1079CL, TM2-2001SL, TM2-2001XX, TM2-2050US, TM2-2052NR, TM2-2057SB, TM2-2150CA, TM2-2150US, TM2-2151NR, TM2T-1000, TM2T-1100, TM2T-2100, TM2T-2200, TX2, TX2-1002AU, TX2-1012NR, TX2-1016AU, TX2-1017AU, TX2-1018AU, TX2-1019AU, TX2-1020AU, TX2-1020CA, TX2-1020US, TX2-1022AU, TX2-1024CA, TX2-1025DX, TX2-1027CA, TX2-1030CM, TX2-1031CM, TX2-1032CM, TX2-1051XX, TX2-1070BR, TX2-1102AU, TX2-1103AU, TX2-1104AU, TX2-1105AU, TX2-1106AU, TX2-1107AU, TX2-1108AU, TX2-1109AU, TX2-1110AU, TX2-1118AU, TX2-1120AU, TX2-1122AU, TX2-1205AU, TX2-1207AU, TX2-1208AU, TX2-1209AU, TX2-1270US, TX2-1274NR, TX2-1277NR, TX2-1305AU, TX2-1307AU, TX2-1308AU, TX2-1310AU, TX2-1323AU, TX2-1326AU, TX2-1370US, TX2-1375DX, TX2-1377NR, TX2Z-1000, TX2Z-1300,

HP/Compaq 19.5V3.33A 7.4mm*5.0mm 65W

HP

EliteBook Revolve series

810 CONVERTIBLE, 810 G2, 810 G3,

Pavilion Chromebook series

14-C010US,

Pavilion SleekBook series

15, 15-B004SG,

Pavilion Sleekbook TouchSmart series

15-B153SG,

ProBook series

4340S, 450 G0, 455 G1, 455 G1 H6P57EA, 650 G1,

ZBook series

14 WORKSTATION

19.5V2.31A 7.4mm*5.0mm 45W

HP

EliteBook series

720 G1, 725 G2, 740 G1, 745 G2, 750 G1, 755 G2, 810 G1, 810 G2, 820 G1, 840 G1, 850 G1,

EliteBook Folio series

9470M, 9480M,

EliteBook Revolve series

810 G1 TABLET, 810 G2 TABLET,

ProBook series

350 G1, 430 G2, 440 G2, 445 G2, 450 G2, 455 G2,

19.5V2.05A 7.4mm*5.0mm

HP series

EliteBook Folio

9470M,

Mini Series

MINI 5101, MINI 5102, MINI 5103

END H14

H15

HP 18.5V3.5A 4.8mm*1.7mm 65W

Compaq

Armada series

100S, 110, 1100, 110S, E300, E500, E500S, E700, M300, M500, M700, V300,

Evo series

800C, 800V, 800W, N1000, N1000C, N1000V, N1005V, N110, N150, N200, N400, N400C, N410C, N600, N600C, N610, N610C, N610V, N620C, N800, N8000, N800C, N800V, N800W,

Presario series

1010 N, 1201VU, 1203VU, 1204VU, 1205VU, 1207VU, 1209VU, 1210VU, 1211VU, 1212VU, 1218TU, 1223TU, 1224TU, 1225TU, 1226TU, 1227TU, 1228TU, 1232TU, 1233TU, 1237TU, 1240TU, 1241TU, 1244TU, 1245TU, 1247TU, 1248TU, 1250TU, 1251TU, 1253TU, 1254TU, 1256TU, 1262TU, 1265TU, 1267TU, 1268TU, 1269TU, 1270TU, 1271TU, 1272TU, 1273TU, 1274TU, 1278TU, 1279TU, 1280TU, 1281TU, 1283TU, 1284TU, 1285TU, 1290TU, 1292TU, 1293TU, 1295TU, 1298TU, 1299TU, 1500, 1500SC, 1500US, 1501, 1502, 1502SC, 1503, 1505US, 1506, 1507, 1508, 1509, 1510, 1510US, 1511, 1512, 1516, 1520, 1520US, 1522, 1525, 1525US, 1531, 1535, 1538, 1550, 1555, 1568, 1570, 1572, 1580, 1814TU, 1822TU, 1823TU, 1825TU, 1826TU, 1827TU, 1901JP, 1902JP, 1903JP, 1928TU, 1929TU, 2018AL, 2021AL, 2023AL, 2024AP, 2029AP, 2037AP, 2038AP, 2200, 2200 N, 2200LA, 2201AP, 2201US, 2201XX, 2202XX, 2203AL, 2203AP, 2203AS, 2203US, 2204AL, 2204AP, 2204AS, 2204US, 2206AL, 2206AP, 2206US, 2208AP, 2208AS, 2209CL, 2210AP, 2210US, 2211AP, 2212AP, 2213AP, 2214AP, 2215AP, 2216AP, 2217AP, 2218AP, 2218RS, 2219AP, 2221AP, 2222AP, 2223US, 2224AP, 2225AP, 2226CL, 2227US, 2228AP, 2229AP, 2230AP, 2231AP, 2231US, 2232AP, 2232US, 2233AP, 2235AP, 2236AP, 2236CL, 2239AP, 2242AP, 2243AP, 2244AP, 2245AP, 2246AP, 2247AP, 2248AP, 2249AP, 2250AP, 2251AP, 2253AP, 2254AP, 2255AP, 2256AP, 2257AP, 2258AP, 2259AP, 2260AP, 2261AP, 2262AP, 2263AP, 2264AP, 2265AP, 2266AP, 2267AP, 2268AP, 2269AP, 2270AP, 2271AP, 2800, 2800CA, 2800T, 2800US, 2801CL, 2805US, 2817TX, 2818TX, 2819TX, 2820TX, 2830TX, 2831TX, 300, 620, 900, 900US, 905, 905US, 910, 910US, 912, 912RSH, 918, 918RSH, 920, 920US, A900, A909US, A910CA, A913CL, A916NR, A918CA, A924CA, A928CA, A930CA, A930XX, A931NR, A935TU, A936CA, A936TU, A938CA, A938TU, A939CA, A940CA, A940NR, A944CA, A945US, A948CA, A949NR, A966TU, A968TU, A969TU, A970TU, A971TU, B1011, B1013, B1014, B1015, B1015A, B1200, B1900, B2000, B2005AP, B2017AL, B3800, B3807AP, B3825AP, C300, C300EU, C301NR, C302NR, C303NR, C304NR, C305LA, C306US, C307NR, C310EA, C310EU, C315LA, C318LA, C350EU, C399XX, C500, C500, C500EA, C500EU, C500T, C501NR, C501XX, C502CA, C502EA, C502EU, C502US, C502XX, C503WM, C504EA, C504EU, C504US, C506CA, C507TU, C507US, C508US, C509NR, C518LA, C540EA, C542EA, C550, C550XX, C551NR, C551XX, C552CA, C552US, C552XX, C554US, C555NR, C556CA, C557CL, C559CL, C560US, C563NR, C564US, C567TU, C568LA, C568TU, C571NR, C581TU, C581WM, C700, C700LA, C700T, C700XX, C701LA, C701XX, C702LA, C702XX, C703LA, C705LA, C706NR, C707LA, C708LA, C709LA, C709TU,

C710BR, C710TU, C711TU, C712NR, C713NR, C714NR, C715NR, C715TU, C717NR, C717TU, C718TU, C720BR, C720TU, C721TU, C725BR, C727US, C730BR, C730T, C730XX, C731XX, C732XX, C735TU, C737BR, C741TU, C743TU, C744TU, C745TU, C746TU, C747TU, C748TU, C749TU, C750LA, C750T, C750TU, C751LA, C751NR, C753TU, C754CA, C756CA, C757CA, C757LA, C758CA, C758LA, C759LA, C760LA, C760T, C760XX, C761TU, C762NR, C763TU, C764NR, C766TU, C768CA, C768LA, C768TU, C769CA, C769US, C770US, C771US, C774TU, C775TU, C776CA, C776NR, C776TU, C777CL, C777NR, C777TU, C778TU, C779TU, C780TU, C781TU, C782TU, C792WU, C793WU, C795WU, C796TU, C796WU, C797TU, C798TU, C798VU, F500, F500EA, F500XX, F501XX, F502EA, F502LA, F504AU, F505AU, F505LA, F506LA, F545EA, F550, F552LA, F553CL, F553US, F555LA, F555US, F557US, F557WM, F558US, F560US, F560XX, F561XX, F562LA, F564LA, F565CA, F565LA, F566LA, F572US, F577CL, F579WM, F700, F700XX, F701XX, F702XX, F706LA, F712NR, F722CA, F730US, F731AU, F732AU, F732NR, F736AU, F737AU, F738AU, F739WM, F750CA, F750US, F754CA, F754LA, F755LA, F755US, F756CA, F756LA, F756NR, F759WM, F760XX, F761US, F761XX, F762NR, F763NR, F764AU, F764CA, F765CA, F767CL, F767NR, F768WM, F769CA, F769CL, F769WM, M2000, M2000Z, M2001XX, M2005US, M2007US, M2008AP, M2009AP, M2010US, M2011AP, M2013AP, M2015AP, M2015CL, M2015LA, M2017AP, M2025AP, M2026AP, M2027AP, M2031AP, M2036AP, M2048AP, M2051AP, M2055AP, M2056AP, M2057AP, M2058AP, M2059AP, M2099XX, M2101US, M2105US, M2108US, M2200, M2203AU, M2214LA, M2215EA, M2236AP, M2246AP, M2249AU, M2250AP, M2250AU, M2251AP, M2254AP, M2255AU, M2256AU, M2257AU, M2257TU, M2258AU, M2258TU, M2259AU, M2259TU, M2260AU, M2261TU, M2262AU, M2262TU, M2263AU, M2263TU, M2264AU, M2265TU, M2267TU, M2273TU, M2274TU, M2276TU, M2277TU, M2299XX, M2301NR, M2301XX, M2305NR, M2308EA, M2370EA, M2401EA, M2401XT, M2405LA, M2406EA, M2411EA, M2412EA, M2425LA, M2500 C, M2501TU, M2502AU, M2502TU, M2503AU, M2503TU, M2504AU, M2504TU, M2505AU, M2505TU, M2506AU, M2506TU, M2507TU, M2508AU, M2508TU, M2509AU, M2510AU, M2510TU, M2511AU, M2512TU, M2513AU, M2513TU, M2514AU, M2514TU, M2515LA, M2516TU, M2517TU, M2519TU, M2520TU, M2521TU, M2522TU, M2523TU, M2524TU, M2525TU, M2526TU, M2527TU, M2528TU, M2529TU, M2599XX, V1000, V1001AD, V1001AP, V1002AD, V1002AP, V1003AD, V1003AP, V1004, V1004AD, V1004AP, V1005AD, V1005AP, V1006AD, V1006AP, V1007AD, V1007AP, V1008AD, V1008AP, V1009AP, V1010AP, V1011AP, V1012AP, V1013AP, V1014AP, V1015AP, V1016AP, V1017AP, V1018AP, V1019AP, V1020AP, V1021AP, V1022AP, V1023AP, V1024AP, V1025AP, V1026AP, V1027AP, V1028AP, V1029AP, V1030AP, V1031AP, V1032AP, V1033AP, V1034AP, V1035AP, V1036AP, V1037AP, V1038AP, V1039AP, V1040AP, V1041AP, V1042AP, V1043XX, V1044AP, V1045AP, V1046AP, V1047AP, V1048AP, V1049AP, V1050AP, V1051AP, V1052AP, V1053AP, V1054AP, V1055AP, V1056AP, V1057AP, V1058AP, V1059AP, V1060AP, V1061AP, V1062AP, V1065AP, V1066AP, V1067AP, V1068AP, V1069AP, V1070AP, V1071AP, V1072AP, V1074AP, V1075AP, V1100, V1101AP, V1102AP, V1103AP, V1105AP, V1106AP, V1107AP, V1108AP, V1109AP, V1110AP, V1113AP, V1114AP, V1115AP, V1116AP, V1117AP, V1118AP, V1119AP, V1120AP, V1121AP, V1122AP, V1125AP, V1126AP, V1130AP, V1131AP, V1132AP, V1133AP, V1134AP, V2000, V2000T, V2000Z, V2001AP, V2001XX, V2002XX, V2009XX, V2010, V2010US, V2015AP, V2016AP, V2021AP, V2022AP, V2023AP, V2024AP, V2025AP, V2027AP,

V2030, V2030AP, V2030US, V2031AP, V2032AP, V2033AP, V2034AP, V2037AP, V2038AP, V2040AP, V2041AP, V2042AP, V2043AP, V2044AP, V2045AP, V2046AP, V2069CL, V2100, V2105AP, V2107AP, V2110US, V2111AP, V2115AP, V2116AP, V2124AP, V2128AP, V2130AP, V2131AP, V2135US, V2136AP, V2140US, V2142AP, V2143AP, V2144AP, V2145AP, V2146CL, V2148AP, V2155AP, V2157AP, V2160AP, V2200, V2205US, V2208CL, V2210US, V2220US, V2300, V2304AP, V2304US, V2305AP, V2305US, V2306US, V2309US, V2310US, V2311US, V2312US, V2321US, V2330AP, V2335US, V2341AP, V2342AP, V2345AP, V2347AP, V2350AP, V2351AP, V2356AP, V2358AP, V2359AP, V2361AP, V2362TU, V2374AP, V2377TU, V2378TU, V2379TU, V2382TU, V2383TU, V2385TU, V2387TU, V2389TU, V2390TU, V2391TU, V2392TU, V2393TU, V2394TU, V2397TU, V2398TU, V2398XX, V2399TU, V2399XX, V2400, V2400AU, V2400TU, V2401CL, V2401TU, V2401XX, V2402US, V2403NR, V2403TU, V2404US, V2405AU, V2405TU, V2405US, V2406TU, V2408AU, V2410TU, V2410US, V2411TU, V2412TU, V2413US, V2414NR, V2415LA, V2415TU, V2416TU, V2417AU, V2417LA, V2418TU, V2421AU, V2422AU, V2423AU, V2424NR, V2427AU, V2428AU, V2429AU, V2430AU, V2434AU, V2436AU, V2500, V2508WM, V2552US, V2555US, V2565US, V2570CA, V2570NR, V2575CA, V2575US, V2582US, V2600, V2601TN, V2601TS, V2602XT, V2603TS, V2604TS, V2605LA, V2605TS, V2606AU, V2606CU, V2607CA, V2607CL, V2608AU, V2608CA, V2608WM, V2609AU, V2609TN, V2610AU, V2610CA, V2610TN, V2610TS, V2610US, V2611TN, V2612AU, V2612TN, V2613TN, V2614TN, V2615AU, V2615LA, V2615TN, V2615US, V2616AU, V2616TS, V2617LA, V2618AU, V2619AU, V2619TN, V2620TN, V2621AU, V2622AU, V2624AU, V2624TS, V2625TS, V2626TS, V2627TS, V2628AU, V2628TN, V2628TS, V2629TN, V2629TS, V2630AU, V2630CA, V2630TN, V2630US, V2631AU, V2631TS, V2634AU, V2634TS, V2635AU, V2635TS, V2636TS, V2637TS, V2638TS, V2639TS, V2644TS, V2645TS, V2646TS, V2650AU, V2650CA, V2652AU, V2653AU, V2655US, V2658US, V2660AU, V2663AU, V2664AU, V2665AU, V2665US, V2670CA, V2670US, V2674AU, V2675AU, V2698XX, V2699XX, V2710US, V2718LA, V2718WM, V2720NR, V2720WM, V2721NR, V3000, V3000T, V3000Z, V3001XX, V3002TU, V3002XX, V3003TU, V3003XX, V3004XX, V3006TU, V3008AU, V3009AU, V3010US, V3011XX, V3013AU, V3014AU, V3014TU, V3015NR, V3016US, V3017LA, V3018CL, V3018US, V3019TU, V3019US, V3020TU, V3020US, V3021TU, V3022TU, V3024AU, V3029TU, V3030TU, V3030US, V3031AU, V3031TU, V3032TU, V3036TU, V3038TU, V3042TU, V3043TU, V3044TU, V3047AU, V3048TU, V3049TU, V3051TU, V3052TU, V3053TU, V3055TU, V3071TU, V3072TU, V3100, V3101XX, V3102XX, V3103XX, V3104XX, V3110CA, V3114AU, V3115LA, V3115TU, V3116TU, V3117LA, V3124TU, V3126TU, V3131AU, V3139AU, V3140AU, V3144AU, V3147AU, V3156AU, V3156TU, V3157AU, V3168AU, V3182TU, V3183TU, V3200, V3218LA, V3230AU, V3231AU, V3241AU, V3241TU, V3242TU, V3245AU, V3247AU, V3254TU, V3255AU, V3255TU, V3257TU, V3258TU, V3300, V3301XX, V3302XX, V3311AU, V3312AU, V3315LA, V3317LA, V3336TU, V3337TU, V3338TU, V3339TU, V3340TU, V3341TU, V3342TU, V3350TU, V3400, V3401TU, V3401TX, V3402AU, V3402TX, V3403TX, V3405AU, V3406AU, V3406TX, V3408TX, V3409AU, V3411TX, V3413TX, V3415LA, V3415TU, V3416TX, V3417LA, V3418LA, V3418TU, V3419TU, V3420AU, V3421AU, V3422AU, V3423AU, V3423TX, V3424TX, V3425TU, V3425TX, V3426AU, V3427AU, V3428TU, V3429AU, V3429TU, V3430AU, V3433AU, V3433TU, V3434AU, V3435AU,

V3436TU, V3439AU, V3443TU, V3444AU, V3444TU, V3445AU, V3445TU, V3446AU,
V3447AU, V3448AU, V3449AU, V3450AU, V3501XX, V3523TU, V3531TU, V3532TU,
V3533TU, V3534TU, V3600 C, V3601AU, V3601TU, V3601XX, V3602AU, V3602TU,
V3602XX, V3603TU, V3603TX, V3604AU, V3606TU, V3607AU, V3607TU, V3608TU,
V3609AU, V3609TU, V3610AU, V3610TU, V3611TX, V3612AU, V3612TX, V3613AU,
V3613TX, V3614TX, V3615TX, V3616TX, V3617LA, V3618LA, V3619LA, V3621AU,
V3621TU, V3622TU, V3623TU, V3624TU, V3625TU, V3632AU, V3633AU, V3634AU,
V3635AU, V3636AU, V3637AU, V3638AU, V3639AU, V3640AU, V3642AU, V3643AU,
V3644AU, V3645AU, V3646AU, V3647AU, V3651AU, V3652AU, V3653AU, V3653TU,
V3654TU, V3655TU, V3656TU, V3657TU, V3658TU, V3659TU, V3661TU, V3662TU,
V3663TU, V3664TU, V3665TU, V3666TU, V3667TU, V3668TU, V3669TU, V3670TU,
V3671TU, V3672TU, V3673TU, V3674TU, V3675TU, V3676TU, V3677TU, V3678TU,
V3679TU, V3680TU, V3700 C, V3701AU, V3701TU, V3701VU, V3701XX, V3702TX,
V3702VU, V3703TU, V3703TX, V3703VU, V3704AU, V3704TU, V3704VU, V3705AU,
V3705TU, V3705VU, V3706AU, V3706TU, V3707AU, V3707TU, V3707TX, V3708AU,
V3708TU, V3709AU, V3709TU, V3710AU, V3710TU, V3711AU, V3711TU, V3712TU,
V3713AU, V3713TU, V3714AU, V3714TU, V3715AU, V3715LA, V3715TU, V3716AU,
V3716TU, V3717LA, V3717TU, V3718LA, V3718TU, V3719AU, V3719TU, V3720AU,
V3720TU, V3722AU, V3723AU, V3723TU, V3724AU, V3724TU, V3725TU, V3726AU,
V3726TU, V3727TU, V3728TU, V3729TU, V3730AU, V3731TU, V3732TU, V3733TU,
V3734TU, V3735TU, V3736AU, V3737AU, V3738AU, V3739AU, V3740AU, V3741AU,
V3741TU, V3742AU, V3743AU, V3744TU, V3745AU, V3746AU, V3746TU, V3747AU,
V3747TU, V3748TU, V3749TU, V3750AU, V3750TU, V3751TU, V3751XX, V3752TU,
V3752XX, V3754TU, V3755AU, V3755TU, V3756TU, V3757TU, V3758TU, V3761TU,
V3762TU, V3763TU, V3764TU, V3766TU, V3767TU, V3768TU, V3769TU, V3770TU,
V3774TU, V3775TU, V3778TU, V3779TU, V3781TU, V3782TU, V3783TU, V3785TU,
V3787TU, V3797TU, V3798TU, V3799TU, V3801AU, V3801TU, V3801TX, V3801XX,
V3802TU, V3803AU, V3804TU, V3804TX, V3805TU, V3806TU, V3808TX, V3809TU,
V3810TU, V3811TU, V3812TU, V3813AU, V3813TU, V3814AU, V3815AU, V3817AU,
V3818AU, V3819TU, V3820AU, V3820TU, V3823AU, V3823TU, V3824AU, V3824TU,
V3825AU, V3826AU, V3826TU, V3827TU, V3828TU, V3829TU, V3830TU, V3831TU,
V3832TU, V3833TU, V3834TU, V3835TU, V3838TU, V3844TU, V3846TU, V3847TU,
V3848TU, V3849TU, V3851XX, V3853TU, V3854TU, V3855TU, V3856TU, V3857TU,
V3901TU, V3904TU, V3904TX, V3906AU, V3906TU, V3907AU, V3907TU, V3908TU,
V3909TU, V3910TX, V3914TU, V3916TU, V3919TU, V3920TU, V3921TU, V3922TU,
V3923TU, V3925TU, V3926TU, V3927TU, V3928TU, V3929TU, V3930TU, V3931TU,
V3932TU, V4000, V4000T, V4000XX, V4002XX, V4003XX, V4004XX, V4005CL, V4005XX,
V4015US, V4020US, V4025US, V4035CA, V4035US, V4100, V4101AP, V4103AP, V4114AP,
V4118AP, V4120US, V4122TU, V4125CL, V4135US, V4200, V4201XX, V4202EA, V4202XX,
V4203XX, V4205EA, V4209TU, V4212TU, V4214TU, V4216TU, V4217EA, V4217TU,
V4218TU, V4219TU, V4220NR, V4220TU, V4222TU, V4223TU, V4225TU, V4227TU,
V4228TU, V4230TU, V4232TU, V4233TU, V4240US, V4245US, V4275EA, V4305EA,
V4308EA, V4310NR, V4320EA, V4322EA, V4325US, V4332EA, V4332US, V4333EA,
V4335EA, V4336EA, V4338EA, V4347EA, V4354EA, V4376EA, V4377EA, V4382EA,

V4387EA, V4400, V4401TU, V4402XX, V4403TU, V4404TU, V4405TU, V4406TU, V4407TU, V4408TU, V4435NR, V4440US, V4450EA, V5000, V5000T, V5002EA, V5004EA, V5005US, V5006EA, V5009EA, V5015US, V5025EA, V5026EA, V5030EA, V5031EA, V5032EA, V5033EA, V5054EA, V5059EA, V5079EA, V5088XX, V5094EA, V5099EA, V5099XX, V5100, V5101TU, V5101US, V5102NR, V5103AU, V5103TU, V5104AU, V5104TU, V5105CA, V5105EU, V5105TU, V5105US, V5106EU, V5106TU, V5107TU, V5108CU, V5108TU, V5109TU, V5110EU, V5110TU, V5111EU, V5111TU, V5115CA, V5115EU, V5115US, V5119US, V5120EU, V5120NR, V5125EU, V5150EA, V5160EA, V5160US, V5162EA, V5189XX, V5199XX, V5200, V5201CA, V5201US, V5203TU, V5204NR, V5204TU, V5204US, V5205NR, V5205TU, V5206OM, V5206TU, V5207NR, V5209US, V5210TU, V5210US, V5211TU, V5213TU, V5215LA, V5215TU, V5218LA, V5218TU, V5219TU, V5220TU, V5221EA, V5221TU, V5222TU, V5223TU, V5224TU, V5225TU, V5226TU, V5228TU, V5229TU, V5230TU, V5231TU, V5232EA, V5239TU, V5243TU, V5299XX, V5300, V5303NR, V5304US, V5306US, V5307US, V5310US, V5315WM, V6000, V6000T, V6000TX, V6000Z, V6001XX, V6002XX, V6003AU, V6012EA, V6016EA, V6048CL, V6057EA, V6100, V6101AU, V6101US, V6101XX, V6102EA, V6102XX, V6103NR, V6104NR, V6104US, V6105EA, V6105NR, V6106TU, V6107US, V6108EA, V6109AU, V6109EA, V6109EU, V6109OM, V6110CA, V6110EA, V6110US, V6112EU, V6113EA, V6115EA, V6115EU, V6115OM, V6117EU, V6120CA, V6120US, V6125TU, V6126EU, V6127EA, V6127TU, V6128EA, V6128EU, V6129EA, V6130US, V6131EU, V6133CA, V6133CL, V6133EU, V6137EU, V6137US, V6138EU, V6139EU, V6140TU, V6141TU, V6143CL, V6144EA, V6145EA, V6147EA, V6148EA, V6149EA, V6150EA, V6151EA, V6151TU, V6152EA, V6155EA, V6171CL, V6180EA, V6181EA, V6182EA, V6198XX, V6199XX, V6200, V6200XX, V6202EA, V6203TU, V6204EA, V6205NR, V6206AU, V6210BR, V6210CA, V6210US, V6212EA, V6213AU, V6213EA, V6215BR, V6215CA, V6216CA, V6216EA, V6217EA, V6218EA, V6220BR, V6223EA, V6223EU, V6224EA, V6225BR, V6230BR, V6230CA, V6233EU, V6254EA, V6261EU, V6263EA, V6264EA, V6272EU, V6299XX, V6300, V6301AU, V6304AU, V6304TU, V6305CA, V6305NR, V6310CA, V6310US, V6313TU, V6316CA, V6317CA, V6318CA, V6318TU, V6319TU, V6320CA, V6399XX, V6400, V6401AU, V6401XX, V6402CA, V6403AU, V6403TU, V6405CA, V6407TU, V6408TU, V6410CA, V6410TU, V6411TU, V6415CA, V6420US, V6421TU, V6422TU, V6423TU, V6428TU, V6444US, V6498XX, V6499XX, V6500, V6500T, V6500Z, V6501AU, V6501XX, V6502AU, V6507AU, V6511TU, V6512TU, V6513TU, V6514TU, V6515TU, V6599XX, V6600, V6601AU, V6604TU, V6605TU, V6606TU, V6607TU, V6608TU, V6609AU, V6609TU, V6611AU, V6611TU, V6612AU, V6612TU, V6613TU, V6614TU, V6615TU, V6616AU, V6616TU, V6617AU, V6618AU, V6620US, V6700, V6700TX, V6701XX, V6702AU, V6702TU, V6703AU, V6703TU, V6703XX, V6705TU, V6706TU, V6707TU, V6709TU, V6710TU, V6710XX, V6711TU, V6712TU, V6713TU, V6714TU, V6715TU, V6719NR, V6741US, V6751XX, V6801AU, V6802TU, V6803TU, V6804TU, V6805TU, V6806TU, V6807TU, V6808TU, V6851XX, V6899XX, V6900, V6903TU, V6904TU, V6905TU, X1000, X1001US, X1002US, X1005EA, X1006EA, X1007EA, X1010AL, X1010CA, X1010EA, X1010US, X1011AL, X1012AL, X1012EA, X1012QV, X1015, X1015US, X1016EA, X1018CL, X1020EA, X1020US, X1021AP, X1022AP, X1023AP, X1026AP, X1027AP, X1028AP, X1028CL, X1029AP, X1030, X1030AP, X1030US, X1031AP, X1032AP, X1033AP, X1034AP, X1035AP, X1036AP, X1037AP, X1038AP, X1040, X1040AP,

X1040US, X1041AP, X1042AP, X1043AP, X1044AP, X1045AP, X1046AP, X1047AP, X1048AP, X1049AP, X1050AP, X1050US, X1051AP, X1052AP, X1054AP, X1055AP, X1056AP, X1057AP, X1058AP, X1058CL, X1060AP, X1061AP, X1062AP, X1063AP, X1064AP, X1065AP, X1066AP, X1067AP, X1068AP, X1069AP, X1070AP, X1071AP, X1072AP, X1073AP, X1074AP, X1075AP, X1076AP, X1077AP, X1078AP, X1079AP, X1080AP, X1081AP, X1082AP, X1083AP, X1084AP, X1085AP, X1086AP, X1087AP, X1088AP, X1089AP, X1090AP, X1091AP, X1092AP, X1093AP, X1094AP, X1095AP, X1096AP, X1097AP, X1098AP, X1099AP, X1105EA, X1110EA, X1115EA, X1140EA, X1155EA, X1200, X1201AP, X1201US, X1202AP, X1203AP, X1204AP, X1205AP, X1206AP, X1207AP, X1208AP, X1209AP, X1210AP, X1210CA, X1210US, X1211AP, X1212AP, X1213AP, X1214AP, X1215AP, X1216AP, X1217AP, X1218AP, X1219AP, X1220AP, X1220EA, X1220US, X1221AP, X1222AP, X1223AP, X1224AP, X1225AP, X1227AP, X1228AP, X1229AP, X1230AP, X1230US, X1231AP, X1232AP, X1233AP, X1234AP, X1236AP, X1237AP, X1238AP, X1239AP, X1240AP, X1241AP, X1242AP, X1300, X1301AP, X1301US, X1302AP, X1303AP, X1304AP, X1305AP, X1306AP, X1307AP, X1308AP, X1309AP, X1310AP, X1311AP, X1312AP, X1313AP, X1314AP, X1315AP, X1316AP, X1317AP, X1318AP, X1319AP, X1320AP, X1321AP, X1322AP, X1326AP, X1327AP, X1328AP, X1329AP, X1330AP, X1360US, X1370US, X1390, X1390US, X1397, X1400, X1401US, X1402AP, X1402US, X1403AP, X1405AP, X1406AP, X1408AP, X1410AP, X1415AP, X1416AP, X1422AP, X1429AP, X1430AP, X1431AP, X1432AP, X1435AP, X1436AP, X1437AP, X1441AP, X1442AP, X1460US, X1480, X1480US, X1500, X1560CA,

Prosignia series

160, 165, 170, 190, 800,

HP

Business Notebook series

510, 530, 550, 6720, 6720S, 6720T, G5000, G6000, NC4000, NC4010, NC4200, NC4300, NC6000, NC6100, NC6105, NC6110, NC6115, NC6120, NC6220, NC6230, NC7200, NC8000, NC8230, NW8000, NX4800, NX4820, NX5000, NX5100, NX6100, NX6105, NX6110, NX6115, NX6120, NX6125, NX6130, NX6330, NX7000, NX7010, NX7040, NX7100, NX7200, NX7220, NX8000, NX9000, NX9020, NX9030, NX9040, NX9050,

Folio series

13, 13-1000,

Mini series

311-1000, 311-1000NR, 311-1001XX, 311-1021NR, 311-1022NR, 311-1025NR, 311-1025TU, 311-1028TU, 311-1036TU, 311-1037NR, 311-1037TU, 311-1038NR, 311-1100, 311-1109TU, 311-1110TU,

Notebook PC series

510, 520, 530, 540, 541, 550,

Pavilion series

DV1000, DV1000-DZ677AV, DV1000-DZ678AV, DV1000-DZ731AV, DV1000T, DV1001AP, DV1001AP-PK809AS, DV1001XX, DV1001XX-PK807AS, DV1002AP-PF352PA, DV1002XX, DV1002XX-PK808AS, DV1003AP-PF353PA, DV1004AP-PF354PA, DV1005AP-PF355PA, DV1006AP-PF356PA, DV1007AP, DV1007AP-PF367PA, DV1008AP, DV1008AP-PF368PA, DV1009AP-PH468PA, DV1009XX, DV1009XX-PR284AS, DV1010, DV1010AP-PH476PA, DV1010CA, DV1010CA-PM056UA, DV1010CA-PM056UAR, DV1010US, DV1010US-PM053UAR, DV1011AP, DV1012AP-PD111PA, DV1012LA, DV1012LA-PQ641LA, DV1013AP-PD110PA, DV1013AP-PD112PA, DV1014AP-PD113PA, DV1014LA-PP888LA, DV1015AP-PD114PA, DV1015LA-PN713LA, DV1016AP-PD117PA, DV1017AP, DV1017AP-PD118PA, DV1018AP, DV1018AP-PD119PA, DV1019AP-PD120PA, DV1010US-PM053UA, DV1020AP-PH482PA, DV1021AP, DV1021AP-PH483PA, DV1022AP, DV1022AP-PN562PA, DV1023AP-PN563PA, DV1024AP, DV1024AP-PN575PA, DV1024LA-PP889LA, DV1025AP, DV1025AP-PN576PA, DV1025LA, DV1025LA-PN712LA, DV1026AP, DV1026AP-PN907PA, DV1027AP, DV1027AP-PN578PA, DV1029AP-PN888PA, DV1029AP-PN908PA, DV1030, DV1030AP-PN910PA, DV1031AP-PP963PA, DV1032AP, DV1032AP-PP971PA, DV1033AP, DV1033AP-PP981PA, DV1034AP, DV1034AP-P982PA, DV1035AP, DV1035AP-PP989PA, DV1036AP, DV1036AP-PS939PA, DV1037AP-PS940PA, DV1040CA, DV1040CA-PM057UA, DV1040CA-PM057UAR, DV1040US, DV1040US-PM054UA, DV1040US-PM054UAR, DV1042QV, DV1042QV-PM055UA, DV1044LA-PP890LA, DV1049CL, DV1049CL-PM058UA, DV1049CL-PM058UAR, DV1060US, DV1060US-PM059UA, DV1060US-PM059UAR, DV1065US, DV1065US-PM061UA, DV1065US-PM061UAR, DV1067EA-PQ563EA, DV1068EA-PQ564EA, DV1071EA-PQ562EA, DV1100, DV1101AP-PS925PA, DV1102AP-PS926PA, DV1115LA, DV1117LA, DV1118AP, DV1120AP, DV1120US, DV1122AP, DV1122AP-PV253PA, DV1125AP, DV1125LA, DV1126AP, DV1127AP, DV1128AP-PV295PA, DV1130US, DV1133WM, DV1134AP, DV1135AP, DV1135LA, DV1139AP, DV1150US, DV1156CL, DV1170US, DV1175US, DV1180US, DV1200, DV1206CL, DV1207US, DV1210US, DV1215WM, DV1217US, DV1220US, DV1227US, DV1240CA, DV1240US, DV1245CL, DV1300, DV1300-DT111AV, DV1301AP, DV1301XX, DV1302AP, DV1302XX, DV1303AP, DV1304AP, DV1306AP, DV1307AP, DV1309AP, DV1310AP, DV1310US, DV1311SE, DV1312AP, DV1315CL, DV1316AP, DV1317AP, DV1317LA, DV1318AP, DV1319AP, DV1320AP, DV1320US, DV1321AP, DV1321US, DV1322AP, DV1323AP, DV1324AP, DV1326AP, DV1327AP, DV1328AP, DV1329AP, DV1330AP, DV1330CA, DV1330US, DV1331SE, DV1332AP, DV1334AP, DV1336AP, DV1340AP, DV1340US, DV1344AP, DV1345AP, DV1346AP, DV1347AP, DV1348AP, DV1353AP, DV1354AP, DV1355AP, DV1356AP, DV1357AP, DV1358AP, DV1359AP, DV1360AP, DV1361AP, DV1362AP, DV1363AP, DV1367TU, DV1368TU, DV1369TU, DV1370TU, DV1371TU, DV1372TU, DV1373TU, DV1374TU, DV1375TU, DV1376TU, DV1377TU, DV1378TU, DV1380TU, DV1383TU, DV1384TU, DV1385TU, DV1386TU, DV1387TU, DV1388TU, DV1390TU, DV1391TU, DV1392TU, DV1395TU, DV1396TU, DV1399XX, DV1400, DV1410US, DV1411SE, DV1420US, DV1421EA, DV1427US, DV1430US, DV1432US, DV1439US, DV1440CA, DV1440US, DV1500, DV1501EA, DV1510CA, DV1510US, DV1515CL, DV1519US, DV1520US, DV1530BR, DV1530CA, DV1530LA, DV1530US, DV1532US, DV1534EA, DV1535EA, DV1535LA, DV1536EA, DV1540CA, DV1540LA,

DV1540US, DV1546EA, DV1547EA, DV1550SE, DV1552EA, DV1555EA, DV1580SE,
DV1586EA, DV1588EA, DV1589EA, DV1591EA, DV1594EA, DV1595EA, DV1596EA,
DV1597EA, DV1598EA, DV1599EA, DV1600, DV1601TN, DV1602TN, DV1605TN,
DV1606TS, DV1607TS, DV1608TS, DV1609TS, DV1610US, DV1612TS, DV1614TS,
DV1618EA, DV1619EA, DV1620EA, DV1620US, DV1621EA, DV1621TN, DV1621TS,
DV1622EA, DV1622NR, DV1623EA, DV1624NR, DV1624TS, DV1625LA, DV1626TN,
DV1627TN, DV1629US, DV1633TN, DV1634TN, DV1635CA, DV1635LA, DV1635TN,
DV1636TN, DV1648US, DV1650CA, DV1650US, DV1656US, DV1657CL, DV1657EA,
DV1658EA, DV1658US, DV1659EA, DV1659US, DV1660CA, DV1660SE, DV1664EA,
DV1665EA, DV1666EA, DV1668EA, DV1669EA, DV1670EA, DV1670US, DV1674EA,
DV1675EA, DV1677EA, DV1679EA, DV1680CA, DV1680EA, DV1680US, DV1688US,
DV1693EA, DV1694EA, DV1695EA, DV1699XX, DV1700, DV1700TU, DV1701TU,
DV1701XX, DV1702XX, DV1703TU, DV1703XX, DV1704XX, DV1705TU, DV1706TU,
DV1707TU, DV1708NR, DV1709TU, DV1710TU, DV1710US, DV1712US, DV1714TU,
DV1715TU, DV1716TU, DV1720LA, DV1721LA, DV1721TU, DV1722TU, DV1725TU,
DV1727TU, DV1730LA, DV1731TU, DV1738OD, DV1740BR, DV1740TU, DV1744TU,
DV1750BR, DV1760BR, DV2000, DV2000T, DV2000Z, DV2001TU, DV2001TX, DV2001XX,
DV2002TU, DV2002TX, DV2002XX, DV2003EA, DV2003TU, DV2003TX, DV2004EA,
DV2004TU, DV2004TX, DV2004XX, DV2005EA, DV2005TU, DV2005TX, DV2005XX,
DV2006EA, DV2006TU, DV2006TX, DV2006XX, DV2007EA, DV2007TU, DV2007TX,
DV2008EA, DV2008TU, DV2008TX, DV2009EA, DV2009TU, DV2009TX, DV2009XX,
DV2010EA, DV2010TU, DV2010TX, DV2011EA, DV2011TU, DV2011TX, DV2011XX,
DV2012EA, DV2012TU, DV2012TX, DV2013EA, DV2013TU, DV2013TX, DV2014EA,
DV2014TU, DV2014TX, DV2015EA, DV2015NR, DV2015TU, DV2015TX, DV2016EA,
DV2016TU, DV2016TX, DV2017EA, DV2017TU, DV2017TX, DV2018EA, DV2018TU,
DV2018TX, DV2019EA, DV2019TU, DV2019TX, DV2020CA, DV2020EA, DV2020TU,
DV2020TX, DV2020US, DV2021TU, DV2021TX, DV2022TU, DV2022US, DV2023TU,
DV2024TU, DV2024TX, DV2025LA, DV2025NR, DV2025TU, DV2025TX, DV2026TU,
DV2026TX, DV2027TU, DV2027TX, DV2028EA, DV2028TU, DV2028TX, DV2029EA,
DV2029TU, DV2029TX, DV2030EA, DV2030TU, DV2030TX, DV2031EA, DV2031TU,
DV2031TX, DV2032EA, DV2032TU, DV2032TX, DV2033EA, DV2033TU, DV2033TX,
DV2034EA, DV2034TU, DV2034TX, DV2035EA, DV2035LA, DV2035TU, DV2035TX,
DV2035US, DV2036EA, DV2036TU, DV2036TX, DV2037TU, DV2037TX, DV2037US,
DV2038TU, DV2038TX, DV2039TU, DV2039TX, DV2040CA, DV2040TU, DV2040TX,
DV2040US, DV2041TU, DV2041TX, DV2042TU, DV2042TX, DV2043TU, DV2043TX,
DV2044TU, DV2044TX, DV2045EA, DV2045TU, DV2046TU, DV2046TX, DV2047CL,
DV2047TU, DV2047TX, DV2048TX, DV2049TX, DV2050TU, DV2050TX, DV2050US,
DV2053EA, DV2054EA, DV2055EA, DV2056EA, DV2057EA, DV2058EA, DV2064EA,
DV2065EA, DV2080EA, DV2081EA, DV2082EA, DV2083EA, DV2084EA, DV2085EA,
DV2088XX, DV2095EA, DV2097EA, DV2098EA, DV2099EA, DV2100, DV2101EU,
DV2101XX, DV2102XX, DV2103EA, DV2103TU, DV2103XX, DV2104EA, DV2104EU,
DV2104NR, DV2104TU, DV2104XX, DV2105EA, DV2105XX, DV2106EA, DV2106EU,
DV2108EA, DV2109NR, DV2110EU, DV2110RS, DV2111RS, DV2112RS, DV2115EA,
DV2115WM, DV2116, DV2116EA, DV2116TX, DV2116WM, DV2119XX, DV2120, DV2120CA,

DV2120LA, DV2120TU, DV2120US, DV2123EU, DV2123TU, DV2125, DV2125EA,
DV2125LA, DV2125NR, DV2126EA, DV2129EA, DV2129TX, DV2129US, DV2130,
DV2130EA, DV2130TX, DV2130US, DV2131EA, DV2133EA, DV2134EA, DV2134US,
DV2135BR, DV2135LA, DV2138XX, DV2140BR, DV2140EU, DV2140TX, DV2141EU,
DV2142TX, DV2143TX, DV2145BR, DV2147EA, DV2149EA, DV2150EA, DV2150TX,
DV2151TX, DV2152EA, DV2152TX, DV2164EU, DV2166EU, DV2171, DV2171CA,
DV2171CL, DV2171EA, DV2172EA, DV2173EA, DV2174, DV2174CL, DV2174EA,
DV2175EA, DV2184EA, DV2185EA, DV2190EA, DV2195EU, DV2196EA, DV2197EA,
DV2200, DV2200EA, DV2201CA, DV2201XX, DV2202CA, DV2202XX, DV2205EA,
DV2207EA, DV2208EA, DV2209EA, DV2209TU, DV2210TU, DV2210US, DV2213CA,
DV2213CL, DV2214US, DV2215EA, DV2215TU, DV2216EA, DV2217EA, DV2220US,
DV2221US, DV2222EA, DV2222LA, DV2224EA, DV2225NR, DV2227EA, DV2240BR,
DV2244EA, DV2245BR, DV2245EA, DV2246EA, DV2247BR, DV2250BR, DV2255BR,
DV2260BR, DV2265EA, DV2267EA, DV2268EA, DV2275EA, DV2276EA, DV2278EA,
DV2281EA, DV2282EA, DV2297EA, DV2298EA, DV2300, DV2301AU, DV2302AU,
DV2303AU, DV2304AU, DV2305AU, DV2306AU, DV2308TU, DV2310CA, DV2310US,
DV2312US, DV2313CA, DV2313CL, DV2315NR, DV2315US, DV2317CA, DV2317US,
DV2320LA, DV2320US, DV2322LA, DV2325LA, DV2400, DV2401XX, DV2402CA,
DV2402TX, DV2402XX, DV2404CA, DV2406TX, DV2407TX, DV2408CA, DV2409TX,
DV2410CA, DV2410TX, DV2410US, DV2411TX, DV2412CA, DV2413CA, DV2413CL,
DV2414TX, DV2415NR, DV2415TX, DV2415US, DV2416US, DV2418CA, DV2418NR,
DV2419US, DV2420LA, DV2420US, DV2422CA, DV2422LA, DV2423LA, DV2425LA,
DV2432CA, DV2432NR, DV2500, DV2500T, DV2500TV, DV2500TW, DV2500TX, DV2501XX,
DV2502XX, DV2503XX, DV2504XX, DV2505XX, DV2506XX, DV2515TX, DV2525TX,
DV2526TX, DV2527TX, DV2528TX, DV2535LA, DV2535TX, DV2539TX, DV2550SE,
DV2600, DV2601XX, DV2602CA, DV2602TU, DV2602TX, DV2602XX, DV2604TX,
DV2605TX, DV2606TU, DV2606TX, DV2607TU, DV2608CA, DV2608TU, DV2609TU,
DV2610CA, DV2610TU, DV2610US, DV2611TU, DV2612CA, DV2612TU, DV2613CL,
DV2613TU, DV2613TX, DV2615NR, DV2615US, DV2617US, DV2618CA, DV2619NR,
DV2620CA, DV2620US, DV2621LA, DV2622CA, DV2622LA, DV2624LA, DV2625LA,
DV2626LA, DV2628TX, DV2629TX, DV2630TX, DV2631TX, DV2633TX, DV2634TX,
DV2635LA, DV2635TX, DV2636TX, DV2638TX, DV2639TX, DV2640TX, DV2641TX,
DV2642TX, DV2643TX, DV2644TX, DV2660SE, DV2700, DV2700TV, DV2700TW,
DV2701XX, DV2702TU, DV2702TX, DV2702XX, DV2703TX, DV2703XX, DV2704TX,
DV2704XX, DV2705TU, DV2705TX, DV2706TU, DV2706TX, DV2707TU, DV2707TX,
DV2708CA, DV2708TU, DV2708TX, DV2709TU, DV2709TX, DV2710CA, DV2710TU,
DV2710TX, DV2712TU, DV2712TX, DV2713CA, DV2713TX, DV2714CA, DV2714TU,
DV2714TX, DV2715CA, DV2715NR, DV2715TX, DV2716CA, DV2716TX, DV2717TX,
DV2718CA, DV2718TX, DV2718US, DV2719NR, DV2719TX, DV2720TX, DV2721TX,
DV2722TX, DV2724CA, DV2725LA, DV2726CA, DV2726LA, DV2727CA, DV2728CA,
DV2730TX, DV2734TX, DV2735TX, DV2736TX, DV2736US, DV2737TX, DV2738TX,
DV2739TX, DV2740SE, DV2740TX, DV2741TX, DV2742SE, DV2745SE, DV2746TX,
DV2747TX, DV2748TX, DV2749TX, DV2750TX, DV2751TX, DV2751XX, DV2752TX,
DV2752XX, DV2755TX, DV2757TX, DV2759TX, DV2763TX, DV2765TX, DV2766TX,

DV2768TX, DV2769TX, DV2770TX, DV2771TX, DV2774TX, DV2779TX, DV2781TX,
DV2800T, DV2800TY, DV2801AU, DV2801TU, DV2801TX, DV2801XX, DV2802AU,
DV2802TU, DV2802TX, DV2803TU, DV2804CA, DV2804TU, DV2805, DV2805TU,
DV2806TU, DV2807NR, DV2807TU, DV2808CA, DV2808TU, DV2809TU, DV2809TX,
DV2810CA, DV2810TU, DV2810TX, DV2811TX, DV2812TX, DV2813TX, DV2814CA,
DV2814TX, DV2815NR, DV2816TX, DV2817CA, DV2818CA, DV2818TX, DV2819NR,
DV2820TX, DV2821TX, DV2823CA, DV2823TX, DV2824TX, DV2825TX, DV2826TX,
DV2828CA, DV2829TX, DV2830TX, DV2831TX, DV2832TX, DV2833TX, DV2834CA,
DV2834TX, DV2835TX, DV2836TX, DV2837TX, DV2838TX, DV2839TX, DV2840SE,
DV2840TX, DV2841TX, DV2842SE, DV2842TX, DV2845SE, DV2846TX, DV2847TX,
DV2848TX, DV2849TX, DV2850TX, DV2851XX, DV2854CA, DV2872LA, DV2890CA,
DV2890NR, DV2894CA, DV2901TU, DV2901TX, DV2902TU, DV2902TX, DV2903TU,
DV2904TU, DV2904TX, DV2905TU, DV2906TU, DV2907TU, DV2909TX, DV2910CA,
DV2911TX, DV2911US, DV2914CA, DV2915CA, DV2915NR, DV2915TX, DV2917CA,
DV2917CL, DV2917TX, DV2919TX, DV2920TX, DV2921TX, DV2925LA, DV2928CA,
DV2928SE, DV2940SE, DV2941SE, DV2945SE, DV2946NR, DV2949SE, DV2988NR,
DV2988SE, DV2990NR, DV2998NR, DV2999NR, DV4-2173NR, DV4000, DV4000-PC253AV,
DV4000-PC268AV, DV4000-PC269AV, DV4000-PH856AV, DV4000-PH857AV,
DV4000-PR496AV, DV4000LA, DV4000XX, DV4000XX-PX249AS, DV4001AP-PV281PA,
DV4001EA-EB916EA, DV4001XX, DV4001XX-PX248AS, DV4002AP-PV282PA,
DV4003AP-PV294PA, DV4004AP-PV298PA, DV4004XX, DV4004XX-PX251AS,
DV4005AP-PV302PA, DV4005US, DV4005US-EA410UA, DV4005XX, DV4006AP-PV303PA,
DV4006XX, DV4006XX-PX250AS, DV4007AP, DV4007AP-PV304PA, DV4007XX,
DV4007XX-PX259AS, DV4008AP-PV316PA, DV4009AP-PV317PA, DV4010AP-PV318PA,
DV4011AP-PV319PA, DV4012AP-PV320PA, DV4013AP-PV321PA, DV4014AP,
DV4014AP-PV332PA, DV4014EA-EA037EA, DV4015AP-PV333PA, DV4015CL,
DV4015CL-PX306UA, DV4015EA-EA034EA, DV4016AP-PY843PA, DV4016EA-EB907EA,
DV4017AP, DV4017AP-PY853PA, DV4017EA-EA032EA, DV4018AP, DV4018AP-PY854PA,
DV4018CL, DV4018EA-EB915EA, DV4019AP-PY881PA, DV4019EA-EA033EA,
DV4020AP-PY882PA, DV4020EA-EA022EA, DV4020US-PX304UA, DV4021AP-PY883PA,
DV4021EA, DV4021EA-EB923EA, DV4022AP, DV4022AP-ED099PA, DV4022EA-EB926EA,
DV4023AP-ED100PA, DV4023EA-EB917EA, DV4024AP, DV4024AP-ED102PA,
DV4024EA-EB924EA, DV4025AP-EE547PA, DV4025EA-EA036EA, DV4026AP-EE548PA,
DV4027EA-EA038EA, DV4030CA, DV4030CA-PX311UA, DV4030EA, DV4030EA-EA021EA,
DV4030EA-EB914EA, DV4030US, DV4030US-PX302UA, DV4031EA-EB910EA, DV4040CA,
DV4040CA-PX308UA, DV4040EA-EB920EA, DV4040US, DV4040US-PX303UA,
DV4043EA-EA030EA, DV4043EA-EB912EA, DV4045EA, DV4045EA-EA027EA,
DV4045EA-EB919EA, DV4046EA-EA028EA, DV4049EA-EB921EA, DV4050EA-EA025EA,
DV4051EA-EB918EA, DV4052EA-EB911EA, DV4054EA-EB913EA, DV4056EA-EA039EA,
DV4057EA-EA029EA, DV4060EA-EA023EA, DV4070EA, DV4070EA-EB925EA,
DV4073EA-EB908EA, DV4075EA-EA024EA, DV4078EA-EA026EA, DV4080EA-EB922EA,
DV4085EA-EA031EA, DV4086EA-EA035EA, DV4100, DV4100-EA292AV, DV4100-EA294AV,
DV4101AP, DV4101AP-PY885PA, DV4102AP, DV4102AP-PY896PA, DV4102EA-EH187EA,
DV4103AP-PY905PA, DV4103EA-EF177EA, DV4104AP-PY906PA, DV4105AP-PY907PA,

DV4106AP-ED098PA, DV4107AP-ED144PA, DV4108AP-ED145PA, DV4108EA-EF175EA,
DV4109AP-ED146PA, DV4109EA-EH197EA, DV4110AP, DV4110AP-ED142PA,
DV4110EA-EH725EA, DV4111AP, DV4111AP-ED143PA, DV4112AP-ED147PA,
DV4113AP-ED148PA, DV4113EA-EH726EA, DV4114AP, DV4114AP-ED149PA, DV4115AP,
DV4115AP-ED150PA, DV4115EA-EF190EA, DV4116AP-ED171PA, DV4117AP,
DV4117AP-ED172PA, DV4118AP-ED174PA, DV4119AP-EE452PA, DV4120AP-EE483PA,
DV4121AP, DV4121AP-EE501PA, DV4122AP-EE500PA, DV4122EA-EF186EA,
DV4123AP-EE517PA, DV4124AP-EE518PA, DV4125AP, DV4125AP-EE524PA,
DV4125EA-EH185EA, DV4125US, DV4125US-EC325UA, DV4126AP-EE528PA,
DV4126EA-EH183EA, DV4127AP-EE529PA, DV4128AP, DV4128AP-EE553PA,
DV4128EA-EH191EA, DV4129AP, DV4129AP-EH019PA, DV4129EA-EH730EA, DV4129US,
DV4130AP, DV4130AP-EH020PA, DV4130EA, DV4130EA-EF171EA, DV4130US,
DV4130US-EC317UA, DV4131EA-EF182EA, DV4134EA-EH180EA, DV4135EA-EH724EA,
DV4136EA-EF183EA, DV4137EA-EH192EA, DV4138EA-EF188EA, DV4139EA-EK552EA,
DV4140EA-EF178EA, DV4141EA-EH731EA, DV4142EA-EH188EA, DV4143EA-EF179EA,
DV4144EA-EK553EA, DV4145EA-EF176EA, DV4146EA-EH182EA, DV4146EA-EH727EA,
DV4148EA-EK551EA, DV4149EA-EH181EA, DV4150CA-EC322UA, DV4150EA,
DV4150EA-EF172EA, DV4150US, DV4150US-EC316UA, DV4151EA-EF185EA,
DV4152EA-EF173EA, DV4152EA-EH196EA, DV4153EA-EH178EA, DV4154EA-EH179EA,
DV4155CL, DV4155CL-EC321UA, DV4155EA-EH186EA, DV4155US, DV4155US-EC324UA,
DV4156EA-EH194EA, DV4157EA-EH732EA, DV4158EA-EF184EA, DV4159EA-EH729EA,
DV4160EA-EH728EA, DV4161EA-EF180EA, DV4162EA-EH189EA, DV4163EA-EF174EA,
DV4164EA-EH184EA, DV4165CL, DV4165CL-EC318UA, DV4165EA-EF187EA,
DV4170CA-EC320UA, DV4170US, DV4170US-EC315UA, DV4174EA-EH733EA,
DV4176EA-EH190EA, DV4178EA-EF189EA, DV4180US-EC327UA, DV4182EA-EH195EA,
DV4199EA-EF181EA, DV4200, DV4201TU, DV4201TX, DV4201XX, DV4202TU, DV4202XX,
DV4203EA-EK915EA, DV4203TX, DV4203XX, DV4205TX, DV4206TX, DV4207TU,
DV4207TX, DV4208TX, DV4209TX, DV4210TX, DV4211TX, DV4212TX, DV4213TX,
DV4214TX, DV4215TX, DV4217CL, DV4218TX, DV4220TX, DV4221TX, DV4222TX,
DV4223CL, DV4223TX, DV4224EA, DV4225NR, DV4226TX, DV4230US,
DV4230US-EC329UA, DV4231EA, DV4250US, DV4253US, DV4257US, DV4268EA,
DV4269US, DV4270US, DV4272US, DV4275NR, DV4302EA, DV4304EA, DV4305EA,
DV4305US, DV4306EA, DV4307CA, DV4307CL, DV4308WM, DV4309EA, DV4310US,
DV4312EA, DV4315EA, DV4318EA, DV4320US, DV4321EA, DV4322EA, DV4324EA,
DV4325EA, DV4326EA, DV4327EA, DV4330CA, DV4330US, DV4334EA, DV4335EA,
DV4335NR, DV4336EA, DV4337EA, DV4339EA, DV4340US, DV4342EA, DV4344EA,
DV4346EA, DV4348EA, DV4350EA, DV4351EA, DV4353EA, DV4354EA, DV4356EA,
DV4357EA, DV4358EA, DV4360EA, DV4363EA, DV4364EA, DV4365EA, DV4367EA,
DV4368EA, DV4376EA, DV4378EA, DV4379EA, DV4381EA, DV4383EA, DV4384EA,
DV4385EA, DV4386EA, DV4388EA, DV4391EA, DV4392EA, DV4394EA, DV4395EA,
DV4396EA, DV4398EA, DV4400, DV4401RS, DV4401XX, DV4402TU, DV4405NR,
DV4410US, DV4419US, DV4420CA, DV4420US, DV4435EA, DV4440EA, DV4445EA,
DV4450EA, DV5000, DV5000EA, DV5000T, DV5000Z, DV5001XX, DV5002EA, DV5003CL,
DV5003EA, DV5005EA, DV5006EA, DV5007EA, DV5008EA, DV5009EA, DV5010EA,

DV5011EA, DV5012EA, DV5016EA, DV5017CL, DV5017EA, DV5018EA, DV5020CA,
DV5020US, DV5021EA, DV5022EA, DV5023EA, DV5024EA, DV5026EA, DV5027EA,
DV5029US, DV5030US, DV5031EA, DV5033EA, DV5034EA, DV5035EA, DV5035NR,
DV5036EA, DV5037EA, DV5040US, DV5041EA, DV5046EA, DV5047EA, DV5050EA,
DV5051EA, DV5052EA, DV5053EA, DV5054EA, DV5055EA, DV5056EA, DV5057EA,
DV5058EA, DV5059EA, DV5061EA, DV5062EA, DV5063EA, DV5074EA, DV5075EA,
DV5077EA, DV5078EA, DV5084EA, DV5088XX, DV5091EA, DV5092EA, DV5093EA,
DV5094EA, DV5095EA, DV5096EA, DV5097EA, DV5098EA, DV5099EA, DV5099XX,
DV5100, DV5102EU, DV5104EU, DV5106EU, DV5107TX, DV5109TX, DV5110CA,
DV5110TX, DV5110US, DV5111TU, DV5111TX, DV5113EU, DV5113TX, DV5114EU,
DV5115EU, DV5115NR, DV5116EU, DV5116NR, DV5117CA, DV5117CL, DV5119EU,
DV5119TX, DV5120EA, DV5120EU, DV5120LA, DV5120US, DV5121EA, DV5121EU,
DV5122EA, DV5122TX, DV5123EA, DV5123TX, DV5124EU, DV5124TX, DV5125EU,
DV5125TX, DV5127EU, DV5127TX, DV5128EU, DV5128TX, DV5129EU, DV5129US,
DV5130CA, DV5130EU, DV5130TX, DV5130US, DV5131EU, DV5131TX, DV5132EU,
DV5132TX, DV5134EA, DV5134EU, DV5135EU, DV5135NR, DV5136EU, DV5137EA,
DV5139US, DV5140CA, DV5140EA, DV5140EU, DV5140US, DV5142EA, DV5143EA,
DV5144EA, DV5145EA, DV5147EA, DV5148EA, DV5149EA, DV5149EU, DV5150EA,
DV5150US, DV5155EU, DV5156EU, DV5157EA, DV5157EU, DV5158EU, DV5159EU,
DV5161EU, DV5163CL, DV5164EA, DV5165EA, DV5166EA, DV5167CL, DV5170US,
DV5173EA, DV5173EU, DV5174EU, DV5176EA, DV5176EU, DV5177EA, DV5178EA,
DV5178US, DV5179EA, DV5186EU, DV5189EU, DV5189XX, DV5190EA, DV5190US,
DV5191EA, DV5192EA, DV5193EA, DV5194EA, DV5196EA, DV5196XX, DV5197EA,
DV5198EA, DV5198XX, DV5199XX, DV5200, DV5200TU, DV5201TX, DV5202TX,
DV5203TX, DV5204TX, DV5205EA, DV5205TU, DV5205TX, DV5206TX, DV5207TX,
DV5208TX, DV5209TX, DV5210EA, DV5210TX, DV5210US, DV5211EA, DV5211TX,
DV5212TX, DV5213TX, DV5214TX, DV5215TX, DV5215US, DV5216CA, DV5216TX,
DV5217CL, DV5218NR, DV5220LA, DV5220TX, DV5220US, DV5221TX, DV5222NR,
DV5222TX, DV5223OM, DV5224NR, DV5224TX, DV5225EA, DV5225TX, DV5226TX,
DV5229OM, DV5229TX, DV5230US, DV5233TX, DV5234US, DV5236OM, DV5237CL,
DV5238EA, DV5239EA, DV5240US, DV5243EU, DV5250US, DV5252EA, DV5269EA,
DV5270EA, DV5271EA, DV5272EA, DV5273EA, DV5278EA, DV5283EA, DV5284EA,
DV5298XX, DV5299XX, DV5300, DV6000, DV6000T, DV6000Z, DV6001EA, DV6001XX,
DV6002XX, DV6003EA, DV6003XX, DV6004EA, DV6005EA, DV6006EA, DV6007EA,
DV6010EA, DV6011EA, DV6012EA, DV6013EA, DV6014EA, DV6015EA, DV6016EA,
DV6017EA, DV6018EA, DV6019EA, DV6020EA, DV6021EA, DV6022EA, DV6023EA,
DV6024EA, DV6025EA, DV6040CA, DV6040US, DV6045NR, DV6054EA, DV6057EA,
DV6058CL, DV6058EA, DV6059EA, DV6060EA, DV6061EA, DV6062EA, DV6063EA,
DV6064EA, DV6065EA, DV6067EA, DV6086EA, DV6087EA, DV6088EA, DV6095EA,
DV6097EA, DV6100, DV6100EA, DV6101EA, DV6101EU, DV6101TU, DV6101TX,
DV6101XX, DV6102EA, DV6102EU, DV6102OD, DV6102TX, DV6102XX, DV6103EA,
DV6103EU, DV6103NR, DV6103TX, DV6103XX, DV6104EA, DV6104EU, DV6104NR,
DV6104TX, DV6105CA, DV6105EA, DV6105EU, DV6105TX, DV6105US, DV6106EA,
DV6106EU, DV6106TX, DV6107EA, DV6107EU, DV6107TX, DV6107US, DV6108EA,

DV6108NR, DV6108TX, DV6108US, DV6109EA, DV6109NR, DV6109OM, DV6109TX,
DV6110BR, DV6110CA, DV6110EA, DV6110EU, DV6110TX, DV6110US, DV6111EA,
DV6111EU, DV6111NR, DV6111TX, DV6112EA, DV6112TX, DV6113CA, DV6113EA,
DV6113EU, DV6113TX, DV6113US, DV6114EA, DV6114TX, DV6115CA, DV6115EA,
DV6115EU, DV6115NR, DV6115TX, DV6116EA, DV6116EU, DV6116NR N, DV6116TX,
DV6117EA, DV6117EU, DV6117TX, DV6118EA, DV6118EU, DV6118NR, DV6118TX,
DV6119EA, DV6119EU, DV6119TX, DV6119US, DV6120BR, DV6120CA, DV6120EA,
DV6120EU, DV6120LA, DV6120SE, DV6120TX, DV6120US, DV6121EA, DV6121EU,
DV6121TX, DV6122EA, DV6122TX, DV6123EA, DV6123EU, DV6123TX, DV6124EA,
DV6124EU, DV6124TX, DV6125BR, DV6125EA, DV6125OM, DV6125SE, DV6125TX,
DV6126EA, DV6126EU, DV6126TX, DV6127EA, DV6127EU, DV6127TX, DV6128EA,
DV6128EU, DV6128OD, DV6128TX, DV6129EA, DV6129EU, DV6129TX, DV6129US,
DV6130CA, DV6130EA, DV6130EU, DV6130TX, DV6130US, DV6131EA, DV6131EU,
DV6131OD, DV6131TX, DV6132EA, DV6132EU, DV6132TX, DV6133EA, DV6133EU,
DV6133OD, DV6133TX, DV6134EA, DV6134EU, DV6134TX, DV6135CA, DV6135EA,
DV6135EU, DV6135NR, DV6135TX, DV6136EA, DV6136EU, DV6136TX, DV6137EA,
DV6137EU, DV6137TX, DV6138EA, DV6138EU, DV6138TX, DV6139EA, DV6139EU,
DV6139TX, DV6139US, DV6140CA, DV6140EA, DV6140EU, DV6140TX, DV6140US,
DV6141EA, DV6141EU, DV6141TX, DV6142EA, DV6142EU, DV6142TX, DV6143EA,
DV6143EU, DV6143TX, DV6144EA, DV6144EU, DV6144TX, DV6145EA, DV6145EU,
DV6145TX, DV6146EA, DV6146EU, DV6146TX, DV6147EA, DV6147EU, DV6147TX,
DV6148EA, DV6148EU, DV6148TX, DV6149EA, DV6149EU, DV6149TX, DV6149US,
DV6150BR, DV6150CA, DV6150EA, DV6150EU, DV6150TX, DV6150US, DV6151EA,
DV6151EU, DV6152EA, DV6152EU, DV6153EA, DV6153EU, DV6154EA, DV6154EU,
DV6155EA, DV6155EU, DV6156EA, DV6156EU, DV6157EA, DV6157EU, DV6158EA,
DV6158EU, DV6159EA, DV6159EU, DV6160EA, DV6160EU, DV6161EA, DV6161EU,
DV6162EA, DV6163EA, DV6164EA, DV6165CL, DV6165EA, DV6165EU, DV6166EA,
DV6167EA, DV6168EA, DV6169EA, DV6170EA, DV6171CL, DV6171EA, DV6172EA,
DV6173EA, DV6174CA, DV6174CL, DV6174EA, DV6175EA, DV6179EA, DV6180EA,
DV6181EA, DV6182EA, DV6182EU, DV6183EA, DV6184EA, DV6184EU, DV6185EA,
DV6185EU, DV6186EA, DV6186EU, DV6187EA, DV6187EU, DV6188EA, DV6188EU,
DV6189EA, DV6189EU, DV6190EU, DV6191EU, DV6195EA, DV6195XX, DV6196EA,
DV6196XX, DV6197EA, DV6197XX, DV6198XX, DV6199XX, DV6200, DV6200EA,
DV6200XX, DV6201EA, DV6201EU, DV6202EU, DV6203EA, DV6203TX, DV6204EA,
DV6204EU, DV6205CA, DV6205EU, DV6205US, DV6206EA, DV6206US, DV6208EA,
DV6208NR, DV6208TX, DV6210EA, DV6210TX, DV6211EA, DV6212EA, DV6213CL,
DV6213EA, DV6214EA, DV6215CA, DV6215EA, DV6215TX, DV6215US, DV6216EA,
DV6216TX, DV6217EA, DV6218EA, DV6218TX, DV6219EA, DV6220BR, DV6220EU,
DV6221TX, DV6223EU, DV6225EU, DV6225US, DV6226US, DV6227CL, DV6230BR,
DV6230EA, DV6231EA, DV6231EU, DV6233EA, DV6233SE, DV6235CA, DV6235EU,
DV6235NR, DV6235US, DV6236EA, DV6236US, DV6237EA, DV6238EA, DV6239EA,
DV6239EU, DV6240EU, DV6241EA, DV6241EU, DV6242EA, DV6242EU, DV6243CL,
DV6243EA, DV6243EU, DV6244EA, DV6244EU, DV6244US, DV6245CA, DV6245EA,
DV6245EU, DV6245US, DV6247CA, DV6247CL, DV6247EA, DV6248EU, DV6249EU,

DV6250EU, DV6251EU, DV6252EU, DV6253CL, DV6253EU, DV6254EA, DV6254EU,
DV6255CA, DV6255EU, DV6255US, DV6256EU, DV6256US, DV6258SE, DV6259EU,
DV6260EU, DV6262EU, DV6263CL, DV6263EU, DV6264EU, DV6265CA, DV6265EA,
DV6265EU, DV6265US, DV6266EU, DV6267CL, DV6267EU, DV6269EU, DV6274EA,
DV6275EA, DV6275US, DV6276EA, DV6276EU, DV6277EA, DV6278EU, DV6280EA,
DV6281EA, DV6283EU, DV6284EU, DV6285EU, DV6286EA, DV6286EU, DV6287EU,
DV6288EA, DV6290EA, DV6291EA, DV6295EU, DV6297EA, DV6298EA, DV6299EA,
DV6299XX, DV6300, DV6303TU, DV6305CA, DV6305US, DV6306RS, DV6307CA,
DV6308CA, DV6308NR, DV6315CA, DV6324US, DV6325CA, DV6325US, DV6326US,
DV6335CA, DV6335US, DV6337CL, DV6337US, DV6338SE, DV6340EU, DV6345US,
DV6353CA, DV6353CL, DV6353US, DV6355CA, DV6355US, DV6357EU, DV6358SE,
DV6363CA, DV6365US, DV6375US, DV6399XX, DV6400, DV6400A, DV6401CA, DV6401TU,
DV6401TX, DV6401XX, DV6402CA, DV6402TU, DV6402XX, DV6403CL, DV6404CA,
DV6404TX, DV6405CA, DV6405US, DV6406CA, DV6406NR, DV6407NR, DV6408CA,
DV6408NR, DV6409CA, DV6409US, DV6409WM, DV6410CA, DV6415CA, DV6415US,
DV6416CA, DV6418CA, DV6420LA, DV6422LA N, DV6423OM, DV6424CA, DV6425CA,
DV6425US, DV6426CA, DV6426US, DV6427CL, DV6428CA, DV6433CL, DV6435CA,
DV6436NR, DV6439NR, DV6445US, DV6446US, DV6447OM, DV6448SE, DV6449US,
DV6450US, DV6451US, DV6452SE, DV6458SE, DV6470US, DV6499XX, DV6500, DV6500T,
DV6500Z, DV6501AU, DV6501XX, DV6502XX, DV6503AU, DV6503TU, DV6504AU,
DV6505AU, DV6505TU, DV6513TX, DV6514TX, DV6518TX, DV6520TX, DV6521TX,
DV6523TX, DV6524TX, DV6531TX, DV6540TX, DV6541TX, DV6542TX, DV6545TX,
DV6547EA, DV6550TX, DV6560US, DV6563CL, DV6565CA, DV6565US, DV6567CL,
DV6568SE, DV6570US, DV6573CL, DV6575CA, DV6575US, DV6585CA, DV6589US,
DV6597XX, DV6598XX, DV6599XX, DV6600, DV6601AU, DV6601TU, DV6601TX,
DV6602AX, DV6603AX, DV6603CA, DV6604AU, DV6604CL, DV6604NR, DV6604TU,
DV6604TX, DV6605CA, DV6605US, DV6607CL, DV6607NR, DV6607RS, DV6608CA,
DV6609WM, DV6610TX, DV6611CA, DV6611TX, DV6612CA, DV6613TX, DV6615TX,
DV6616TX, DV6618CA, DV6618TX, DV6619TX, DV6620LA, DV6620TX, DV6621TX,
DV6622CA, DV6622TX, DV6623CL, DV6623TX, DV6624CA, DV6624TX, DV6625CA,
DV6625TX, DV6625US, DV6626CA, DV6626TX, DV6626US, DV6627CA, DV6627NR,
DV6627OM, DV6628TX, DV6628US, DV6629CA, DV6629TX, DV6629US, DV6629WM,
DV6631CA, DV6633US, DV6634NR, DV6636NR, DV6640BR, DV6640US, DV6642CA,
DV6643CL, DV6645CA, DV6645US, DV6646US, DV6647CL, DV6647NR, DV6648SE,
DV6651XX, DV6652XX, DV6653CL, DV6654US, DV6660SE, DV6661SE, DV6662SE,
DV6663CA, DV6663CL, DV6663US, DV6670CA, DV6672US, DV6675US, DV6693US,
DV6696NR, DV6699XX, DV6700, DV6700T, DV6700Z, DV6701AX, DV6701CA, DV6701TU,
DV6701TX, DV6701US, DV6701VX, DV6701XX, DV6702AU, DV6702AX, DV6702TU,
DV6702TX, DV6702VX, DV6703AU, DV6703AX, DV6703TU, DV6703VX, DV6704AU,
DV6704AX, DV6704CA, DV6704NR, DV6704TX, DV6704VX, DV6705AX, DV6705CA,
DV6705TU, DV6705TX, DV6705VX, DV6706AU, DV6706AX, DV6707AX, DV6707TX,
DV6707US, DV6708AX, DV6708TX, DV6709TX, DV6710AX, DV6710TX, DV6711AX,
DV6713CA, DV6714CA, DV6714TX, DV6715TX, DV6716CA, DV6716TX, DV6717TX,
DV6718CA, DV6718TX, DV6719TX, DV6720LA, DV6720TX, DV6721LA, DV6721TX,

DV6722LA, DV6722TX, DV6724CA, DV6725CA, DV6725TX, DV6725US, DV6726TX,
DV6727CA, DV6727TX, DV6728CA, DV6728TX, DV6729CA, DV6729TX, DV6729US,
DV6730TX, DV6731TX, DV6732TX, DV6734TX, DV6735TX, DV6736NR, DV6736TX,
DV6737TX, DV6739TX, DV6740TX, DV6742TX, DV6743TX, DV6744CA, DV6744TX,
DV6745TX, DV6745US, DV6746CA, DV6747CL, DV6747NR, DV6748CA, DV6748US,
DV6749TX, DV6750TX, DV6751TX, DV6751US, DV6751XX, DV6753CA, DV6753CL,
DV6753TX, DV6754TX, DV6755CA, DV6755US, DV6756US, DV6757CA, DV6758US,
DV6759TX, DV6762TX, DV6763TX, DV6764TX, DV6765TX, DV6766TX, DV6768TX,
DV6769TX, DV6770SE, DV6770TX, DV6771TX, DV6772NR, DV6772TX, DV6775TX,
DV6775US, DV6776TX, DV6777TX, DV6778TX, DV6779TX, DV6780CA, DV6780SE,
DV6780TX, DV6781TX, DV6782TX, DV6783TX, DV6784TX, DV6785CA, DV6785SE,
DV6785TX, DV6786TX, DV6787TX, DV6788TX, DV6789TX, DV6790TX, DV6791TX,
DV6792TX, DV6793TX, DV6794TX, DV6795TX, DV6796TX, DV6798TX, DV6800,
DV6801AX, DV6801CA, DV6801TU, DV6801TX, DV6802AX, DV6802TU, DV6802TX,
DV6803AX, DV6803TU, DV6803TX, DV6804AX, DV6804TU, DV6804TX, DV6805CA,
DV6805TU, DV6805TX, DV6806TX, DV6807TX, DV6807US, DV6808TX, DV6809US,
DV6809WM, DV6810TX, DV6810US, DV6811TX, DV6812NR, DV6814CA, DV6815NR,
DV6815TX, DV6816TX, DV6817TX, DV6818CA, DV6818TX, DV6819TX, DV6820TX,
DV6821TX, DV6822TX, DV6823TX, DV6823US, DV6824CA, DV6824TX, DV6825CA,
DV6825TX, DV6827CA, DV6827TX, DV6828TX, DV6829TX, DV6830TX, DV6830US,
DV6831TX, DV6832TX, DV6833TX, DV6833US, DV6834CA, DV6834TX, DV6835CA,
DV6835NR, DV6835TX, DV6836TX, DV6837CL, DV6837TX, DV6838CA, DV6838NR,
DV6838TX, DV6839CL, DV6839TX, DV6840TX, DV6841TX, DV6847TX, DV6848TX,
DV6851XX, DV6853CA, DV6853CL, DV6854CA, DV6858CA, DV6864CA, DV6870US,
DV6871US, DV6872LA, DV6874CA, DV6875CA, DV6875SE, DV6880SE, DV6883CL,
DV6884CA, DV6885CA, DV6885SE, DV6898CA, DV6899XX, DV6900, DV6901TU,
DV6901TX, DV6902TU, DV6902TX, DV6903TU, DV6903TX, DV6904CA, DV6907CA,
DV6907TX, DV6908TX, DV6909TX, DV6910CA, DV6911OM, DV6911US, DV6912TX,
DV6913CA, DV6913RS, DV6915CA, DV6915NR, DV6916TX, DV6917CL, DV6917NR,
DV6917TX, DV6918SE, DV6918TX, DV6919CA, DV6919TX, DV6920TX, DV6921TX,
DV6923TX, DV6926NR, DV6928US, DV6929NR, DV6929WM, DV6930US, DV6933CL,
DV6934CA, DV6935CA, DV6936US, DV6937CL, DV6938SE, DV6939CA, DV6940SE,
DV6948CA, DV6958SE, DV6968CA, DV6974CA, DV6976CA, DV6985SE, DV6988CA,
DV6995LA, DV6998CA, DV8000, DV8000T, DV8000Z, DV8002EA, DV8005EA, DV8010EA,
DV8013CL, DV8013XX, DV8027EA, DV8028EA, DV8029EA, DV8035EA, DV8040US,
DV8040XX, DV8045EA, DV8051EA, DV8075EA, DV8088US, DV8099XX, DV80XXUS,
DV8100, DV8102EA, DV8110US, DV8113CL, DV8113EA, DV8114EA, DV8116EA, DV8117EA,
DV8120CA, DV8125NR, DV8130US, DV8135EA, DV8135NR, DV8140US, DV8155EA,
DV8173EA, DV8175EA, DV8176EA, DV8177EA, DV8178EA, DV8179EA, DV8195EA,
DV8197EA, DV8199EA, DV81XXUS, DV8200, DV8201TX, DV8202TX, DV8203TX,
DV8204TX, DV8205TX, DV8206TX, DV8207TX, DV8208TX, DV8209TX, DV8210CA,
DV8210EA, DV8210US, DV8211EA, DV8211EU, DV8212EA, DV8213CL, DV8213EA,
DV8214EA, DV8214TX, DV8215EA, DV8215TX, DV8219EA, DV8220CA, DV8220EA,
DV8220US, DV8221EA, DV8222EA, DV8223EA, DV8225CA, DV8225EA, DV8225NR,

DV8226EA, DV8227EA, DV8228EA, DV8229EA, DV8230CA, DV8230EA, DV8230US,
DV8231EA, DV8233CL, DV8233EA, DV8235EA, DV8235NR, DV8240US, DV8251EA,
DV8252EU, DV8253EA, DV8254EA, DV8260EA, DV8275EA, DV8275LA, DV8279EA,
DV8280EA, DV8280US, DV8286EA, DV8287EA, DV8289EA, DV8289XX, DV8290EA,
DV8291EA, DV8292EA, DV8293EA, DV8294EA, DV8295EA, DV8298EA, DV8298XX,
DV8299XX, DV8300, DV8300TX, DV8301NR, DV8301TX, DV8302TX, DV8304TX,
DV8305CA, DV8305TX, DV8305US, DV8306EA, DV8306TX, DV8307EA, DV8307TX,
DV8309US, DV8310US, DV8312TX, DV8314TX, DV8315NR, DV8315TX, DV8318TX,
DV8320EA, DV8320US, DV8321TX, DV8322EA, DV8323EA, DV8325EA, DV8327CA,
DV8327CL, DV8327US, DV8328CA, DV8333CL, DV8339US, DV8375LA, DV8379EA,
DV8380US, DV8382EA, DV8389EA, DV8390EA, DV8391EA, DV8393EA, DV8395EA,
DV8398EA, DV8399XX, DV8400, DV8408US, DV9000, DV9000EA, DV9000T, DV9000Z,
DV9001EA, DV9001XX, DV9002EA, DV9002NR, DV9002XX, DV9003EA, DV9003TX,
DV9003XX, DV9004EU, DV9004TX, DV9004XX, DV9005CA, DV9005EA, DV9005TX,
DV9005US, DV9005XX, DV9006EA, DV9006OM, DV9006TX, DV9008EA, DV9008NR,
DV9009CA, DV9009CL, DV9009NR, DV9009TX, DV9009US, DV9010CA, DV9010TX,
DV9010US, DV9011TX, DV9012TX, DV9013CA, DV9013CL, DV9013TX, DV9014EA,
DV9014TX, DV9015EA, DV9015TX, DV9016EA, DV9016TX, DV9017EA, DV9017TX,
DV9018EA, DV9019EA, DV9019TX, DV9020TX, DV9021TX, DV9022EA, DV9022TX,
DV9023US, DV9024EA, DV9030EA, DV9030US, DV9035EA, DV9035NR, DV9036EA,
DV9037EA, DV9038EA, DV9039EA, DV9040EA, DV9040EU, DV9040US, DV9041EA,
DV9042EA, DV9043EA, DV9044EA, DV9045EA, DV9046EA, DV9048EA, DV9049EA,
DV9050EA, DV9051EA, DV9052EA, DV9053EA, DV9055EA, DV9056EA, DV9057EA,
DV9058EA, DV9059EA, DV9060EA, DV9060US, DV9061EA, DV9062EA, DV9063EA,
DV9064EA, DV9065EA, DV9066EA, DV9067EA, DV9068EA, DV9069EA, DV9071EA,
DV9072EA, DV9073EA, DV9074CL, DV9074EA, DV9075EA, DV9075EU, DV9075LA,
DV9076EA, DV9076EU, DV9077EA, DV9077EU, DV9078EA, DV9079EA, DV9080EA,
DV9081EA, DV9082EA, DV9082EU, DV9083EA, DV9084EA, DV9085EA, DV9085EU,
DV9086EA, DV9087EA, DV9088EA, DV9089EA, DV9090EA, DV9091EA, DV9092EA,
DV9093EA, DV9093EU, DV9094EA, DV9095EU, DV9095XX, DV9096EA, DV9096XX,
DV9097EA, DV9097XX, DV9098XX, DV9099EA, DV9099XX, DV9100, DV9200, DV9200XX,
DV9201CA, DV9201TX, DV9202EA, DV9202TX, DV9204TX, DV9205CA, DV9205EU,
DV9205US, DV9206EU, DV9206TX, DV9207TX, DV9207US, DV9208NR, DV9208TX,
DV9209TX, DV9210CA, DV9210TX, DV9210US, DV9211EA, DV9211TX, DV9212EA,
DV9212TX, DV9213EA, DV9213TX, DV9214EA, DV9214TX, DV9215TX, DV9216EA,
DV9216TX, DV9217EA, DV9217TX, DV9218EA, DV9218TX, DV9219EA, DV9219TX,
DV9220CA, DV9220EU, DV9220TX, DV9220US, DV9221EA, DV9221TX, DV9225US,
DV9230US, DV9231CA, DV9232EU, DV9233CA, DV9233CL, DV9233EU, DV9235NR,
DV9237EU, DV9241EA, DV9243EA, DV9244EA, DV9244EU, DV9248EA, DV9252EU,
DV9253EA, DV9254EU, DV9255EA, DV9260NR, DV9260US, DV9265EA, DV9265LA,
DV9266EA, DV9266EU, DV9267EA, DV9268EA, DV9269EA, DV9271EA, DV9272EA,
DV9273EA, DV9274EU, DV9275EA, DV9275LA, DV9276EA, DV9283EA, DV9285EA,
DV9286EA, DV9287CL, DV9288EA, DV9289EA, DV9291EA, DV9292EU, DV9293EA,
DV9294EA, DV9294EU, DV9295EA, DV9295EU, DV9296EA, DV9296EU, DV9297EA,

DV9299EA, DV9299XX, DV9300, DV9301TX, DV9302TX, DV9303EU, DV9303TX,
DV9304EU, DV9304TX, DV9305EU, DV9306TX, DV9307TX, DV9308EA, DV9308NR,
DV9308TX, DV9309EA, DV9309EU, DV9309TX, DV9310CA, DV9310EA, DV9310EU,
DV9310TX, DV9310US, DV9311EA, DV9311EU, DV9311TX, DV9312EA, DV9312TX,
DV9313EA, DV9314EA, DV9315CA, DV9315EA, DV9316EA, DV9317CA, DV9317CL,
DV9317EA, DV9318CA, DV9318EA, DV9319EA, DV9320CA, DV9320EA, DV9320US,
DV9321EA, DV9322EA, DV9324EA, DV9330CA, DV9330US, DV9331EU, DV9332EA,
DV9332EU, DV9334US, DV9335NR, DV9337EU, DV9338EU, DV9339US, DV9340EA,
DV9341EU, DV9342EU, DV9343CA, DV9343EU, DV9344EU, DV9345EU, DV9346EA,
DV9347CL, DV9348EA, DV9350EA, DV9351EA, DV9361EA, DV9362EA, DV9363EA,
DV9372EU, DV9374EU, DV9375EU, DV9377EA, DV9378EA, DV9379EA, DV9380CA,
DV9380EA, DV9381EA, DV9385EA, DV9389EA, DV9390EA, DV9391EU, DV9392EA,
DV9393EA, DV9394EA, DV9395EA, DV9396EA, DV9397EA, DV9398EA, DV9398EU,
DV9399EA, DV9400, DV9401XX, DV9407NR, DV9408CA, DV9408NR, DV9410CA,
DV9410US, DV9413CL, DV9417CA, DV9417CL, DV9418CA, DV9420CA, DV9420US,
DV9428CA, DV9428NR, DV9429US, DV9438CA, DV9443CA, DV9500, DV9500EW,
DV9501AU, DV9501XX, DV9502XX, DV9503AU, DV9505TX, DV9507TX, DV9508TX,
DV9509TX, DV9511TX, DV9512TX, DV9513TX, DV9515CA, DV9515EF, DV9515EO,
DV9516TX, DV9518EM, DV9518TX, DV9519TX, DV9520EB, DV9520TX, DV9521EJ,
DV9521TX, DV9522TX, DV9525EN, DV9525EO, DV9525US, DV9530EB, DV9530EF,
DV9530EM, DV9532EM, DV9533EF, DV9535NR, DV9535US, DV9540EB, DV9540US,
DV9541EV, DV9542EV, DV9543CL, DV9543EV, DV9547CL, DV9548CA, DV9548US,
DV9550EO, DV9550EP, DV9552ES, DV9555EG, DV9560EA, DV9560EG, DV9560ER,
DV9562EZ, DV9565EG, DV9570EL, DV9570EO, DV9572EA, DV9574EA, DV9574LA,
DV9575EF, DV9575EM, DV9575EN, DV9575EO, DV9575EP, DV9575ES, DV9575LA,
DV9575NR, DV9576EA, DV9580EE, DV9580EG, DV9580EL, DV9580EN, DV9580EO,
DV9580ET, DV9580EZ, DV9580US, DV9581EE, DV9585EG, DV9585EL, DV9588EF,
DV9590EA, DV9590ED, DV9590EG, DV9590ER, DV9590ET, DV9590EZ, DV9592EF,
DV9595EA, DV9595ED, DV9596XX, DV9597XX, DV9598XX, DV9599XX, DV9600,
DV9601AU, DV9601TX, DV9602AU, DV9602TX, DV9603AU, DV9603TX, DV9604AU,
DV9604TX, DV9605EF, DV9605EM, DV9605EO, DV9605TX, DV9606CA, DV9606TX,
DV9607TX, DV9607US, DV9608CA, DV9608ES, DV9608NR, DV9608TX, DV9610CA,
DV9610EB, DV9610EF, DV9610EM, DV9610ET, DV9610EV, DV9610TX, DV9610US,
DV9611TX, DV9612CA, DV9612TX, DV9613TX, DV9614CA, DV9614TX, DV9615CA,
DV9615TX, DV9616CA, DV9616TX, DV9617NR, DV9617TX, DV9618CA, DV9620EN,
DV9620ET, DV9620US, DV9623CA, DV9623CL, DV9623ED, DV9625CA, DV9625ER,
DV9625EW, DV9626US, DV9627CL, DV9628CA, DV9628NR, DV9629CA, DV9630EB,
DV9630ED, DV9630EF, DV9630ET, DV9631EF, DV9631EM, DV9634CA, DV9635CA,
DV9635EF, DV9635EM, DV9638US, DV9639EO, DV9640CA, DV9640US, DV9643EO,
DV9644CA, DV9645ED, DV9645EF, DV9645EM, DV9645EO, DV9646EM, DV9647EF,
DV9647EM, DV9649EF, DV9649EM, DV9650ES, DV9650US, DV9651XX, DV9652XX,
DV9653CL, DV9655EA, DV9655EO, DV9655EZ, DV9657CL, DV9657EM, DV9657EO,
DV9658EA, DV9660EB, DV9660EF, DV9660EG, DV9660EI, DV9660EV, DV9665EL,
DV9665EO, DV9667EA, DV9670ED, DV9670EE, DV9670EF, DV9670EL, DV9670EM,

DV9670EO, DV9675EG, DV9675EL, DV9675EO, DV9680ED, DV9680EF, DV9680EP,
DV9680EV, DV9680EW, DV9680EZ, DV9681ER, DV9682EG, DV9684EG, DV9685EO,
DV9686EO, DV9687EO, DV9688EG, DV9689EA, DV9690EE, DV9690EI, DV9690EL,
DV9690EN, DV9690EV, DV9690EW, DV9690EZ, DV9691EG, DV9694EG, DV9695EA,
DV9695EF, DV9695EG, DV9695EL, DV9695EO, DV9698EO, DV9699EF, DV9700, DV9700T,
DV9700Z, DV9701AU, DV9701AX, DV9701TX, DV9701XX, DV9702AU, DV9702AX,
DV9702TX, DV9702XX, DV9703AX, DV9703TX, DV9703XX, DV9704AX, DV9704TX,
DV9705AX, DV9705TX, DV9706AX, DV9706TX, DV9711TX, DV9712TX, DV9714TX,
DV9715NR, DV9715TX, DV9716TX, DV9717TX, DV9718TX, DV9719TX, DV9720CA,
DV9720TX, DV9720US, DV9723CA, DV9723CL, DV9724CA, DV9727CL, DV9727TX,
DV9727US, DV9728CA, DV9728CL, DV9728TX, DV9729TX, DV9730CA, DV9730NR,
DV9730TX, DV9730US, DV9731CA, DV9732TX, DV9733TX, DV9734NR, DV9735TX,
DV9736CA, DV9736TX, DV9737TX, DV9738TX, DV9740CA, DV9740TX, DV9740US,
DV9741TX, DV9742TX, DV9743CL, DV9743TX, DV9744CA, DV9744TX, DV9745TX,
DV9746TX, DV9747CL, DV9747TX, DV9748CA, DV9750US, DV9751XX, DV9758CA,
DV9770LA, DV9774CA, DV9775LA, DV9780LA, DV9785LA, DV9800, DV9803TX,
DV9804CA, DV9808CA, DV9808TX, DV9809TX, DV9810CA, DV9810TX, DV9810US,
DV9811TX, DV9812TX, DV9812US, DV9813TX, DV9814TX, DV9815NR, DV9815TX,
DV9817CL, DV9818TX, DV9819TX, DV9819WM, DV9820TX, DV9820US, DV9821TX,
DV9822TX, DV9823CA, DV9823CL, DV9823TX, DV9824CA, DV9825NR, DV9827CL,
DV9830US, DV9831CA, DV9834CA, DV9838CA, DV9843CL, DV9847CA, DV9851XX,
DV9854CA, DV9858CA, DV9894CA, DV9899XX, DV9900, DV9901TX, DV9903CA,
DV9904CA, DV9907CA, DV9908CA, DV9910CA, DV9910US, DV9912NR, DV9913CL,
DV9917CL, DV9920US, DV9922US, DV9924CA, DV9925NR, DV9927CL, DV9930US,
DV9933CA, DV9933CL, DV9933NR, DV9934CA, DV9999US, DX6600, DX6650CA,
DX6650US, DX6653CA, DX6665CA, DX6667CL, DX6697US, DX6699XX, G3000, G3000EA,
G3050EA, G3100, G5000, G5001TU, G5002TU, G5003EA, G5009EA, G5040EA, G5042EA,
G5050, G5050XX, G5051TU, G6000, G6000XX, G7000, G7001TU, G7002TU, G7030,
G7030XX, G7031TU, G7032TU, G7060, G7061TU, G7091TU, TX1000, TX1001XX,
TX1002XX, TX1003XX, TX1017AU, TX1020EA, TX1021AU, TX1030EA, TX1040EA,
TX1070BR, TX1080EA, TX1100, TX1110CA, TX1110US, TX1115NR, TX1119US, TX1120US,
TX1127CL, TX1200, TX1201XX, TX1202AU, TX1202XX, TX1205US, TX1206AU, TX1208CA,
TX1210CA, TX1210US, TX1215NR, TX1217CL, TX1218AU, TX1218CA, TX1219US,
TX1220AU, TX1220CA, TX1220US, TX1228CA, TX1230LA, TX1232LA, TX1304AU,
TX1304CA, TX1305AU, TX1305CA, TX1305US, TX1306NR, TX1307AU, TX1308CA,
TX1308NR, TX1313AU, TX1314AU, TX1314CA, TX1315AU, TX1316AU, TX1317AU,
TX1318AU, TX1318CA, TX1319AU, TX1320AU, TX1320CA, TX1320US, TX1321AU,
TX1325NR, TX1327CL, TX1330LA, TX1332LA, TX1400, TX1401AU, TX1403AU, TX1404AU,
TX1410US, TX1414CA, TX1416CA, TX1417CL, TX1418CA, TX1419NR, TX1420CA,
TX1420US, TX1499US, TX2000, TX2000Z, TX2002AU, TX2003AU, TX2005AU, TX2006AU,
TX2008AU, TX2010AU, TX2013AU, TX2014AU, TX2015AU, TX2016AU, TX2018AU,
TX2019AU, TX2020AU, TX2021AU, TX2023AU, TX2024AU, TX2025AU, TX2026AU,
TX2027AU, TX2030AU, TX2031AU, TX2032LA, TX2033AU, TX2051XX, TX2052XX,
TX2053XX, TX2054XX, TX2104AU, TX2104CA, TX2105, TX2105AU, TX2106AU, TX2107AU,

TX2108AU, TX2108CA, TX2109AU, TX2110AU, TX2110CA, TX2110US, TX2113CL, TX2114CA, TX2115NR, TX2117CL, TX2120US, TX2151XX, TX2152XX, TX2500, TX2500Z, TX2501AU, TX2504AU, TX2507AU, TX2508AU, TX2508CA, TX2510AU, TX2510CA, TX2511AU, TX2512AU, TX2513AU, TX2513CL, TX2514AU, TX2514CA, TX2516AU, TX2517AU, TX2517CA, TX2517CL, TX2518AU, TX2519AU, TX2520AU, TX2521AU, TX2524CA, TX2525AU, TX2525NR, TX2526AU, TX2527AU, TX2528AU, TX2532AU, TX2534AU, TX2551XX, TX2552XX, TX2601AU, TX2604AU, TX2604CA, TX2605AU, TX2608AU, TX2608CA, TX2609AU, TX2610AU, TX2611AU, TX2612AU, TX2614AU, TX2615AU, TX2616AU, TX2617CA, TX2622NR, TX2623CA, TX2635US, TX2697CL, V9500T, V9500Z, X1000, X1000Z, ZE2000, ZE2000-PM341AV, ZE2000-PM342AV, ZE2000T, ZE2000T-PQ648AV, ZE2000Z, ZE2000Z-PV336AV, ZE2000Z-PV337AV, ZE2001AP-PS928PA, ZE2001EA-PS723EA, ZE2001EA-PS733EA, ZE2001XX, ZE2002AP-PT362PA, ZE2002EA-PS728EA, ZE2003AP-PT363PA, ZE2004AP-PT369PA, ZE2004US, ZE2004US-PX390UA, ZE2005AP-PT519PA, ZE2005EA-PW956EA, ZE2005US, ZE2006AP-PT520PA, ZE2007AP-PT521PA, ZE2007EA-PS735EA, ZE2008AP-PT522PA, ZE2008WM, ZE2008WM-X391UA, ZE2009AP-PT523PA, ZE2010AP, ZE2010AP-PT532PA, ZE2010BR, ZE2010BR-PX285LA, ZE2010EA-PS721EA, ZE2011AP, ZE2011AP-PT533PA, ZE2012AP, ZE2012AP-PT539PA, ZE2013AP, ZE2013AP-PT540PA, ZE2014AP, ZE2014AP-PV278PA, ZE2015AP, ZE2015AP-PV283PA, ZE2015EA-PS722EA, ZE2015US, ZE2015US-PX382UA, ZE2016AP, ZE2016AP-PV284PA, ZE2017AP, ZE2017AP-PV285PA, ZE2018AP, ZE2018AP-PV293PA, ZE2019AP-PY858PA, ZE2020AP-PY859PA, ZE2020BR, ZE2020BR-PX286LA, ZE2020CA, ZE2020CA-PX387UA, ZE2020EA-PS737EA, ZE2020EA-PW955EA, ZE2021EA-PW952EA, ZE2022AP, ZE2022EA-PW949EA, ZE2023EA-PW962EA, ZE2024EA-PW947EA, ZE2025EA-PS726EA, ZE2025EA-PS738EA, ZE2026EA-PS724EA, ZE2027EA-PS736EA, ZE2028EA-PS727EA, ZE2030BR, ZE2030BR-PX287LA, ZE2039EA-PS729EA, ZE2040BR, ZE2040BR-PX288LA, ZE2040EA-PS720EA, ZE2044EA-PW959EA, ZE2044EA-PW961EA, ZE2045EA-PS734EA, ZE2050EA-PW948EA, ZE2050EA-PW963EA, ZE2055EA-PS730EA, ZE2058EA-PW958EA, ZE2060EA-PS725EA, ZE2062EA-PW954EA, ZE2062EA-PW960EA, ZE2068EA-PS732EA, ZE2070EA-PS719EA, ZE2070EA-PS731EA, ZE2090EA-PW951EA, ZE2091EA-PW957EA, ZE2099XX, ZE2108WM, ZE2109US, ZE2110US, ZE2113US, ZE2114US, ZE2115US, ZE2117US, ZE2200, ZE2201XX, ZE2202XX, ZE2204AP, ZE2204AU, ZE2206AU, ZE2207AP, ZE2207AU, ZE2208AP, ZE2209XX, ZE2210AU, ZE2210BR, ZE2211AP, ZE2211AU, ZE2212AP, ZE2213TU, ZE2215TU, ZE2216TU, ZE2220BR, ZE2250EA, ZE2296XX, ZE2297XX, ZE2298XX, ZE2299XX, ZE2300, ZE2308, ZE2308EA, ZE2308WM, ZE2309NR, ZE2315, ZE2315US, ZE2320LA, ZE2372EA, ZE2401EA, ZE2401XT, ZE2405EA, ZE2409EA, ZE2410EA, ZE2415EA, ZE2500, ZE2505AU, ZE2506AU, ZE4900, ZT3000, ZT3001US, ZT3010, ZT3010AP, ZT3010EA, ZT3010US, ZT3011AP, ZT3012EA, ZT3013AP, ZT3014AP, ZT3015AP, ZT3015EA, ZT3016AP, ZT3017AP, ZT3017EA, ZT3017WM, ZT3018AP, ZT3019AP, ZT3019EA, ZT3020, ZT3020AP, ZT3020EA, ZT3020US, ZT3021AP, ZT3022AP, ZT3022EA, ZT3023AP, ZT3024AP, ZT3024EA, ZT3025AP, ZT3026AP, ZT3027AP, ZT3028AP, ZT3029AP, ZT3030AP, ZT3030EA, ZT3031AP, ZT3032AP, ZT3033AP, ZT3034AP, ZT3035AP, ZT3036AP, ZT3037AP, ZT3038AP, ZT3039AP, ZT3040AP, ZT3041AP, ZT3043AP, ZT3044AP, ZT3045AP, ZT3046AP, ZT3047AP, ZT3048AP, ZT3049AP, ZT3050AP, ZT3050EA, ZT3051AP,

ZT3068CL, ZT3101EA, ZT3101US, ZT3105EA, ZT3106EA, ZT3110EA, ZT3111EA, ZT3113EA, ZT3114EA, ZT3115EA, ZT3116EA, ZT3120EA, ZT3130EA, ZT3131EA, ZT3140US, ZT3170US, ZT3200, ZT3201US, ZT3202AP, ZT3206AP, ZT3207AP, ZT3208AP, ZT3209AP, ZT3210AP, ZT3210EA, ZT3211AP, ZT3211EA, ZT3212AP, ZT3213AP, ZT3214AP, ZT3214EA, ZT3215AP, ZT3215EA, ZT3216AP, ZT3217AP, ZT3218AP, ZT3219AP, ZT3220AP, ZT3221AP, ZT3222AP, ZT3225AP, ZT3228AP, ZT3229AP, ZT3230AP, ZT3231AP, ZT3232AP, ZT3232EA, ZT3235AP, ZT3236AP, ZT3237AP, ZT3239EA, ZT3240EA, ZT3241EA, ZT3242EA, ZT3250, ZT3250US, ZT3260EA, ZT3280US, ZT3300, ZT3301AP, ZT3301US, ZT3302AP, ZT3302US, ZT3303AP, ZT3304AP, ZT3305AP, ZT3306AP, ZT3307AP, ZT3308AP, ZT3309AP, ZT3311AP, ZT3312AP, ZT3313AP, ZT3314AP, ZT3315AP, ZT3316AP, ZT3317AP, ZT3318AP, ZT3319AP, ZT3320AP, ZT3321AP, ZT3323AP, ZT3325AP, ZT3326AP, ZT3327AP, ZT3328AP, ZT3330AP, ZT3331AP, ZT3332AP, ZT3338AP, ZT3339AP, ZT3340US, ZT3341AP, ZT3343AP, ZT3344AP, ZT3345AP, ZT3346AP, ZT3348AP, ZT3349AP, ZT3349CL, ZT3350AP, ZT3350US, ZT3351AP, ZT3354AP, ZT3355AP, ZT3355US, ZT3358AP, ZT3359AP, ZT3380US, ZT3380XX, ZT3400, ZT4000, ZT4900,

Special Edition series

L2000, L2005A3, L2005A4, L2005CL, L2005CM, L2005CO, L2005CU, L2005CX, L2005US, L2098XX, L2099XX, L2105CA, L2105CL, L2105NR, L2205NR, L2300, L2310CU,

Voodoo Envy series

133 NV4010NA, 133 NV4015NA, 133 NV4020NA, 133 NV4040NA, 133 NV4045NA, 133 NV4050NA, 133 NV4070NA, 133 NV4075NA, 133 NV4080NA,

18.5V2.7A 4.8mm*1.7mm 50W

Compaq

Armada series

110, E500, E500S, E700, M300, M700, SB, V300,

Evo series

N110, N115, N150, N160, N180, N200, N400C, N410C, N600, N600C, N610, N610C, N610V, N620C,

LTE series

ELITE, LITE,

Presario series

1500, 2800, 2800AP, 2800AU, 2800CA, 2800EA, 2800SC, 2800TC, 2800US, 2801AP, 2801EA, 2801SC, 2801TC, 2802AP, 2802EA, 2802SC, 2802TC, 2803TC, 2804SC, 2804TC, 2805AP, 2805AU, 2805EA, 2805TC, 2805US, 2806AP, 2806EA, 2806SC, 2807AP, 2808EA, 2809AP, 2809FR, 2810AP, 2810AU, 2810CA, 2810EA, 2810LA, 2810SC, 2810TC, 2811AP, 2811EA, 2811SW, 2812AP, 2812AU, 2812SP, 2812TC, 2813TC, 2814AP, 2814AU, 2815AP, 2815AU, 2815EA, 2815LA, 2815SP, 2815TC, 2816EA, 2816KR, 2816TC, 2817AP, 2817AR, 2817EA, 2817KR, 2817TC, 2818AP, 2818FR, 2818KR, 2818TC, 2819AP, 2819TC, 2820AP, 2820AU, 2820EA, 2820SC, 2820TC, 2821AP, 2821AU, 2821DE, 2821EA, 2821SC, 2821TC, 2822AP, 2822EA, 2822TC, 2823AP, 2823AU, 2823TC, 2824AP, 2824TC, 2825AP, 2825EA,

2825TC, 2826AP, 2826EA, 2826TC, 2827AP, 2827TC, 2828AP, 2828TC, 2829AP, 2829TC, 2830AP, 2830AU, 2830EA, 2830SC, 2830TC, 2831AP, 2831SC, 2831TC, 2832AP, 2832SC, 2832TC, 2833TC, 2834TC, 2835AP, 2835EA, 2836AP, 2836TC, 2837AP, 2837EA, 2837TC, 2838AP, 2838TC, 2839AP, 2839TC, 2840AP, 2840TC, 2841AP, 2842AP, 2843AP, 2844AP, 2845AP, 2846AP, 2850AP, 2851AP, 2852AP, 2853AP, 2854AP, 2855AP, 2856AP, 2857AP, 2858AP, 2859AP, 2860AP, 2861AP, 2862AP, 2863AP, 2864AP, 2865AP, 2866AP, 2867AP, 2868AP, 2869AP, 2870AP, 2871AP, 2872AP, 2873AP, 2874AP, 2875AP, 2876AP, 2877AP, 2878AP, 2878CL, 2879AP, 2879CL, 2880AP, 2880CL, 2881CL, 2882AP, 2883AP, 2884AP, 2885AP, 2886AP, 2887AP, 2888AP, 2889AP, 2890AP, 2891AP, 2892AP, 2893AP, 2894AP, 2895AP, 2896AP, 2897AP, 2898AP, 2899AP, 300, 900, 900LA, 900US, 900XX, 901AP, 901EA, 901XX, 902AP, 902AU, 902EA, 902FR, 902XX, 903AP, 903EA, 903KR, 903TU, 903XX, 904AP, 905AP, 905AU, 905LA, 905TC, 905US, 906EA, 906US, 907AP, 908EA, 908TU, 909EA, 910AP, 910EA, 910US, 912EA, 912RSH, 914EA, 915US, 916US, 917DE, 918RSH, 920AP, 920CA, 920EA, 921AP, 922UK, 923AP, 925AP, 925EA, 927AP, 935AP, 940AP, 943AP, 945AP, 950AP, 955AP, A900,

Prosignia series

120, 122, 124, 140, 142, 144, 150, 160, 161, 162, 165, 170, 190, 486, 586,

END H15

H16

Lenovo 20V3.25A 4.0mm*1.7mm 65W

Lenovo
FLEX4-1570,

IdeaPad SERIES
100-151IBD, 100-15IBY, 510S-13IKB,

Lenovo 20V2.25A 4.0mm*1.7mm 45W

Lenovo
B50-10, FLEX 4, FLEX4-1470, FLEX4-1570,

Chromebook SERIES
100S, N21,

IdeaPad SERIES
100 14", 100 15", 100-14, 100-14IBR, 100-14IBY, 100-15, 100-15IBD, 100-15IBY, 100S 14",
100S-14IBR, 510S-14ISK, 710S, 710S-13, 710S-13ISK, I100,

Yoga SERIES
310-14, 510-14, 710-13,

Toshiba 19V1.58A 19V2.1A 19V2.37A 4.0mm*1.7mm

Toshiba Thrive 10-inch Tablet / 7-inch Tablet / AT105 / AT105-T1016 / AT105-T1032 /
AT105-T108 / AT105-T108S

Radius 12 P25W, Satellite U925t U920t W35Dt L30W L35W P30W P35W,
U925T-S2100, U925T-S2120, U925T-S2130, U925T-S2300, U925T-S2301

Toshiba Portege Z10T Z15T Z20T WT20 PA5072U-1ACA PA5192U-1ACA PA3922U-1ARA
PA5072A-1AC3

Toshiba Chromebook 2 13.3 inch CB30:
CB30-B, CB30-B3121, CB30-B3122, CB30-B3123

Toshiba Chromebook 2 13.3 inch CB35:
CB35-B, CB35-B3330, CB35-B3340; CB35-C, CB35-C3300

HP 19V2.1A 19V1.58A 19.5V2.05A 4.0mm*1.7mm

HP Mini 210 PC series
Hp Mini 110, 210, 1000, 1100
Compaq Mini 110, 210, 700, Cq10

END H16