



Asus 19V 3.42A 4.0mm*1.35mm 65W

Asus

UX30, X302LJ, X302UJ, X302UV, X303L,

Transformer Book Flip series

TP300LJ, TP300LJ-DW024H,

Zenbook series

U38DT, UX301, UX301LA, UX302L, UX303L, UX303LA, UX303LB, UX303LN, UX303U, UX303UA,

UX303UB, UX32L, UX32LN, UX360, UX360C, UX360CA, UX360UA, UX360UAK, UX50,

Zenbook Prime series

UX32V, UX32VD, UX42V, UX42VS, UX52VS,

Asus 19V 2.37A 4.0mm*1.35mm 45W

Asus

F540S, F553M, X302LJ, X302UA, X302UJ, X302UV, X441SC, X441UA, X441UV, X456UA, X540LA, X540LJ, X540SC, X540YA, X541SC, X541UA, X553M, X556UA,

TaiChi series

21, 31,

Vivobook series

F201E, Q200, Q200E, S200, S200E, X201, X201E, X202, X202E,

VivoBook Flip series

TP301UA, TP501UA,

Zenbook series

BX21A, BX31A, BX32A, U38DT, U38N, UK31K, UX21, UX21A, UX21E, UX21E-KX007V, UX21E-KX008D, UX301, UX301LA, UX302L, UX302LA, UX302LG, UX302LG-C4019H, UX302LG-C4019P, UX303L, UX303LA, UX303LB, UX303LN, UX303U, UX303UA, UX303UB, UX305C, UX305CA, UX305UA, UX31, UX310UA, UX31A, UX31A-1AR4, UX31A-1AR5, UX31A-1AR7, UX31A-AB71, UX31A-AB72, UX31A-BHI5T11, UX31A-DB51, UX31A-DB52, UX31E, UX31K, UX31LA, UX32A, UX32L, UX32LA, UX32LN, UX330CA, UX330UA, UX360, UX360C, UX360CA, UX360UA, UX360UAK, UX42VS, UX50, UX52VS, UX560UA,

Zenbook Prime series

UX32V, UX32VD, UX42V, UX42VS, UX52VS,

Asus 19V 1.75A 4.0mm*1.35mm 33W

VivoBook series

F200MA F102BA X102BA X200MA X200LA K200MA C200MA C300MA X102BA F102BA R103BA
X200CA X200LA X200MA X201E X202E F200CA R200CA F200MA F200LA F201E

ZenBook series

UX305 UX21A UX31A UX32A BX21A BX31A BX32A F201E Q200E S200E S220 X200T X201E X202E
C200 C300 Q200 S200L S220 X453m F453 X403M