



**19V 4.74A HP 7.4mm\*5.0mm 90W**

Compaq

Presario series

320, 321, 325, 326, 420, 421, 621, CQ32, CQ35, CQ40, CQ41, CQ42, CQ45, CQ50, CQ50Z, CQ60, CQ61, CQ62, CQ70, CQ71, CQ72,

HP

### Business Notebook series

2210B, 2510P, 2710P, 6510B, 6515B, 6520S, 6530B, 6530S, 6531S, 6535B, 6535S, 6710B, 6710S, 6715B, 6715S, 6730B, 6730S, 6735B, 6735S, 6830S, 6910P, 8510P, 8510W, 8710P, 8710W, NC2400, NC4400, NC6220, NC6230, NC6320, NC6400, NC8430, NW8440, NW9440, NX6310, NX6315, NX6320, NX6325, NX7300, NX7400, NX9420,

### EliteBook series

2530P, 2730P, 6930P, 8440P, 8440W, 8460P, 8460W, 8530P, 8530W, 8540P, 8540W, 8730P,

### Envy series

13, 14, 14-1000XX, 14-1001TX, 14-1010NR, 14-1011NR, 14-1110NR, 14-1111NR, 14-1150CA, 14-1154CA, 14-1155CA, 14-1160SE, 14-1163SE, 14-1210NR, 14-1211NR, 14-1260SE, 14-2001XX, 14-2020NR, 14-2050SE, 14-2054SE, 14-2070NR, 14-2090CA, 14-2130NR, 14-2160CA, 14-2160SE, 14-2161SE, 14T-1000, 14T-1100, 14T-1200, 14T-2000, 15, 17,

### HDX series

X16-1001XX, X16-1004TX, X16-1006TX, X16-1008TX, X16-1009TX, X16-1011TX, X16-1012TX, X16-1013TX, X16-1014TX, X16-1015TX, X16-1025NR, X16-1040US, X16-1044NR, X16-1056CA, X16-1140US, X16-1145DX, X16-1155CA, X16-1160US, X16-1201TX, X16-1202TX, X16-1203TX, X16-1301TX, X16-1370US, X16-1375DX, X16T-1000, X16T-1100, X16T-1200,

### Pavilion series

DM1, DM1-1004TU, DM1-1005TU, DM1-1006TU, DM1-1010EO, DM1-1020ED, DM1-1020SA, DM1-1022TU, DM1-1023TU, DM1-1025TU, DM1-1029TU, DM1-1030SA, DM1-1031TU, DM1-1117TU, DM1-1118TU, DM1-1121TU, DM1-1122TU, DM1-1126TU, DM1-1128TU, DM1-1130TU, DM1-1190EE, DM1-2001AU, DM1-2001XX, DM1-2002AU, DM1-2002NR, DM1-2004AU, DM1-2005AU, DM1-2010NR, DM1-2011NR, DM1-2140CA, DM1-3005XX, DM1-3010NR, DM1-3011NR, DM1-3020US, DM1-3023NR, DM1-3025DX, DM1-3040CA, DM1-3210US, DM1-3214NR, DM1-3240CA, DM1-3245CA, DM1-3248CA, DM1-4001XX, DM1-4010US, DM1-4013NR, DM1-4018CA,

DM1-4050US, DM1-4051XX, DM1-4054NR, DM1-4170US, DM1Z-2000, DM1Z-2100,  
DM1Z-3000, DM1Z-3200, DM1Z-4000, DM1Z-4100, DM3, DM3-1001AU,  
DM3-1001TU, DM3-1002AX, DM3-1004XX, DM3-1006AX, DM3-1007AU,  
DM3-1007AX, DM3-1007TU, DM3-1008AX, DM3-1008TU, DM3-1009AX,  
DM3-1009TU, DM3-1011TX, DM3-1012TX, DM3-1013AX, DM3-1016TU, DM3-1017TX,  
DM3-1018TX, DM3-1019TX, DM3-1020AX, DM3-1022AX, DM3-1026TX, DM3-1030US,  
DM3-1034TX, DM3-1035DX, DM3-1039WM, DM3-1040US, DM3-1044NR,  
DM3-1047CL, DM3-1047NR, DM3-1053XX, DM3-1058NR, DM3-1103AU,  
DM3-1105AU, DM3-1105AX, DM3-1107AU, DM3-1107AX, DM3-1108AX,  
DM3-1108TU, DM3-1109AX, DM3-1110TX, DM3-1112AX, DM3-1113TX,  
DM3-1114AX, DM3-1115AX, DM3-1116TX, DM3-1121AX, DM3-1124CA,  
DM3-1124TX, DM3-1125TX, DM3-1126AX, DM3-1126TX, DM3-1130US,  
DM3-1131NR, DM3-1140US, DM3-1148LA, DM3-1150EE, DM3-1180EE, DM3-1190EE,  
DM3-2001AX, DM3-2010US, DM3-3001XX, DM3-3004XX, DM3-3010CA,  
DM3-3010US, DM3-3011NR, DM3-3012NR, DM3-3027CL, DM3-3110US,  
DM3-3112NR, DM3-3130CA, DM3T-1000, DM3T-1100, DM3T-3000, DM3Z-1000,  
DM3Z-1100, DM3Z-2000, DM4, DM4-1001TU, DM4-1001TX, DM4-1002TU,  
DM4-1003XX, DM4-1004TU, DM4-1004XX, DM4-1018TX, DM4-1060US,  
DM4-1062NR, DM4-1063CL, DM4-1063HE, DM4-1065DX, DM4-1150CA,  
DM4-1160US, DM4-1162US, DM4-1164NR, DM4-1165DX, DM4-1173CL,  
DM4-1201US, DM4-1250CA, DM4-1253CL, DM4-1265DX, DM4-1273CA,  
DM4-1275CA, DM4-1277SB, DM4-2015DX, DM4-2033CL, DM4-2050US,  
DM4-2053CA, DM4-2055CA, DM4-2058CA, DM4-2070US, DM4-2074NR,  
DM4-2153CA, DM4-2165DX, DM4-2180CA, DM4-2180US, DM4-2181NR,  
DM4-2184NR, DM4-2185CA, DM4-2191US, DM4-3007XX, DM4-3050US,  
DM4-3055DX, DM4-3090SE, DM4T-1000, DM4T-1100, DM4T-1200, DM4T-2000,  
DM4T-2100, DM4T-3000, DV2, DV2-1001XX, DV2-1003AU, DV2-1005AU,  
DV2-1007AU, DV2-1008AU, DV2-1011AX, DV2-1013AX, DV2-1014AX, DV2-1015AX,  
DV2-1016AX, DV2-1017AX, DV2-1018AX, DV2-1019AX, DV2-1020AX, DV2-1021AX,  
DV2-1024AX, DV2-1025AX, DV2-1026AX, DV2-1027AX, DV2-1028AX, DV2-1029AX,  
DV2-1030AX, DV2-1030US, DV2-1031AX, DV2-1033CL, DV2-1039WM, DV2-1110US,  
DV2-1118AX, DV2-1118NR, DV2-1119AX, DV2-1120AX, DV2-1121AX, DV2-1126AX,  
DV2-1134NR, DV2-1156XX, DV2-1199US, DV2-1201AU, DV2-1201AX, DV2-1202AU,  
DV2-1203AU, DV2-1206AU, DV2-1208AU, DV2-1209AU, DV2-1209AX, DV2-1210AX,  
DV2-1215AX, DV2Z-1100, DV3-1051XX, DV3-1052XX, DV3-1073CL, DV3-1075CA,  
DV3-1075US, DV3-1077CA, DV3-1253NR, DV3-2001TU, DV3-2001XX, DV3-2017TX,  
DV3-2023TX, DV3-2025TX, DV3-2028TX, DV3-2029TX, DV3-2035TX, DV3-2123TX,  
DV3-2150TX, DV3-2150US, DV3-2155MX, DV3-2157CL, DV3-2202TU, DV3-2203TU,  
DV3-2204TU, DV3-2209TX, DV3-2214TX, DV3-2216TX, DV3-2217TX, DV3-2219TX,  
DV3-2220EF, DV3-2228TX, DV3-2230TX, DV3-2231TX, DV3-2234TX, DV3-2237TX,  
DV3-2238TX, DV3-2239TX, DV3-2242TX, DV3-2244TX, DV3-2250EW, DV3-2302TU,

DV3-2302TX, DV3-2303TU, DV3-2307TX, DV3-2309TX, DV3-2310TX, DV3-2312TX,  
DV3-2313TX, DV3-2314TX, DV3-2315TX, DV3-2316TX, DV3-2320TX, DV3-2328TX,  
DV3-2331TX, DV3-2350EE, DV3-2355EE, DV3-4001TX, DV3-4007TX, DV3-4010TX,  
DV3-4019TX, DV3-4020TX, DV3000, DV3001TX, DV3002TX, DV3003TX, DV3004TX,  
DV3005TX, DV3005XX, DV3006TX, DV3006XX, DV3007TX, DV3007XX, DV3008TX,  
DV3009TX, DV3010TX, DV3011TX, DV3012TX, DV3013TX, DV3014TX, DV3015TX,  
DV3016TX, DV3017TX, DV3018TX, DV3019TX, DV3020TX, DV3021TX, DV3022TX,  
DV3023TX, DV3024TX, DV3025TX, DV3026TX, DV3027TX, DV3028TX, DV3029TX,  
DV3030TX, DV3100, DV3101TX, DV3102TX, DV3103TX, DV3104TX, DV3105TX,  
DV3106TX, DV3107TX, DV3108TX, DV3109TX, DV3110TX, DV3111TX, DV3112TX,  
DV3113TX, DV3114TX, DV3115TX, DV3116TX, DV3117TX, DV3118TX, DV3119TX,  
DV3120TX, DV3500, DV3500EA, DV3500EN, DV3500ER, DV3500T, DV3501TX,  
DV3502TX, DV3503TX, DV3504TX, DV3505EA, DV3505XX, DV3506LA, DV3506TX,  
DV3507EA, DV3507TX, DV3508BR, DV3508TX, DV3509TX, DV3510ER, DV3510NR,  
DV3510TX, DV3511TX, DV3512TX, DV3513TX, DV3514TX, DV3515EE, DV3515EF,  
DV3515EI, DV3515TX, DV3516TX, DV3517TX, DV3518TX, DV3519TX, DV3520ER,  
DV3520TX, DV3521TX, DV3522TX, DV3523TX, DV3524TX, DV3525EF, DV3525TX,  
DV3526TX, DV3527TX, DV3528TX, DV3529TX, DV3530ES, DV3530ET, DV3530TX,  
DV3531TX, DV3532TX, DV3533TX, DV3534TX, DV3535TX, DV3536TX, DV3537TX,  
DV3538TX, DV3539TX, DV3540ES, DV3540TX, DV3541TX, DV3542TX, DV3543TX,  
DV3544TX, DV3545EI, DV3545TX, DV3550EE, DV3550EG, DV3550EL, DV3550EO,  
DV3550EP, DV3550ES, DV3550EZ, DV3560EP, DV3560EV, DV3570EI, DV3600,  
DV3600EC, DV3600EG, DV3600EO, DV3600T, DV3601TX, DV3602TX, DV3603TX,  
DV3604LA, DV3604TX, DV3605TX, DV3606TX, DV3607TX, DV3608TX, DV3609TX,  
DV3610EA, DV3610EO, DV3610T, DV3610TX, DV3611TX, DV3612TX, DV3613TX,  
DV3614TX, DV3615TX, DV3616TX, DV3617TX, DV3618TX, DV3619TX, DV3620EF,  
DV3620TX, DV3621TX, DV3622TX, DV3623TX, DV3624TX, DV3625EE, DV3625EI,  
DV3625TX, DV3626TX, DV3627TX, DV3628TX, DV3629EB, DV3629TX, DV3630TX,  
DV3631TX, DV3632TX, DV3633TX, DV3634TX, DV3635TX, DV3636TX, DV3637TX,  
DV3640EW, DV3650EF, DV3650EG, DV3650EI, DV3650EK, DV3650EL, DV3650EP,  
DV3650EZ, DV3655EE, DV3660EI, DV3660EJ, DV3660EW, DV3680ES, DV3699EF,  
DV3700, DV3701TX, DV3702TX, DV3703TX, DV3704TX, DV3705TX, DV3706TX,  
DV3707TX, DV3800, DV3888NR, DV3T-2000, DV3Z-1000, DV4, DV4-1000,  
DV4-1001AX, DV4-1001XX, DV4-1002AX, DV4-1002XX, DV4-1004TU, DV4-1004TX,  
DV4-1005TX, DV4-1006TX, DV4-1007TX, DV4-1008TX, DV4-1009TX, DV4-1010TX,  
DV4-1011TX, DV4-1012TX, DV4-1013TX, DV4-1014, DV4-1014N, DV4-1014NR,  
DV4-1014TX, DV4-1015, DV4-1016, DV4-1019TX, DV4-1020, DV4-1020TX,  
DV4-1020US, DV4-1022TX, DV4-1023TX, DV4-1024TX, DV4-1025TX, DV4-1026TX,  
DV4-1027TX, DV4-1028, DV4-1028TX, DV4-1028US, DV4-1029TX, DV4-1030,  
DV4-1030TX, DV4-1031TX, DV4-1032TX, DV4-1033TX, DV4-1034TX, DV4-1036TX,  
DV4-1040, DV4-1046TX, DV4-1047TX, DV4-1048TX, DV4-1049TX, DV4-1050,

DV4-1051TX, DV4-1051XX, DV4-1052TX, DV4-1052XX, DV4-1053XX, DV4-1055TX,  
DV4-1070, DV4-1101XX, DV4-1102XX, DV4-1107TX, DV4-1108TX, DV4-1109TX,  
DV4-1110TX, DV4-1114NR, DV4-1116TX, DV4-1117CA, DV4-1117NR, DV4-1118CA,  
DV4-1118TX, DV4-1120, DV4-1120US, DV4-1121BR, DV4-1121CA, DV4-1123US,  
DV4-1124NR, DV4-1125, DV4-1125NR, DV4-1127TX, DV4-1129TX, DV4-1130TX,  
DV4-1132TX, DV4-1134TX, DV4-1139TX, DV4-1140GO, DV4-1140TX, DV4-1142TX,  
DV4-1143GO, DV4-1143TX, DV4-1144TX, DV4-1144US, DV4-1145, DV4-1145GO,  
DV4-1145TX, DV4-1146TX, DV4-1147CL, DV4-1147TX, DV4-1148TX, DV4-1149TX,  
DV4-1150TX, DV4-1153TX, DV4-1154TX, DV4-1155, DV4-1155SE, DV4-1155TX,  
DV4-1157TX, DV4-1159TX, DV4-1161TX, DV4-1163TX, DV4-1164TX, DV4-1165TX,  
DV4-1166CA, DV4-1166TX, DV4-1168TX, DV4-1169TX, DV4-1201AU, DV4-1201TX,  
DV4-1202AU, DV4-1202TX, DV4-1203AU, DV4-1203TX, DV4-1204AU, DV4-1204TX,  
DV4-1205TU, DV4-1206TU, DV4-1207TU, DV4-1208TU, DV4-1209TU, DV4-1210TU,  
DV4-1212TU, DV4-1212TX, DV4-1213TU, DV4-1213TX, DV4-1214TU, DV4-1214TX,  
DV4-1215TU, DV4-1215TX, DV4-1216TX, DV4-1217TX, DV4-1218TX, DV4-1219TX,  
DV4-1220TX, DV4-1220US, DV4-1221TX, DV4-1222NR, DV4-1222TX, DV4-1223TX,  
DV4-1224TX, DV4-1225DX, DV4-1225TX, DV4-1226TX, DV4-1227TX, DV4-1227US,  
DV4-1229TX, DV4-1230TX, DV4-1233TX, DV4-1234TX, DV4-1235TX, DV4-1236TX,  
DV4-1237TX, DV4-1238TX, DV4-1239TX, DV4-1243TX, DV4-1244TX, DV4-1245TX,  
DV4-1246TX, DV4-1247TX, DV4-1249TX, DV4-1250TX, DV4-1251TX, DV4-1252TX,  
DV4-1253TX, DV4-1254TX, DV4-1256TX, DV4-1257TX, DV4-1260TX, DV4-1261TX,  
DV4-1265DX, DV4-1272CM, DV4-1275MX, DV4-1280US, DV4-1281US, DV4-1282CM,  
DV4-1283CL, DV4-1287CL, DV4-1292CM, DV4-1302TX, DV4-1303TX, DV4-1304TU,  
DV4-1304TX, DV4-1305TU, DV4-1306TU, DV4-1307TU, DV4-1308TU, DV4-1309TU,  
DV4-1310TU, DV4-1311TU, DV4-1312TU, DV4-1313DX, DV4-1313TU, DV4-1314TU,  
DV4-1315TU, DV4-1316TU, DV4-1316TX, DV4-1317TU, DV4-1317TX, DV4-1318TX,  
DV4-1319TX, DV4-1322TX, DV4-1322US, DV4-1323TX, DV4-1324TX, DV4-1325TX,  
DV4-1327TX, DV4-1329TX, DV4-1330TX, DV4-1331TX, DV4-1332TX, DV4-1365DX,  
DV4-1379NR, DV4-1404TX, DV4-1412TU, DV4-1413LA, DV4-1415TU, DV4-1424LA,  
DV4-1427NR, DV4-1428DX, DV4-1428TX, DV4-1430US, DV4-1431US, DV4-1432TX,  
DV4-1433SB, DV4-1433US, DV4-1434TX, DV4-1435DX, DV4-1437TX, DV4-1438TX,  
DV4-1442TX, DV4-1443TX, DV4-1444DX, DV4-1502TU, DV4-1506TX, DV4-1509TX,  
DV4-1511TX, DV4-1514DX, DV4-1520BR, DV4-1526TX, DV4-1528TX, DV4-1530BR,  
DV4-1531TX, DV4-1540US, DV4-1541US, DV4-1543SB, DV4-1547SB, DV4-1548DX,  
DV4-1548NR, DV4-1551DX, DV4-1555DX, DV4-1580BR, DV4-1601TU, DV4-2012BR,  
DV4-2014BR, DV4-2016BR, DV4-2040US, DV4-2041NR, DV4-2045DX, DV4-2046NR,  
DV4-2049US, DV4-2049WM, DV4-2051XX, DV4-2058NR, DV4-2103TU, DV4-2103TX,  
DV4-2104TU, DV4-2105TU, DV4-2106TX, DV4-2107TX, DV4-2108TX, DV4-2113LA,  
DV4-2114TX, DV4-2116TX, DV4-2118TX, DV4-2119TX, DV4-2124TX, DV4-2125TX,  
DV4-2140US, DV4-2141NR, DV4-2142NR, DV4-2145DX, DV4-2148CA, DV4-2153CL,  
DV4-2155DX, DV4-2160US, DV4-2161NR, DV4-2162NR, DV4-2164US, DV4-2165DX,

DV4-2167SB, DV4-2169NR, DV4-2170US, DV4-4001XX, DV4-4004XX, DV4-4030US, DV4-4031HE, DV4-4032NR, DV4-4033NR, DV4-4038CA, DV4-4048CA, DV4-4140US, DV4-4141US, DV4-4270US, DV4I-2100, DV4T, DV4T-1000, DV4T-1100, DV4T-1200, DV4T-1200SE, DV4T-1300, DV4T-1300SE, DV4T-1400, DV4T-1500, DV4T-1600, DV4T-4000, DV4T-4100, DV4T-4200, DV4Z-1000, DV4Z-1100, DV4Z-1200, DV5, DV5-1000, DV5-1000T, DV5-1000US, DV5-1000Z, DV5-1001AU, DV5-1001TU, DV5-1001TX, DV5-1001XX, DV5-1002, DV5-1002AX, DV5-1002NR, DV5-1002TX, DV5-1002US, DV5-1002XX, DV5-1003CL, DV5-1003NR, DV5-1003XX, DV5-1004NR, DV5-1004TU, DV5-1004TX, DV5-1004XX, DV5-1005TU, DV5-1006AX, DV5-1006TU, DV5-1007, DV5-1007AX, DV5-1007CA, DV5-1007CL, DV5-1007TU, DV5-1008AX, DV5-1008CA, DV5-1008TU, DV5-1008TX, DV5-1009TU, DV5-1010, DV5-1010TU, DV5-1010US, DV5-1011, DV5-1011TX, DV5-1012TX, DV5-1013TX, DV5-1014TX, DV5-1015NR, DV5-1017NR, DV5-1017TX, DV5-1018TX, DV5-1019, DV5-1020, DV5-1022TX, DV5-1023TX, DV5-1024TX, DV5-1025TX, DV5-1026TX, DV5-1027TX, DV5-1028CA, DV5-1028TX, DV5-1029TX, DV5-1030, DV5-1030TX, DV5-1031TX, DV5-1032, DV5-1032TX, DV5-1033TX, DV5-1034CA, DV5-1034TX, DV5-1037TX, DV5-1038TX, DV5-1039TX, DV5-1040EW, DV5-1040TX, DV5-1041TX, DV5-1042TX, DV5-1043TX, DV5-1044CA, DV5-1044TX, DV5-1045TX, DV5-1046TX, DV5-1053TX, DV5-1054TX, DV5-1055TX, DV5-1056TX, DV5-1057TX, DV5-1058TX, DV5-1059TX, DV5-1062TX, DV5-1063TX, DV5-1064TX, DV5-1093XX, DV5-1094XX, DV5-1096XX, DV5-1098NR, DV5-1098XX, DV5-1099NR, DV5-1099XX, DV5-1100, DV5-1100Z, DV5-1102AX, DV5-1102TX, DV5-1103TU, DV5-1103TX, DV5-1104TX, DV5-1105AX, DV5-1105TU, DV5-1105TX, DV5-1107AX, DV5-1109AX, DV5-1111CA, DV5-1112AX, DV5-1112CA, DV5-1113, DV5-1113US, DV5-1114AX, DV5-1114TX, DV5-1115TX, DV5-1116, DV5-1116US, DV5-1118CA, DV5-1119NR, DV5-1119TX, DV5-1120, DV5-1120US, DV5-1121CA, DV5-1122TX, DV5-1123TX, DV5-1124TX, DV5-1125NR, DV5-1125TX, DV5-1126TX, DV5-1127CL, DV5-1128CA, DV5-1130CA, DV5-1130TX, DV5-1132, DV5-1132US, DV5-1133CA, DV5-1135CA, DV5-1135TX, DV5-1136TX, DV5-1137TX, DV5-1138CA, DV5-1138NR, DV5-1140, DV5-1140US, DV5-1143TX, DV5-1150, DV5-1150US, DV5-1157CA, DV5-1159SE, DV5-1160, DV5-1160US, DV5-1166, DV5-1166US, DV5-1174CA, DV5-1183CL, DV5-1196XX, DV5-1197XX, DV5-1198XX, DV5-1199XX, DV5-1201AX, DV5-1201TU, DV5-1201TX, DV5-1202AU, DV5-1202AX, DV5-1202TU, DV5-1202TX, DV5-1203AU, DV5-1203TX, DV5-1204AX, DV5-1204TU, DV5-1205AU, DV5-1205AX, DV5-1205TU, DV5-1206AU, DV5-1206AX, DV5-1206TU, DV5-1207AU, DV5-1207TU, DV5-1208AU, DV5-1208TU, DV5-1209AX, DV5-1210AX, DV5-1211AX, DV5-1212AX, DV5-1213AX, DV5-1214AX, DV5-1215AX, DV5-1215CA, DV5-1216AX, DV5-1216TX, DV5-1217TX, DV5-1218AX, DV5-1220TX, DV5-1224TX, DV5-1225CA, DV5-1225TX, DV5-1227TX, DV5-1228TX, DV5-1229TX, DV5-1230TX, DV5-1230US, DV5-1231TX, DV5-1233SE, DV5-1234SE, DV5-1234TX, DV5-1235DX, DV5-1236TX, DV5-1237TX, DV5-1238TX, DV5-1250US, DV5-1251NR, DV5-1253CL, DV5-1387NR, DV5-1388US, DV5-1392NR, DV5-2003XX, DV5-2035DX,

DV5-2043CL, DV5-2045DX, DV5-2051XX, DV5-2052XX, DV5-2070US, DV5-2072NR, DV5-2073NR, DV5-2074DX, DV5-2075NR, DV5-2077CL, DV5-2080BR, DV5-2129WM, DV5-2130US, DV5-2132DX, DV5-2134CA, DV5-2134US, DV5-2135DX, DV5-2138CA, DV5-2144CA, DV5-2155DX, DV5-2230US, DV5-2231NR, DV5-2238NR, DV5-2268CA, DV5105EU, DV5118EU, DV5T, DV5T-1000, DV5T-1100, DV5T-1200SE, DV5T-2000, DV5T-2100, DV5T-2200, DV5TSE-1100, DV5Z, DV5Z-1000, DV5Z-1100, DV5Z-1200, DV6, DV6-1001TX, DV6-1001XX, DV6-1004TX, DV6-1005TX, DV6-1006TX, DV6-1007TX, DV6-1008TX, DV6-1010TX, DV6-1014TX, DV6-1015TX, DV6-1027NR, DV6-1030CA, DV6-1030US, DV6-1038CA, DV6-1050US, DV6-1051XX, DV6-1053CL, DV6-1054CL, DV6-1101AU, DV6-1102AU, DV6-1102TU, DV6-1103AU, DV6-1103TU, DV6-1104AU, DV6-1104TU, DV6-1105AU, DV6-1105TU, DV6-1106AU, DV6-1107AU, DV6-1107AX, DV6-1108AU, DV6-1108AX, DV6-1109AU, DV6-1109AX, DV6-1110AU, DV6-1111AX, DV6-1112AX, DV6-1113TX, DV6-1114TX, DV6-1115TX, DV6-1116TX, DV6-1117TX, DV6-1118TX, DV6-1119TX, DV6-1120TX, DV6-1122US, DV6-1127TX, DV6-1131TX, DV6-1133TX, DV6-1149WM, DV6-1158TX, DV6-1201AU, DV6-1202AU, DV6-1202TU, DV6-1203AU, DV6-1203AX, DV6-1203TU, DV6-1203TX, DV6-1204TX, DV6-1206AU, DV6-1207AU, DV6-1207AX, DV6-1208AU, DV6-1221AX, DV6-1221TX, DV6-1222AX, DV6-1230US, DV6-1234NR, DV6-1234TX, DV6-1238NR, DV6-1240US, DV6-1241TX, DV6-1243CL, DV6-1244SB, DV6-1247CL, DV6-1250US, DV6-1253CL, DV6-1255TX, DV6-1256TX, DV6-1259DX, DV6-1260SE, DV6-1261TX, DV6-1263CL, DV6-1264TX, DV6-1265TX, DV6-1266TX, DV6-1268NR, DV6-1268TX, DV6-1270LA, DV6-1280US, DV6-1299LX, DV6-1303TU, DV6-1306EW, DV6-1308EW, DV6-1309TX, DV6-1310EQ, DV6-1310SL, DV6-1310TX, DV6-1314TX, DV6-1315TX, DV6-1316TX, DV6-1318TX, DV6-1320EQ, DV6-1320SL, DV6-1320SP, DV6-1322TX, DV6-1325TX, DV6-1330EA, DV6-1330EP, DV6-1330EQ, DV6-1330SP, DV6-1330TX, DV6-1331TX, DV6-1334TX, DV6-1334US, DV6-1335TX, DV6-1340EA, DV6-1340SL, DV6-1350SL, DV6-1350US, DV6-1351NR, DV6-1352DX, DV6-1353CL, DV6-1354US, DV6-1355DX, DV6-1359WM, DV6-1360US, DV6-1361SB, DV6-1362NR, DV6-1363CL, DV6-1375DX, DV6-1380EK, DV6-1441EE, DV6-1444EE, DV6-1446EE, DV6-1460EL, DV6-2001XX, DV6-2005AU, DV6-2005SF, DV6-2005SP, DV6-2006AU, DV6-2006TX, DV6-2007AU, DV6-2007AX, DV6-2010EA, DV6-2010EP, DV6-2010EQ, DV6-2010SL, DV6-2012AX, DV6-2015SL, DV6-2018AX, DV6-2019AX, DV6-2020SL, DV6-2025SL, DV6-2043US, DV6-2044DX, DV6-2051XX, DV6-2057CL, DV6-2066DX, DV6-2088DX, DV6-2090EP, DV6-2101AU, DV6-2101TU, DV6-2109AX, DV6-2109TX, DV6-2110AX, DV6-2110EL, DV6-2110SB, DV6-2111AX, DV6-2111TX, DV6-2112EL, DV6-2112TX, DV6-2115SL, DV6-2116EL, DV6-2117AX, DV6-2118EL, DV6-2119EL, DV6-2120EB, DV6-2120EE, DV6-2120SL, DV6-2123EL, DV6-2124EL, DV6-2125TX, DV6-2126EL, DV6-2126TX, DV6-2127EL, DV6-2127TX, DV6-2128CA, DV6-2129EL, DV6-2129TX, DV6-2130EL, DV6-2131EE, DV6-2131EL, DV6-2134EE, DV6-2134TX, DV6-2135EE, DV6-2136EL, DV6-2137EL, DV6-2137SL, DV6-2138EE, DV6-2141SL, DV6-2142SL, DV6-2143TX, DV6-2144NR, DV6-2144TX, DV6-2145EL, DV6-2150US, DV6-2151CL, DV6-2151EE,

DV6-2152NR, DV6-2154EE, DV6-2155DX, DV6-2155SE, DV6-2156TX, DV6-2157EL, DV6-2157SB, DV6-2157TX, DV6-2157US, DV6-2157WM, DV6-2158EE, DV6-2158NR, DV6-2158TX, DV6-2159EE, DV6-2159TX, DV6-2160EL, DV6-2162NR, DV6-2162SL, DV6-2163SL, DV6-2163TX, DV6-2164CA, DV6-2164EE, DV6-2164SL, DV6-2166SB, DV6-2168SL, DV6-2170SL, DV6-2170US, DV6-2171EE, DV6-2171NR, DV6-2171SL, DV6-2173CL, DV6-2175TX, DV6-2176TX, DV6-2180US, DV6-2182NR, DV6-2190EP, DV6-2190US, DV6-2192EL, DV6-3001AU, DV6-3001TX, DV6-3001XX, DV6-3002AU, DV6-3002XX, DV6-3003TU, DV6-3003XX, DV6-3004AX, DV6-3004TX, DV6-3006AX, DV6-3006TU, DV6-3007AX, DV6-3008TX, DV6-3010US, DV6-3012HE, DV6-3013CL, DV6-3013NR, DV6-3015TX, DV6-3016TX, DV6-3017NR, DV6-3019WM, DV6-3020US, DV6-3022US, DV6-3023NR, DV6-3023TX, DV6-3024TX, DV6-3025DX, DV6-3030US, DV6-3031NR, DV6-3031TX, DV6-3032NR, DV6-3033CL, DV6-3033HE, DV6-3033TX, DV6-3034NR, DV6-3034TX, DV6-3035TX, DV6-3036TX, DV6-3037NR, DV6-3037SB, DV6-3037TX, DV6-3040TX, DV6-3040US, DV6-3041TX, DV6-3049TX, DV6-3050US, DV6-3051XX, DV6-3053HE, DV6-3053TX, DV6-3055DX, DV6-3108CA, DV6-3109CA, DV6-3114CA, DV6-3118CA, DV6-3120US, DV6-3121NR, DV6-3122US, DV6-3123CL, DV6-3124NR, DV6-3127DX, DV6-3129NR, DV6-3130US, DV6-3131NR, DV6-3132NR, DV6-3133NR, DV6-3134CA, DV6-3134NR, DV6-3138CA, DV6-3140US, DV6-3143CA, DV6-3143CL, DV6-3143US, DV6-3144CA, DV6-3145DX, DV6-3147CA, DV6-3147SB, DV6-3150US, DV6-3152NR, DV6-3153NR, DV6-3155DX, DV6-3158CA, DV6-3160US, DV6-3163CL, DV6-3163NR, DV6-3167CA, DV6-3170CA, DV6-3174CA, DV6-3181NR, DV6-3194CA, DV6-3210US, DV6-3212NR, DV6-3216US, DV6-3217CL, DV6-3223CL, DV6-3225DX, DV6-3227CL, DV6-3230US, DV6-3231NR, DV6-3232NR, DV6-3234NR, DV6-3236NR, DV6-3237NR, DV6-3238NR, DV6-3240CA, DV6-3240US, DV6-3243CL, DV6-3250US, DV6-3257CL, DV6-3257SB, DV6-3259WM, DV6-3263CL, DV6-3264CA, DV6-3267CL, DV6-3268CA, DV6-3270CA, DV6-3275CA, DV6-3278CA, DV6-3280CA, DV6-3284CA, DV6-3286CA, DV6-3287CL, DV6-3370CA, DV6-3375CA, DV6-4001XX, DV6-4051NR, DV6-4052NR, DV6-4053CA, DV6-6013CL, DV6-6020CA, DV6-6033CL, DV6-6040CA, DV6-6047CL, DV6-6051XX, DV6-6070CA, DV6-6090US, DV6-6091NR, DV6-6096NR, DV6-6097NR, DV6-6104CA, DV6-6104NR, DV6-6106NR, DV6-6108US, DV6-6110US, DV6-6111NR, DV6-6112NR, DV6-6113CL, DV6-6115NR, DV6-6116NR, DV6-6117DX, DV6-6118NR, DV6-6119WM, DV6-6120US, DV6-6121HE, DV6-6123CL, DV6-6123NR, DV6-6124CA, DV6-6126NR, DV6-6127CL, DV6-6128CA, DV6-6128NR, DV6-6130CA, DV6-6130US, DV6-6131US, DV6-6135CA, DV6-6135DX, DV6-6136NR, DV6-6138NR, DV6-6140US, DV6-6144CA, DV6-6145CA, DV6-6145DX, DV6-6148CA, DV6-6148NR, DV6-6149NR, DV6-6150US, DV6-6152NR, DV6-6153CA, DV6-6153CL, DV6-6154NR, DV6-6155CA, DV6-6157NR, DV6-6158NR, DV6-6159US, DV6-6161HE, DV6-6163CL, DV6-6167CL, DV6-6169US, DV6-6170US, DV6-6172NR, DV6-6173CL, DV6-6175CA, DV6-6178CA, DV6-6180US, DV6-6181NR, DV6-6182NR, DV6-6183NR, DV6-6184CA, DV6-6185NR, DV6-6186NR, DV6-6188CA, DV6-6190US, DV6-6193CA, DV6-6195CA, DV6-6B19WM, DV6-6B21HE, DV6-6B22HE, DV6-6B27NR, DV6-6B47DX,



DV6-6B48NR, DV6-6B51NR, DV6-6B75CA, DV6-6B83CA, DV6-6C10US, DV6-6C13CL, DV6-6C14NR, DV6-6C15NR, DV6-6C40CA, DV6-6C40US, DV6-6C43CL, DV6-6C50CA, DV6-6C50US, DV6-6C53CL, DV6-6C53NR, DV6327CA, DV6327CL, DV6T-1000, DV6T-1100, DV6T-1200, DV6T-1300, DV6T-2000, DV6T-2300, DV6T-3000, DV6T-3100, DV6T-3200, DV6T-4000, DV6T-6000, DV6T-6100, DV6T-6B00, DV6T-6C00, DV6Z-1000, DV6Z-1100, DV6Z-2000, DV6Z-2100, DV6Z-3000, DV6Z-3100, DV6Z-3200, DV6Z-6100, DV6Z-6B00, DV6Z-6C00, DV7, DV7-1000, DV7-1001, DV7-1001TX, DV7-1001XX, DV7-1002, DV7-1002XX, DV7-1003, DV7-1003TX, DV7-1003XX, DV7-1004, DV7-1004TX, DV7-1005, DV7-1006, DV7-1006TX, DV7-1007, DV7-1008, DV7-1008TX, DV7-1009, DV7-1009TX, DV7-1010, DV7-1010, DV7-1010TX, DV7-1011, DV7-1011TX, DV7-1012, DV7-1012TX, DV7-1013, DV7-1013TX, DV7-1014, DV7-1014CA, DV7-1015, DV7-1016, DV7-1016NR, DV7-1016TX, DV7-1017, DV7-1017TX, DV7-1018, DV7-1018TX, DV7-1019, DV7-1020, DV7-1020TX, DV7-1021, DV7-1021TX, DV7-1022, DV7-1023, DV7-1023CL, DV7-1023TX, DV7-1024, DV7-1024TX, DV7-1025, DV7-1025NR, DV7-1025TX, DV7-1026, DV7-1027, DV7-1027CA, DV7-1027TX, DV7-1029, DV7-1030, DV7-1030TX, DV7-1031, DV7-1034, DV7-1034CA, DV7-1034TX, DV7-1035, DV7-1038, DV7-1038CA, DV7-1040, DV7-1045, DV7-1050, DV7-1051, DV7-1051XX, DV7-1052, DV7-1052XX, DV7-1053, DV7-1053XX, DV7-1055, DV7-1060, DV7-1065, DV7-1070, DV7-1075, DV7-1080, DV7-1090, DV7-1093, DV7-1094, DV7-1095, DV7-1098, DV7-1099, DV7-1100, DV7-1101XX, DV7-1102TX, DV7-1102XX, DV7-1103TX, DV7-1103XX, DV7-1123CA, DV7-1127CL, DV7-1128CA, DV7-1129WM, DV7-1130, DV7-1130US, DV7-1132NR, DV7-1133CL, DV7-1134, DV7-1134US, DV7-1135NR, DV7-1137, DV7-1137US, DV7-1150, DV7-1151XX, DV7-1153CA, DV7-1157CL, DV7-1170, DV7-1170US, DV7-1174CA, DV7-1175NR, DV7-1177CA, DV7-1183CL, DV7-1201TX, DV7-1201XX, DV7-1206TX, DV7-1207TX, DV7-1208TX, DV7-1209TX, DV7-1210TX, DV7-1214TX, DV7-1215TX, DV7-1216TX, DV7-1223CA, DV7-1228CA, DV7-1232NR, DV7-1240US, DV7-1243CL, DV7-1245CA, DV7-1245DX, DV7-1247CL, DV7-1253CA, DV7-1261WM, DV7-1262US, DV7-1264NR, DV7-1267CL, DV7-1270CA, DV7-1270US, DV7-1273CL, DV7-1275DX, DV7-1279WM, DV7-1285DX, DV7-1424NR, DV7-1426NR, DV7-1444US, DV7-1448DX, DV7-1450US, DV7-1451NR, DV7-1464NR, DV7-1468NR, DV7-2001XX, DV7-2003TX, DV7-2012TX, DV7-2013TX, DV7-2016TX, DV7-2021TX, DV7-2040CA, DV7-2040US, DV7-2043CL, DV7-2107TX, DV7-2110TX, DV7-2111US, DV7-2114TX, DV7-2122TX, DV7-2123TX, DV7-2124TX, DV7-2125TX, DV7-2126TX, DV7-2128TX, DV7-2170US, DV7-2173CL, DV7-2177CL, DV7-2180US, DV7-2185DX, DV7-2204TX, DV7-2206TX, DV7-2210TX, DV7-2211TX, DV7-2212EF, DV7-2212SF, DV7-2212TX, DV7-2230EA, DV7-2270EF, DV7-2270US, DV7-2273CL, DV7-2277CL, DV7-2301NR, DV7-3001XX, DV7-3002TX, DV7-3003TX, DV7-3010EW, DV7-3020EW, DV7-3025SF, DV7-3030EW, DV7-3051XX, DV7-3057NR, DV7-3060US, DV7-3061NR, DV7-3063CL, DV7-3065DX, DV7-3067CL, DV7-3067NR, DV7-3069WM, DV7-3078NR, DV7-3079NR, DV7-3079WM, DV7-3080ED, DV7-3080US, DV7-3085DX, DV7-3089NR, DV7-3090ED, DV7-3101TX, DV7-3108TX, DV7-3112TX,

DV7-3113TX, DV7-3114TX, DV7-3115TX, DV7-3116TX, DV7-3118TX, DV7-3120TX,  
DV7-3126TX, DV7-3127TX, DV7-3130SB, DV7-3133EL, DV7-3140EB, DV7-3148CA,  
DV7-3155EB, DV7-3155EL, DV7-3160EB, DV7-3160EL, DV7-3160EP, DV7-3160US,  
DV7-3162NR, DV7-3163CL, DV7-3164CL, DV7-3165DX, DV7-3165EB, DV7-3165EL,  
DV7-3166EB, DV7-3166NR, DV7-3167NR, DV7-3169WM, DV7-3171NR, DV7-3173NR,  
DV7-3174CA, DV7-3174NR, DV7-3180US, DV7-3183CL, DV7-3183NR, DV7-3186CL,  
DV7-3187CL, DV7-3188CL, DV7-4001TX, DV7-4003TX, DV7-4003XX, DV7-4007TX,  
DV7-4009TX, DV7-4010TX, DV7-4013TX, DV7-4021TX, DV7-4022TX, DV7-4051NR,  
DV7-4053CL, DV7-4060US, DV7-4061NR, DV7-4065DX, DV7-4069WM, DV7-4070US,  
DV7-4071NR, DV7-4073NR, DV7-4077CL, DV7-4080US, DV7-4083CL, DV7-4087CL,  
DV7-4101XX, DV7-4104CA, DV7-4127CA, DV7-4138CA, DV7-4148CA, DV7-4151NR,  
DV7-4153CL, DV7-4154CA, DV7-4157CL, DV7-4165DX, DV7-4167CA, DV7-4169WM,  
DV7-4170US, DV7-4171US, DV7-4173US, DV7-4174CA, DV7-4177CA, DV7-4177NR,  
DV7-4178CA, DV7-4178NR, DV7-4179NR, DV7-4180US, DV7-4182NR, DV7-4183CL,  
DV7-4190US, DV7-4191NR, DV7-4197CL, DV7-4198CA, DV7-4223CA, DV7-4248CA,  
DV7-4260CA, DV7-4263CL, DV7-4264CA, DV7-4267CL, DV7-4269WM, DV7-4270US,  
DV7-4272US, DV7-4273US, DV7-4274NR, DV7-4276NR, DV7-4277NR, DV7-4278NR,  
DV7-4280US, DV7-4283CL, DV7-4285DX, DV7-4287CL, DV7-4288CA, DV7-4289US,  
DV7-4290US, DV7-4293NR, DV7-4294NR, DV7-4295US, DV7-4296NR, DV7-4297CL,  
DV7-5001XX, DV7-5070CA, DV7-6001XX, DV7-6070CA, DV7-6113CL, DV7-6123CL,  
DV7-6135DX, DV7-6143CL, DV7-6153NR, DV7-6154NR, DV7-6156NR, DV7-6157CL,  
DV7-6157NR, DV7-6158CA, DV7-6160CA, DV7-6163CL, DV7-6163US, DV7-6165US,  
DV7-6166NR, DV7-6168NR, DV7-6169NR, DV7-6175US, DV7-6178US, DV7-6179US,  
DV7-6184CA, DV7-6185US, DV7-6187CL, DV7-6188CA, DV7-6191NR, DV7-6193CA,  
DV7-6195US, DV7-6197CA, DV7-6199US, DV7-6B01XX, DV7-6B32US, DV7-6B55DX,  
DV7-6B56NR, DV7-6B57NR, DV7-6B63US, DV7-6B71NR, DV7-6B73NR, DV7-6B75NR,  
DV7-6B77DX, DV7-6B78US, DV7-6B91NR, DV7-6C20US, DV7-6C23CL, DV7-6C43CL,  
DV7-6C50CA, DV7-6C60US, DV7-6C63NR, DV7-6C70CA, DV7-6C80US, DV7-6C90US,  
DV7T, DV7T-1000, DV7T-1100, DV7T-1200, DV7T-2000, DV7T-2200, DV7T-3000,  
DV7T-3300, DV7T-4000, DV7T-4100, DV7T-5000, DV7T-6000, DV7T-6100, DV7T-6B00,  
DV7T-6C00, DV7Z, DV7Z-1000, DV7Z-1100, DV8-1000EB, DV8-1001XX, DV8-1003TX,  
DV8-1010TX, DV8-1080ED, DV8-1100EB, DV8-1107TX, DV8-1108TX, DV8-1200,  
DV8T-1000, DV8T-1100, DV8T-1200, G32, G4-1010U, G4-1011N, G4-1015D,  
G4-1016D, G4-1020U, G4-1021C, G4-1022C, G4-1051X, G4-1104D, G4-1107N,  
G4-1117D, G4-1117N, G4-1118N, G4-1125D, G4-1135D, G4-1137C, G4-1164C,  
G4-1167C, G4-1204N, G4-1207N, G4-1213N, G4-1215D, G4-1226N, G4-1229D,  
G4-1264C, G4-1311N, G42, G42-101XX, G42-200XX, G42-230US, G42-232NR,  
G42-240US, G42-241HE, G42-243CL, G42-247SB, G42-250BR, G42-301NR,  
G42-303DX, G42-328CA, G42-367CL, G42-410US, G42-415DX, G42-475DX, G42T-200,  
G42T-300, G42T-400, G4T-1000, G4T-1100, G4T-1200, G4T-1300, G50, G50-100,  
G50-102CA, G50-102NR, G50-103CA, G50-103NR, G50-104CA, G50-104NR,

G50-106NR, G50-108NR, G50-109NR, G50-111NR, G50-112NR, G50-113CA,  
G50-113NR, G50-116CA, G50-118NR, G50-120CA, G50-121CA, G50-122CA,  
G50-123NR, G50-124NR, G50-126NR, G50-133US, G50-201CA, G50-209CA,  
G50-211CA, G50-213CA, G50-215CA, G50-219CA, G56, G56-100XX, G56-118CA,  
G56-122US, G56-123NR, G56-125NR, G56-126NR, G56-127NR, G56-128CA,  
G56-129WM, G56-141US, G56-151XX, G6-1A01, G6-1A19W, G6-1A20C, G6-1A21C,  
G6-1A22C, G6-1A30U, G6-1A31N, G6-1A32N, G6-1A35C, G6-1A40C, G6-1A43C,  
G6-1A44C, G6-1A45C, G6-1A46C, G6-1A50C, G6-1A50U, G6-1A52N, G6-1A53N,  
G6-1A55C, G6-1A59W, G6-1A60U, G6-1A65U, G6-1A66N, G6-1A67N, G6-1A69U,  
G6-1A71N, G6-1A75D, G6-1B22C, G6-1B23C, G6-1B28C, G6-1B33C, G6-1B34C,  
G6-1B35C, G6-1B37C, G6-1B38C, G6-1B39W, G6-1B49W, G6-1B50U, G6-1B53C,  
G6-1B54C, G6-1B55C, G6-1B58C, G6-1B59C, G6-1B59W, G6-1B60U, G6-1B61C,  
G6-1B61N, G6-1B66N, G6-1B67C, G6-1B68N, G6-1B70U, G6-1B71H, G6-1B74C,  
G6-1B75C, G6-1B76U, G6-1B78N, G6-1B79C, G6-1B79D, G6-1B79U, G6-1B81C,  
G6-1B87C, G6-1B97C, G6-1C13C, G6-1C31N, G6-1C32N, G6-1C33C, G6-1C35D,  
G6-1C36H, G6-1C37C, G6-1C39C, G6-1C40C, G6-1C41C, G6-1C43N, G6-1C44W,  
G6-1C45D, G6-1C51N, G6-1C53N, G6-1C54W, G6-1C55C, G6-1C55N, G6-1C56N,  
G6-1C57D, G6-1C58C, G6-1C58D, G6-1C59N, G6-1C60C, G6-1C61C, G6-1C62U,  
G6-1C64C, G6-1C70C, G6-1C71C, G6-1C74C, G6-1C75C, G6-1C77N, G6-1C79N,  
G6-1C81N, G6-1C87N, G6-1D40CA, G6-1D60CA, G6-1D60U, G6-1D62N, G6-1D72N,  
G60, G60-100, G60-101CA, G60-101TU, G60-102XX, G60-103XX, G60-104CA,  
G60-104XX, G60-108CA, G60-117US, G60-118NR, G60-119OM, G60-120CA,  
G60-120US, G60-121CA, G60-121WM, G60-123CL, G60-125CA, G60-125NR,  
G60-126CA, G60-127CL, G60-127NR, G60-128CA, G60-129CA, G60-146CA,  
G60-201TU, G60-202TU, G60-203TU, G60-208CA, G60-219CA, G60-225CA,  
G60-228CA, G60-230CA, G60-230US, G60-231WM, G60-233CA, G60-233NR,  
G60-234CA, G60-235CA, G60-235DX, G60-235WM, G60-236US, G60-237NR,  
G60-237US, G60-238CA, G60-243CL, G60-243DX, G60-244DX, G60-247CL,  
G60-249CA, G60-249WM, G60-438NR, G60-440US, G60-441US, G60-442OM,  
G60-443CL, G60-443NR, G60-445DX, G60-447CL, G60-453NR, G60-458DX,  
G60-471NR, G60-501NR, G60-506US, G60-507DX, G60-508US, G60-513NR,  
G60-519WM, G60-526NR, G60-530US, G60-531NR, G60-533CL, G60-535DX,  
G60-536NR, G60-549DX, G60-552NR, G60-553NR, G60-630US, G60-633NR,  
G60-635DX, G60-637CL, G60-642NR, G60-645NR, G60-647NR, G60T-200, G60T-500,  
G60T-600, G61, G61-101TU, G61-102TU, G61-103TU, G61-104TU, G61-110EA,  
G61-202TU, G61-203TU, G61-204TU, G61-301TU, G61-302TU, G61-304NR,  
G61-306NR, G61-320US, G61-321NR, G61-322NR, G61-327CL, G61-336NR,  
G61-400EP, G61-400SL, G61-405EL, G61-405SL, G61-407SL, G61-410EB, G61-410EL,  
G61-415EL, G61-415SB, G61-420EB, G61-420SL, G61-424CA, G61-425EL,  
G61-429WM, G61-430EL, G61-435SL, G61-440EL, G61-450EE, G61-451EE, G61-452EE,  
G61-453EE, G61-454EE, G61-465SL, G61-511WM, G61-631NR, G61-632NR, G62,

G62-100EB, G62-100EE, G62-100SL, G62-101TU, G62-101XX, G62-103XX, G62-110EE, G62-120EL, G62-120SL, G62-120SW, G62-125SL, G62-130SL, G62-140EL, G62-140US, G62-143CL, G62-144DX, G62-145NR, G62-147NR, G62-149WM, G62-165SL, G62-166SB, G62-200XX, G62-201XX, G62-219CA, G62-219WM, G62-220US, G62-222US, G62-223CL, G62-224HE, G62-225DX, G62-225NR, G62-226NR, G62-227CL, G62-228CL, G62-228NR, G62-229NR, G62-229WM, G62-231NR, G62-233NR, G62-234DX, G62-236NR, G62-237US, G62-238NR, G62-251TU, G62-251XX, G62-318CA, G62-320CA, G62-323CA, G62-325CA, G62-327CA, G62-337NR, G62-339WM, G62-340US, G62-341NR, G62-343NR, G62-346NR, G62-347CL, G62-347NR, G62-348CA, G62-348NR, G62-352CA, G62-352US, G62-353NR, G62-354CA, G62-355CA, G62-355DX, G62-357CA, G62-358CA, G62-358NR, G62-359CA, G62-363NR, G62-364DX, G62-365CA, G62-367DX, G62-371DX, G62-372US, G62-373DX, G62-374CA, G62-378CA, G62-404NR, G62-407DX, G62-415NR, G62-420CA, G62-423CA, G62-435DX, G62-448CA, G62-454CA, G62-455DX, G62-457CA, G62-457DX, G62-465DX, G62-470CA, G62-474CA, G62-478CA, G62-A21EZ, G62-A35ET, G62M-300, G62T-100, G62T-250, G62T-350, G62X-400, G6T-1A00, G6T-1B00, G6T-1C00, G6T-1D00, G6Z-1C00, G7-1001X, G7-1017C, G7-1019W, G7-1033C, G7-1051X, G7-1070U, G7-1073N, G7-1075D, G7-1075N, G7-1076N, G7-1077N, G7-1081N, G7-1083N, G7-1084N, G7-1085N, G7-1086N, G7-1101X, G7-1113C, G7-1117C, G7-1139W, G7-1149W, G7-1150U, G7-1153N, G7-1154N, G7-1156N, G7-1158N, G7-1167D, G7-1173C, G7-1173D, G7-1174C, G7-1175C, G7-1178C, G7-1219W, G7-1222N, G7-1227N, G7-1237D, G7-1255D, G7-1257D, G7-1260C, G7-1260U, G7-1261N, G7-1263C, G7-1263N, G7-1264N, G7-1265N, G7-1269N, G7-1270C, G7-1272N, G7-1273N, G7-1277D, G7-1279D, G7-1281N, G7-1310U, G7-1312N, G7-1320C, G7-1330C, G70, G70-246US, G70-250CA, G70-250US, G70-257CL, G70-258US, G70-460US, G70-463CL, G70-467CL, G70-468NR, G70-481NR, G70T-200, G71, G71-329WM, G71-333NR, G71-340US, G71-343US, G71-345CL, G71-347CL, G71-349WM, G71-358NR, G71-441NR, G71-442NR, G71-445US, G71-447US, G71-448CL, G71-449WM, G71T-300, G71T-400, G72, G72-130SB, G72-227WM, G72-250US, G72-251NR, G72-251XX, G72-252US, G72-253NR, G72-257CL, G72-259WM, G72-260US, G72-261US, G72-262NR, G72-A30EM, G72-B27CL, G72-B49WM, G72-B50US, G72-B53NR, G72-B54NR, G72-B57CL, G72-B60US, G72-B61NR, G72-B62US, G72-B63NR, G72-B66US, G72-B67CA, G72-B67US, G72-C55DX, G72T-200, G72T-B00, G7T-1000, G7T-1100, G7T-1200, HDX16, HDX18,

#### ProBook series

4230 S, 4310S, 4311S, 4320S, 4320T, 4321S, 4325S, 4326S, 4330S, 4331S, 4410S, 4411S, 4415S, 4416S, 4420S, 4421S, 4425S, 4430S, 4431S, 4435S, 4436S, 4510S, 4510S/CT, 4515S, 4515S/CT, 4520, 4520S, 4525S, 4530S, 4535S, 4710S, 4710S/CT,

4720S, 4730S, 5220M, 5310M, 5320M, 5330M, 6360B, 6440B, 6445B, 6450B, 6455B, 6460B, 6465B, 6470B, 6475B, 6540B, 6545B, 6550B, 6555B, 6560B, 6565B, 6570B,

Tablet PC series

TC4400,

TouchSmart Series

TM2, TX2,

*Rugged series*

NR3600, NR3610,

*Tablet PC series*

TC4400,

*TouchSmart series*

TM2, TM2-1000EE, TM2-1001XX, TM2-1004TX, TM2-1005TX, TM2-1010EE, TM2-1012TX, TM2-1013TX, TM2-1014TX, TM2-1016TX, TM2-1018TX, TM2-1019TX, TM2-1020TX, TM2-1070US, TM2-1072NR, TM2-1073NR, TM2-1079CL, TM2-2001SL, TM2-2001XX, TM2-2050US, TM2-2052NR, TM2-2057SB, TM2-2150CA, TM2-2150US, TM2-2151NR, TM2T-1000, TM2T-1100, TM2T-2100, TM2T-2200, TX2, TX2-1002AU, TX2-1012NR, TX2-1016AU, TX2-1017AU, TX2-1018AU, TX2-1019AU, TX2-1020AU, TX2-1020CA, TX2-1020US, TX2-1022AU, TX2-1024CA, TX2-1025DX, TX2-1027CA, TX2-1030CM, TX2-1031CM, TX2-1032CM, TX2-1051XX, TX2-1070BR, TX2-1102AU, TX2-1103AU, TX2-1104AU, TX2-1105AU, TX2-1106AU, TX2-1107AU, TX2-1108AU, TX2-1109AU, TX2-1110AU, TX2-1118AU, TX2-1120AU, TX2-1122AU, TX2-1205AU, TX2-1207AU, TX2-1208AU, TX2-1209AU, TX2-1270US, TX2-1274NR, TX2-1277NR, TX2-1305AU, TX2-1307AU, TX2-1308AU, TX2-1310AU, TX2-1323AU, TX2-1326AU, TX2-1370US, TX2-1375DX, TX2-1377NR, TX2Z-1000, TX2Z-1300,

**HP/Compaq 19.5V3.33A 7.4mm\*5.0mm 65W**

HP

*EliteBook Revolve series*

810 CONVERTIBLE, 810 G2, 810 G3,

*Pavilion Chromebook series*

14-C010US,

*Pavilion SleekBook series*

15, 15-B004SG,

*Pavilion Sleekbook TouchSmart series*

15-B153SG,

*ProBook series*

4340S, 450 G0, 455 G1, 455 G1 H6P57EA, 650 G1,

*ZBook series*

14 WORKSTATION

**19.5V2.31A 7.4mm\*5.0mm 45W**

HP

*EliteBook series*

720 G1, 725 G2, 740 G1, 745 G2, 750 G1, 755 G2, 810 G1, 810 G2, 820 G1, 840 G1, 850 G1,

*EliteBook Folio series*

9470M, 9480M,

*EliteBook Revolve series*

810 G1 TABLET, 810 G2 TABLET,

*ProBook series*

350 G1, 430 G2, 440 G2, 445 G2, 450 G2, 455 G2,

19.5V2.05A 7.4mm\*5.0mm

HP series

EliteBook Folio

9470M,

Mini Series

MINI 5101, MINI 5102, MINI 5103,