

Exchangeable Tips for ACT Laptop AC Adapter

Standard Tips AC2050 and AC2055 and AC2060

Type	Picture	Output Voltage	Tips Size	Included in	Suitable for notebook brands	Fit for laptops
T1		19.0V - 3.42A	φ2.5*0.7		Asus Samsung	See full list in below attachment page 4
T2		19.0V - 2.37A 3.42A 4.74A	φ5.5*1.7	AC2050 AC2055 AC2060	Acer Dell	See full list in below attachment page 5 ~7
T3		19.0V 1.58A 2.37A 3.43A 4.74A	φ4.0*1.7		HP Dell	See full list in below attachment page 8
T4		19.0V - 3.44A	φ5.5*3.0		Samsung	Samsung: N-Series, For Samsung Series 5, For Samsung X-Series 60W(19V 3.15A)AD-6019A, AD-6019(V), SPA-690E/E, SPA-690E/UK, SPA-830E/EUR SPA-830E/UK, SPA-A10E/E, SPA-A10E/UK, SPA-P30 (5.5*3.0mm) , SPA-P30E, SPA-P30E/E, SPA-P30E/UK, SPA-T10E/EUR, SPA-T10/UK, SPA-V20E/E, SPA-V20E/UK, SPA-X10, SPA-X10/E, SPA-X10/UK, SPA-X19/E 90W(19V 4.74A)
T5		19.5V - 3.33A 4.62A	φ4.5*3.0	AC2050 AC2055 AC2060	HP Dell	See full list in below attachment page 9 ~ 10
T6		19.0V - 2.37A 3.42A 4.74A	φ4.0*1.35	AC2050 AC2055 AC2060	Asus	See full list in below attachment page 11
T7		20.0V - 3.25A 4.5A	φ7.9*5.5		IBM Lenovo	See full list in below attachment page 12
T8		18.5V 3.51A	φ7.45*5.0		HP / Compaq	See full list in below attachment page 13 ~ 16

T9		18.5V 3.51A 4.86A	φ4.8*1.7		HP / Compaq Asus	See full list in below attachment page 17 ~ 18
T10		18.5V 3.51A 4.86A	4.8*1.7	AC2050 AC2055 AC2060	HP/Compaq	See full list in below attachment page 19
T11		19.0V 2.37A 3.42A 4.74A	φ 5.5*2.5	AC2050 AC2055 AC2060	IBM / LS / Dell / HP Delta / Toshiba Liteon / Gateway Nec / Acer / Asus	See full list in below attachment page 20
T12		19.5V 2.3A 3.33A 4.62A	φ 6.5*4.5		Sony Fujitsu Panasonic	See full list in below attachment page 21 ~ 23
T13		19.0V 2.1A 2.36A 3.42A 4.74 A	φ 3.0*1.1	AC2050 AC2055 AC2060	Samsung Acer LG	See full list in below attachment page 24 ~ 26
T14		19.5V 2.31A 3.33A 4.62A	φ 4.5*3.0		Dell Ultrabook	See full list in below attachment page 27
T15		19.5V 2.31A 3.33A 4.62A	φ 7.4*5.0	AC2050 AC2055 AC2060	Dell	See full list in below attachment page 28
T16		20.0V 3.25A	φ 4.0*1.0		Asus	Acer/Asus/ Chrombook, Cloudbook, Aspire Laptops Asus Asus VivoBook X202 X201 K200CA C200 C300 C300MA X200 X200CA X200MA Q200 S200, Eee Book E402MA E403sa E502MA EXA1206UH
T17		19.0V 2.37A 3.42A 4.74A	φ 5.5*2.1		Acer Asus	See full list in below attachment page 29
T18		19.5V 3.33A 4.62A	φ 4.8*1.7		HP LG	HP Pavilion Chromebook 14, 14-b00, 14-c00; 15, 15-b00, 15-c00 Series; HP Envy Pro 4, 4t, 6, 6t, 6z, 13, 13t; HP Touchsmart Sleekbook 4, 6; HP Pavilion Sleekbook 6, 14-b, 14-c, 14-f, 14z-b, 14-b000, 14-c000, 14-f000, 14z-b000, 15-b, 15t-b. 15z-b, 15-b000, 15z-b000 Series; HP Envy Spectre Xt Pro 13 14 15; HP Spectre XT Touchsmart 13, 14, 15, nv13, nv14, nv15

T19		20.0V 3.25A 4.5A	11*4.6	AC2050 AC2055 AC2060	Lenovo	See full list in below attachment page 30
T21		19.0V 3.42A	φ4.5*3.0		Asus	See full list in below attachment page 31
T23		19.0V 1.58A 2.37A 3.42A 4.74A	φ4.0*1.7		HP	See full list in below attachment page 32 ~ 33

Free Tip Service

If your laptop/notebook requires another tip then the tips which are supplied with this product, you can send a request for the right tip to ACT (please check the tiplist in this manual). We cannot guarantee that we have the requested tip at all time. When available, our support desk will send the tip to you for free.

You can send your request for the tip to us by using the supportform on our website: <https://support.act-connectivity.com/hc/requests/new>

T1

Asus / Samsung:

AD-4019S, AD-4019SL, PA-1400-14, AA-PA2N40S, AD-4019W, AA-PA2N40L,
BA44-00278A, AA-PA3NS40/US, BA44-00279A, PA-1400-24, CPA09-002A, AD-4019P
A900X1NA03A, P900X1A, NP900X1A, NP900X1AA01, NP900X1US, NP900X1B-A01US, NP900X1B-A01,
NP900X1BA01US, NP900X1B, NP900X1B-900X1B, P900X1B,
NP900X1B-AB 02US, NP900X3A, NP900X3A-B02, NP900X3AB02US, NP900X1B-A01SE, NP900X1B-A01,
NP900X1BA01SE, NP900X1B

END T1

T2

Dell / Acer:

Aspire 4250 Aspire 4250-E352G50Ml Aspire 4250G Aspire 4250Z Aspire 4251 Aspire 4251G Aspire 4251Z Aspire 4252 Aspire 4252G Aspire 4252Z Aspire 4253 Aspire 4253G Aspire 4333 Aspire 4339 Aspire 4349 Aspire 4350 Aspire 4350G Aspire 4352 Aspire 4352G Aspire 4551 Aspire 4551G Aspire 4551G-P322G32Mn Aspire 4551P battery Aspire 4552 Aspire 4552-5078 Aspire 4552G Aspire 4560 Aspire 4560G Aspire 4625 Aspire 4733Z Aspire 4738 Aspire 4738G Aspire 4738Z Aspire 4738ZG Aspire 4739 Aspire 4739Z Aspire 4741 Aspire 4741G Aspire 4741G-332G32Mnsk Aspire 4741G-332G50Mn Aspire 4741G-372G50Mnkk02 Aspire 4741G-372G50Mnkk06 Aspire 4741G-432G50Mnkk01 Aspire 4741G-5452G50Mnkk04 Aspire 4741G-5462G50Mnkk05 Aspire 4741G-5464G50Mn Aspire 4741Z Aspire 4741ZG Aspire 4741ZG-P602G50Mnkkc Aspire 4741ZG-P622G50Mnkk03 battery Aspire 4743 Aspire 4743G Aspire 4743Z Aspire 4743ZG Aspire 4749 Aspire 4749Z Aspire 4750 Aspire 4750G Aspire 4750Z Aspire 4750ZG Aspire 4752 Aspire 4752G Aspire 4752Z Aspire 4752ZG Aspire 4755 Aspire 4755G Aspire 4755ZG Aspire 4771 Aspire 4771G Aspire 4771Z Aspire 5250 Aspire 5251 Aspire 5251-1005 Aspire 5251-1549 Aspire 5252 Aspire 5253 Aspire 5253G Aspire 5333 Aspire 5336 Aspire 5349 Aspire 5350 Aspire 5551 Aspire 5551-2013 Aspire 5551-2036 Aspire 5551-2805 Aspire 5551-4200 Aspire 5551-4937 Aspire 5551G Aspire 5551G -4280 Aspire 5551G -4591 Aspire 5551G-P324G32Mn Aspire 5551-P323G32Mnsk battery Aspire 5552 Aspire 5552G Aspire 5560 Aspire 5560 V3 Aspire 5560(15.4 screen) Aspire 5560G Aspire 5733 Aspire 5733Z Aspire 5736Z Aspire 5741 Aspire 5741-332G25Mn Aspire 5741-333G32Mn Aspire 5741-334G32Mn Aspire 5741-334G50Mn Aspire 5741-3404 Aspire 5741-3541 Aspire 5741-433G32Mn Aspire 5741-434G50Mn Aspire 5741-5698 Aspire 5741-5763 Aspire 5741G Aspire 5741G-332G50Mn Aspire 5741G-333G32Bn Aspire 5741G-334G50Mn Aspire 5741G-334G64Mn Aspire 5741G-434G64Bn Aspire 5741G-5452G50Mnck Aspire 5741G-5452G50Mnkk Aspire 5741G-5452G50Mnsk Aspire 5741Z Aspire 5741ZG Aspire 5742 Aspire 5742G Aspire 5742Z Aspire 5742ZG Aspire 5749 Aspire 5749G Aspire 5749Z Aspire 5749ZG Aspire 5750 Aspire 5750G Aspire 5750G-2312G50 Aspire 5750TG Aspire 5750Z battery Aspire 5750ZG Aspire 5755 Aspire 5755G Aspire 5755Z Aspire 5755ZG Aspire 7251 Aspire 7551 Aspire 7551-2755 Aspire 7551-3068 Aspire 7551-3416 Aspire 7551-3634 Aspire 7551-5358 Aspire 7551G Aspire 7551G-5407 Aspire 7551G-5821 Aspire 7551G-6477 Aspire 7551Z Aspire 7551ZG Aspire 7552G Aspire 7552G-5107 Aspire 7552G-5488 Aspire 7552G-6061 Aspire 7560 Aspire 7560G Aspire 7741 Aspire 7741-333G25Mn Aspire 7741-5137 Aspire 7741-7870 Aspire 7741G Aspire 7741G-333G25Bn Aspire 7741G-333G32Mn Aspire 7741G-334G50Mn Aspire 7741G-3647 Aspire 7741G-374G64Mn Aspire 7741G-434G50Mn Aspire 7741G-464G64Mn Aspire 7741G-7017 Aspire 7741Z Aspire 7741Z-4475 Aspire 7741Z-4592 Aspire 7741Z-4633 Aspire 7741Z-4643 Aspire 7741Z-4815 Aspire 7741Z-5731 Aspire 7741ZG Aspire 7741ZG-P604G50Mn Aspire 7741Z-P614G50Mn Aspire 7750 Aspire 7750G Aspire 7750Z Aspire 7750ZG Aspire AS4250-C52G25Mikk Aspire AS5250-C52G25Mikk Aspire AS5250-C53G25Mikk Aspire AS5250-E352G32Mikk Aspire AS5253-C52G32Mnkk Aspire AS5253-C54G50Mnkk Aspire AS5253-E353G32Mnrr Aspire AS5253-E354G32Mnkk battery Aspire AS5741 Aspire AS5741-H32C/S Aspire AS5741-H32C/SF Aspire AS5741-H54D/LS Aspire AS5741-H54D/S Aspire AS5741-H54D/SF Aspire AS5741-N32C/KF Aspire AS5741-N32D/K Aspire AS5741-N54E/K Aspire AS5741-N54E/KF Aspire E1 Aspire E1-421 Aspire E1-431 Aspire E1-471 Aspire E1-531 Aspire E1-531-2697 Aspire E1-531-4444 Aspire E1-571 Aspire E1-571-6492 Aspire E1-571-6650 Aspire S3-951 Aspire V3 Aspire V3-471G Aspire V3-551 Aspire V3-551-8664 Aspire V3-551-8809 Aspire V3-551G Aspire V3-571 Aspire V3-571-6643 Aspire V3-571-6800 Aspire V3-571G Aspire V3-571G-6602 Aspire V3-571G-

6641 Aspire V3-571G-9435 Aspire V3-731-4695 Aspire V3-771 Aspire V3-771-6683 Aspire V3-771G
Aspire V3-771G-6601 Aspire V3-771G-6650 Aspire V3-771G-9665 Aspire V3-771G-9875 battery
TravelMate 4370 TravelMate 4740 TravelMate 4740-352G32Mn TravelMate 4740-432G50Mna
TravelMate 4740-5261 TravelMate 4740-5452G50MnssbTravelMate 4740-5462G50Mnss02 TravelMate
4740-7552 TravelMate 4740-7787 TravelMate 4740G TravelMate 4740Z Travelmate 4740ZG TravelMate
4750Travelmate 4750G Travelmate 4750GZ Travelmate 4750Z TravelMate 5335 TravelMate 5340
TravelMate 5340G Travelmate 5344 TravelMate 5542TravelMate 5542G Travelmate 5735 Travelmate
5735G TravelMate 5735Z Travelmate 5735ZG TravelMate 5740 TravelMate 5740-332G16Mn TravelMate
5740-332G25Mn TravelMate 5740-333G25Mn TravelMate 5740-333G32Mn TravelMate 5740-
352G25Mn TravelMate 5740-372G25Mnss TravelMate 5740-434G32Mn TravelMate 5740-5092
TravelMate 5740-524G32Mn TravelMate 5740-5896 TravelMate 5740-5952TravelMate 5740-6070
TravelMate 5740-6291TravelMate 5740-6529 TravelMate 5740G TravelMate 5740G-334G32Mn
TravelMate 5740G-434G32MnTravelMate 5740G-524G50Mn TravelMate 5740G-528G64Mn TravelMate
5740G-5452G32Mnss TravelMate 5740G-6765 Travelmate 5740Z TravelMate 5740Z-P602G25Mn
TravelMate 5740Z-P604G32Mnss battery TravelMate 5742 TravelMate 5742-372G25Mn TravelMate
5742-373G32Mn TravelMate 5742-463G32Mn TravelMate 5742-5562G50Mnss01 TravelMate 5742-
7013 TravelMate 5742-7159 TravelMate 5742-7399 TravelMate 5742-7906 TravelMate 5742-7908
TravelMate 5742G TravelMate 5742ZTravelMate 5742Z-4693 TravelMate 5742ZG TravelMate 5744
TravelMate 5744G TravelMate 5744Z Travelmate 5760 Travelmate 5760G TravelMate 5760Z TravelMate
5760ZGTravelMate 6495 TravelMate 6495G TravelMate 6495T TravelMate 6495TG TravelMate 6595
TravelMate 6595G TravelMate 6595T TravelMate 6595TGTravelMate 7340 TravelMate 7740 TravelMate
7740-352G32Mn TravelMate 7740-353G25Mnss TravelMate 7740-434G32Mnss TravelMate 7740G
TravelMate 7740G-434G50Mnss TravelMate 7740Z TravelMate 7740ZG TravelMate 7740ZG-
P604G50MnssTravelMate 7740Z-P604G32Mnss Travelmate 7750TravelMate 7750G TravelMate 7750Z
Travelmate 7750ZG TravelMate 8472 TravelMate 8472 HFTravelMate 8472G TravelMate 8472G HF
TravelMate 8472TTravelMate 8472T HF TravelMate 8472TG TravelMate 8472TG HF travelmate
8472ZTravelMate 8473 TravelMate 8473G TravelMate 8473T TravelMate 8473TG TravelMate 8473Z
TravelMate 8572 TravelMate 8572G TravelMate 8572TTravelMate 8572T HF TravelMate 8572TG
Travelmate 8572Z TravelMate 8573 TravelMate 8573G TravelMate 8573T TravelMate 8573TG
TravelMate P243 TravelMate P243-M TravelMate TM5740 TravelMate TM5740-X322TravelMate
TM5740-X322D TravelMate TM5740-X322DF battery TravelMate TM5740-X322DHBF TravelMate
TM5740-X322DOF TravelMate TM5740-X322DPF TravelMate TM5740-X322F TravelMate TM5740-
X322HBFTTravelMate TM5740-X322OF TravelMate TM5740-X322PF TravelMate TM5740-X522
TravelMate TM5740-X522D TravelMate TM5740-X522DF TravelMate TM5740-X522DHBF TravelMate
TM5740-X522DOF TravelMate TM5740-X522DPF TravelMate TM5740-X522F TravelMate TM5740-
X522HBF TravelMate TM5740-X522OF TravelMate TM5740-X522PF TravelMate TM5742 TravelMate
TM5742-X732 TravelMate TM5742-X732D TravelMate TM5742-X732DFTravelMate TM5742-X732DHBF
TravelMate TM5742-X732DOF TravelMate TM5742-X732DPF TravelMate TM5742-X732F TravelMate
TM5742-X732HBFTTravelMate TM5742-X732OF TravelMate TM5742-X732PF TravelMate TM5742-X742
TravelMate TM5742-X742D TravelMate TM5742-X742F TravelMate TM5742-X742HBF TravelMate
TM5742-X742OF TravelMate TM5742-X742PF battery
Emachines:
D440 D442 D443 D443 D520 D528 D640 D640G D642 D644 D720 D728 D729 D729Z D730 D732 D732Z
E440 E442 E443 E443 E529 E642 E644E644GE729Z E730 E732 MS2305 battery

GATEWAY

EasyNote LM82 EasyNote LM83 EasyNote LM85 EasyNote LM86 EasyNote LM87 EasyNote LM89
EasyNote LM94 EasyNote LM98 EasyNote LS11HREasyNote LS11SB EasyNote LS13SB EasyNote LS44HR
EasyNote NM85 EasyNote NM86 EasyNote NM87 EasyNote NM88 EasyNote NM89 EasyNote NM98
EasyNote NS11 EasyNote NS13 EasyNote NS44 EasyNote NS85 EasyNote TM01 EasyNote TM80 EasyNote
TM81 EasyNote TM82 EasyNote TM83EasyNote TM85 EasyNote TM86 EasyNote TM87 EasyNote TM89
EasyNote TM94 EasyNote TM97 EasyNote TM98 EasyNote TM99 EasyNote TSEasyNote TS11 EasyNote
TS11-HR EasyNote TS13 EasyNote TS13-HR EasyNote TS44 EasyNote TS44-HR EasyNote TS45EasyNote
TSX66 NE46RNE56R NS41 NS41I NS51 NS51I NV47 NV47 NV47H NV49C NV49C13C NV49xx NV50A NV51
NV51B NV51M NV53 NV53ANV53A11u NV55C NV55SNV57 NV59C NV73A NV75S NV77H Packard

END T2

T3

HP / Dell:

HP:

HP Mini 1000 Vivienne Tam Edition PC Series

NG624EA, NG625EA, NG626EA, NG627EA, NG628EA, NG630EA, NG631EA, NG632EA, NG633EA, NG634EA, NG640EA, NG641EA, NG644EA, NG646EA, NL037PA

HP Mini 1000 PC Series

HP Compaq Mini 110 210 700 CQ10 200 210t 100e 1000 1010 1100 1101 1103 1104 2102 1110 110-1012NR 110-3135dx 210-1091nr 210-1076nr 210-1032cl

1000, 1010NR, 1030NR, 1033CL, 1035NR, FN819AV, FQ729AAR, FQ729AV, FR832AV, FT313UAR, FT313UA, FT315UAR, FT315UA, FW376UAR, FW376UA, FY348LA, FZ978UAR, FZ978UA, NB914AV, NC953AS, NC954AS, NE570PA, NE571PA, NE572PA, NE573PA, NE574PA, NE575PA, NE576PA, NE577PA, NE578PA, NE579PA, NE580PA, NE581PA, NE582PA, NE585PA, NE590PA, NE594PA, NG837LA, NJ209LA, NQ332LA

HP Mini 1100 PC Series

1110NR, 1111NR, 1120NR, 1125NR, 1130NR, 1136NR, 1141NR

NB133UAR, NB133UA, NB135UAR, NB135UA, NB137UAR, NB137UA, NB140UA, NB141UA, NB142UAR, NB142UA, NP994UAR, NP994UA

HP Mini 1100 Vivienne Tam Edition PC Series

1140NR Vivienne Tam, NB134UAR, NB134UA

HP Compaq Mini 110 210 700 CQ10 200 210t 100e 1000 1010 1100 1101 1103 1104 2102 1110 110-1012NR 110-3135dx 210-1091nr 210-1076nr 210-1032cl.

HP Mini 110-1046NR 110-1030NR 110-1050NR 110-1100 110-1125NR 110-1127NR 110-3015DX 110-3030NR 110-3098NR 110-3110NR 110-3130NR 110-3131DX 110-3135DX 110-3500 110-3510NR 110-3525DX 110-3530NR 110-3700 110-3731CL 110-3735DX 110-3830NR 110-4100 110-4250NR

HP Mini 210-1000 210-1010NR 210-1018CL 210-1030NR 210-1032CL 210-1070NR 210-1076NR 210-1091NR 210-1095NR 210-1100 210-1142CL 210-1170NR 210-1171NR 210-1199DX 210-2000 210-2050NR 210-2060NR 210-2061WM 210-2070NR 210-2075NR 210-2080NR 210-2090NR 210-2100 210-2130NR 210-2145DX 210-2190 210-2355DX 210-3000 210-3040NR 210-3050NR 210-3060NR 210-3070NR 210-3080NR 210-4000

HP Compaq Cq10 Series HP Compaq Mini 102 110c 700 701 705 730 731 733 735 Series

Dell Vostro 5460 V5460 5560 01X9K3 P41G V3460 5470 5439 5480 4539 5539

END T3

T5

HP:

HP Envy 15-j019so 15-j020eo Envy 17-j010el(120W)

HP Zbook 65W : 14 G2 / 14 G7 / 14U G4 / 14U G5 / 14U G6 / 15U G2 / 15U G3 / 15U G4 / 15U G5 / 15U G6 / x2 G4 Firefly Mobile Detachable Workstation,Elitebook 720 725 735 745 755 820 830 840 850 840r 848 G1 G2 G3 G4 G5 G6 G7 G8 1020 1030 1040 1050 Revolve 810 Folio 9470m 9480m, ProBook 640 G1, 640 G2, 640 G3, 640 G4, 640 G5, 650 G1, 650 G2, 650 G3, 650 G4, 650 G5, 430 440 446 450 455 470 640 650 645 655 G1 G2 G3 G4 G5 G6 x360 11 G1 G2 G3 EE, Chromebook 11 G3 G4 G5 EE, 13 14 G1(X360 Pavilion, Envy, Elitebook 840, ProBook, Spectre, Chromebook 11 14)

HP Pavilion 15-e010us 15-e020us 15-e043cl 15-n019wm 15-n065nr 17-e017dx 17-e019dx 17-e020dx 17-e020us 17-e021nr 17-e049wm 17-e055nr 17-e110dx, HP Envy touch smart sleek Book m6-k, m7-j, 15-j, 17-j Series: HP Envy touch smart 17-j000 17-j010dx 17-j078ca HP ENVY TouchSmart Sleekbook M6 M7: m6-ae151dx m6-k000 m6-k001xx m6-k010dx m6-k012dx m6-k015dx m6-k125dx m6-n010dx m6-n012dx m6-n015dx m6-n113dx m6-w011dx m6-w102dx m7-j000 m7-j010dx m7-j020dx m7-j120dx m7-k010dx m7-k111dx

HP Chromebook 14 Series:HP Chromebook 14-q010nr, 14-q020nr,14-q030nr/ 15 Series Notebook: HP Pavilion 15-N042EF 15-N088EF 15-N020EL 15-N000 15-N010US 15-N020US 15-N028US 15-N040US HP Pavilion 15-N046US 15-N007AU/

17 Series Notebook: HP Pavilion 17-e107nr 17-E109nr 17-e108nr 17-e086nr HP Pavilion 17-e040us 17-e046us 17-e056us 17-e150us

HP Stream x360 11 13 14 11-r010nr 11-r014wm 11-r020nr 11-h000 11-h110nr 11t-h100 11-h010ca 11-h010nr 11-h013dx 11t-h000 11-d010nr 11-d010wm 11-d011wm 11-d020nr 13-c010nr 13-p110nr 13-p120nr 13-p111nr 13-p113cl 13-p117cl 13-p120ca 13z-p100 14-ax040wm 14-ax020wm 14-ax020nr 14-ax010wm 14-an013nr 14-an012nr 13-s128nr 13-s192nr 15-n210us 15-n210dx 15-n211dx 15-n220us 15-n228us 15-n230us 15-n240us 15-n260us 15-n280us 15-n290nr m3-u001dx m3-u003dx

HP Spectre 360 X2 13-g000 Laptop 13-g100 13-g110dx 13-g118ca 13-m000 13-m010dx 13-m100 13-m110ca 13-m110dx 13t-g100 13t-m000 13t-m1000 13-3000 13t-3000 13t-h200 13-3010dx 13-3018ca 13-h210dx 13-h211nr 13-4001dx 13-4005dx 13-4100dx 13-4105dx 13-4110dx 13-4116dx 13-4193dx 13-4194dx 13-4195dx 13-h210dx 13-h211nr 15-ap012dx

HP Pavilion 15-f003dx 15-f004dx 15-f018dx 15-f019dx 15-f111dx 15-f215dx 15-f100dx 15-f305dx 15-f004wm 15-f009wm 15-f010wm 15-f014wm 15-f023wm 15-f024wm 15-f033wm 15-f039wm 15-f059wm 15-f085wm 15-f111dx 15-f125wm 15-f133wm 15-f162dx 15-f205dx 15-f209wm 15-f215dx 15-f211wm 15-f222wm 15-f233wm 15-ay103dx 15-ay104dx 15-ay191ms 15-ay039wm 15-ay041wm 15-ay070wm 15-ay107cl 15-ay147cl 15-ay053nr 15-ay061nr 15-ay063nr 15-ay083nr 15-ay145nr 15-ay163nr 15-f224wm 15-f271wm 15-f272wm

HP Pavilion 15 Series :HP Pavilion 15-e000si 15-e000eia 15-e000sia 15-e000sk 15-e000sr 15-e000sx

HP Pavilion 15-e001au HP Pavilion 15-e002se 15-e002sia 15-e002sr
HP Pavilion 15-e003ax 15-e003sh 15-e003ep 15-e003sp 15-e003sr
HP Pavilion 15-e004ax 15-e004au 15-e004ej Pavilion 15-e004sl 15-e004sr
HP Pavilion 15-e005sr 15-e005sv 15-e005sx 15-e005ax
HP Pavilion 15-e006au 15-e006ax 15-e006ea 15-e006sg 15-e006sr
HP Pavilion 15-e007a 15-e007sr HP Pavilion 15-e008ea 15-e008ee

HP Pavilion 14-dh0013nr 14-ce2068st 15-cw1063wm 11m-ap0013dx 15-ay024ds 15 ay103dx ay014dx
ay039wm ay011nr ay013nr ay012dx Laptop
HP Pavilion Laptop 14 14m 14s 14-dk 14s-dk 14-dq 14s-dq 14-dy 14s-fq 14-df 14-dh 14m-dh 14-ax 14-
ds 14-fq 14s-fq 14-ck 14-bs 14-dw 14m-dw 14-bw 14-ce 14-cf 14-ck 14-ak 14-an 14-ce 14-cb 14-df 14m-
ba 14-ac 14-cm 14-da 14-r0xx Laptop: HP Laptop 14-fq1097nr, HP Pavilion Laptop 14-ec0023nr, 14z-
ec000 14-ec0013dx 14-ec0023nr

Elitebook 820 G3 G4 /830 G5 / 840 G3 G4 G5 / 850 G3 G4 G5 / ProBook 450 G3 G5 / 640 G2 G3 G4 G5
/ 650 G2 G3 / EliteBook Folio 1040 G1 G2 G3, x360 1030 G1 G2 Pavilion x360 11-k120nr 13-s128nr 13-
s192nr m3-u001dx m3-u003dx Stream 11 Pro G3 Stream 11 Pro G4 EE Chromebook 11 EE G2 G3 G4 G5
Spectre x360 x2 Part

Inspiron 11 3000 Series: 3147 3148 3152 3153 3157 3158 3162 (P24T) 3168 3169 3179 3185 3195 P20T
P24T P25T

Inspiron 14 3000 Series: 3441 3451 3458 3464 3482 P60G P89G

Inspiron 15 3000 Series: 3521 3551 3552 3555 3558 3565 3576 3581 3582 3583 P28F P47F P52F P63F
P75F

Inspiron 3000 Series: 3655 3780 D20M P35E

Inspiron 13 5000 Series: 5368 5378 5379 P69G

Inspiron 14 5000 Series: 5447 5448 5452 5458 5459 5481 5482 5485 P49G P64G P93G

Inspiron 15 5000 Series: 5523 5545 5551 5552 5555 5558 5559 5565 5566 5567 5568 5570 5575 5578
5579 5582 5584 5585 P26F P39F P51F P66F P32E P58F P75F P78F P85F P77F

Inspiron 17 5000 Series: 5755 5758 5759 5765 5767 5770 P28E P32E P35E

Inspiron 13 7000 Series: 7347 7348 7212 7352 7353 7359 7368 7373 7375 7378 7386 P57G P69G P83G
P91G

Inspiron 14 7000 Series: 7437 7472 P42G P74G

Inspiron 15 7000 Series: 7558 7568 7569 7570 7572 7573 7579 7580 7586 P55F P58F P70F P61F P76F

Inspiron 17 7000 Series: 7773 7778 7779 7786 P30E

XPS 13: 9343 9350 9360

Inspiron AIO Desktops: 3048 3052 3059 3252 3452 3455 3668

Latitude 12: 7202 Latitude 13: 3379 7350 Latitude 14: E5450 Vostro 14: 3458 3459 5459

Vostro 15: 3358 3558 3559

XPS 11: 9P33 XPS12 12D: L221x 9Q23 9Q33 XPS13: 321X 322X L321X L322X 3943 9333 9343 9344

XPS15: 9530 9550

Optiplex 3020 3040 7040 9020 3046

END T5

T6

Asus:

ASUS VivoBook X202 X201 K200CA C200MA C300MA

ASUS VivoBook X200 X200CA X200MA

ASUS VivoBook Q200 Q200E S200 S200E

ASUS Vivobook X102BA R103BA X200LA X200MA X201E X202E F102BA F201E F200CA

R200CA F200MA F200LA F201E-KX064H, F201E-KX065H

ASUS EeeBook E402MA E403sa E502MA

ASUS Ultrabook Zenbook Prime UX21A Series

ASUS Ultrabook Zenbook Prime UX31A Series

ASUS Ultrabook Zenbook Prime UX32A Series

ASUS Ultrabook Zenbook Prime UX42A Series

ASUS Zenbook UX305 Series

ASUS Zenbook UX310UA Series,

ASUS Transformer Book Flip T300LA,TP300LA

ASUS Taichi 21 31

ASUS FL8700 FL5900 VM520U/590Z R414U UX430

ASUS UX330UA;UX330U;UX360CA-DBM2T

ASUSX360C;Q534U;UX360UA;R541U;R541UA;K556UQ;Q534UX;UX303U;X556UV;X556UR;X556U;Q304U;Q304UA;Q304UA-BBI5T10;Q303UA;Q303U;Q504U;X202

Vivobook F201E Q200E S200E X201E X202E

Asus Zenbook UX21A, UX31A

ASUS: X553 X553M X553MA X553S X553SA Zenbook UX303UA UX303UB UX305CA UX305FA UX305LA UX305UA UX360CA

ASUS: Flip Q302L Q302LA-BBI5T14 Q302LA-BBI5T19 Q302LA-BHI3T09 Q302LA-BHI3T11 Q302LA-BBI5T16

ASUS: Transformer Book Flip Trio T300 T300LA TP300 TP300LA TP300LD TX201 TX201LA T300LA-DH51T TP300LD-RHI5T15

ASUS Vivobook Flip 15 14 13 17 S13 S14 S15 X540 X540S X540L X540SA X540LA X540LJ X540NA X540N X540U X540UA X540UV X540Y X540YA X541NA X541N X541S X541SA X541SC X541UA X541UV X541UJ X541U X541 X441U X441UV X441UA X441S X441SC X441SA E402MA E402M E402SA E402S E402NA E402N E403S E403SA E403N E403NA S510UQ S510UN S510UA S510UF S510UR S510U S510 S530FN S530FA S530UF S530UN S530UA S410UA S410UQ S410UN S410UF S430UN S430UA S430UF S430FA S430FN R416SA R416S.

ASUS Vivobook Flip 15 TP510U TP510UA TP510UQ TP510

END T6

T7

IBM / Lenovo:

Lenovo ThinkPad R60, R60e, R61, R61e, R61i, R400, R410, R500, R510, SL300, SL400, SL500, SL510 ,T60, T60p, T61, T61p, T400, T410, T420, T430, T500, T510, T520, T530, W500, X60, X60s, X60 Tablet, X61, X61s, X61 Tablet, X61LS, X100E X120E X130E X131E X140E ,X200, X200s, X201, X201s, X210, X220, X230, X200 Tablet, X201 Tablet, X300, X301, Z60 Z60t Z61 , Z60m, Z61e, Z61m, Z61t, 3000 C100, C200, 3000 N100, N200, 3000 V100, V200

ThinkPad 420 SL300 T430 T430u T420 T430i T430s T420i T410i

Lenovo Thinkpad Edge 13 14 15 E220S E420 E425 E420S E430 E430c E520 E525 E530 E530c E535 E545 B490 B590 R400 R61 R61i S230u

Fit for ThinkPad X1 Yoga 1st Gen

ThinkPad X240 X240S X250 X260 X270 T431s T440 T440p T440s T450 T450s T460 T460s T470 T470s T550 T560 T570 S431 S440 S531 S540 (P40 Yoga) P50 P50S P51S L440 L450 L460 L470 L540 P50s

ThinkPad Edge E431 E440 E450 E455 E460 E531 E540 E550 E550C E555 E560 E570 E570C E575 E455 E560P G40 G41 G50 G51 G70 Z50-70 Z50-75 Z40-70 Z40-75 Z40-TOUCH Z50-70 Z50-T Z41-70 Z70-80 Z70 Z71 Z410 Z510 Z710

- Lenovo B50 G40 G50 G51 G70 S21e S41 U31 V110 V310 Z40 Z41 Z50 Z51 Z70; Essential G500 G500s G505 G505s G510;

- IdeaPad 300 series Z Series Z50 IdeaPad 300 500 500s S210 S500 S510p U330 U430 U430p U530 Z510;

- Yoga 2 Pro S1 S3 S5 11 12 13 14 15 260 500 730; Flex 2 3 10 11 14 15 15D 1120 1130 1480 1580; W550s X240 X250 X260 X1 Carbon Helix;

- Chromebook 11e N20p

END T7

T8

HP:

Compaq

TC4400, 515, 610, 620

Compaq Mini

311c, 311c-1010SA, 311c-1070SF

Compaq Presario

CQ35-111TU, CQ35-233TX, CQ35-101TX, CQ35-117TX, CQ35-206TU, CQ35-108TU, CQ35-202TX, CQ35-225TX, CQ35-114TX, CQ35-243TX, CQ35-105TU, CQ35-125TX, CQ35-217TU, CQ35-111TX, CQ35-235TX, CQ35-102TU, CQ35-118TX, CQ35-207TU, CQ35-108TX, CQ35-226TX, CQ35-115TU, CQ35-244TX, CQ35-105TX, CQ35-126TX, CQ35-217TX, CQ35-112TU, CQ35-236TX, CQ35-102TX, CQ40-503TX, CQ40-311AX, CQ40-412TU, CQ40-527TX, CQ40-118AU, CQ40-610TX, CQ40-129AX, CQ40-320TU, CQ40-420AX, CQ40-158TU, CQ40-345TU, CQ40-107AX, CQ40-111TU, CQ40-510TU, CQ40-318TU, CQ40-536TX, CQ40-122AX, CQ40-136TU, CQ40-326TU, CQ40-101AU, CQ40-424TX, CQ40-304AX, CQ40-404TU, CQ40-518TU, CQ40-409TU, CQ40-524AX, CQ40-116AU, CQ40-555TU, CQ45-103AU, CQ45-204TX, CQ45-404TU, CQ45-128TX, CQ45-220TX, CQ45-321TX, CQ45-109TX, CQ45-211TU, CQ45-414TX, CQ45-141TX, CQ45-304TX, CQ45, CQ45-202TX, CQ45-401TU, CQ45-122TX, CQ45-217TX, CQ45-311TX, CQ45-105TX, CQ45-208TU, CQ45-408TX, CQ45-135TX, CQ45-301TX, CQ45-417TX, CQ45-148TX, CQ45-328TX, CQ45-116TX, CQ45-214TX, CQ45-308TU, CQ45-103TU, CQ50-104NR, CQ50-116AU, CQ50-110EM, CQ50-115AU, CQ50-106EF, CQ50-139NR, CQ50-103ER, CQ50-109AU, CQ50-105EW, CQ50-128NR, CQ50-112AU, CQ50-215NR, CQ50-101LA, CQ50-107NR, CQ50-105AU, CQ50-116EE, CQ50-110EO, CQ50-115NR, CQ50-100CA, CQ50-107AU, CQ50-139WM, CQ50-103EZ, CQ50-109CA, CQ50-105EZ, CQ50-130EC, CQ50-112EO, CQ50-217CL, CQ50-101XX, CQ60-100ER, CQ60-218EA, CQ60-122EL, CQ60-106AU, CQ60-228EL, CQ60-137EL, CQ60-210AU, CQ60-110EM, CQ60-415EN, CQ60-309AU, CQ60-204TU, CQ60-213EM, CQ60-116EM, CQ60-119TU, CQ60-103EL, CQ60-220EO, CQ60-130EB, CQ60-107TU, CQ60-407AU, CQ60-250EG, CQ60-151EM, CQ60-210ET, CQ60-112TX, CQ60-420ER, CQ60-215EM, CQ60-100EA, CQ60-217EF, CQ60-120EV, CQ60, CQ40, CQ50, CQ45, CQ61-280EJ, CQ61-122EL, CQ61-210SH, CQ61-100SO, CQ61-220EJ, CQ61-109TU, CQ61-225TU, CQ61-115EI, CQ61-203TX, CQ61-206TX, CQ61-127TU, CQ61-211TU, CQ61-104SL, CQ61-221TX, CQ61-110ES, CQ61-230SS, CQ61-118TU, CQ61-120ET, CQ61-210ER, CQ61-100EO, CQ61-140EJ, CQ61-218TU, CQ61-106TU, CQ61-225EE, CQ61-113TU, CQ61-241EZ, CQ61-205ER, CQ61-125EL, CQ61, CQ70-230EL, CQ70-115ES, CQ70-265EG, CQ70-123EO, CQ70-205EF, CQ70-102XX, CQ70-158EZ, CQ70-215EM, CQ70-110EO, CQ70-246EZ, CQ70-118NR, CQ70-100ER, CQ70-130EO, CQ70-210ED, CQ70-105EB, CQ70-116EA, CQ70-230EO, CQ70-124CA, CQ70-205EM, CQ70-103EB, CQ70-201TU, CQ70-215EO, CQ70-110ER, CQ70-250EG, CQ70-120EF, CQ70-201TX, CQ70-101TU, CQ70-134CA, CQ71, CQ-70, CQ71-230ED, CQ71-103EF, CQ71-210ER, CQ71-250EP, CQ71-115SF, CQ71-220SO, CQ71-140SA, CQ71-205EO, CQ71-235SO, CQ71-110EG, CQ71-215ER, CQ71-130EB, CQ71-230EG, CQ71-103SF, CQ71-210SA, CQ71-250SB, CQ71-120ED, CQ71-220SS, CQ71-145EZ, CQ71-205SG, CQ71-240EB, CQ71-110EL, CQ71-215SF, CQ71-130ES, CQ71-200SB, CQ71-230EW, CQ71-105EE, CQ71-210SF, C700, CQ20, CQ35

HP

G50, G50-112NR, G50-104NR, G50-219CA, G50-126NR, G50-113CA, G50-106NR, G50-201CA, G50-116CA, G50-108NR, G50-100, G50-209CA, G50-118NR, G50-109NR, G50-100EA, G50-211CA, G50-123NR, G50-110EA, G50, G50-102NR, G50-213CA, G50-124NR, G50-111NR, G50-103NR, G50-215CA,

G60, G60-100EM, G60-225CA, G61, G60-458DX, G60-117EM, G60-238CA, G60-214EM, G60-125NR, G60-442OM, G60-108CA, G60-235CA, G60-120CA, G60T-200, G60-433CA, G60-101CA, G60-228CA, G61-101TU, G60-468CA, G60-117US, G60-243CL, G60-215EM, G60-126CA, G60-443CL, G60-114EA, G60-235DX, G60-201TU, G60-120EM, G60-437CA, G60-101TU, G60-230CA, G61-102TU, G61, G70, G70-100 CTO, G70-257CL, G70-120EM, G70-463CL, G70, G70-105EA, G70T-100, G70-467CL, G70-212EM, G70-110EA, G70T-200, G70-468NR, G70-213EM, G70-110EM, G70-246US, G70-111EA, G70-450CA, G70-250CA, G70-111EM, G70-258US, G70-457CA, G70-250US, G70-120EA, G70-460US, 2133, 2533, 2533T, 4410, 4410T, 550, G40, G41, G42, G72

HP Compaq

NX6310, NX6315, NX6320, NX6325, NX7300, NX7400, NW8440, 6830S, 6720T, 6730S, NC2400, NC4400, NC6230, NC6320, NC6400, NC8430, 8510P, 8510W, 8710P, 8530P, 8710W, 8530W, 8730W, 6735B, 6530B, 6910P, 6735S, 6530S, 6930P, 6715S, 6531S, 6715B, 6535B, 6515B, 6710B, 6535S, 6500, 6710S, 6730B, 6700, 6520S, 6510B, 2230S, 2510P, 2710P

HP Compaq Business Notebook

2210B, 2400, 2510P, 2710P, 430, 431, 435, 436, 630, 635, 631, 6515B, 6530S, 6531S, 6535S, 6710S, 6715B, 6720T, 6730S, 6735S, 8510P, 8510W, 8710P, NC2400, NC4400, NC6105, NC6110, NC6115, NC6140, NC6200 CTO, NC6230, NC6300, NC6320, NC6400, NC8430, NW8440, NW9440, NX5100, NX6100, NX6105, NX6110, NX6115, NX6125, NX6130, 8710W, 8530W, 8730W, 6735B, 6530B, 6910P, 6930P, 6715S, 6535B, 6710B, 6730B, 6700, 6520S, 6510B, 6500

HP EliteBook

2730P, 2230S, 2530P, 8530W, 8730W, 2530P, 6930P, 8530P

HP Mobile thin Client

2533T, 4410T, 6720T

HP OmniBook

2000, 2510p, 2000CS, 2710p, 2000CT, 2210b, 800CT, 800, 800CS, 800CS/CT, 425, 430, 400, 300, 600, 600C, 600CT

HP Pavilion

DV3-2027ee, DV3-2121tx, DV3-2150ev, DV3-2006tx, DV3-2014tx, DV3-2105ee, DV3-2035tx, DV3-2130ez, DV3-2022tx, DV3-2115ee, DV3-2090en, DV3-2147tx, DV3-1077ca, DV3-2004tu, DV3-2030eo, DV3-2129tx, DV3-2165ee, DV3-2010el, DV3-2019tx, DV3-2110tx, DV3-2051ea, DV3-2139tx, DV3, DV3-2001tu, DV3-2027tx, DV3-2122tx, DV3-2150us, DV3-2007ee, DV3-2015ee, DV4-1117tx, DV4-1433cl, DV4-1210tu, DV4-1007tx, DV4z-1000, DV4-1132tx, DV4-1225dx, DV4-1402tu, DV4-1035tx, DV4-1150es, DV4-1248tx, DV4-1100ea, DV4-1199eo, DV4-1304tx, DV4-1317tx, DV4-1123tx, DV4-1214tx, DV4-1019tx, DV4-1140tx, DV4-1231tx, DV4-1413tx, DV4-1052xx, DV4-1160tx, DV4-1262cm, DV4-1105tx, DV4-1416la, DV4-1203tu, DV4-1428dx, DV4-12, DV5-1114es, DV5-1299ee, DV5-1137tx, DV5-1198eg, DV5-1220ed, DV5-1025eg, DV5-1120ec, DV5-1145ee, DV5-1203eg, DV5-1104em, DV5-1230et, DV5-1040eh, DV5-1124tx, DV5-1158ep, DV5-1208au, DV5-1003cl, DV5-1110eg, DV5-1250er, DV5-1065ec, DV5-1130ej, DV5-1170es, DV5-1212eo, DV5-1010ea, DV5-1215ee, DV5-1015eg, DV5-1116ee, DV5-1140en, DV5-1199es, DV6-1106tx, DV6-1217tx, DV6-1170ep, DV6-1247eo, DV6-1010et, DV6-1223sf, DV6-1260ep, DV6-1030eb, DV6-1138tx, DV6-1230sb, DV6-1280es, DV6-1050us, DV6-1211sa, DV6-1148tx, DV6-1239et, DV6-1215er, DV6-1154tx, DV6-1240sf, DV6-1000, DV6-1119tx, DV6-1220ez, DV6-1199ee, DV6-1250eq, DV6-1020ed, DV6-1225tx, DV6-1265tx, DV6-1040ej, DV6-1140es, DV7, DV5, DV6, DV4, DV3, DV7-1205eg, DV7-2040eo, DV7-1004tx, DV7-2110sf, DV7z-1100, DV7-2190eq, DV7-1137us, DV7-1215eg, DV7-2070ea, DV7-1023tx, DV7-2120sf, DV7-1100ef, DV7-1160eg, DV7-2005eg, DV7-

1235eo, DV7-2103tx, DV7-1060ep, DV7-2133eg, DV7-1110en, DV7-1190es, DV7-2020tx, DV7-1264nr, DV7-2160eg, DV7-1125eb, DV7-1130ed, DV7-1209em, DV7-2050ei, DV7-1014tx, DV3000, DV3004tx, DV3017tx, DV3030tx, DV3011tx, DV3024tx, DV3005tx, DV3018tx, DV3012tx, DV3025tx, DV3006tx, DV3019tx, DV3000, DV3013tx, DV3026tx, DV3007tx, DV3020tx, DV3001tx, DV3014tx, DV3027tx, DV3008tx, DV3021tx, DV3002tx, DV3015tx, DV3028tx, DV3009tx, DV3022tx, DV3003tx, DV3016tx, DV3029tx, DV3010tx, DV3023tx, DV3112tx, DV3106tx, DV3119tx, DV3100, DV3113tx, DV3107tx, DV3120tx, DV3101tx, DV3114tx, DV3108tx, DV3102tx, DV3115tx, DV3109tx, DV3103tx, DV3116tx, DV3110tx, DV3104tx, DV3117tx, DV3111tx, DV3105tx, DV3118tx, DV3100, DV3500, DV3505tx, DV3525tx, DV3560ep, DV3512tx, DV3536tx, DV3500t, DV3520tx, DV3550eg, DV3508tx, DV3530tx, DV3516tx, DV3542tx, DV3505xx, DV3526tx, DV3560ev, DV3513tx, DV3537tx, DV3501tx, DV3521tx, DV3550el, DV3509tx, DV3531tx, DV3517tx, DV3543tx, DV3506la, DV3527tx, DV3570ei, DV3514tx, DV3538tx, DV3502tx, DV3522tx, DV3550eo, DV3510er, DV3532tx, DV3600, DV3620tx, DV3660ew, DV3606tx, DV3630tx, DV3615tx, DV3650el, DV3625tx, DV3601tx, DV3610tx, DV3640ew, DV3621tx, DV3680es, DV3607tx, DV3631tx, DV3616tx, DV3650ep, DV3626tx, DV3602tx, DV3611er, DV3650ef, DV3622tx, DV3699ef, DV3608tx, DV3632tx, DV3617tx, DV3650ez, DV3627tx, DV3603tx, DV3611tx, DV3650eg, DV3623tx, DV3600ec, DV3609tx, DV3633tx, DV3700, DV3704tx, DV3705tx, DV3706tx, DV3707tx, DV3700, DV3701tx, DV3702tx, DV3703tx, DV3800, DV3888nr, DV4-1000, DV4T-1000, DV4-1000 CTO, ZE5500, ZE5600, ZE5700

HP ProBook

4410S, 4440S, 4530S, 4720S, 6455B, 6475B, 6565B, 4415S, 4510S, 4540S, 4730S, 6460B, 6550B, 6570B, 4420S, 4520S, 4545S, 4740S, 6465B, 6555B, 4430S, 4525S, 4710S, 6450B, 6470B, 6560B, 4535S, 5310M, 4411S, 4416S, 4515S, 4310, 4311S, 4310S, 4710S

HP ProBook 430 G1 430 G2 440 G1 440 G2 450 G1 450 G2 455 G1 455 G2 640 G1 645 G1 650 G1 655 G1, HP EliteBook 720 G1 725 G2 740 G1 740 G2 745 G2 750 G1 750 G2 755 G2 820 G1 820 G2 840 G1 840 G2 850 G1 850 G2, HP 2000 laptop 2000-2b09wm 2000-2a20nr 2000-2b19wm , g series, g62-223cl g62-435dx (eve 更新)

HP 2000 Series 2000-2b09wm 2000-2a20nr 2000-2b19wm 2000-2b29wm 2000-2d19wm 2000-329wm 2000-2d24dx 2000-363nr 2000-354nr 2000-412nr 2000-219dx 2000-299wm 2000-2d60dx 2000-2d22dx 2000-2d49wm 2000-2b89wm 2000-2b49wm 2000-365dx 2000-2b44dx 2000-2c25dx 2000-2c34nr 2000-2c12nr 2000-369wm 2000-2c29wm

HP Pavilion DV7 dv7-2273cl dv7-2180us dv7-2185dx dv7-3165dx dv7-3085dx dv7-3080us dv7-3079wm dv7-3065dx dv7-3188cl dv7-3173nr dv7-3060us dv7-4183cl dv7-4065dx dv7-6b32us dv7-6c95dx dv7-6c43cl dv7-6135dx dv7-6175us dv7-6b55dx dv7-6b78us

HP Pavilion DV6 dv6-1378nr dv6-1259dx dv6-1355dx dv6-1350us dv6-1359wm dv6-1352dx dv6-1238nr dv6-1030us dv6-2155dx dv6-2066dx dv6-2050us dv6-2162nr dv6-2190us dv6-3127dx dv6-3225dx dv6-3122us dv6-3123cl dv6-3025dx dv6-3231nr dv6-3257cl dv6-6c35dx dv6-6c40us dv6-6c14nr dv6-6033cl dv6-6c16nr dv6-6c50us dv6-7013cl dv6-7138us dv6-7043cl dv6-7020us dv6-7245us dv6-7078ca dv6-7213nr

HP Pavilion DV5 dv5-1235dx dv5-1125nr dv5-1392nr dv5-1254us dv5-2035dx dv5-2134us dv5-2145dx dv5-2134nr

HP Pavilion DV4 dv4-1540us dv4-1548nr dv4-2145dx dv4-2160us dv4-2165dx dv4-4140us dv4-4141us

HP Pavilion G6 g6-1d45dx g6-1b79dx g6-1d70us g6-1b60us g6-2249wm g6-2123us g6-2231dx g6-

2123us g6-2010nr g6-2342dx

HP Pavilion G7 g7-1260us g7-1310us g7-1365dx g7-1167dx g7-1219wm g7-1150us g7-2269wm g7-2340dx g7-2240us g7-2270us g7-2323dx g7-2247us

HP Pavilion DM4 dm4-1160us dm4-1065dx dm4-2015dx dm4-2180us dm4-2070us dm4-2165dx dm4-3055dx dm4-3099se dm4-3013cl dm4-3050us

END T8

T9

HP:

Compaq Evo Series; N110 , N150, N200,N400c,N410c, N600c,N610c, N620c, N800, N800c, N800v,N800w; Compaq Armada Series;110,110s, E300,E500,E500s,E700,M300, M500,M700 ,V300; Compaq Presario 900,1700, ZZ00, Z800, B1000,B2000,B3000, M2000, V1000, V2000, V2100,V2200,V2300, V2400, VZ500, V2600, VZ700,V3000,V3100, V3300, V3300, V3400, V3500,V3600,V4000,V6000, V6100, V6200, V6300,V6400,V6500Series;HP Pavillion DV1000, DV1100, DV1200, DV1300, DV1400, DV1500, DV1600, DV1700, DV2000, DV2100, DV4000, DV6000, DV6100, DV6500, DV6600, DV8000, DV8200, DV8300, DV9000, DV9100, DV9200, DV9300, DV9400, DV9500, DV9600, DV9700, DV9800, DV9900, DX6600 Series ZT3000, ZT3200, ZT3300, HP Compaq ZE2000, ZE2100, ZE2200, ZE2300, ZE2400, X1000, X1100, X1200, X1300, X1400, X1500 Series Series; Tablet PC TC1000, TC1100, MZ000, TC4Z00 series; Business, Notebook nc4000, nc4010, nc4Z00, nc6000, nx6110, nc6120, nc6ZZ0, ix6Z30, nc8000, nc8230, nw8000, nwBZ00, nw8240, nx5000, nx6110, nx6125, nx7000, nx7010, nx8220, nx9000, nx9020, nx9030 , nx9040 series

Hp Envy

4-1004TU, 4-1025TU, 4-1026TU, 4-1028TU, 4-1029TU, 4-1030TU, 4-1031TU, 4-1032TU, 4-1032TX, 4-1033TX, 4-1034TX, 4-1035TX, 4-1036TX, 4-1037TX, 4-1038TX, 4-1043TU, 4-1044TU, 4-1045TU, 4-1046TU, 4-1047TU, 4-1048TU, 4-1049TU, 4-1050BR, 4-1050TU, 4-1051TU, 4-1051TX, 4-1052TU, 4-1052TX, 4-1053TU, 4-1053TX, 4-1054TU, 4-1054TX, 4-1055TU, 4-1055TX, 4-1056TX, 4-1057TX, 4-1058TX, 4-1059TX, 4-1060TX, 4-1061TX, 4-1062TX, 4-1063TX, 4-1064TX, 4-1066TX, 4-1101TU, 4-1102TU, 4-1102TX, 4-1103TU, 4-1103TX, 4-1104TU, 4-1104TX, 4-1105DX, 4-1105TU, 4-1105TX, 4-1106TX, 4-1107TU, 4-1107TX, 4-1108TU, 4-1108TX, 4-1109TU, 4-1109TX, 4-1110TU, 4-1110TX, 4-1110US, 4-1111TX, 4-1115DX, 4-1115DX/I5-3317U, 4-1117NR, 4-1130US, 4-1150BR, 4-1150LA, 4-1152LA, 4-1155LA, 6-1002TU, 6-1007TX, 6-1008TX, 6-1011TU, 6-1012TU, 6-1013TU, 6-1013TX, 6-1014TU, 6-1015TU, 6-1015TX, 6-1016TU, 6-1017TU, 6-1017TX, 6-1018TU, 6-1018TX, 6-1019TU, 6-1019TX, 6-1020TU, 6-1021TU, 6-1022TU, 6-1022TX, 6-1023TX, 6-1024TU, 6-1024TX, 6-1025TU, 6-1025TX, 6-1026TU, 6-1101TU, 6-1101TX, 6-1102TU, 6-1102TX, 6-1103TX, 6-1110US, 6-1129WM, 6-1131NR, 6-1140CA, 6-1146NR, 6-1168CA, 6-1180CA

HP Pavilion

14-B000ED, 14-B000EE, 14-B000EI, 14-B000EO, 14-B000ET, 14-B001EA, 14-B001EIA, 14-B001TX, 14-B002TX, 14-B004TU, 14-B005AU, 14-B006AU, 14-B007AU, 14-B008AU, 14-B009AU, 14-B009TU, 14-B010AU, 14-B010US, 14-B012AU, 14-B013AU, 14-B014AU, 14-B014TU, 14-B015AU, 14-B015DX, 14-B022AU, 14-B023TX, 14-B024TU, 14-B025TU, 14-B028AU, 14-B028TU, 14-B030TU, 14-B031TU, 14-B034TU, 14-B035TU, 14-B038TU, 14-B043TU 14-B062LA CTO, 14Z-B000

Asus Eee PC 1001P ASUS Eee PC 1005 Series: Asus Eee PC 1005H, Asus Eee PC 1005HE, Asus Eee PC 1005HR, Asus Eee PC 1005P, Asus Eee PC 1005PE, ASUS Eee PC 1005HA Series: Asus Eee PC 1005HA Asus Eee PC 1005HAB, Asus Eee PC 1005HA-B, Asus Eee PC 1005HA-E, Asus Eee PC 1005HA-P Asus Eee PC 1005HA-V, Asus Eee PC 1005HA-A, Asus Eee PC 1005HA-E, Asus Eee PC 1005HA-P Asus Eee PC 1005HA-V, Asus Eee PC 1005HA_GG, Asus Eee PC 1005HA-EU1X, Asus Eee PC 1005HA-EU1X-BK, Asus Eee PC 1005HA-PU1X, Asus Eee PC 1005HA-PU1X-BK, Asus Eee PC 1005HA-PU1X-BU Asus Eee PC 1005HA-VU1X, Asus Eee PC 1005HA-VU1X-BK, Asus Eee PC 1005HA-VU1X-WT

Asus Eee PC 1005HA-VU1X-BU, Asus Eee PC 1005HA-VU1X-PI, ASUS Eee PC 1008HA Series:, Asus Eee PC 1008HA, Asus Eee PC 1008HAG, Asus Eee PC 1008P, ASUS Eee PC 1101HA Series:, Asus Eee PC 1101HA Asus Eee PC 1101HA_GG, Asus Eee PC 1101HAG, Asus Eee PC 1101HAB, Asus Eee PC 1101HGO
Asus Eee PC 101HA-MU1X, Asus Eee PC 101HA-MU1X-BK, ASUS Eee PC 1104HA Series, ASUS Eee PC 1106HA Series, ASUS Eee PC 1201 Series: Asus Eee PC 1201N, Asus Eee PC 1201NL, Asus Eee PC 1201T
Asus Eee PC 1201HA, Asus Eee PC 1201HAG, NEC Versa LITEPAD, NEC Versa VX, Gateway Solo 1100, 2100, 2150, 2200, 2300, 2300LS, 2300XL, 2500, 2500LS, 2500SE, 2500XL, 2540, 5100, 5100XL, 5150LS, 5150SE, 5150XL, 9100, 9100LS, 9100SE, 9100XL, 9150, 9300, 9300CX

HP Compaq Presario

Compaq Presario 2200 Series 2800 Series B1000, B2000, B3000 Series C300 Series C500 Series C700 Series F700 Series F500 Series M2000 Series V1000 Series V2000 Series V2100 Series V2200 Series V2300 Series V2400 Series V2500 Series V2600 Series V2700 Series V3000 Series V3100 Series V3200 Series V3300 Series V3400 Series V3500 Series V4000 Series V5000 Series V6000 Series V6100 Series V6200 Series V6300 Series V6400 Series V6500 Series

HP Pavilion

HP Pavilion DV1000 Series DV1100 Series DV1200 Series DV1400 Series DV1500 Series DV1600 Series DV1700 Series DV2000 Series DV2100 Series DV2200 Series DV2300 Series DV4000 Series DV4100 Series DV4300 Series DV4400 Series DV5000 Series DV5200 Series DV6000 Series DV8000 Series DV9000 Series ZT3000 Series ZT3100 Series ZT3200 Series ZT3300 Series ZT3400 Series HP Compaq ZE4900 Series HP Compaq ZE2000, ZE2100, ZE2200, ZE2300, ZE2400 Series Compaq Presario X1000 Series Compaq Presario X1100, X1200, X1300, X1400, X1500 Series

END T9

T10

HP:

For Compaq Presario 2100 Series:

For Compaq Presario 2500 Series

For Compaq Business Notebook n1050v Series

For HP Compaq Business Notebook nx9000 series

For HP Compaq Business Notebook nx9010 series

For HP Pavilion D Series:

DA720AV, DA723AV, DA726AV, DA731AV, DA732AV, DB385A, DB386A

For HP Omnibook XT Series

XT276, XT375, XT412, XT4345QV, XT5300, XT5366WM, XT537QV, XT545, XT5477WM, XT595

For HP Omnibook ZE Series

ZE4100, ZE4115, ZE4125, ZE4145, ZE4200, ZE4220, ZE4230, ZE4236, ZE42240, ZE4315CA, ZE4315US, ZE4325CA, ZE4325US, ZE4335US, ZE4365US, ZE4401, ZE4402, ZE4420, ZE4430, ZE4455EA, ZE5155, ZE5170, ZE5185, ZE5200, ZE5279, ZE5300, ZE5395US, ZE5478CL, ZE5490US

For HP Omnibook ZT1000 Series

END T10

T11

Acer / HP / Compaq / Asus / Toshiba / IBM / Lenovo / LG / Clevo / Fujitsu / Gateway / Advent / Packard Bell / MSI / Benq / Medion

TOSHIBA Satellite A100, A110, A130, A135, A2000, A205, L100, L10, L15, L20, L25, L30, L35, L40, L45, M200, M30, M35, M45, M50, M55, M65, M70, P200, Pro A100, Pro L10, Pro L20, Pro M50, Pro M70, Pro L100, U300, U305, 1000, 1005, 1115, 1130, 1200, 1600, 1620, 1640, 1730, 1750, 1900, 1905, 1955 series;

Tecra L2 series; Qosmio F45 series;
Equium A100, L100, M70 series;

IBM/Lenovo IdeaPad 3000 Y300, Y310, Y400, Y430, Y500, Y510, Y530 series; Compaq ACY13, APL10, APL11, BCL3Z, BCQ1Z, CL3Z, CQ12, CY13, APL10, PL11, TS30H series; BENQ Joye-book series;

CLEVO 2700, 66 Series, 86Z, 86CE, 98 Series;

FUJITSU LifeBook A1010, A3110, C1211, C1320, C1410, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, E2010, E330, E380, E4010, E4010D, E6624, E6634, E6644, E6654, E6664, E7010, E7110, E8000, E8000D, E8010, E8010D, E8020, E8210, N3400, N3410, N3500, N3510, S6310, S2210, S6310, S6410, S2210, SS7000, S7000D, S7010, S7010D, S7011, S7020, S7025, S7110, T4010, T4010D, T4210, T4020, Amilo D6820, Amilo D8820, Biblio4100L, N6110, N6220, V1010, FMV-BIBLO MG75S, FMV-BIBLO NBxx Series

DELL Inspiron 1000, 1200, 1300, 2200, 3000, 3500, 3200, 7000, B120, B130, Latitude 110L series;

GATEWAY Solo 400, Solo 450, Solo 600, W322, M320 series;

AVERATEC 3000, 3120, 3150, 3150H, 3150Hd, 3150HS, 3150P, 3150HW, 3120V, 5110, 5110H, 5110Hx, 5110P, 6200, AV6200H60, AV6240, 6240 series;

Asus Zenbook Vivobook Eee Book A53s A53u A450 A52f A53e A54c A55a F554 X401 X450 X501 X502 X550 X551 X552 X554 X555 X550V X550C Y481C W519L V450C W518L

END T11

T12

Sony / Samsung / Panasonic / Fujitsu / Dell / Canon / AST

AST

ADVANTAGE EXPLORER 100XL ADVANTAGE EXPLORER 212 ADVANTAGE EXPLORER 486DX4

CANON

CANON i70 PORTABLE PRINTER CANON i70 PORTABLE PRINTER

DELL

TS30G

FUJITSU

FMV-BIBLO LOOX P70R FMV-BIBLO LOOX P70S FMV-BIBLO LOOX T50H FMV-BIBLO LOOX T50J FMV-BIBLO LOOX T50K

FMV-BIBLO LOOX T70H FMV-BIBLO LOOX T70J FMV-BIBLO LOOX T70K FMV-BIBLO LOOX T70L FMV-BIBLO LOOX T75L

FMV-BIBLO MG50R FMV-BIBLO MG55R LIFEBOOK 270 LIFEBOOK 280 LIFEBOOK 400

LIFEBOOK 420 LIFEBOOK 435 LIFEBOOK 470 LIFEBOOK 520 LIFEBOOK 530

LIFEBOOK 531 LIFEBOOK 535 LIFEBOOK 555 LIFEBOOK 565 LIFEBOOK 585

LIFEBOOK 635 LIFEBOOK 655 LIFEBOOK 656 LIFEBOOK 665 LIFEBOOK 675

LIFEBOOK 690 LIFEBOOK 735 LIFEBOOK 755 LIFEBOOK 756 LIFEBOOK 765

LIFEBOOK 770 LIFEBOOK 785 LIFEBOOK 790 LIFEBOOK 990 LIFEBOOK A4170

LIFEBOOK B2130 LIFEBOOK B2131 LIFEBOOK B2175 LIFEBOOK B2545 LIFEBOOK B2562

LIFEBOOK B2566 LIFEBOOK B2610 LIFEBOOK B2620 LIFEBOOK B2630 LIFEBOOK B3000

LIFEBOOK B3020 LIFEBOOK B5010 LIFEBOOK B6000 LIFEBOOK B6110 LIFEBOOK B6210

LIFEBOOK B8200 LIFEBOOK B8220 LIFEBOOK C325 LIFEBOOK C340 LIFEBOOK C350

LIFEBOOK C352 LIFEBOOK C353 LIFEBOOK C360 LIFEBOOK C4120 LIFEBOOK C4155

LIFEBOOK C4157 LIFEBOOK C4235 LIFEBOOK C425 LIFEBOOK C5130 LIFEBOOK C5235

LIFEBOOK C6175 LIFEBOOK C6177 LIFEBOOK C6185 LIFEBOOK C6320 LIFEBOOK C6330

LIFEBOOK C6525 LIFEBOOK C6535 LIFEBOOK C6537 LIFEBOOK C6545 LIFEBOOK C6547

LIFEBOOK C6556 LIFEBOOK C6557 LIFEBOOK C6577 LIFEBOOK C6581 LIFEBOOK C6591

LIFEBOOK C6611 LIFEBOOK C6631 LIFEBOOK C6651 LIFEBOOK C6731 LIFEBOOK C7651

LIFEBOOK C7661 LIFEBOOK E330 LIFEBOOK E335 LIFEBOOK E340 LIFEBOOK E342

LIFEBOOK E350 LIFEBOOK E351 LIFEBOOK E360 LIFEBOOK E362 LIFEBOOK E370

LIFEBOOK E380 LIFEBOOK E390 LIFEBOOK E5140 LIFEBOOK E5320 LIFEBOOK E5520

LIFEBOOK E6520 LIFEBOOK E6540 LIFEBOOK E6541 LIFEBOOK E6550 LIFEBOOK E6550

LIFEBOOK E6555 LIFEBOOK E6556 LIFEBOOK E6557 LIFEBOOK E6570 LIFEBOOK E6571

LIFEBOOK E6577 LIFEBOOK I4187 LIFEBOOK I4190 LIFEBOOK L SERIES LIFEBOOK P1000

LIFEBOOK P1032 LIFEBOOK P1035 LIFEBOOK P1110 LIFEBOOK P1120 LIFEBOOK P1510

LIFEBOOK P1610 LIFEBOOK P2046 LIFEBOOK P2110 LIFEBOOK P2120 LIFEBOOK P5000

LIFEBOOK P5010 LIFEBOOK P5020 LIFEBOOK P7000 LIFEBOOK P7010 LIFEBOOK P7120

LIFEBOOK P7230 LIFEBOOK P8210 LIFEBOOK S2010 LIFEBOOK S2020 LIFEBOOK S2110

LIFEBOOK S4510 LIFEBOOK S4542 LIFEBOOK S4546 LIFEBOOK S4572 LIFEBOOK S5582

LIFEBOOK S6000 LIFEBOOK S6010 LIFEBOOK S6110 LIFEBOOK S6120 LIFEBOOK S6130

LIFEBOOK S6210 LIFEBOOK S6220 LIFEBOOK S6230 LIFEBOOK S6231 LIFEBOOK S6240

LIFEBOOK T3010 LIFEBOOK T4010 LIFEBOOK U1010 LIFEBOOK U8240 PENCENTRA 130

PENCENTRA 200 POINT 1600 POINT 510 STYLISIC ST4000 STYLISIC ST4110
STYLISIC ST4120 STYLISIC ST4121 STYLISIC ST5000 STYLISIC ST5010 STYLISIC ST5011
STYLISIC ST5020 STYLISIC ST5021 STYLISIC ST5022 STYLISTIC 1000 STYLISTIC 1200
STYLISTIC 2300 STYLISTIC 3400 STYLISTIC 3500 STYLISTIC 500 STYLISTIC LT
STYLISTIC LT C500 STYLISTIC LT P600 STYLISTIC ST4121 STYLISTIC ST5030 STYLISTIC ST5031
STYLISTIC ST5032

PANASONIC

TOUGHBOOK CF-01 TOUGHBOOK CF-07 TOUGHBOOK CF-17 TOUGHBOOK CF-25 TOUGHBOOK CF-27
TOUGHBOOK CF-28 TOUGHBOOK CF-33 TOUGHBOOK CF-34 TOUGHBOOK CF-35 TOUGHBOOK CF-37
TOUGHBOOK CF-41 TOUGHBOOK CF-45 TOUGHBOOK CF-47 TOUGHBOOK CF-61 TOUGHBOOK CF-62
TOUGHBOOK CF-63 TOUGHBOOK CF-71

SAMSUNG

SENS 700 SENS 800

Sony Vaio Series

VAIO PCG-1A1N VAIO PCG-1G1N VAIO PCG-384 VAIO PCG-431L VAIO PCG-432L
VAIO PCG-481N VAIO PCG-4C1N VAIO PCG-4L3N VAIO PCG-500 VAIO PCG-505
VAIO PCG-505BX VAIO PCG-505E VAIO PCG-505F VAIO PCG-505G VAIO PCG-505GX
VAIO PCG-505LS VAIO PCG-505R VAIO PCG-505RS VAIO PCG-505RX VAIO PCG-505S
VAIO PCG-505SX VAIO PCG-505TR VAIO PCG-505TS VAIO PCG-505TX VAIO PCG-505V
VAIO PCG-505X VAIO PCG-6C1N VAIO PCG-792L VAIO PCG-883L VAIO PCG-C1
VAIO PCG-C1F VAIO PCG-C1MAH VAIO PCG-C1MGP VAIO PCG-C1MHP VAIO PCG-C1MR
VAIO PCG-C1MRX VAIO PCG-C1MSX VAIO PCG-C1MV VAIO PCG-C1MVM VAIO PCG-C1MVMKIT
VAIO PCG-C1MVP VAIO PCG-C1MVPM VAIO PCG-C1MW VAIO PCG-C1MW1 VAIO PCG-C1MWP
VAIO PCG-C1MWP1 VAIO PCG-C1MZX VAIO PCG-C1R VAIO PCG-C1X VAIO PCG-C1XS
VAIO PCG-GP VAIO PCG-GR VAIO PCG-GR114EK VAIO PCG-GR150K VAIO PCG-GR170K
VAIO PCG-GR230 VAIO PCG-GR250 VAIO PCG-GR270 VAIO PCG-GR290 VAIO PCG-GR300
VAIO PCG-GR315 VAIO PCG-GR370 VAIO PCG-GR390 VAIO PCG-GR3E VAIO PCG-GR3F
VAIO PCG-GR3N VAIO PCG-GR5E VAIO PCG-GR5F VAIO PCG-GR5N VAIO PCG-GR7
VAIO PCG-GR9 VAIO PCG-GR90E VAIO PCG-GR9E VAIO PCG-GT1 VAIO PCG-GT3
VAIO PCG-R290 VAIO PCG-R5GP VAIO PCG-RX99P VAIO PCG-SR1 VAIO PCG-SR17
VAIO PCG-SR19GT VAIO PCG-SR1C VAIO PCG-SR1G VAIO PCG-SR1M VAIO PCG-SR27K
VAIO PCG-SR31K VAIO PCG-SR33K VAIO PCG-SR5K VAIO PCG-SR7K VAIO PCG-SR9
VAIO PCG-SR9C VAIO PCG-SR9G VAIO PCG-SR9M VAIO PCG-SRX VAIO PCG-SRX3
VAIO PCG-SRX3E VAIO PCG-SRX3F VAIO PCG-SRX41P VAIO PCG-SRX7 VAIO PCG-SRX77
VAIO PCG-SRX77E VAIO PCG-SRX7E VAIO PCG-SRX7F VAIO PCG-SRX7S VAIO PCG-SRX87
VAIO PCG-TR1A VAIO PCG-TR1AP VAIO PCG-TR2A VAIO PCG-TR2AP1 VAIO PCG-TR2AP3
VAIO PCG-TR3A VAIO PCG-TR3AP1 VAIO PCG-TR3AP2 VAIO PCG-V505A VAIO PCG-V505AC
VAIO PCG-V505ACK VAIO PCG-V505ACP VAIO PCG-V505AK VAIO PCG-V505AP VAIO PCG-V505AX
VAIO PCG-V505AXP VAIO PCG-V505BX VAIO PCG-V505BXP VAIO PCG-V505DC1 VAIO PCG-V505DX
VAIO PCG-V505DXP VAIO PCG-V505EC VAIO PCG-V505EX VAIO PCG-V505EXP VAIO PCG-Z1
VAIO PCG-Z1 VAIO PCG-Z1A VAIO PCG-Z1A1 VAIO PCG-Z1AP1 VAIO PCG-Z1AP2
VAIO PCG-Z1AP3 VAIO PCG-Z1FP VAIO PCG-Z1GP VAIO PCG-Z1M VAIO PCG-Z1MP
VAIO PCG-Z1RA VAIO PCG-Z1RAP1 VAIO PCG-Z1RAP2 VAIO PCG-Z1RAP3 VAIO PCG-Z1RGP
VAIO PCG-Z1RMP VAIO PCG-Z1RSP VAIO PCG-Z1SP VAIO PCG-Z1VA VAIO PCG-Z1VAP

VAIO PCG-Z1VAP1 VAIO PCG-Z1VAP2 VAIO PCG-Z1VCP VAIO PCG-Z1VE VAIO PCG-Z1VFP
VAIO PCG-Z1VGP VAIO PCG-Z1VJP VAIO PCG-Z1VLP VAIO PCG-Z1VP VAIO PCG-Z1VT/P
VAIO PCG-Z1VTP VAIO PCG-Z1VTP VAIO PCG-Z1WA VAIO PCG-Z1WAMP1 VAIO PCG-Z1WAMP2
VAIO PCG-Z1WAMP2 VAIO PCG-Z1WAMP3 VAIO PCG-Z1WAP VAIO PCG-Z1WAP VAIO PCG-Z1WXFP
VAIO PCG-Z1XGP VAIO VGN-S260 VAIO VGN-S360 VAIO VGN-T140P VAIO VGN-T150P
VAIO VGN-T160 VAIO VGN-T240 VAIO VGN-TZ17GN VAIO VGN-X505 VAIO VGN-X505ZP

END T12

T13

Samsung / Acer / LG:

TOSHIBA Satellite A100, A110, A130, A135, A2000, A205, L100, L10, L15, L20, L25, L30, L35, L40, L45, M200, M30, M35, M45, M50, M55, M65, M70, P200, Pro A100, Pro L10, Pro L20, Pro M50, Pro M70, ProL100, U300, U305, 1000, 1005, 1115, 1130, 1200, 1600, 1620, 1640, 1730, 1750, 1900, 1905, 1955 series; Tecra L2 series; Qosmio F45 series;

Equium A100, L100, M70 series; IBM/Lenovo IdeaPad 3000 Y300, Y310, Y400, Y430, Y500, Y510, Y530 series;

Compal ACY13, APL10, APL11, BCL3Z, BCQ1Z, CL3Z, CQ12, CY13, APL10, PL11, TS30H series;

BENQ Joye-book series; CLEVO 2700, 66 Series, 86Z, 86CE, 98 Series;

FUJITSU LifeBook A1010, A3110, C1211, C1320, C1410, C2010, C2110, C2111, C2210, C2220, C2230, C2240, C2310, C2320, C2330, E2010, E330, E380, E4010, E4010D, E6624, E6634, E6644, E6654, E6664, E7010, E7110, E8000, E8000D, E8010, E8010D, E8020, E8210, N3400, N3410, N3500, N3510, S6310, S2210, S6310, S6410, S2210, SS7000, S7000D, S7010, S7010D, S7011, S7020, S7025, S7110, T4010, T4010D, T4210, T4020, Amilo D6820, Amilo D8820, Biblio4100L, N6110, N6220, V1010, FMV-BIBLO MG75S, FMV-BIBLO NBxx Series DELL Inspiron 1000, 1200, 1300, 2200, 3000, 3500, 3200, 7000, B120, B130, Latitude 110L series; GATEWAY Solo 400, Solo 450, Solo 600, W322, M320 series;

AVERATEC 3000, 3120, 3150, 3150H, 3150Hd, 3150HS, 3150P, 3150HW, 3120V, 5110, 5110H, 5110Hx, 5110P, 6200, AV6200H60, AV6240, 6240 series;

aspire swith12

Acer TravelMate TMX313-M-6824

Acer TravelMate P236

Acer Chromebook 13 CB5:CB5-C810-T7ZT CB5-311-T1UU CB5-311-T677 CB5-311-T7NN CB5-311-T9B0 CB5-311-T9Y2

Acer Chromebook 14 CB3-431:CB3-431-C5EX CB3-431-C5FM CB3-431-C5XK

Acer Chromebook 15 C910 CB3 CB5:C910-54M1 C910-C37P C910-C453 CB3-531-C4A5 CB5-571-C09S CB5-571-C1DZ CB5-571-C4G4 CB5-571-C4T3 CB5-571-C5XU CB5-571-C6DL CB5-571-C9DH

Acer Chromebook C720 C720P C720-2103 C720-2420 C720-2800 C720-2802 C720-2827 C720-2844 C720-2848 C720P C720P-2457 C720P-2600 C720P-2625 C720P-2661 C720P-2666 C720P-2834

Acer Aspire S5 S7 S5-371 S5-391 S7-191 S7-391 S7-392 S7-393 S5-371-52JR S5-391-6836 S5-391-9860 S5-391-9880

S7-191-6400 S7-191-6447 S7-191-6640 S7-191-6859 S7-391-6413 S7-391-6468 S7-391-6478 S7-391-6810 S7-391-6812

S7-391-6818 S7-392-6425 S7-392-6484 S7-392-6807 S7-392-6832 S7-392-7863 S7-392-9404 S7-392-9439 S7-392-9460

Acer Iconia W7 W700 W700-6454 W700-6465 W700-6495 W700-6499 W700-6602 W700-6607 W700-6680 W700-6691 W700-6831 W700P W700P-6621 W700P-6821

Acer Chromebook R 11 C720 C720P C730E C738T C740 CB3 CB5: CB3-111-C4HT CB3-111-C670 CB3-111-C6EQ CB3-111-C8UB CB3-131-C3SZ CB3-131-C3VC CB5-132T-C1LK CB5-132T-C32M CB5-132T-C8ZW C720-2103 C720-2420 C720-2800 C720-2802 C720-2827 C720-2844 C720-2848 C720-3404 C720-3605 C720-3871 C720P-2457 C720P-2600 C720P-2625 C720P-2661 C720P-2666 C720P-2834 C738T-C44Z C740-C3P1 C740-C4PE

Acer Chromebook 11 R11:

C720: C720-2103 C720-2420 C720-2800 C720-2802 C720-2827 C720-2844 C720-2848 C720-3404 C720-3605 C720-3871

C720p: C720p-2457 C720p-2600 C720p-2625 C720p-2661 C720p-2666 C720p-2834

C740: C740-C3P1 C740-C4PE

CB3-111: CB3-111 CB3-111-C19A CB3-111-C4HT CB3-111-C4T3 CB3-111-C670 CB3-111-C6EQ CB3-111-C8UB CB3-111-C9DJ

Acer Chromebook 13:

C810: C810-T9CA C810-T7ZT

CB5-311: CB5-311 CB5-311-T1UU CB5-311-T5BD CB5-311-T5X0 CB5-311-T677 CB5-311-T7NN CB5-311-T9B0 CB5-311-T9Y2 CB5-311P CB5-311P-T9AB

Acer Chromebook 14:

CB3-431: CB3-431-C5EX CB3-431-C5FM CB3-431-C5XK

Acer Chromebook 15:

C910: C910-3916 C910-54M1 C910-C37P C910-C453

CB3-531: CB3-531 CB3-531-C4A5

CB5-571: CB5-571 CB5-571-362Q CB5-571-58HF CB5-571-C09S CB5-571-C1DZ CB5-571-C4T3 CB5-571-C5XU CB5-571-C6DL CB5-571-C7QN CB5-571-C9DH

Acer One Cloudbook 11 14:

AO1-131: AO1-131-C620 AO1-131-C7DW AO1-131-C9PM AO1-131-C9RK

AO1-431: AO1-431-C3TM AO1-431-C7F9 AO1-431-C8G8

Acer Aspire S5 S7 R5 R7:

S5-371: S5-371-52JR

S5-391: S5-391-6419 S5-391-6495 S5-391-6836 S5-391-9860 S5-391-9880

S7-191: S7-191-6400 S7-191-6447 S7-191-6640 S7-191-6859

S7-391: S7-391-6413 S7-391-6468 S7-391-6478 S7-391-6810 S7-391-6812 S7-391-6818 S7-391-6822

S7-391-9411 S7-391-9427 S7-391-9492 S7-391-9839 S7-391-9886

S7-392: S7-392-5401 S7-392-6803 S7-392-6807 S7-392-6832 S7-392-7863 S7-392-7885 S7-392-9404

S7-392-9439 S7-392-9460 S7-392-9890 S7-393: S7-393-7451

R5-471T: R5-471T-51UN R5-471T-52EE R5-471T-71W2

R7-371T: R7-371T-50V5 R7-371T-50ZE R7-371T-59L6 R7-371T-59ZK

R7-372T: R7-372T-77LE

Acer Aspire V13 V3-331-P0QW V3-371-51UJ V3-371-56R5 V3-371-57JZ V3-371-596F V3-372T-5051

Acer Aspire One Cloudbook 11 14: AO1-131 AO1-131M AO1-431 AO1-431M: AO1-131-C620 AO1-131-C7DW AO1-131-C9PM AO1-131-C9RK AO1-431-C3TM AO1-431-C7F9 AO1-431-C8G8

Aspire S5 S7 S5-371 S5-391 S7-191 S7-391 S7-392 S7-393: S5-371-52JR S5-391-6419 S5-391-6495 S5-391-6836 S5-391-9860 S5-391-9880 S7-191-6400 S7-191-6447 S7-191-6640 S7-191-6859 S7-391-6413 S7-391-6468 S7-391-6478 S7-391-6810 S7-391-6812 S7-391-6818 S7-391-6822 S7-391-9411 S7-391-9427 S7-391-9492 S7-391-9839 S7-391-9886 S7-392-5401 S7-392-6803 S7-392-6807 S7-392-6832 S7-392-7863 S7-392-7885 S7-392-9404 S7-392-9439 S7-392-9460 S7-392-9890 S7-393-7451

Aspire R 14 13 R5-471T R7-371T R7-372T: R5-471T-51UN R5-471T-52EE R5-471T-71W2 R7-371T-50V5 R7-371T-50ZE R7-371T-59L6 R7-371T-59ZK R7-372T-77LE

Aspire V 13 V3-331 V3-371 V3-372T: V3-331-P0QW V3-371-51UJ V3-371-56R5 V3-371-57JZ V3-371-596F V3-372T-5051

- Acer One Cloudbook 11 14 Series: AO1-131 AO1-431, Acer Aspire S5 S7 Series: S5-371 S5-391 S7-191 S7-391 S7-392 S7-393, Acer Aspire R5 R7 Series: R5-471T R7-371T R7-372T, Acer Aspire V13 Series: V3-331 V3-371 V3-372T

END T13

T14

Dell:

Dell Inspiron 11 3000 Series Dell XPS 12 Series Dell XPS 13-L322X Series
Dell Inspiron 14 3000 Series Dell XPS 12 (9Q23) Dell XPS 13-4040SLV Ultrabook
Dell Inspiron 15 3000 Series Dell XPS 12 (9Q33) Dell XPS 13 Ultrabook Series
Dell Inspiron 15-3551 Dell XPS 12 Ultrabook Dell XPS 13-4040SLV Ultrabook
Dell Inspiron 15-3552 Dell XPS L221X Dell XPS 13-6928SLV Ultrabook
Dell Inspiron 15 5000 Series Dell XPS Duo 12-9Q23 Dell XPS 13-L321X Ultrabook Series
Dell Inspiron 15 7000 Series Dell XPS 12D-1501 Dell XPS 13(L321x) Series
Dell Inspiron 15 I7568-5248T Dell XPS 12D-1508 Dell XPS 13-0015SLV
Dell Inspiron 15-3558 Dell XPS 12D-1701 Dell XPS 13-1000SLV
Dell XPS 12D-1708
Dell XPS 13D Series
Dell Inspiron 14 (7437) Series Dell XPS 12D-2708 Dell XPS 13D-3608
Dell XPS 13D-3708
Dell Vostro 3458-3625 Dell XPS 13 Series Dell XPS 13D-4501
Dell Vostro 15-3000, Dell XPS 13 -0015SLV Dell XPS 13D-4508
Dell Vostro 3558-8317 Dell XPS 13 -4002SLV Dell XPS 13D-4608
Dell Inspiron 11 3000 Series, 11 3147, 11 3148, 11 3152, 11 3153, 11 3162
13 7000 Series, 13 7347, 13 7348, 13 7353, 13 7359
14 3000 Series, 14 3451, 14 i3451, 14 3452, 14 3458, 14 i3458
14 5000 Series, 14 5458, 14 5457, 14 5459
14 7000 Series, 14 7437, 14 i7437, 14 7437T, 14 i7437T
15 3000 Series, 15 3551, 15 i3551, 15 3552, 15 3558
15 5000 Series, 15 5552, 15 5555, 15 i5555, 15 5558, 15 i5558, 15 5559
15 7000 Series, 15 7558, 15 i7558, 15 7568

HP ENVY TOUCHSMART 15-J053XX NOTEBOOK PC,
HP ENVY TOUCHSMART 15-J073CA NOTEBOOK PC,
HP ENVY TOUCHSMART 17-J023CL NOTEBOOK PC,
HP ENVY TOUCHSMART 17-J030US NOTEBOOK PC,
HP ENVY TOUCHSMART 17-J037CL NOTEBOOK PC,
HP ENVY TOUCHSMART M7-J010DX NOTEBOOK PC,
HP Envy 17-j000 ,17-j010us,17-j034ca,17-j070ca,17-j051ei
HP Envy 17-j170ca,17-073ca,17-073ca,17-j013cl,17-j098EF
HP Envy17-j023cl ,17-j027cl,17-j043cl

HP Model 15 14 17 Touch 15-dw 15-dy 15-db 15-ef 15-dx 15-da 15-ay 15-ba 15-bw 15-f 15-u 15-bs 15-af 15-au 15-eh 15-cw 15-ac 15-ax 15-d 15-di 15-dr 15-ed(2.31A)

END T14

T15

Dell:

Dell Latitude E6410, Dell Inspiron Series 1150, 1420, 1501, 1520, 1521, 1525, 1720, 1721, 300m, 500m, 510m, 6000, 600m, 630m, 6400, 640m, 700m, 710m, 8500, 8600, 9200, 9300, 9400, E1405, E1505, E1705 Dell Latitude Series 100L, X1, X300, XT Tablet PC, E5400, E6400 Dell Latitude D Series D400, D410, D420, D500, D505, D510, D520, D530, D531, D600, D610, D620, D630, D630c, D800, D810, D820, D830 Dell Latitude M Series M2300, M4300, M60, M65 Mobile Workstation, M70 Dell Precision Workstation Series M20, M60, M70 Dell Vostro Series 1000, 1310, 1400, 1500, 1510 Dell XPS Series XPS M1210, XPS M1330, XPS M140, XPS M1530, XPS M1730, XPS 1530, XPS 1710 Dell Studio Series Studio 1735, Studio 1737, Studio 1500, Studio 1700, Studio 17, Studio 15 1450, NS110

Dell Rugged 5404 Rugged 5414 Latitude 12 Rugged Extreme 7204 7214 Latitude 14 Rugged Extreme 7404 Latitude 3150 3160 3180 3189 3300 3330 3340 3350 3380 3440 3460 3470 3480 3488 3540 3550 3560 3570 3580 3588 Latitude 5280 5288 5290 5450 5480 5488 5490 5495 5580 590 Latitude 7 280 7290 7380 7414 7480 7490 Latitude E4200 E4300 E4310 Latitude E5250 E5270 E5400 E5410 E5420 E5430 E5440 E5470 E5500 E5510 E5520 E5530 E5540 E550 E5570 Latitude E6220 E6230 E6320 E6330 E6400 E6410 E6420 E6430 30U ATG E6430s E6440 E6500 E6510 E6520 E6530 E6540 E7240 Latitude Ultrabook E7250 E7270 E7440 E7450 E7470

Dell Vostro 242, Vostro 2520, Vostro 2521, Vostro 3450, Vostro 3460, Vostro 3550

Chromebook 3120 Chromebook 11 3180 3189 2-in-1 Inspiron 14 3000 (3437) 14R (5437) Inspiron 15 7000 (7537) (7548) 15R (5537) Inspiron 17 (3737) 7R (57) 37) Vostro 2100 2110 2120 3360 5404 5414 7214 7390 7414

END T15

T17

Asus / Acer:

ASUS.ACER

Acer Aspire Series:

1410 1640 1640Z 1650 1650Z 1680 1690 1690-II

2020 2420 2920

3000 3030 3050 3100 3200 3500 3510 3610 3620 3630 3650 3660 3670 3680

4220 4310 4320 4520 4710 4710Z 4720 4920

5000 5030 5050 5100 5310 5315 5500 5500Z 5510 5520 5570 5570Z 5580 5710 5710Z 5715Z 5720
5920G

7100 9400

Acer Ferrari Series: 1000 1100

Acer TravelMate Series:

C200 C210 380

2300 2310 2350 2400 2410 2420 2450 2460 2470 2480

3000 3010 3020 3030 3040 3200 3210 3220 3230 3250 3260 3270 3300

4000 4010 4020 4050 4060 4070 4080 4100 4100-II 4150 4220 4310 4320 4500 4520 4600 4600-II 4650
4720

5100 5210 5220 5310 5320 5510 5520 5600 5710 5720

6000 6231 6291 6292 6492 6592

7320 7720

8000 8100 8100A

END T17

T19

Lenovo / IBM:

LENOVO ULTRABOOK:

Lenovo IdeaPad Lenovo Laptop Charger

IdeaPad B5400, IdeaPad Flex 10, IdeaPad Flex 2 14, IdeaPad Flex 2 15, IdeaPad Flex 2 Pro. IdeaPad G700, IdeaPad G710, IdeaPad U330, IdeaPad U430, IdeaPad U430p, IdeaPad U530, IdeaPad Y50, IdeaPad Y70, IdeaPad Yoga 11, IdeaPad Yoga 11S, IdeaPad Yoga 13, IdeaPad Yoga 2 Pro 13 Lenovo Laptop Charger

Lenovo ThinkPad Lenovo Laptop Charger

ThinkPad 240, Edge E431, Edge E531, Edge E540, Edge E555, Helix Series, L440, L540, S431, ThinkPad S440, ThinkPad S531, ThinkPad S540, ThinkPad T431, ThinkPad T431s, ThinkPad T440, ThinkPad T440p, ThinkPad T440s, ThinkPad T540p, ThinkPad W540, ThinkPad X1 Carbon Series, ThinkPad X240, ThinkPad X240s, ThinkPad Yoga 11E, ThinkPad Z50-70 Lenovo Laptop Charger

Lenovo Yoga Lenovo Laptop Charger

Yoga 2 11, Yoga 2 Pro, Yoga 3 Pro

Lenovo Thinkpad(Yellow Tip(11x5mm))

9000P, 9000K, Y9000K, Y9000X, R9000K, R7000P, Y7000P

END T19

T21

Asus:

Zenbook UX51V BX51V U500V R510J X550 U38

UX501J4720 G501JW UX501VW PA-1121-18 G60VW YX570U

ASUS PRO ExpertBook P2451 P2451FA P2451FA-EB0476 P2451FA-XS51 P2451FA-XS74 P2451F P2451FB
P2540 P2540F P2540FA P2540FB P2540N P2540NV P2540NV-YH21 P2540U P2540UA P2540UA-AB51
P2540UA-XS51 P2540UA-XS71 P2540UB P2540UB-XB51 P2540UB-XB71 P2540UV ASUS PRO
ExpertBook P5 P5440FA P5440FA-BM0161R P5440FA-BM0164R P5440FA-BM0184R P5440FA-
BM0355R P5440FA-BM0584R P5440FA-BM0715 P5440FA-BM0788R P5440FA-BM1094R P5440FA-
BM1312 P5440FA-XS51 P5440FA-XS74 P5440FF P5440FF-BM0002R p5440ff-bm0141r

ASUS PRO P45V P55V P500 P751JA P751JF P1440F P1440FA P1440FB P1440U P1440UA P1440UF
P2420LA P2440U P2440UQ-XS71 P2520 P2520L P2520LA P2520LA-XB31 P2520LA-XH31 P2520LA-XH52
P2520LJ P2530UA P2530UJ P2710 P2710JA P3540F P3540FA P3540FB P5240FA P5240FF P5240U
P5240UA P5240UF P5340FA P5340FF P5340U P5340UA P5340UF P5430UA P5430UF PU301L PU301LA
PU401 PU401LA PU500C PU500CA PU500CA-XO002X PU500CA-XO003H PU500CA-XO016P PU550
PU550CA PU551LA PU551LA-XO126G PU551LD

Asus ZenBook ZenBook Pro UX501 UX501J UX501V Rog G501 G501J G501V G501JW N501JW N501JW-
1A N501JW-1B N501JW-2A N501JW-2B N501VW N501VW-1A N501VW-2A N501VW-2B N501VW-3A
PU551JH Pro Essential PU551JH-1A ROG G501VW SIMPRO DOCK DOCK-1A ULTRA DOCKING STATION-
1A ZenBook Pro UX501JW UX501LW UX501VW

END T21

T23

HP:

1000, 1001TU, 1002TU, 1003TU, 1004TU, 1005TU, 1007TU, 1008TU, 1009TU, 1010LA, 1010NR, 1011TU, 1012TU, 1013TU, 1014TU, 1015TU, 1016TU, 1017TU, 1018TU, 1019TU, 1020LA, 1020TU, 1030NR, 1033CL, 1035NR, 1050LA, 1090LA, 1097EI, 1098EI, 1099ED, 1099EE, 1099EF, 1099EG, 1099EI, 1099EL, 1099EM, 1099EN, 1099EP, 1099ER, 1099ES, 1099ET, 1099EW, 110, 110-1011TU, 110-1012NR, 110-1016TU, 110-1017TU, 110-1020NR, 110-1021TU, 110-1025DX, 110-1025TU, HP Compaq 110-1030NR, 110-1031NR, 110-1033CL, 110-1034NR, 110-1037CA, 110-1037NR, 110-1042TU, 110-1045DX, 110-1047TU, 110-1049TU, 110-1051TU, 110-1052TU, 110-1057TU, 110-1058TU, 110-1071TU, 110-1072TU, 110-1079TU, 110-1081TU, 110-1132TU, 110-1133TU, 1100, 1101TU, 1102TU, 1105TU, 1106TU, 1107TU, 1108TU, 1109TU, 110c, 110c-1010EB, 110c-1010EC, 110c-1010ER, 110c-1010ES, 110c-1010ET, 110c-1010SB, 110c-1010SD, 110c-1011EO, 110c-1011SO, 110c-1020EI, 110c-1020EJ, 110c-1020EO, 110c-1020ST, 110c-1025ES, 110c-1030ER, 110c-1030EV, 110c-1030S, 110c-1040DX, 110c-1040EC, 110c-1050EF, 110c-1050EJ, 110c-1110EJ, 110c-1110EQ, 110c-1110SA, 110c-1120SS, 110c-1130SF, 1110TU, 1111TU, 1112TU, 1113TU, 1114TU, 1115NR, 1116TU, 1117TU, 1118TU, 1119TU, 1120BR, 1122TU, 1123TU, 1124TU, 1125NR, 1125TU, 1126TU, 1127TU, 1128TU, 1133CA, 1135CA, 1141NR, 1150LA, 1150NR, 1151NR, 1152NR, 1160CM, 1180CM, 1190BR, 1198EO, 1199EB, 1199EC, 1199EE, 1199EH, 700, 700EA, 700ED, 700EE, 700EF, 700EI, 700EK, 700EL, 700EN, 700EP, 700ER, 700ES, 700ET, 700EW, 701ED, 701EG, 701EI, 701EM, 701EN, 701ER, 701ES, 701ET, 702EA, 702EG, 703EA, 705EI, 705EL, 705ES, 730EB, 730EE, 730EJ, 730EO, 730EQ, 731EH, 735EF, 735EJ, 735EO, 735EQ, 735ES, Compaq Mini 110c Series, Compaq Mini 700 Series, HP Mini 1000 Series, HP Mini 110 Series, HP Mini 1100 Series
for HP mini 1030 1033 1035NR series
for HP 1010NR series
for HP notebook 1137NR
for HP Mini 1000 PC Series 1000, FN819AV, FQ729AAR, FQ729AV, FR832AV, FT313UAR, FT313UA, FT315UAR, FT315UA, FW376UAR, FW376UA, FY348LA, FZ978UAR, FZ978UA, NB914AV, NC953AS, NC954AS, NE570PA, NE571PA, NE572PA, NE573PA, NE574PA, NE575PA, NE576PA, NE577PA, NE578PA, NE579PA, NE580PA, NE581PA, NE582PA, NE585PA, NE590PA, NE594PA, NG837LA, NJ209LA, NQ332LA for HP Mini 1000 Vivienne Tam Edition PC Series NG624EA, NG625EA, NG626EA, NG627EA, NG628EA, NG630EA, NG631EA, NG632EA, NG633EA, NG634EA, NG640EA, NG641EA, NG644EA, NG646EA, NL037PA for HP Mini 110-1000 Series Mini 110-1001TU, Mini 110-1006TU, Mini 110-1007TU, Mini 110-1008TU, Mini 110-1011TU, Mini 110-1012NR, Mini 110-1013TU, Mini 110-1014TU, Mini 110-1015LA, Mini 110-1016TU, Mini 110-1017TU, Mini 110-1019TU, Mini 110-1020LA, Mini 110-1020NR, Mini 110-1025DX, Mini 110-1025TU, Mini 110-1027TU, Mini 110-1030CA, Mini 110-1030NR, Mini 110-1032TU, Mini 110-1033CL, Mini 110-1034TU, Mini 110-1035TU, Mini 110-1045DX, Mini 110-1050LA, Mini 110-1050NR Compaq Mini 110c-1000 Series Mini 110c-1001NR, Mini 110c-1010EA, Mini 110c-1010EE, Mini 110c-1010ES, Mini 110c-1010ET,

Mini 110c-1010SA, Mini 110c-1010SB, Mini 110c-1010SH, Mini 110c-1010SP, Mini 110c-1011SA, Mini 110c-1020EI,

Mini 110c-1030EK, Mini 110c-1030EQ, Mini 110c-1050EFLenovo

B50-10

Lenovo IdeaPad

100 14 80MH0025MT N2840, 100 14", 100 15", 100 80MH N2940, 100 80MH N3540, 100-14 80MH000YUS, 100-14 80MH0012US, 100-14IBY, 100-14IBY N2840, 100-15IBD, 100-15IBY, 100-15IBY 80MJ N2940, 100-15IBY N2840, 100-15IBY N3540, 80MH0008MJ, 80MH0054MJ, 80MJ Series, 80MJ0015CF, 80MJ0016CF, 80MJ0017US, 80MJ0018US, 80MJ001AUS, 80MJ001BUS, 80MJ001CGE, 80MJ001DGE, 80MJ001EGE, 80MJ00AEUS, Ideapad 80MH Series 14"

END T23