



## CamLine Pro firmware update

Firmware

Update

# Cam Line Pro firmware update

## Table of contents

1.0 Update Firmware .....	2
1.1 Download the firmware. ....	2
1.2 Firmware Update using your PC .....	2
2.0 How to access the camera again after the update using the APP: .....	3
2.1 How to change the default password using the APP: .....	3
3.0 Release notes: .....	4
4.0 Frequently Asked Questions and other related information .....	4
5.0 Service and support.....	4
6.0 Warning and points of attention .....	5
7.0 Warranty conditions.....	6

## 1.0 Update Firmware

This installation manual guides you through the installation process of the CamLine Pro camera firmware. Use the following steps to correctly install the firmware.

### 1.1 Download the firmware.

1. Go to our website [www.eminent-online.com](http://www.eminent-online.com)
2. Select the search field and enter the model number of your Eminent CamLine Pro camera example: EM6350.
3. Click **"Drivers/Software"**.
4. Download the firmware from the support section.
5. Extract the downloaded file.

### 1.2 Firmware Update using your PC

*Before you start updating the Firmware, please make sure the camera is connected to your network via an Ethernet cable. This to prevent possible interruption in your WiFi network. Make sure the CamLine Pro software is installed on your PC. If not please download and install it from the website.*



*Please note: After updating the firmware the settings of the camera will be reset to the factory default settings incl. the WiFi settings, and the password of the camera is changed to "ipcam" instead of the password mentioned on the ID card or bottom label of the IP camera.*

Login to the web interface (Browser).

1. Double click the 'CamLine Pro' shortcut placed on your desktop.  
(This program has to be installed on your desktop for more information please check the full manual).

2. From the software interface click “+”.
3. Click “**LAN search**”.
4. A list of available cameras is being displayed.
5. Doubleclick the camera you wish to update.
6. Your web browser will be opened and you will be prompted to enter the credentials of the camera.
7. Use by default the username “admin” and as password check the ID/Password card (in case of a restore to factory defaults the default password is “ipcam”).
8. Click “**Sign in**” from the option “For IE, Firefox, Google, Safari Browser”.
9. Press the button “**Options**”.
10. Click “**System Settings**”.
11. Click “**System Maintenance**”.
12. From the option “**System Upgrade**” Click “**Browse**”.
13. Now browse to the folder containing the downloaded firmware file .pkg and click “**Open**”.
14. Click “**OK**” a status bar will appear to indicate the progress of the firmware update.
15. When the update is successful the CamLine Pro IP camera will automatically reboot.





*Please note: Do not power off the camera during the upgrade procedure. The firmware update process can take up to 10 minutes.*





*Please note: After updating the firmware the settings of the camera will be reset to the factory default settings incl. the WiFi settings, and the password of the camera is changed to “ipcam” instead of the password mentioned on the ID card or bottom label of the IP camera.*

## 2.0 How to access the camera again after the update using the APP:

- Open the CamLine Pro APP.
- Press “” in the camera window you’ve just updated.
- Press “”.
- Change the password to: ipcam.
- Press the “back” arrow.

## 2.1 How to change the default password using the APP:

- Open the CamLine Pro APP.
- Press “” in the camera window you’ve just updated.

- Press .
- Select **“Advanced settings”**.
- Select **“Camera password”**.
- First enter the old password.
- Change the password to the password you wish to use for the camera and confirm the password in the fields **“New”** and **“Confirm”**.
- Press **“OK”**.



*Please note: Repeat the steps “2.0 How to access the camera again after the update using the APP:” for the new password.*

## 3.0 Release notes:

**Version V10.4.10.2.1-20170221**

### **Improvements:**

- Time server has been changed from time.windows.com to time.nist.gov (time.windows.com is no longer available) this solves the incorrect time.
- The webport has been changed from port 81 to port 443.



*Please note: After updating the firmware you will need to clear your web browsers cache memory to be able to use the new video plug-in in the web browser. The instructions for clearing your cache varies from browser to browser.*

## 4.0 Frequently Asked Questions and other related information

The latest Frequently asked questions for your product can be found on the support page of your product. Eminent will update these pages frequently to assure you have the most recent information. Visit [www.eminent-online.com](http://www.eminent-online.com) for more information about your product.

## 5.0 Service and support

This users manual has been carefully written by Eminent's technical experts. If you have problems installing or using the product, please fill out the support form at the website [www.eminent-online.com/support](http://www.eminent-online.com/support).

You can also contact us by phone. Please check [www.eminent-online.com/support](http://www.eminent-online.com/support) for the helpdesk phone number and opening hours.

## 6.0 Warning and points of attention



Due to laws, directives and regulations set out by the European parliament, some (wireless) devices could be subject to limitations concerning its use in certain European member states. In certain European member states the use of such devices could be prohibited. Contact your (local) government for more information about this limitations.

Always follow up the instructions in the manual\*, especially where it concerns devices which need to be assembled.

Warning: In most cases this concerns an electronic device. Wrong/improper use may lead to (severe) injuries!

Repairing of the device should be done by qualified Eminent staff. The warranty immediately voids when products have undergone self repair and/or by misuse. For extended warranty conditions, please visit our website at [www.eminent-online.com/warranty](http://www.eminent-online.com/warranty).

*\*Tip: Eminent manuals are written with great care. However, due to new technological developments it can happen that a printed manual does not longer contain the most recent information.*

*If you are experiencing any problems with the printed manual or you cannot find what you are looking for, please always check our website [www.eminent-online.com](http://www.eminent-online.com) first for the newest updated manual.*

*Also, you will find frequently asked questions in the FAQ section. It is highly recommended to consult the FAQ section. Very often the answer to your questions will be found here.*

## 7.0 Warranty conditions

The five-year Eminent warranty applies to all Eminent products, unless mentioned otherwise before or during the moment of purchase. After buying a second-hand Eminent product the remaining period of warranty is measured from the moment of purchase by the product's initial owner. Eminent warranty applies to all Eminent products and parts, indissolubly connected or mounted to the product it concerns. Power supply adapters, batteries, antennas and all other products not directly integrated in or connected to the main product or products of which, without reasonable doubt, can be assumed that wear and tear during use will show a different pattern than the main product, are not covered by the Eminent warranty. Products are not covered by the Eminent warranty when exposed to incorrect/improper use, external influences or when opening the service parts of the product by parties other than Eminent. Eminent may use refurbished materials for repair or replacement of your defective product. Eminent cannot be held responsible for changes in network settings by internet providers. We cannot guarantee that the Eminent networking product will keep working when settings are changed by the internet providers. Eminent cannot guarantee the working of web services, apps and other third party content that is available through Eminent products. Eminent products with an internal hard disk have a limited warranty period of two years on the hard disk. Eminent could not be held responsible for any data lost. Please make sure that if the product stores data on a hard drive or other memory source, you will make a copy before you return the product for repair.

### When my product gets defective

Should you encounter a product rendered defective for reasons other than described above: Please contact your point of purchase for taking care of your defective product.



[WWW.EMINENT-ONLINE.COM](http://WWW.EMINENT-ONLINE.COM)

Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.

The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Eminent is a member of the Intronic Group