

EW3961

Product Title from CMS (UK)

en

Manual

EW3961 Product Title from CMS

Table of contents

1.0 Introduction	2
1.1 Packing contents	2
2.0 Using the laptop charger.....	2
2.1 Connecting the laptop charger to your laptop.....	3
2.2 Using the USB port.....	4
3.0 Frequently Asked Questions and other related information	4
4.0 Service and support.....	5
5.0 Warning and points of attention	5
6.0 Warranty conditions.....	6

1.0 Introduction

Congratulations with the purchase of this high-quality Ewent product! This product has undergone extensive testing by Ewent's technical experts. Should you experience any problems with this product, you are covered by a two-year Ewent warranty. Please keep this manual and the receipt in a safe place.

Register your product now on www.ewent-online.com and receive product updates!

1.1 Packing contents

The following parts need to be present in the packing:

- Laptop charger
- Power tips
- Safety instructions

2.0 Using the laptop charger

You only have to connect the power supply, and check whether the voltage corresponds with the voltage of your laptop. Then connect the power connector to your laptop to start charging your laptop.

Calculating the necessary power for your laptop

In case you want to know if the laptop charger can be used with your laptop you can use the following calculation:

If your original laptop charger has an output of 15V 3A, you need a charger which delivers a minimum of 45 Watts (**15V x 3A**).

2.1 Connecting the laptop charger to your laptop

Hint: Before using the charger, check what voltage is needed to charge your laptop. Usually, this can be found on the bottom of your laptop or in the user's manual of your laptop.

1. Take the laptop charger and power connectors out of the packaging.

Connecting the wrong power tip can mean you are using the wrong voltage. This can lead to damaging the laptop or other connected devices!

2. Choose the power tip which fits the power input of your laptop. You can fit the tip to the power input of your laptop first, without connecting this power tip to the laptop charger. Each power connector has its own voltage. Below, you will find a table with the supplied power tips and voltages per brand.

EW3961 :

Type	Output Voltage	Tips Size	Notebook Brand
M1	15V	6,3 x 3,0 x 10,7 mm	Toshiba Satellite (Pro) series, NEC Versa
M3	16V	6,0 x 4,4 x 10,7mm	Panasonic, Sony, Fujitsu
M4	18,5V	4,8 x 1,7 x 10,7 mm	Compaq, HP, LG
M5	19V	5,5 x 2,5 x 10,7 mm	HP, Compaq, Acer, Toshiba, Fujitsu, Gateway IBM, Dell, NEC, Delta, LiteOn, Asus, Lenovo
M6	19V	5,0 x 3,0 x 10,7 mm	Samsung
M7	19V	5,5 x 2,1 x 10,7 mm	Acer Travelmate series, Delta, HP, Gateway, Toshiba, LiteOn
M8	19,5V	6,0 x 4,4 x 10,7 mm	Sony PCG GRS Series, Fijitsu
M9	19,5V	7,4 x 5,0 x 12,5 mm	Dell
M12	18,5V	7,4 x 5,0 x 12,5 mm	HP, Compaq

Free Tip Service

If your laptop/notebook requires another tip then the tips which are supplied with this product, you can send a request for the right tip to Ewent (please check the tiplist in this manual). We cannot guarantee that we have the requested tip at all time. When available, our support desk will send the tip to you for free.

*You can send your request for the tip to us by using the supportform on our website:
<http://www.ewent-online.com>*

3. Once you know for sure which power tip fits your laptop, disconnect the power connector from the laptop.
4. The voltage needs to correspond with the voltage needed for your laptop. If it does not correspond with the voltage needed for your laptop, do not connect it to your laptop.
5. Connect the power tip to your laptop.
6. Connect the power cable to the laptop charger. Connect the other side of the power cable to a cigarette lighter outlet. The laptop charger will now start charging your laptop.

2.2 Using the USB port

The USB connector supplies 10W (5 Volt @ 2 Amperes) and can be used to charge USB devices such as mobile phones, MP3 players and even the latest generation of tablet computers.

1. Connect the USB device you want to charge to the USB port of the charger using a USB cable.
2. Connect the charger to a cigarette lighter outlet.
3. The charger will now start to charge the connected USB device.

3.0 Frequently Asked Questions and other related information

The latest Frequently asked questions for your product can be found on the support page of your product. Ewent will update these pages frequently to assure you have the most recent information. Visit www.ewent-online.com for more information about your product.

4.0 Service and support

This user's manual has been carefully written by Ewent's technical experts. If you have problems installing or using the product, please fill out the support form at the website www.ewent-online.com/

You can also contact us by phone. Please check www.ewent-online.com/ for the helpdesk phone number and opening hours.

5.0 Warning and points of attention



Due to laws, directives and regulations set out by the European parliament, some (wireless) devices could be subject to limitations concerning its use in certain European member states. In certain European member states the use of such devices could be prohibited. Contact your (local) government for more information about this limitations.

Always follow up the instructions in the manual*, especially where it concerns devices which need to be assembled.

Warning: In most cases this concerns an electronic device. Wrong/improper use may lead to (severe) injuries!

Repairing of the device should be done by qualified Ewent staff. The warranty immediately voids when products have undergone self repair and/or by misuse. For extended warranty conditions, please visit our website at www.ewent-online.com.

**Tip: Ewent manuals are written with great care. However, due to new technological developments it can happen that a printed manual does not longer contain the most recent information.*

If you are experiencing any problems with the printed manual or you cannot find what you are looking for, please always check our website www.ewent-online.com first for the newest updated manual.

Also, you will find frequently asked questions in the FAQ section. It is highly recommended to consult the FAQ section. Very often the answer to your questions will be found here.

6.0 Warranty conditions

The two-year Ewent warranty applies to all Ewent products, unless mentioned otherwise before or during the moment of purchase. After buying a second-hand Ewent product the remaining period of warranty is measured from the moment of purchase by the product's initial owner. Ewent warranty applies to all Ewent products and parts, indissolubly connected or mounted to the product it concerns. Power supply adapters, batteries, antennas and all other products not directly integrated in or connected to the main product or products of which, without reasonable doubt, can be assumed that wear and tear during use will show a different pattern than the main product, are not covered by the Ewent warranty. Products are not covered by the Ewent warranty when exposed to incorrect/improper use, external influences or when opening the service parts of the product by parties other than Ewent. Ewent may use refurbished materials for repair or replacement of your defective product. Ewent cannot be held responsible for changes in network settings by internet providers. We cannot guarantee that the Ewent networking product will keep working when settings are changed by the internet providers. Ewent cannot guarantee the working of web services, apps and other third party content that is available through Ewent products. Ewent products with an internal hard disk have a limited warranty period of two years on the hard disk. Ewent could not be held responsible for any data lost. Please make sure that if the product stores data on a hard drive or other memory source, you will make a copy before you return the product for repair.

When my product gets defective

Should you encounter a product rendered defective for reasons other than described above: Please contact your point of purchase for taking care of your defective product.

e'went
by eminent

www.ewent-online.com

Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders. The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.

Ewent is a member of the Eminent Group

