



EM6275
Easy Pro View HD Pan/Tilt IP Camera

en

Manual

EM6275 – Easy pro view HD Pan/Tilt IP camera

Table of contents

1.0 Introduction	4
1.1 Packaging contents	4
1.2 Requirements to access the camera.....	5
1.3 Major hardware components.	5
2.0 Installing the camera	7
2.1 Connecting the camera to your network using a network cable.....	7
2.2 Which App should I install?.....	8
2.3 Installing the Easy Pro View App on an Android device	8
2.4 Installing the Easy Pro View App on an Apple device	9
2.5 Installing the software and camera on a PC or notebook (Windows).....	11
2.6 Installing the software and camera on a MAC.....	12
2.7 Adding the camera to a wireless network.....	16
2.7.1 Connecting to Wi-Fi using the WiFi QR code scanner.....	16
2.7.2 Connecting to Wi-Fi using the WPS button.	17
2.7.3 Connecting to Wi-Fi using the App.....	18
2.7.4 Connecting to Wi-Fi using the PC (windows).	18
2.7.5 Connecting to Wi-Fi using the MAC.	18
2.8 Micro SD-Card installation	20
2.9 Mounting the camera on the wall or ceiling	20
3.0 Viewing images	21
3.1 On your smartphone/tablet (Android, iPhone, iPad)	21
3.2 On your PC (Windows) in a remote location.	21
3.3 Alarm-notification recording (micro SD-Card).....	21
3.4 Via the Internet using the web portal.....	21
4.0 Easy Pro View for iPhone/iPad/Android.....	22
4.1 The Layout of Easy Pro View.....	22
4.2 See the live video	23
4.3 Pan/Tilt control	25
4.4 Delete camera	29
4.5 Camera adjustment	30
4.6 Alarm notification.....	31
4.7 Stream settings.....	33
4.8 Video settings.....	35
4.8.1 Video	36
4.8.2 Control.....	37
4.8.3 Night mode control	38
4.8.4 Camera info.....	40
4.9 Camera Settings.....	41
4.9.1 Information	42
4.9.2 Network	43
4.9.3 Schedule	48

4.10 Admin	56
4.10.1 Date/time	57
4.10.2 Upgrade	58
4.10.3 Reboot.....	58
4.11 SD-Card Playback	59
4.12 Local Search	61
4.13 Information	63
5.0 The webpage of the camera	64
5.1 Login to the webpage	64
5.2 Information	65
5.3 Network	65
5.3.1 Wired Network	66
5.3.2 Wi-Fi security.....	67
5.3.3 Advanced	69
5.4 Video.....	70
5.4.1 Video Display	70
5.4.2 Video Settings	71
5.4.3 Mobile Video settings.....	73
5.4.4 Night mode Control.....	74
5.5 Schedule	74
5.5.1 E-mail/FTP alarm.....	75
5.5.2 Speaker Alarm.....	77
5.5.3 NAS settings.....	78
5.5.4 SD-Card settings	81
5.5.5 Scheduling.....	82
5.6 Admin	83
5.6.1 Admin login.....	84
5.6.2 LED Display Control	84
5.6.3 Date/Time.....	85
5.6.4 Upgrade	86
5.6.5 Reboot.....	88
5.6.6 Set to factory default.....	89
6.0 Dropbox.....	90
6.1 Configure the camera to record to your Dropbox account	90
6.1.1 Android.....	90
6.1.2 iPod/iPhone	91
6.1.3 iPad.....	91
6.2 Configure the APP to get access to the Dropbox recordings	92
6.2.1 Android.....	92
6.2.2 iPod/iPhone/iPad	92
6.3 Playback of Dropbox recordings	93
6.3.1 Android.....	93
6.3.2 iPod/iPhone/iPad	93
6.4 Changing the recording settings	94
6.4.1 Login to the webpage	94
6.4.2 Video Settings	95

7.0 Frequently Asked Questions and other related information	97
8.0 Service and support.....	97
9.0 Warning and points of attention	97
10.0 Warranty conditions	99

1.0 Introduction


Congratulations with the purchase of this high-quality Eminent product! This product has undergone extensive testing by Eminent's technical experts. Should you experience any problems with this product, you are covered by a five-year Eminent warranty. Please keep this manual and the receipt in a safe place.

Register your product now on www.eminent-online.com and receive product updates!

1.1 Packaging contents

The following parts need to be present in the packing:

- EM6275 Easy pro view HD Pan/Tilt IP camera
- Power supply
- Quick install guide
- Network cable
- Mounting bracket
- Screws and plugs
- CD-ROM with software and wizard
- ID/Password card




1.2 Requirements to access the camera.

It is very easy to access the video images of the EM6275 on your smartphone, tablet or PC. You only need the ID and password that is written on your ID/Password card and download the application for your device. You do not need to remember or setup the configuration of your modem/router to be able to access the camera.


1.3 Major hardware components.

The components on the front of the EM6275 are:




- Microphone – for receiving the audio/voice. Effective distance is about 5 meters.
- Light detector – for light intensity detection to be able to switch automatically between Day and Night
- Lens – the lens is inside the camera body and the focus of the lens is fixed, you do not need to spend time to adjust the focus, the effective focus range is from 30cm to infinity. There are two lens for day and night usage separately.
- IR LED – for the Infra-Red lighting of the night mode usage.
- WPS button – this is to automatically synchronize the Wi-Fi settings with a WPS capable Wi-Fi router.
- Reset button – this is the button to reset the EM6275 to default factory settings. You need to use a small stick like pencil or tooth stick to press the reset button for more than 3 seconds to enable the reset function. Usually when you forgot the administrator account, you will probably need to do this reset action to reset to the default factory settings. Please refer to section 5.6.6 for more details.
- Internal Speaker – for two way audio and speaker alarm usage.

The components on the top of the EM6275 are:




- Micro-SD card indication LED(yellow) – this LED is to indicate the status of the Micro-SD card recording, it will be on when the Micro-SD card is inserted and will blink during recording.
- Ethernet indication LED (blue) – this LED is to indicate if the Ethernet link is ok and packet traffic is sending/receiving. When the Ethernet cable is connected, the LED is on. When there is packet sending/receiving, the LED is blinking blue light.
- Status indication LED (red) – this LED is to indicate the Internet connection status. When the Internet connection is connected, the LED will be constant red light. If there is any Internet connection problem, the LED will be blinking red light.
- Micro-SD card slot – for inserting the Micro-SD Card. (support up to 32G bytes)

The components on the back of the EM6275 are:



- Power jack – this is the place to plug in the power adapter. The power needed for this EM6275 is 12V/1.0A or 5V/1A, please make sure you are using the correct power adapter.
- Ethernet jack – this is the place to plug in the RJ45 Ethernet cable. When the Ethernet link is ok, the Ethernet indication LED on the front side will be blue light.

The components on the bottom of the EM6275 are:



- Bracket screw hole – this is the position to screw in a universal mounting bracket (not included) for cameras.
- Bracket slots – This is used to mount the device to the wall or ceiling using the enclosed mounting bracket.


2.0 Installing the camera

A few short and simple steps are necessary to connect and assign the camera, and to enjoy the use of the camera. Use the following steps to connect the camera.

2.1 *Connecting the camera to your network using a network cable*

We advise to connect the camera first with a network cable. Once the camera works correctly, you can use your wireless network.

1. Connect the camera to a power outlet using the supplied power adapter.
2. Connect the camera to your router or switch using the supplied network cable.



2.2 Which App should I install?

Choose the right App for your preferences/device

Feature	Description	Easy Pro View	Easy Pro View HD	Easy Pro View
Platform	Support device	iPhone/iPod	iPad only	Android
CAMID/Password	ID/Password Access	YES	YES	YES
Remote Live viewing	Remote Live video viewing	YES	YES	YES
Video Recording & Playback	Video record and playback on device	YES	YES	YES
PUSH Notification	Motion/Audio alert directly to smartphone	YES	YES	YES
Remote SD card Video Playback	Retrieve video data from SD card remotely	YES	YES	YES
Advance Video setting	Wi-Fi Scan, test and other advanced settings	YES	YES	YES
Local device Auto-search	Local device scan and auto-search	YES	YES	YES
Motion Detection Push Alert	Push notification on motion detection	YES	YES	YES
Audio Detection Push Alert	Audio notification on motion detection	YES	YES	YES
Cost	Retail Price at App Store	FREE	FREE	FREE

For this manual we use Easy Pro View on iPod/iPhone.


2.3 Installing the Easy Pro View App on an Android device

Before you can view the video of the camera, you need to download and install the app “Easy Pro View” from the “Play Store”.



If you already have installed the APP, please make sure you have installed the latest version of the APP.

1. Download and install the app “Easy Pro View” from the “Play Store”.
2. Open Easy Pro View.
3. Select the “+” button to add the camera to the App.
4. A new window opens to enter the data of the camera.
5. Enter the following fields:
 Camera name: Enter a description of the camera (example: front door)
 CamID: Enter the ID provided on the ID/Password card.
 Password: Enter the 4 digit password provided on the ID/Password card.
 Optional: Enable Dynamic icon update to get an update of the camera icon every time you have connected to the camera.
 Enable the option “Save admin password” to save the admin password.
6. Select “**OK**” to add the camera.




2.4 Installing the Easy Pro View App on an Apple device

Before you can view the video of the camera, you need to download and install the app “Easy Pro View” from the “App Store”.



If you already have installed the APP, please make sure you have installed the latest version of the APP.

1. Download and install the app “Easy Pro View” from the “App Store”.
2. Open Easy Pro View.
3. Select the “+” button to add the camera to the App.
4. A new window opens to enter the data of the camera.
5. Enter the following fields:
 - Camera name: Enter a description of the camera (example: front door)
 - CamID: Enter the ID provided on the ID/Password card.
 - Password: Enter the 4 digit password provided on the ID/Password card.
 - Optional: Enable Dynamic icon update to get an update of the camera icon every time you have connected to the camera.
 - Enable the option “Save admin password” to save the admin password.
6. Select “**DONE**” to add the camera.



Switch ON/OFF for
dynamic icon update

Switch ON/OFF to save
admin password


Click to select trigger
source for alarm
notification (section 4.6)


**For iPad download and install Easy Pro View HD this adds the possibility to view more IP-Cams in one screen and the screen is adjusted to use in landscape mode.*

2.5 Installing the software and camera on a PC or notebook (Windows).

Before you can view the video of the camera, you need to install the software "Easy Pro View" from the CD-ROM.

1. Insert the CD in the CD-ROM.
2. If auto-run is enabled the Wizard should start.
3. Run the wizard to install the application Easy Pro View/Play.
4. There are 2 applications installed on the PC: Easy Pro View and Easy Pro Play.
5. Open Easy Pro View. (If prompted with a screen about the firewall click always allow).
6. If the computer and the EM6275 is connected to the same network, The CAM ID will be displayed in the **"Auto Search"** list. You can double click the **"Auto Search"** to search all the connected IP CAMs any time. The only thing left right now for seeing the video is to double click the CAM ID item in the "Auto Search" list. A window asking for password input will pop up. Please enter the password displayed on your ID/Password card into this field and click **"OK"**. The video will then be displayed on the window.
7. If the EM6275 is not in the same network as the computer you can add the EM6275 by right clicking the mouse button on **"Camera List"** and select **"new Camera"**.





8. Camera name: Enter a description of the camera (example: front door)
9. CamID: Enter the ID provided on the ID/Password card.
10. Password: Enter the 4 digit password provided on the ID/Password card.



11. Select "OK" to add the camera.



With the toolbar you can select how and the amount of video feeds you would like to view on your monitor from 1 to 36 screens.


2.6 Installing the software and camera on a MAC.


Before you can view the video of the camera, you need to install the software "Easy Pro View" from the CD-ROM.

1. Insert the installation CD-ROM in the CD- or DVD-ROM drive, or download the driver from our website.
2. Open Finder.
3. Go to the CD-ROM.
4. Open the folder 'software/MAC'.
5. Launch the .dmg file.
6. the following "DISK IMAGE" virtual disk will be appeared on the Desktop of your Mac OSX system. (This "DISK IMAGE" virtual disk will be auto-removed after rebooting Mac OSX system.)




7. Drag and drop the EasyProView.app icon to the **“Applications”** folder.
8. The application is now successfully installed on your MAC
9. Open Easy Pro View.





10. If the computer and the EM6275 is connected to the same network, use the search  button to find the camera in your local network. The CAM ID will be

displayed in the list.




11. Click the corresponding CAM ID you wish to add. The only thing left right now for seeing the video is to enter the password displayed on your ID/Password card into the password field and click **“OK”**.




12. Now if you click the  button you will be able to drag and drop the desired CAM

ID into a empty window to view the video stream on your MAC.




13. If the EM6275 is not in the same network as the computer you can add the EM6275 by clicking the  button next to the text **"Camera List"**.



14. Now click **"New camera"**.

15. Name: Enter a description of the camera (example: front door)

16. ID: Enter the ID provided on the ID/Password card.
17. Password: Enter the 4 digit password provided on the ID/Password card.



18. Select "OK" to add the camera.



With the toolbar you can select how and the amount of video feeds you would like to view on your monitor from 1 to 6 screens.

2.7 Adding the camera to a wireless network

There are 3 options to connect the EM6275 to your wireless network. First option is to use the WPS button (Modem/router needs to support the WPS option). The second option is to use the software installed on your PC (windows). Third option is to configure the settings by using the App.

2.7.1 Connecting to Wi-Fi using the WiFi QR code scanner

With this new feature you are now able to setup your WiFi fast and simple on the Easy Pro View cameras.



Notice: If you have a Dual-band modem/router please make sure your smartphone/tablet is not connected to a 5Ghz WiFi connection. The Easy Pro View cameras do not support 5Ghz WiFi connections.

- First make sure your Android or Apple Smartphone/Tablet is connected to the same Wireless network as you wish to connect your Easy Pro View camera to.
- Open the APP.
- Select at the bottom the button "WiFi setup".
- You will first get an explanation on your screen how this feature works and what steps need to be taken.
- When you have seen the explanation **and you have removed the network cable from the camera** press the "Next" button.
- You will be prompted to enter the password for your WiFi network enter the correct password for this WiFi network.
- Press "OK".
- There will appear a QR code on the screen of your Smartphone/Tablet.

- Now press the **"WPS"** button on your Easy Pro View camera and check if the Status LEDs are blinking.
- Now lineup the QR-code displayed on the screen of your Smartphone/Tablet facing the camera with a distance between 10~20cm.
- Once the QR code is accepted the status LEDs will light up (the EM6250HD, EM6270 and the EM6275 will also confirm with a beep).
- The camera will now reboot and connect to your WiFi network.
- If the camera ID has not yet been added to the camera list of the APP you will be prompted to add the camera to the camera list (if preferred you can change the camera name in the pop-up screen).

2.7.2 Connecting to Wi-Fi using the WPS button.

1. Disconnect the Ethernet cable from the camera.
2. Press the WPS button on the camera.(1 second)
3. Press the WPS button on your modem/router.(please refer to the manual of the modem router for information about how to start WPS synchronization)
4. The blue LED will start blinking (Camera is synchronizing the wireless encryption settings with your modem/router). The synchronization is ready when the Blue status LED continuously lit.




2.7.3 Connecting to Wi-Fi using the App.


1. Ensure the camera is connected to the network with a Ethernet cable.
2. Start the App "Easy Pro View".
3. Select the "**Camera settings**" menu by pressing the arrow next to the camera you would like to configure.
4. (if prompted Login with username: (default "admin")
Password: (default "leave blank")
5. Select "**Network**"
6. "**Wi-Fi Network**"
7. "**Enable**" Wi-Fi
8. A list of available wireless networks will be displayed.
9. Select the wireless network you want to connect to (if not displayed press "**Refresh**")
10. Enter the wireless encryption key and press "**OK**"
11. Disconnect the Ethernet cable to connect to the wireless network.

2.7.4 Connecting to Wi-Fi using the PC (windows).

1. Ensure the camera is connected to the network with a Ethernet cable.
2. Install the software on the CD-ROM
3. Start "Easy Pro View"
4. Right click on camera ID in the "**Auto search**" list and click "**Web configure**"
5. Login with username: (default "admin")
Password: (default "leave blank")
6. Click "**Network**"
7. Click "**WiFi security**"
8. A control panel will appear for your Wi-Fi settings
9. Select "**Enable WiFi function**" (to activate the WiFi module)
10. Now you can use 2 different ways to configure the camera to connect to the Wi-Fi network; manually or you can use the software to AutoDetect your Wi-Fi network.
11. Click "**WiFi scan**" to search for available wireless networks.
12. Select the Wireless network you want to connect to.
13. Enter the Encryption settings and the WPA-PSK key of the wireless network and click "**Save & Apply**".
14. Disconnect the Ethernet cable to connect to the wireless network.

2.7.5 Connecting to Wi-Fi using the MAC.

1. Ensure the camera is connected to the network with a Ethernet cable.
2. Install the software on the CD-ROM
3. Start "Easy Pro View"
4. Click the  button next to the "**Camera ID**"
5. Click "**Camera settings**"
6. Login with username: (default "admin")
Password: (default "leave blank")
7. Click "**Network**"
8. Click "**WiFi network**"



9. A control panel will appear for your Wi-Fi settings

10. Select the Wi-Fi checkbox **“Enabled”** (to activate the Wi-Fi module)



11. Now you can use 2 different ways to configure the camera to connect to the Wi-Fi network; manually or you can use the software to AutoDetect your Wi-Fi network.

12. Select the Wireless network you want to connect to from the list or select “Other”

to manually configure the Wi-Fi connection.

13. Enter the Encryption settings and the WPA-PSK key of the wireless network and click "**Update**".
14. Disconnect the Ethernet cable to connect to the wireless network.

2.8 Micro SD-Card installation

To be able to automatically record the video stream you will need to install a Micro SD-Card (not included) into the micro SD-Card reader/writer of the EM6275 (max. 32GB micro SD-Card).



2.9 Mounting the camera on the wall or ceiling

1. Once the camera is connected correctly with your computer, you can mount the camera on a wall or ceiling.
2. Mark the holes at the location where you want to mount the camera.
3. Drill the holes and fill the holes with the supplied plugs and screws.
4. Mount the supplied mounting bracket to the wall or ceiling.
5. Mount the camera on to the mounting bracket.
6. Connect the power supply into the wall socket and connect the power tip to the camera.
7. Connect additionally the Ethernet cable into the Router and the camera (not necessary if the camera is connected via Wi-Fi).

3.0 Viewing images

You can view the images both on your computer and on your smartphone screen, as we explain in the sections below.

Optionally, you can install the supplied software so you can find the camera directly with your computer and make recordings with your computer.

3.1 On your smartphone/tablet (Android, iPhone, iPad)

Start the App Easy Pro View (HD)* press the camera-icon of the camera you wish to view. The device will start connecting with the camera and will show live images of the camera.

**Easy Pro View HD is for iPad only this App ads the possibility to view more IP-Cams in one screen and the screen is adjusted to use in landscape mode.*

3.2 On your PC (Windows) in a remote location.


After Easy Pro View software is installed, it's very easy to add a camera item in the "Camera List" folder of the Easy Pro View software, key in the CAM ID and Password (from the ID/Password card). And then double click this camera item. You will then see the Camera video immediately. No further NAT/router setting modifications are needed. The camera can be controlled remotely as well.

3.3 Alarm-notification recording (micro SD-Card)

The EM6275 offers the possibility to record video images and store them on the micro SD-Card when a security sensor (PIR, motion or sound) is triggered. This function needs to be enabled in the settings of the camera. To playback these recordings you need to start the Easy Pro View App. Press and hold the camera-icon of the camera you would like to playback the recordings until a menu is displayed. Select the option "SD card playback". Now you can select the date and time of the recording you wish to playback to start viewing the video images.


3.4 Via the Internet using the web portal


You can view live camera images on internet by logging into the online portal <http://easyproview.eminent-online.com/> enter the CAM ID and password, you do not need to open a port in the router, the camera will be accessible automatically. This feature is only supported by Internet Explorer.




4.0 Easy Pro View for iPhone/iPad/Android

4.1 The Layout of Easy Pro View







4.2 See the live video




1. Select "camera List"
2. Select the camera you wish to view.




4.3 Pan/Tilt control

To move the camera lens (Pan/Tilt) in Android or iOS swipe the screen to the desired direction to move the lens in that direction.



Windows software:

For Windows software use the Pan/Tilt control buttons.




Use of Patrol presets.

The EM6275 has the possibility to save lens positions as a patrol preset. This gives you the possibility to cycle from 1 preset to the next preset you have set (This feature is only available in the Windows software and the WebUI).


- Position the lens to the preset you wish to save.



- Click "Patrol"



- Click "**Set**" on the preset you wish to save
- Click "**Goto**" to test the preset



- If you wish to add the presets to the patrol check the checkboxes of the presets. You can also change the duration of the preset to be displayed and the travel speed between the presets in the same menu.
- Finally click **"Save patrol points"**




- Now when you press the play button the camera lens will cycle between the presets you have set.

WebUI:

For WebUI use the Pan/Tilt control buttons of the WebUI interface.


Use of Patrol presets.

The EM6275 has the possibility to save lens positions as a patrol preset. This gives you the possibility to cycle from 1 preset to the next preset you have set (This feature is only available in the Windows software and the WebUI).






- Position the lens to the preset you wish to save.



- Click “” on the preset you wish to save




- Click “ (65,54) ” to test the preset
- If you wish to add the presets to the patrol check the checkboxes of the presets. You can also change the duration of the preset to be displayed and the travel speed between the presets in the same menu.



- Now when you press the patrol button the Camera lens will cycle between the presets you have set.

4.4 Delete camera




Slide the camera you wish to delete from right to left, the “Delete” button will appear, press the button to delete the camera from the list.


4.5 Camera adjustment



Press to
configure the
camera
settings



Press the blue icon as shown in above picture.
Below menu will appear.




Switch ON/OFF for
dynamic icon update


Switch ON/OFF for saving
admin password

4.6 Alarm notification

Select “**Alarm Notification**”

If prompted enter username and password (By default username “admin” password “empty”).





Select the trigger source and click **"Update"**.


If the alarm is triggered you will receive an alarm notification. As shown in below picture, press "View" to view the live stream including pre-recording buffer (if SD-card is installed).

The temperature feature can only be used with Push Notification it's not possible to use it as alarm trigger for E-mail notification or NAS recording.



4.7 Stream settings


This option allows you to set the bandwidth and quality of the live stream of your mobile connection. In most cases the bandwidth of your mobile phone will be lower in comparison to your home internet connection. In some cases we advise you to change these values. For example your telecom provider charges you for every MB send to your phone (roaming). If you choose a lower resolution and/or frame rate the bandwidth and amount of MB will be lowered.





1. You can adjust the bandwidth from 32Kbps to 2Mbps.
2. You can choose to adjust resolution and frame rate manually or switch to Auto (recommended)

3. Change the resolution (manual)
4. Change frame rate (manual)
5. Enable/disable the microphone.

4.8 Video settings



4.8.1 Video



Video Colour: User can set the video colour: Coloured or black and white.

Brightness: Control the brightness of the camera video from 1(dark) ~ 10(Bright) level.

Sharpness: Control the level of sharpness and clearness of the image.

Low Light Sensitivity: The level of the camera senses the low light condition.

Place: You can choose the camera installation environment in order to make camera automatically adjust for the best image quality.


Preference: You can choose image quality, video motion, better quality or best quality as your preference of the video quality.


Time display on video: Enabling this function will make the camera embed the time information into the picture.

Microphone: Disable or enable the microphone. When you enable the Mic., the user who monitors the image can hear the sounds.

Video Flip: This function is to flip the image for mounting camera upside down.


4.8.2 Control





4.8.3 Night mode control

Configure how the Night mode is controlled.





Night mode by schedule.



Night mode by manual.




4.8.4 Camera info

View camera information.





4.9 Camera Settings






4.9.1 Information

View camera information (different information as described in section 4.8.4)





4.9.2 Network





You can select if the camera will use a Dynamic (DHCP) IP address or a Static IP address (default setting is DHCP).



Switch on to enable Wi-Fi function



Select the Wi-Fi network you wish to connect to. If necessary enter the encryption key of the Wi-Fi network







In some special situations, your network environment only provides PPPoE connection (ADSL service), there is no NAT/router available. You will then need to set the PPPoE settings. For more information see section 5.3.3

4.9.3 Schedule




Email alarm





Switch on to enable E-mail alarm function

Select motion sensitivity and e-mail trigger source



Switch on to enable E-mail sending



Fill in email recipients



Switch off if you want to enter a SMTP server manually.





Speaker alarm




Select speaker alarm trigger and how many alarm loop times. Press Alarm test to test alarm.

SD-Card




Switch ON and select the type of recording always/scheduled

Select circular or stop recording if disk (SD-Card) space is full



Scheduling






Select the trigger source: Email alarm, Speaker alarm, SD-Card record



Select the time period

4.10 Admin

The Admin menu provides the possibility to change System date/time, Upgrade Firmware or reboot device remotely.




4.10.1 Date/time




Select the time zone and press update.
The IP-Camera will reset.

4.10.2 Upgrade

This function is not available please view section 5.6.4




4.10.3 Reboot









4.11 SD-Card Playback



Press to view recorded files from SD-Card



Select the date and time of the recorded video you wish to play




4.12 Local Search



Use this option to scan your internal-network for available Easy Pro View IP camera's.




Select the camera from the list to add it to the camera list.



You need to give a name to the camera and enter the password to complete the installation of the camera.

4.13 Information



5.0 The webpage of the camera

The Eminent camera is also an IP camera with its own webpage. This means you can login to the webpage by using the camera's IP Address. Use the following steps to login to the webpage and change any of the camera settings.

5.1 Login to the webpage

1. Double click the 'Easy Pro View' shortcut placed on your desktop.
(This program has been installed and described in section 2.5).
2. The program will automatically search for your camera in your network. When found, the camera will be displayed in the list.
3. Right mouse button click your camera, click "web configure"




4. Now a browser screen will appear.
5. Fill out the camera's username and password. By default, the username is 'admin' and the password is 'empty'.

In the section below, we assume you logged in using Internet Explorer. The menu will be slightly different when using another browser.

5.2 Information

The first page of the web configuration of the EM6275 is the information page. You can see the model name/firmware version, CAM ID, registration status, network type and current video settings(bandwidth, resolution) in this page.

The EM6275 can be viewed remotely by the Easy Pro View software or App only when the EM6275 is registered. If the EM6275 is not registered, please check the Ethernet wiring of your network environment. The “Network type” field displays the network connection(wired or wireless) and method(DHCP, PPPoE or static ip) the EM6275 is running. The “Video users” field displays the number of connected video viewing users. (maximal amount of users connected simultaneously is 20 users).



5.3 Network

The Network menu allows you to configure the network settings of the EM6275 such as IP address, subnet mask, gateway, DNS Server, Wi-Fi, Wi-Fi encryption, and PPPoE

5.3.1 Wired Network

The Wired Network page allows you to modify the network settings of the wired Ethernet. The default settings use DHCP to obtain an IP address automatically. In most of the home and office network environment, there is a DHCP server running. In this situation, by using this default settings, the EM6275 can work immediately in most of the time.

If the Ethernet cable is unplugged, the EM6275 will lose connection. But as soon as the Ethernet cable is plugged in again, the EM6275 will obtain a new IP address immediately.

EMINENT *Easy Pro View*
IP Camera

Network Settings(For wired ethernet)

☒ Obtain an IP address automatically

☐ Use the following IP address

IP address: 192 . 168 . 1 . 123

Subnet mask: 255 . 255 . 255 . 0

Default gateway: 192 . 168 . 1 . 1

☒ Obtain DNS server address automatically

☐ Use the following DNS server address

Preferred DNS server: 168 . 95 . 1 . 1

Alternate DNS server: 168 . 95 . 192 . 1

Save & Apply

language: English

If the network environment does not support DHCP function, you will need to set the network settings of the EM6275 manually. Please fill in all the fields including “IP address”, “Subnet mask”, “Default gateway” and “DNS server” to let the network work. All these settings must correspond with the settings of your network environment, otherwise the EM6275 cannot work.

The default setting is “Obtain an IP address automatically”.

EMINENT *Easy Pro View*
IP Camera

Network Settings(For wired ethernet)

☐ Obtain an IP address automatically

☒ Use the following IP address

IP address: 192 . 168 . 1 . 123

Subnet mask: 255 . 255 . 255 . 0

Default gateway: 192 . 168 . 1 . 1

☐ Obtain DNS server address automatically

☒ Use the following DNS server address

Preferred DNS server: 168 . 95 . 1 . 1

Alternate DNS server: 168 . 95 . 192 . 1

Save & Apply

5.3.2 Wi-Fi security

You can use the wireless connection to connect the EM6275 to the network. If your network environment has a 802.11 b/g/n router or AP running, you can click the “Enable Wi-Fi function” button to enable the wireless connection.

EMINENT *Easy Pro View*
IP Camera

WiFi Security Settings

☒ Enable WiFi function ☐ Disable WiFi function

SSID:

Security mode: ☒ None ☐ WEP ☐ WPA(2)-PSK(WPA personal)

WEP Encryption: 64 bits(10 hex digits)

WEP Key: 234567890

WPA Encryption: TKIP

WPA-PSK Key:

Save & Apply IP address WiFi test WiFi Scan

In order to use the wireless network, you need to fill in the following fields:

1. SSID – this is the ID (name) of the wireless router or AP of your wireless network environment, this must be set correctly.
2. Security mode – this is the security mode used in your wireless router or AP. You need to choose one of the three modes – None, WEP or WPA-PSK.
WEP : Wireless Encryption Protocol.

WPA/WPA2 : Wi-Fi Protected Access.

PSK : Pre-Shared Key.

TKIP : Temporal Key Integrity Protocol.

AES : Advanced Encryption Standard.

3. WEP encryption – when the WEP mode is chosen, you need to choose between 64-bit(5 char), 64-bit(10 hex), 128-bit(13 char) and 128-bit(26 hex) encryption mode, and then fill out the WEP key correctly.
4. WPA encryption - when the WPA-PSK mode is chosen, you need to choose between TKIP and AES encryption mode, and then fill out the WPA-PSK key correctly. WPA2-PSK is also supported. But WPA Enterprise or WPA2 Enterprise is not supported.



All the fields in this page must be filled out correctly, with the same settings as the wireless router or AP are using.

You can click the “Wi-Fi test” button to check if the EM6275 can connect to the wireless network for these settings. You will need to unplug the Ethernet cable to enable the wireless connection after the “Wi-Fi test” is successful.

You can click the “Wi-Fi scan” button to scan for all the available access points nearby. See figure for reference.

If you want to define a fixed IP address when using a Wi-Fi connection, please click the “IP address” button and enter your preferred IP address.


After the settings are updated click “Save & Apply”, The device does not need to reboot to let the Wi-Fi work, To enable the Wi-Fi, unplug the Ethernet cable.



5.3.3 Advanced

In some special situation, your network environment only provides PPPoE connection (ADSL service), there is no NAT/router available. You will then need to set the PPPoE settings in the “Advanced Network” page. Only the PPPoE username and password are needed to let PPPoE work. After the “Save & Apply” button is clicked, the PPPoE function will work immediately. You can check the “Registration status” in the “Information” page to see if the EM6275 is registered using the PPPoE connection.

Please notice that the DHCP or static IP settings in the “Network” page can work together with the PPPoE connection. Only the PPPoE has higher priority, so, if the PPPoE is working, the EM6275 will use PPPoE to connect to the Internet. The default setting is “Disable PPPoE”.



5.4 Video

The Video menu allows you to configure the Video settings of the EM6275 such as Resolution, Frame rate, Day & Night, Flip image, Brightness, Sharpness, Video Colour, Indoor or outdoor image quality, Mobile stream.

5.4.1 Video Display

This page allows you to view the video display and control the Day & Night movement of the camera. For the first time use of this display on a computer, an ActiveX component will be automatically downloaded into the browser (This will only work in Microsoft Internet Explorer, run Internet explorer as administrator). This could take some time, depending on the internet speed. The component is downloaded from a public domain, the computer must be connected to the Internet.

If you want to modify the video display screen size, please refer to section 5.4.2 for more details.



5.4.2 Video Settings

The EM6275 is designed to provide high quality video for viewing from Easy Pro View software. In this page, you can modify some settings related to the video viewing:


1. Password (play video) – this is the password needed for viewing the video from the Easy Pro View software (provided on ID/Password card). Together with the CAM ID, you can view the video of the EM6275 anywhere in the world via the Internet.

Note : *If the EM6275 has been restored to factory defaults the password will change to "ipcam"*

2. Internet speed – this is the Internet bandwidth of your network environment. Higher value will generate higher video quality. But if your Internet connection cannot provide more bandwidth than the specified value, the video quality could degrade. So, please key in a value that is lower than your internet bandwidth.
3. Adjust resolution & frame rate automatically – you can let the system select the suitable video resolution and frame rate automatically for you. The selection is based on the "Internet speed" value. This is the recommended default setting.
4. Resolution – there are five choices : 320x240, 480x360 640x400, 1024x768 and 1280x800 (1280x800 is only available for PC software). If you decide to choose the value manually, you can choose one of the five values. But, please be noticed that if the Internet speed is slow (low value), high resolution(1280x800) or frame rate could cause very bad video quality.
5. Frame rate – the video frame display rate. Higher value means faster movement and continuity in the video display.
6. Favor/Preference – choose between "Video motion", "Image quality", "better quality" and "best quality". When the real bandwidth is not enough for the selected "Internet speed", the system will need to degrade the video motion or image

quality. This selection will decide if the user want to maintain the “video motion” or “image quality” when the internet speed is not good enough.

7. Brightness – the brightness of the video, lower value means darker display.
8. Sharpness – the sharpness of the video, higher value means sharper video.
9. Low light sensitivity – The low light sensitivity could be normal, high or very high. When the low light sensitivity is high, the system could see better video clearance under low light situation, but the moving object will not be very clear under this low light environment. Under very dark environment, set to “very high” will get better video clearance. The default value of this setting is “high”.
10. Video color – choose between “colored” and “black & white”.
11. Video flip – can do “normal” or “flip” video display, this is needed if the EM6275 is installed on the ceiling or wall.
12. Outdoor/Indoor video – for better video display quality, modify this setting when taking indoor or outdoor video. The default setting is “Outdoor video”, in most cases, this is also ok for indoor usage. Under some special cases, there could be some lines on the video display when the EM6275 is taking indoor video. In this situation, change the setting to “Indoor video” will solve the problem. Please also be noticed that in “Indoor video” setting, the video display of outdoor view is very vague. For indoor usage, if there is strong sun light into the room, please select the “indoor+sun light” choice. (Some light sources interfere the video quality to change the frequency of the recordings you need to select indoor video or indoor+sunlight to change the value to 60Hz or 50Hz.
13. Enable/disable audio microphone – you can enable or disable the audio microphone on the EM6275. If disable, there will be no voice on the Easy Pro View video viewing.
14. Enable/disable time display on video – if enabled, the date/time of the system will be displayed on the left-upper corner of the video.
When this modification is saved, it works immediately, but all the connected video viewing users will be disconnected.



EMINENT *Easy Pro View*
IP Camera

Video Settings

IP CAM ID: 003019003

Password(play video): 1234

Internet speed: 1.5Mbps

☒ Adjust resolution & frame rate automatically

☐ Use the following values

Resolution: 640x480(VGA)

Frame rate: 10fps

Favor/Preference: Image Quality

Brightness: 5(medium)

Sharpness: 3

Low light sensitivity: high

Video color: colored

Video Flip: Normal


☐ Outdoor video ☐ Indoor video ☒ Indoor+Sun light

language: English

5.4.3 Mobile Video settings

The EM6275 is able to be viewed from a 3G mobile phone, please download “Easy Pro View”/“Easy Pro View HD” software from App Store for iPhone/iPad and “Easy Pro View” from Android Market for Android Mobiles and pads..

The audio, video frame rate, resolution and bandwidth for 3G mobile access could be set independently from the video settings for LAN access. The maximum allowed resolution is 1024x768 and maximum allowed bandwidth is 2mbps.



EMINENT *Easy Pro View*
IP Camera

Mobile Video Settings

mobile bandwidth: 128Kbps

☒ Select resolution & frame rate automatically

☐ Use the following values

Resolution: 640x480(VGA)

Frame rate: 15fps

☒ Enable audio ☐ Disable audio

Save & Apply

language: English

5.4.4 Night mode Control

The EM6275 is able to work both in day time and night time. There is an IR LED that can let the EM6275 see the objects in the night. This night mode control page is to control when the time the IR LED will be on. There are three ways to control the night mode (IR LED) :

1. Automatic day and night mode switch : the EM6275 will automatically turn on the IR LED when the night time is arrived or the environment is becoming dark. There is a light sensor on the EM6275 that is doing this light detection.
2. Scheduled time of night mode : the EM6275 can also be scheduled to turn on the IR LED in a time range of each day.
3. Manual night mode control : the EM6275 can be manually forced to night mode(IR LED on) or day mode(IR LED off).

In order to get better video colour display during day time and night time, there are two video sensors and two lenses on the EM6275 for day and night separately. This make sure the video colour quality is excellent compared to other IP camera's.

The screenshot displays the 'Night Mode Control' configuration page of the Eminent Easy Pro View IP Camera. The interface features a blue sidebar on the left with navigation links: Information, Network, Video (with sub-links for Display, Video Settings, Mobile Video, and Night Mode), Schedule, and Admin. At the bottom of the sidebar is a language dropdown set to 'English'. The main content area has a title bar with the Eminent logo, a smartphone icon, a cloud icon, and the text 'Easy Pro View IP Camera'. Below the title bar, the 'Night Mode Control' section contains three radio button options: 'Automatic day and night mode switch' (selected), 'Scheduled time of night mode', and 'Manual night mode control'. The 'Scheduled time of night mode' option includes a 'During time' field with a time range of 22:00 to 6:00. The 'Manual night mode control' option includes a 'Mode' dropdown set to 'Day' and a 'Current Status' field showing 'Day'. A 'Save & Apply' button is located at the bottom right of the settings area.

5.5 Schedule

The Schedule menu allows you to configure and manage when and how the alarm notifications are triggered. You can configure the way of notification: Email/FTP, Speaker, Push notification. You can also configure where the video images are recorded: NAS, Micro SD-card, FTP server. Also you can set which sensor triggers what type of alarm or recording.

5.5.1 E-mail/FTP alarm

The EM6275 provides the Email/ftp function, you can enable or schedule the Email/ftp ability in this page, the EM6275 will then send out an email with a jpeg picture attached in the email and/or send out the jpeg picture file to a ftp server. The related settings are explained below:

1. Email/FTP trigger – choose between “motion”, “PIR”, “schedule” and “disable”
 - A. If “motion” is selected, it means that when there is a motion detected, the system will send out the email and/or ftp with the captured video snapshot.
 - B. If “PIR” is selected, it means that when there is a PIR alarm detected, the system will send out the email and/or ftp with the captured video snapshot. If the PIR alarm is constantly on, the EM6275 will keep sending out email/ftp message every second for up to 30 seconds.
 - C. If “schedule” is selected, it means that the email/ftp alarm detection and triggering will be scheduled by the “scheduling” in section 5.5.5.
 - D. “disable” will disable the email/ftp alarm.
2. Motion sensitivity – there are 10 possible choices in this field.
3. “High” means high sensitivity, i.e., the motion detection is triggered by a very small movement in the video image. If “High” is selected and the size of the moving object is larger than about 1% of the whole video area, it is detected. Please be noticed that the real size of the object could be large or small, anyway, the detection is only based on the relative size of the object. Probably a small pencil moving near the EM6275 could be detected, but a moving car far away from the EM6275 could not be detected.
4. “Low” means low sensitivity, i.e., the motion detection is triggered by a very large movement. If the size of the moving object is larger than about 10% of the whole video area, it is detected. “Median” means 3% to trigger the detection.
5. Send email message – if this item is enabled, the EM6275 will send out an email message with the jpeg picture attached to the specified email account.
6. Email recipient#1~#3 – this is the email address to receive the detection notice message. An email message with the jpeg picture file named by the date/time of the triggered moment will reach this address.
7. Send FTP message – if this item is enabled, the EM6275 will send out a jpeg picture file to the specified ftp account.
8. FTP server – this is the FTP server address to receive the jpeg file.
9. FTP username/password – this is the username/password to login into the FTP server, so, this triggered jpeg file will be allowed to reach this FTP server.
10. Remote folder – the jpeg file will be put under this folder of the FTP server.

When this modification is Saved, it works immediately, but all the connected video viewing users will be disconnected.

The default setting is “Disable”.

EMINENT *Easy Pro View*
IP Camera

Information
Network
Video
Schedule
Email/ftp Alarm
 ▶ Speaker Alarm
 ▶ NAS Settings
 ▶ SD-Card
 ▶ Scheduling
Admin

language: English ▼

Email/FTP Alarm Settings

Email/FTP Trigger: ☐ Motion ☒ PIR ☐ Schedule ☐ Disable

Motion sensitivity: 3

Trigger Interval: 10 seconds(1~600)

☒ Send Email message

Email recipient#1: test@eminent-online.com

Email recipient#2:

Email recipient#3:

☒ Send FTP message

FTP Server: ftp.test.com

Username: test

Password:

Remote folder:

Save & Apply Advanced

For the email message to work, a SMTP server is required. Click the “advanced” button will display the SMTP server settings page. A default SMTP server is provided, so that the user does not need to use a specific SMTP server. But, anyway, the user could also specify his own SMTP server.

1. SMTP server – this is the SMTP server that will help to transfer the email message. This server is irrelevant to the “Email recipient” address.
2. SMTP username/password – this is the account to use the SMTP server to transfer the email message. The SMTP server and username/password account are only for transfer the email message to the “Email recipient”, the “Email recipient” could be on another email server or any reachable email address. The username and password fields could be left empty if no authentication is needed for the SMTP server.
3. SMTP server test – after the settings are filled, you could press “SMTP server test” to check if all the settings are correct. If the default SMTP server is chosen, it will test the default SMTP server.


The screenshot shows the 'Easy Pro View IP Camera' web interface. On the left is a blue sidebar with a menu: Information, Network, Video, Schedule, Email/ftp Alarm (highlighted), Speaker Alarm, NAS Settings, SD-Card, Scheduling, Admin, and a language dropdown set to 'English'. The main content area is titled 'SMTP Server Settings' and contains two radio buttons: 'Use the default SMTP server' (selected) and 'Use the user defined SMTP server'. Below these are three input fields: 'SMTP server' (with a 'port 25' label), 'SMTP Username' (with a placeholder '(name@server)'), and 'SMTP Password'. At the bottom are two buttons: 'Save & Apply' and 'SMTP server test'.

Note: Sound sensor is only available in the App.

5.5.2 Speaker Alarm

The EM6275 provides speaker alarm function, a PIR or video motion detection could trigger the speaker alarm. The duration of the alarm could also be set. The related settings are explained below:

1. Speaker alarm trigger— select the trigger mode of the speaker alarm
 - A. Motion trigger – if this is selected, the speaker alarm signal will be active when video motion is detected. The detection sensitivity is set In the “motion detection” page.
 - B. PIR trigger – if this is selected, the speaker alarm will work when the PIR sensor is detected..
 - C. Schedule – if this is selected, the speaker alarm is scheduled according to the settings of scheduling in section 5.5.5.
 - D. Disable—disable the speaker alarm.
2. Alarm loop times – this is the number of the loop times of the speaker alarm.



5.5.3 NAS settings

The EM6275 provides the recording of the video files into a standard NAS (Network Access Storage) device. The EM6275 connects to the NAS device using the standard LMX_NS/CIFS/SSN protocols that are the same as the Microsoft Windows network neighbourhood protocols. This makes the EM6275 easily record the video files to all the standard NAS devices in the market. Since there are a lot of different choices, including prices and scales, users can decide by themselves which is best for their needs. By using this function, the standard NAS device is becoming a NVR (Network Video Recorder) device.

Note : when the EM6275 is doing NAS recording, this is counted as one video user. (max. 20 users can be connected at the same time)


1. If the "Always Recording" is selected, the system will start to record to the NAS storage device immediately and keep recording always. If the "Schedule Recording" is selected, the system will do the NAS recording according to the "scheduling" in section 5.5.5. "Disable Recording" will disable this NAS recording.
2. When doing the NAS recording, the system will check the free disk space of the NAS device. If the free disk space is less than the specified number, the system will do "Circular recording" (overwrite the oldest recorded files of this EM6275 in the NAS device) or "Stop recording" as selected. If the "keep recorded video for xx days" is selected, the system will do circular recording and over write the recorded video files older than xx days ago.
3. The EM6275 can connect to the NAS device by using the "NAS name" or "NAS IP address". If the NAS device and the EM6275 are in the same local area network, the EM6275 can automatically locate and connect to the NAS device by the "NAS

name". If the NAS device uses a fixed IP address(either in the local area network or in the public internet), the EM6275 can connect to it by the "NAS IP address".

4. The "Shared folder name" is the folder in the NAS device that will record the video files of the EM6275.
5. The "NAS access account" and "NAS access password" are the username and password to login into the specified "Shared folder name" of the NAS device.
6. NAS Scan – use this to scan for some specific NAS devices in the same network. Not all the NAS devices are supported for this scan function.
7. NAS Info – display the NAS storage capacity and available disk space.
8. Configure NAS (web) – click this to connect to the web configuration page of the NAS device. Need to key in the login username/password of the NAS device.
9. Access NAS files – on the Microsoft Windows platform, click this to access the files on the NAS devices.

In the Microsoft Windows environment, you can access to the NAS device by keying the URL address "\\NAS name\\"shared folder name" or "\\NAS IP address\\"shared folder name" in the windows Internet Explorer, and then key in the "NAS access account" and "NAS access password" to the prompted login window. The video files are recorded under the subfolder IPCamRecordFiles/Recording/ID-ID, where ID is the ID of the EM6275. All the recorded files are with the name of hhmmss.crf format, where hh is the hour, mm is the minute, ss is the second of the starting time of the recording video. The files are segmented every five minutes. Users can use the free bundled Easy Pro Play software to play back the video files.

EMINENT



Easy Pro View
IP Camera

Information

Network

Video

Schedule

Email/ftp Alarm

Speaker Alarm

NAS Settings

SD-Card

Scheduling

Admin

Language: English

NAS Storage Settings

☐ Always Recording
 ☒ Schedule Recording
 ☐ Disable Recording

☒ Keep recorded video for 7 days (Circular recording)

☐ If free disk less than 0 GB

☐ Circular recording
☐ Stop recording

Use NAS IP address

192 . 168 . 100 . 40

Shared folder name

test

NAS access account

test

NAS access password

test


[Configure NAS\(Web\)](#)
[Access NAS Files](#)

Save & Apply

NAS Scan

NAS Info

EMINENT



Easy Pro View
IP Camera

Information

Network

Video

Schedule

Email/ftp Alarm

Speaker Alarm

NAS Settings

SD-Card

Scheduling

Admin

Language: English

NAS Storage Information

NAS Disk Capacity

1829.3 GB

NAS Disk Used

436.6 GB(23 %)

NAS Disk Free

1392.8 GB(77 %)

NAS Record

Recording Now


OK


5.5.4 SD-Card settings

The EM6275 provides the recording of the video files into a standard Micro SD-Card. Since this recording is directly to the SD-Card, there is no network packets loss problem when recording to remote device through internet.

Note : when the EM6275 is doing SD-Card recording, this is counted as one video user. Please refer to appendix B about allowed maximum video users.

1. If the “Always Recording” is selected, the system will start to record to the SD-Card immediately and keep recording always. If the “Schedule Recording” is selected, the system will do the SD-Card recording according to the “scheduling” in section 5.5.5. “Disable Recording” will disable this SD-Card recording.
2. When doing the SD-Card recording, the system will check the free disk space of the SD-Card. If the disk space is full (no free disk space), the system will do “Circular recording”(overwrite the oldest recorded files in the SD-Card) or “Stop recording” as selected.
3. SD-Card status – the SD-Card inserted or removed status is displayed here.
4. SD-Card files – a list of recorded video files will be displayed that are stored on the micro SD-Card with information including file name and recorded time under the directory of each date. The recorded file could be separately downloaded or deleted on this page.





5.5.5 Scheduling

The EM6275 provides the scheduling function for the motion detection triggered email/ftp sending and/or the NAS recording with the individual parameters set in the . “Email/ftp alarm” settings and the “NAS settings” page. Totally 12 schedule list items are allowed. There is no conflict check for the scheduling, it means that the scheduling time could be overlapped, and the EM6275 will do all the scheduled events during the overlapped time period. For the scheduling of the Email/ftp sending and/or NAS recording, the “Schedule” option must enabled in the “Email/ftp alarm” settings and/or the “NAS settings”.

1. Schedule list – all the scheduling are listed in this area. Each listed item can be modified or deleted by pressing the “Edit” or “Delete” button.
2. Email/ftp Alarm – for each scheduling, if this is selected and the “Motion triggered” and/or “PIR triggered” is enabled, the EM6275 will trigger the email/ftp sending in the scheduled time period when the video motion is detected and/or PIR alarm is detected.
3. Speaker Alarm – for each scheduling, if this is selected and the “Motion triggered” and/or “PIR triggered” is enabled, the EM6275 will trigger the speaker alarm in the scheduled time period when the video motion is detected and/or PIR alarm is detected.
4. NAS Record – for each scheduling, if this is selected, either “Continuous” or “Motion triggered” or “PIR triggered” could be enabled. For “Continuous”, it means that EM6275 will do the video recording to the NAS device during the whole scheduled period. For “Motion triggered” and/or “PIR triggered”, it means that the EM6275 will do the video recording to the NAS device for 30 seconds during the scheduled period each time when the video motion is detected and/or PIR alarm is

detected. There is a five seconds pre-recording (only available when SD-Card is installed) of the triggered recording to keep the critical moment recorded.

5. SD-Card Record – for each scheduling, if this is selected, either “Continuous” or “Motion triggered” or “PIR triggered” could be enabled. For “Continuous”, it means that the EM6275 will do the video recording to the SD-Card during the whole scheduled period. For “Motion triggered” and/or “PIR triggered”, it means that the EM6275 will do the video recording to the SD-Card for 30 seconds during the scheduled period each time when the video motion is detected and/or PIR alarm is detected. There is a five seconds pre-recording (only available when SD-Card is installed) of the triggered recording to keep the critical moment recorded.
6. For the scheduling period, can choose between “Every week”, “Every day” or “Fixed time” :
 - A. For “Every week”, can choose week days of the week and set the time duration of each day.
 - B. For “Every day”, can set the time duration of every day for the scheduling.
 - C. For “Fixed time”, can set the starting date/time and the end date/time of the scheduling period.

The screenshot displays the 'Easy Pro View IP Camera' web interface. On the left is a blue sidebar menu with options: Information, Network, Video, Schedule (selected), Admin, and a language dropdown set to 'English'. The 'Schedule' section is expanded, showing sub-options: Email/ftp Alarm, Speaker Alarm, NAS Settings, SD-Card, and Scheduling (highlighted in blue). The main content area is titled 'Schedule Management' and contains a table of settings:

Schedule Management	
<input type="checkbox"/> Email/ftp Alarm	Email/ftp schedule not enabled
<input type="checkbox"/> Speaker Alarm	Spk alarm schedule not enabled
<input type="checkbox"/> NAS Record	NAS schedule not enabled
<input checked="" type="checkbox"/> SD-Card Record	<input type="radio"/> Continuous <input type="radio"/> Motion triggered <input checked="" type="radio"/> PIR triggered
<input checked="" type="radio"/> Every week <input type="radio"/> Every day	<input type="checkbox"/> Sun <input checked="" type="checkbox"/> Mon <input checked="" type="checkbox"/> Tue <input type="checkbox"/> Wed <input type="checkbox"/> Thu <input type="checkbox"/> Fri <input type="checkbox"/> Sat During time: 00 : 00 ~ 00 : 00
<input type="radio"/> Fixed time	Start time : 2013 / 03 / 12 13 : 00 End time : 2013 / 03 / 12 13 : 30
<input type="button" value="Add Schedule"/>	


5.6 Admin

The Admin menu allows you to configure and maintain the EM6275. Here you can set the Date/Time, LED display status, Admin login, Upgrade the Firmware for the EM6275 and reboot the EM6275.

5.6.1 Admin login

In this page, you can modify the web login account. With this account, you can login to the EM6275 and do any modifications. The default account is “admin” without password. If the login account is forgotten, you can reset the EM6275 to the factory default settings by following the steps in section 5.6.6 and login with the “admin” account.

Please be noticed that this account is different from the video play password in the “Video settings” page.



The screenshot shows the web interface of an Eminent Easy Pro View IP Camera. The top header features the 'EMINENT' logo, a mobile phone icon with a cloud, and the text 'Easy Pro View IP Camera'. A left sidebar contains a menu with options: Information, Network, Video, Schedule, and Admin. The 'Admin' option is expanded, showing sub-options: Admin login (selected), LED Control, Date/Time, Upgrade, and Reboot. Below the menu is a language dropdown set to 'English'. The main content area is titled 'Web Access & Password Settings' and contains a table with the following fields:


Web Access & Password Settings	
Web access port	80
Username	admin
Password	
Password confirm	

At the bottom right of the settings area is a 'Save & Apply' button.

5.6.2 LED Display Control

The EM6275 provides the Led Display Control function, you can enable or disable the led display/indication on the front panel of the EM6275. The related settings are explained below:

1. Normal led display – select this to enable the status led and Ethernet led display.
2. Turn off led display always – select this to disable the status led and Ethernet led display.
3. Turn off led display after network connected – select this then the led will display when the Internet connection has some problem, the led display will be off when the Internet connection is successful.




5.6.3 Date/Time

The EM6275 can synchronize the date/time with the universally available time server (for example time.windows.com) through NTP protocol. The date/time will then be corrected with the time server anytime when the Internet is connected.

Users can choose the different Time Zone of their areas to display the correct time. For some Time Zone areas, the “Daylight Saving Time” could be enabled or disabled. When the “Daylight Saving Time” is enabled, the start and stop time of the Daylight Saving Time could be edited.

The camera has an internal real time clock that can maintain the date/time even when the camera is not connected to internet.



5.6.4 Upgrade

This installation manual guides you to the installation process of the Easy Pro View camera firmware. Use the following steps to correctly install the firmware.

Download the firmware.

1. Go to our website www.eminent-online.com.
2. Select the search field and enter the model number of your Eminent Easy Pro View camera example: EM6275.
3. Select the product.
4. Download the firmware from the support section.
5. Extract the downloaded file.

Firmware Update using your PC

Before you start updating the Firmware please make sure the camera is connected to your network via an Ethernet cable to prevent possible interruption in your WiFi network. Make sure the Easy Pro View software is installed on your PC. If not please install it first from the CD delivered with your camera or download the latest version from the website.



Note: If the extracted download folder contains a “.cfg” and a “.n.f” file. Please make sure both files are upgraded to the camera by repeating step 6 to 11.

Login to the web interface.

1. Double click the ‘Easy Pro View’ shortcut placed on your desktop.
(This program has to be installed on your desktop for more information please check the full manual).
2. The program will automatically search for your camera in your network. When found, the camera will be displayed in the list.
3. Right mouse button click your camera, click **“Web configure”**



4. Now a browser screen will appear.
5. Fill out the camera's username and password. By default, the username is 'admin' and the password is 'please leave this blanc'.

Note: This is **NOT** the Camera ID and Password which is mentioned on the card!

In this section, we assume you logged in using Internet Explorer.
The menu will be slightly different when using another browser.

6. Click in the left menu the button "Admin".

The screenshot shows the Eminent Easy Pro View IP Camera web interface. On the left is a blue sidebar menu with options: Information, Network, Video, Schedule, and Admin. The 'Admin' option is selected. Below the menu is a language dropdown set to 'English'. The main content area has a header with the Eminent logo and 'Easy Pro View IP Camera'. Below the header is a table titled 'IP CAM Information'.

IP CAM Information	
Model	Eminent / v030408 / plus
IP CAM ID	003-019-003
Registration status	Registered(3+uPaP)
Network type	Wired(DHCP) - (ip=192.168.100.139)
Video user	0
Video resolution	640 x 480
Video bandwidth	512K bps
Email ftp Alarm	On
NAS Record	Recording Now
SD-Card Record	Recording Now
Mac Address(Hex)	00:1B:C7:02:12:02

7. Click "Upgrade".

The screenshot shows the Eminent Easy Pro View IP Camera web interface with the 'Admin' menu selected. The 'Upgrade' option is highlighted in the left sidebar. The main content area has a header with the Eminent logo and 'Easy Pro View IP Camera'. Below the header is a section titled 'Firmware upgrade'.

☐ Upgrade from FTP server ☒ Upgrade from local file

FTP Server:

Username:


Password:

Firmware filename:

Firmware location:

8. Select the option "Upgrade from local file".
9. Select the option "Browse" and browse to the file location of the downloaded firmware.

10. Click **“Upgrade”**.





11. After successfully upgrading the Easy Pro View IP camera it will reboot automatically.

Please note: do not power off the camera during the upgrade procedure. The firmware upgrade process can take up to 10 minutes.

5.6.5 Reboot

You can restart the EM6275 manually on this page. All the connected video viewing users will be disconnected.






5.6.6 Set to factory default

For some reason, for example you forgot the web login password, you may want to set the EM6275 to the factory default settings. The only thing you need to do is using a stick to press the “reset” button on the back of the EM6275 body for more than 4 seconds and release it, do this when the EM6275 is powered on. The EM6275 will reset to the factory default settings and restart automatically.

Note: The web login account will be “admin” (no password), the play-video password will be “ipcam” after reset to factory default.



6.0 Dropbox


This feature provides a solution to secure your recordings in the cloud (Dropbox). To use this feature you need to have a Dropbox account. If you do not have a Dropbox account create a Dropbox account by clicking the following link:

<http://www.dropbox.com>.

Notice: The Dropbox feature will record to a cloud storage. The quality of the recording is determined by the video settings of the "Main stream". If you are experiencing internet connection issues after enabling the Dropbox feature please lower the "Main Stream" settings of your Easy Pro View camera. These settings will be explained in the chapter "Changing the recording settings".

6.1 Configure the camera to record to your Dropbox account


6.1.1 Android

1. Open the Easy Pro View APP
2. Open the menu by pressing the arrow  next to the camera and select "**Camera settings**".
3. If you are prompted with a login screen please use the correct username and password (by default the username is "**admin**" and the password field is left empty).

*Note: This is **NOT** the Camera ID and Password which is mentioned on the card!*

4. Press "**Schedule**"
5. Press "**NAS/Cloud**"
6. Select the option "**Dropbox**"
7. Set recording to "**ON**".
8. Now determine if you wish to record constantly "**Always recording**" or if you wish to record using the schedule "**Schedule recording**".
9. Set the minimum of disk space that should stay available on your Dropbox (minimum setting is 200MB)
10. If the settings have been set please press "**Update**"
11. Now press "**Login**"
12. A browser window will be opened. Now enter your login credentials for your Dropbox account, to give your camera access to your Dropbox account (If you do not have a Dropbox account please create a Dropbox account at <http://www.dropbox.com>).


6.1.2 iPod/iPhone

1. Open the Easy Pro View APP
2. Open the menu by pressing the arrow  next to the camera and select **"Camera settings"**.
3. If you are prompted with a login screen please use the correct username and password (by default the username is "admin" and the password field is left empty).

*Note: This is **NOT** the Camera ID and Password which is mentioned on the card!*

4. Press **"Schedule"**
5. Press **"NAS/Cloud"**
6. Select the option **"Dropbox"**
7. Set recording to **"ON"**.
8. Now determine if you wish to record constantly **"Always recording"** or if you wish to record using the schedule **"Schedule recording"**.
9. Set the minimum of disk space that should stay available on your Dropbox (minimum setting is 200MB)
10. If the settings have been set please press **"Update"**
11. Now press **"Login"**
12. A browser window will be opened. Now enter your login credentials for your Dropbox account, to give your camera access to your Dropbox account (If you do not have a Dropbox account please create a Dropbox account at <http://www.dropbox.com>).

6.1.3 iPad

1. Open the Easy Pro View APP
2. Open the menu by pressing the arrow  next to the camera and select **"Camera"**.
3. If you are prompted with a login screen please use the correct username and password (by default the username is "admin" and the password field is left empty).

*Note: This is **NOT** the Camera ID and Password which is mentioned on the card!*

4. Press **"Schedule"**
5. Press **"NAS/Cloud"**
6. Select the option **"Dropbox"**
7. Set recording to **"ON"**.
8. Now determine if you wish to record constantly **"Always recording"** or if you wish to record using the schedule **"Schedule recording"**.
9. Set the minimum of disk space that should stay available on your Dropbox (minimum setting is 200MB)
10. If the settings have been set please press **"Update"**

11. Now press **"Login"**
12. A browser window will be opened. Now enter your login credentials for your Dropbox account, to give your camera access to your Dropbox account (If you do not have a Dropbox account please create a Dropbox account at <http://www.dropbox.com>).

6.2 Configure the APP to get access to the Dropbox recordings.

6.2.1 Android

1. Open the Easy Pro View APP
2. Select the option **"Playback"** at the bottom left of the APP.
3. Select the button **"Dropbox"** (in case you do not get the Dropbox button please check if you have installed the latest version of the APP (check chapter Download/Update the APP))
4. Press the **+** to add a Dropbox account.
5. Now please enter your credentials of your Dropbox account (If you do not have a Dropbox account please create a Dropbox account at <http://www.dropbox.com>).
6. If prompted by Dropbox to give permission to ipcam_S to get access to your Dropbox select **"Allow"**.
7. Now your account is added to the menu **"Playback->Dropbox"**

6.2.2 iPod/iPhone/iPad

1. Open the Easy Pro View APP
2. Select the option **"Playback"** at the bottom left of the APP.
3. Select the button **"Dropbox"** (in case you do not get the Dropbox button please check if you have installed the latest version of the APP (check chapter Download/Update the APP))
4. Press the **+** to add a Dropbox account.
5. Now please enter your credentials of your Dropbox account (If you do not have a Dropbox account please create a Dropbox account at <http://www.dropbox.com>).
6. If prompted by Dropbox to give permission to ipcam_S to get access to your Dropbox select **"Allow"**.
7. Now your account is added to the menu **"Playback->Dropbox"**

6.3 Playback of Dropbox recordings

6.3.1 Android

1. Open the Easy Pro View APP
2. Select the option **"Playback"** at the left bottom corner of the APP.
3. Select the button **"Dropbox"** (in case you do not get the Dropbox button please check if you have installed the latest version of the APP (check chapter Download/Update the APP))
4. Select your Dropbox account you have added to the APP earlier to the list.
5. You will now get an overview of all cameras that have permission to record to your Dropbox account.
6. Select the Camera ID you wish to view.
7. You will now get an overview of all the dates that the selected camera has recorded to your Dropbox account (date is displayed as YYYYMMDD).
8. Select the date you wish to view.
9. Now you will see all the recordings of the selected camera and date. The filename is based upon the recording time. HHMMSS.crf select the file/time of the recording you wish to playback.
10. The file will be loaded from your Dropbox and you can now playback the file on your Smartphone/Tablet.

6.3.2 iPod/iPhone/iPad

1. Open the Easy Pro View APP
2. Select the option **"Playback"** at the left bottom corner of the APP.
3. Select the button **"Dropbox"** (in case you do not get the Dropbox button please check if you have installed the latest version of the APP (check chapter Download/Update the APP))
4. Select your Dropbox account you have added to the APP earlier to the list.
5. You will now get an overview of all cameras that have permission to record to your Dropbox account.
6. Select the Camera ID you wish to view.
7. You will now get an overview of all the dates that the selected camera has recorded to your Dropbox account (date is displayed as YYYYMMDD).
8. Select the date you wish to view.
9. Now you will see all the recordings of the selected camera and date. The filename is based upon the recording time. HHMMSS.crf select the file/time of the recording you wish to playback.
10. The file will be loaded from your Dropbox and you can now playback the file on your Smartphone/Tablet.

6.4 Changing the recording settings

Advised bandwidth settings based on your internet **upload** speed:

Bandwidth	Resolution	Frame Rate
64kbps	320 x 240	5
128kbps	320 x 240	15
256kbps	320 x 240	20
512kbps	640 x 480	10
768kbps	640 x 480	15
1Mbps	1024 x 768	10
1.2Mbps	1024 x 768	10
1.5Mbps	1024 x 768	15
2Mbps	1280 x 800	15
3Mbps	1280 x 800	25

Please make sure the total bandwidth of all your Easy Pro View cameras do not exceed your internet upload bandwidth (preferably make sure there is enough upload bandwidth available for other devices).

Example: Internet upload speed = 10 Mbps

And you wish to use 3 Easy Pro View cameras that can record to Dropbox simultaneously and you still wish to keep a minimum Internet upload connection of 3-4 Mbps.


$10\text{Mbps} - 4\text{Mbps} = 6\text{Mbps}$

$6\text{Mbps} / 3\text{ cameras} = 2\text{Mbps per camera}$

Setup all 3 cameras to 2Mbps with a max. resolution of 1280x800 @15fps

6.4.1 Login to the webpage

1. First make sure the PC software is installed on your desktop or laptop.
2. Double click the 'Easy Pro View' shortcut placed on your desktop.
3. The program will automatically search for your camera in your network. When found, the camera will be displayed in "**Auto search**" list.
4. Right mouse button click your camera, click "**Web configure**"




5. Now a browser screen will appear.
6. Fill out the camera's username and password. By default, the username is 'admin' and the password should not be entered.

*Note: This is **NOT** the Camera ID and Password which is mentioned on the card!*

7. Now click "**Video**"
8. Click "**Video settings**"

6.4.2 Video Settings

The Easy Pro View camera is designed to provide high quality video for viewing from Easy Pro View software. In this settings menu you can modify the Main Stream settings that are related to the Dropbox recording and video streaming.



1. Internet speed – this is the Internet upload bandwidth of your network environment. Higher value will generate higher video quality and bandwidth. But if your Internet **upload** connection cannot provide more bandwidth than the specified value, the video quality could degrade and other devices using the same internet connection can experience connection issues. Please make sure to use a value that is lower than your internet upload bandwidth.
2. Adjust resolution & frame rate automatically – you can let the system select the suitable video resolution and frame rate automatically for you. The selection is based on the “Internet speed” value. This is the recommended default setting.
3. Resolution – there are five choices : 320x240, 480x360 640x400, 1024x768 and 1280x800. If you decide to choose the value manually, you can choose one of the five values. Please be noticed that if the Internet speed is slow (low value), high resolution(1280x800) or frame rate could cause bad video quality.
4. Frame rate – the video frame display rate. Higher value means faster movement and continuity in the video display.
5. Favour/Preference – choose between “Video motion”, “Image quality”, “better quality” and “best quality”. When the real bandwidth is not enough for the selected “Internet speed”, the system will need to degrade the video motion or image quality. This selection will decide if the user want to maintain the “video motion” or “image quality” when the internet speed is not good enough.
6. Sharpness – the sharpness of the video, higher value means sharper video.

7.0 Frequently Asked Questions and other related information

The latest Frequently asked questions for your product can be found on the support page of your product. Eminent will update these pages frequently to assure you have the most recent information. Visit www.eminent-online.com for more information about your product.

8.0 Service and support

This user manual has been carefully written by Eminent's technical experts. If you have problems installing or using the product, please fill out the support form at the website www.eminent-online.com/support.

You can also contact us by phone. Please check www.eminent-online.com/support for the helpdesk phone number and opening hours.

9.0 Warning and points of attention



Due to laws, directives and regulations set out by the European parliament, some (wireless) devices could be subject to limitations concerning its use in certain European member states. In certain European member states the use of such devices could be prohibited. Contact your (local) government for more information about this limitations.

Always follow up the instructions in the manual*, especially where it concerns devices which need to be assembled.

Warning: In most cases this concerns an electronic device. Wrong/improper use may lead to (severe) injuries!

When you connect the device to the mains, make sure it will not be damaged or subject to (high) pressure.

A power socket is needed which should be close and easy accessible from the device.

Repairing of the device should be done by qualified Eminent staff. Never try to repair the device yourself. The warranty immediately voids when products have undergone self-repair and/or by misuse. For extended warranty conditions, please visit our website at www.eminent-online.com/warranty.

Dispose of the device appropriately. Please follow your countries regulation for the disposal of electronic goods.

Please check below safety points carefully:

- Do not apply external force on the cables
- Do not unplug the device by pulling the power cable
- Do not place the device near heating elements
- Do not let the device come in contact with water or other liquids
- If there is any strange sound, smoke or odor, remove the device immediately from the power outlet.
- Do not put any sharp objects into the venting hole of a product
- Do not use any damaged cables (risk of electric shock)
- Keep the product out of reach of children
- Wipe off the product with soft fabric, not water mop.
- Keep the power plug and outlet clean
- Do not unplug the device from the power outlet with wet hands
- Unplug the device when you don't use it for a long time
- Use the device at a well ventilated place

**Tip: Eminent manuals are written with great care. However, due to new technological developments it can happen that a printed manual does not longer contain the most recent information. If you are experiencing any problems with the printed manual or you cannot find what you are looking for, please always check our website www.eminent-online.com first for the newest updated manual.*

Also, you will find frequently asked questions in the FAQ section. It is highly recommended to consult the FAQ section. Very often the answer to your questions will be found here.

10.0 Warranty conditions

The five-year Eminent warranty applies to all Eminent products, unless mentioned otherwise before or during the moment of purchase. After buying a second-hand Eminent product the remaining period of warranty is measured from the moment of purchase by the product's initial owner. Eminent warranty applies to all Eminent products and parts, indissolubly connected or mounted to the product it concerns. Power supply adapters, batteries, antennas and all other products not directly integrated in or connected to the main product or products of which, without reasonable doubt, can be assumed that wear and tear during use will show a different pattern than the main product, are not covered by the Eminent warranty. Products are not covered by the Eminent warranty when exposed to incorrect/improper use, external influences or when opening the service parts of the product by parties other than Eminent. Eminent may use refurbished materials for repair or replacement of your defective product. Eminent cannot be held responsible for changes in network settings by internet providers. We cannot guarantee that the Eminent networking product will keep working when settings are changed by the internet providers. Eminent cannot guarantee the working of web services, apps and other third party content that is available through Eminent products. Eminent products with an internal hard disk have a limited warranty period of two years on the hard disk. Eminent could not be held responsible for any data lost. Please make sure that if the product stores data on a hard drive or other memory source, you will make a copy before you return the product for repair.

When my product gets defective

Should you encounter a product rendered defective for reasons other than described above: Please contact your point of purchase for taking care of your defective product.



Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.

The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Eminent is a member of the Intronics Group